

Part No. 216339-A  
December 2003

4655 Great America Parkway  
Santa Clara, CA 95054

# **Reference for the BayStack 380-24T and 24F Command Line Interface, Software Version 3.0**

**NORTEL**  
**NETWORKS™**

## Copyright © 2003 Nortel Networks

All rights reserved. December 2003.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks NA Inc.

The software described in this document is furnished under a license agreement and may be used only in accordance with the terms of that license. The software license agreement is included in this document.

## Trademarks

Autotopology, BayStack, BaySecure, Business Policy Switch 2000, Nortel Networks, the Nortel Networks logo, Optivity, Optivity Policy Services, Preside, and Quick2Config are trademarks of Nortel Networks.

Microsoft, MS, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

Java is a trademark of Sun Microsystems, Inc.

Acrobat and Adobe are trademarks of Adobe Systems, Inc.

All other trademarks and registered trademarks are the property of their respective owners.

## Restricted rights legend

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Notwithstanding any other license agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government regarding its use, reproduction, and disclosure are as set forth in the Commercial Computer Software-Restricted Rights clause at FAR 52.227-19.

## Statement of conditions

In the interest of improving internal design, operational function, and/or reliability, Nortel Networks Inc. reserves the right to make changes to the products described in this document without notice.

Nortel Networks Inc. does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Portions of the code in this software product may be Copyright © 1988, Regents of the University of California. All rights reserved. Redistribution and use in source and binary forms of such portions are permitted, provided that the above copyright notice and this paragraph are duplicated in all such forms and that any documentation, advertising materials, and other materials related to such distribution and use acknowledge that such portions of the software were developed by the University of California, Berkeley. The name of the University may not be used to endorse or promote products derived from such portions of the software without specific prior written permission.

**SUCH PORTIONS OF THE SOFTWARE ARE PROVIDED "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.**

In addition, the program and information contained herein are licensed only pursuant to a license agreement that contains restrictions on use and disclosure (that may incorporate by reference certain limitations and notices imposed by third parties).

## USA requirements only

### Federal Communications Commission (FCC) Compliance Notice: Radio Frequency Notice

**Note:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy. If it is not installed and used in accordance with the instruction manual, it may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to take whatever measures may be necessary to correct the interference at their own expense.

## European requirements only

### EN 55 022 statement

This is to certify that the Nortel Networks BayStack 380-24T 10/100/1000 Switch is shielded against the generation of radio interference in accordance with the application of Council Directive 89/336/EEC, Article 4a. Conformity is declared by the application of EN 55 022 Class A (CISPR 22).

**Warning:** This is a Class A product. In a domestic environment, this product may cause radio interference, in which case, the user may be required to take appropriate measures.

**Achtung:** Dieses ist ein Gerät der Funkstörgrenzwertklasse A. In Wohnbereichen können bei Betrieb dieses Gerätes Rundfunkstörungen auftreten, in welchen Fällen der Benutzer für entsprechende Gegenmaßnahmen verantwortlich ist.

**Attention:** Ceci est un produit de Classe A. Dans un environnement domestique, ce produit risque de créer des interférences radioélectriques, il appartiendra alors à l'utilisateur de prendre les mesures spécifiques appropriées.

### AEC Declaration of Conformity

This product conforms (or these products conform) to the provisions of the R&TTE Directive 1999/5/EC.

## Japan/Nippon requirements only

### Voluntary Control Council for Interference (VCCI) statement

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラス A 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

## Taiwan requirements

### Bureau of Standards, Metrology and Inspection (BSMI) Statement

#### 警告使用者:

這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

## Canada requirements only

### Canadian Department of Communications Radio Interference Regulations

This digital apparatus (BayStack 380 10/100/1000 Switch) does not exceed the Class A limits for radio-noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

### Règlement sur le brouillage radioélectrique du ministère des Communications

Cent appareil numérique (BayStack 380 10/100/1000 Switch) respecte les limites de bruits radioélectriques visant les appareils numériques de classe A prescrites dans le Règlement sur le brouillage radioélectrique du ministère des Communications du Canada.

## Nortel Networks Inc. software license agreement

This Software License Agreement (“License Agreement”) is between you, the end-user (“Customer”) and Nortel Networks Corporation and its subsidiaries and affiliates (“Nortel Networks”). PLEASE READ THE FOLLOWING CAREFULLY. YOU MUST ACCEPT THESE LICENSE TERMS IN ORDER TO DOWNLOAD AND/OR USE THE SOFTWARE. USE OF THE SOFTWARE CONSTITUTES YOUR ACCEPTANCE OF THIS LICENSE AGREEMENT. If you do not accept these terms and conditions, return the Software, unused and in the original shipping container, within 30 days of purchase to obtain a credit for the full purchase price.

“Software” is owned or licensed by Nortel Networks, its parent or one of its subsidiaries or affiliates, and is copyrighted and licensed, not sold. Software consists of machine-readable instructions, its components, data, audio-visual content (such as images, text, recordings or pictures) and related licensed materials including all whole or partial copies. Nortel Networks grants you a license to use the Software only in the country where you acquired the Software. You obtain no

---

rights other than those granted to you under this License Agreement. You are responsible for the selection of the Software and for the installation of, use of, and results obtained from the Software.

**1. Licensed Use of Software.** Nortel Networks grants Customer a nonexclusive license to use a copy of the Software on only one machine at any one time or to the extent of the activation or authorized usage level, whichever is applicable. To the extent Software is furnished for use with designated hardware or Customer furnished equipment (“CFE”), Customer is granted a nonexclusive license to use Software only on such hardware or CFE, as applicable. Software contains trade secrets and Customer agrees to treat Software as confidential information using the same care and discretion Customer uses with its own similar information that it does not wish to disclose, publish or disseminate. Customer will ensure that anyone who uses the Software does so only in compliance with the terms of this Agreement. Customer shall not a) use, copy, modify, transfer or distribute the Software except as expressly authorized; b) reverse assemble, reverse compile, reverse engineer or otherwise translate the Software; c) create derivative works or modifications unless expressly authorized; or d) sublicense, rent or lease the Software. Licensors of intellectual property to Nortel Networks are beneficiaries of this provision. Upon termination or breach of the license by Customer or in the event designated hardware or CFE is no longer in use, Customer will promptly return the Software to Nortel Networks or certify its destruction. Nortel Networks may audit by remote polling or other reasonable means to determine Customer’s Software activation or usage levels. If suppliers of third party software included in Software require Nortel Networks to include additional or different terms, Customer agrees to abide by such terms provided by Nortel Networks with respect to such third party software.

**2. Warranty.** Except as may be otherwise expressly agreed to in writing between Nortel Networks and Customer, Software is provided “AS IS” without any warranties (conditions) of any kind. NORTEL NETWORKS DISCLAIMS ALL WARRANTIES (CONDITIONS) FOR THE SOFTWARE, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ANY WARRANTY OF NON-INFRINGEMENT. Nortel Networks is not obligated to provide support of any kind for the Software. Some jurisdictions do not allow exclusion of implied warranties, and, in such event, the above exclusions may not apply.

**3. Limitation of Remedies.** IN NO EVENT SHALL NORTEL NETWORKS OR ITS AGENTS OR SUPPLIERS BE LIABLE FOR ANY OF THE FOLLOWING: a) DAMAGES BASED ON ANY THIRD PARTY CLAIM; b) LOSS OF, OR DAMAGE TO, CUSTOMER’S RECORDS, FILES OR DATA; OR c) DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), WHETHER IN CONTRACT, TORT OR OTHERWISE (INCLUDING NEGLIGENCE) ARISING OUT OF YOUR USE OF THE SOFTWARE, EVEN IF NORTEL NETWORKS, ITS AGENTS OR SUPPLIERS HAVE BEEN ADVISED OF THEIR POSSIBILITY. The forgoing limitations of remedies also apply to any developer and/or supplier of the Software. Such developer and/or supplier is an intended beneficiary of this Section. Some jurisdictions do not allow these limitations or exclusions and, in such event, they may not apply.

#### **4. General**

a) If Customer is the United States Government, the following paragraph shall apply: All Nortel Networks Software available under this License Agreement is commercial computer software and commercial computer software documentation and, in the event Software is licensed for or on behalf of the United States Government, the respective rights to the software and software documentation are governed by Nortel Networks standard commercial license in accordance with U.S. Federal Regulations at 48 C.F.R. Sections 12.212 (for non-Odd entities) and 48 C.F.R. 227.7202 (for Odd entities).

b) Customer may terminate the license at any time. Nortel Networks may terminate the license if Customer fails to comply with the terms and conditions of this license. In either event, upon termination, Customer must either return the Software to Nortel Networks or certify its destruction.

c) Customer is responsible for payment of any taxes, including personal property taxes, resulting from Customer’s use of the Software. Customer agrees to comply with all applicable laws including all applicable export and import laws and regulations.

d) Neither party may bring an action, regardless of form, more than two years after the cause of the action arose.

- e) The terms and conditions of this License Agreement form the complete and exclusive agreement between Customer and Nortel Networks.
- f) This License Agreement is governed by the laws of the country in which Customer acquires the Software. If the Software is acquired in the United States, then this License Agreement is governed by the laws of the state of New York.

---

# Contents

---

<b>Preface</b> .....	<b>21</b>
About this guide .....	21
Before you begin .....	21
Text conventions .....	22
Related publications .....	23
How to get help .....	23
<b>Chapter 1</b>	
<b>CLI Basics</b> .....	<b>25</b>
CLI command modes .....	26
Port numbering .....	29
Port numbering in standalone mode .....	29
IP notation .....	29
Accessing the CLI .....	30
Setting the CLI password .....	31
cli password command .....	32
Getting help .....	33
Basic navigation .....	33
General navigation commands .....	33
Keystroke navigation .....	34
help command .....	35
no command .....	36
default command .....	36
logout command .....	37
enable command .....	37
configure command .....	38
interface command .....	38
disable command .....	39

end command	39
exit command	39
Managing basic system information	40
show sys-info command	40
Managing MAC address forwarding database table	41
show mac-address-table command	42
mac-address-table aging-time command	43
default mac-address-table aging-time command	44
Setting the default management system	44
<b>Chapter 2</b>	
<b>General CLI commands</b>	<b>45</b>
Setting the terminal	46
show terminal command	46
terminal command	47
Pinging	47
ping command	48
show cli	49
show gbic-info	49
Automatically loading configuration file	50
configure network command	50
show config-network command	51
Assigning and clearing IP addresses	52
ip address command	53
no ip address command	53
ip default-gateway command	54
no ip default-gateway command	55
show ip command	55
Assigning and clearing IP addresses for specific units	56
default ip address command	57
Setting Telnet access	57
show telnet-access command	58
telnet-access command	58
no telnet-access command	59
default telnet-access command	60



---

Setting boot parameters . . . . .	60
boot command . . . . .	61
ip bootp server command . . . . .	61
no ip bootp server command . . . . .	62
default ip bootp server command . . . . .	62
Setting TFTP parameters . . . . .	63
show tftp-server command . . . . .	63
tftp-server command . . . . .	64
no tftp-server command . . . . .	64
default tftp-server command . . . . .	64
copy config tftp command . . . . .	65
copy tftp config command . . . . .	65
Upgrading software . . . . .	66
download command . . . . .	66
Observing LED indications . . . . .	68
Upgrading software images . . . . .	69
Displaying interfaces . . . . .	69
show interfaces command . . . . .	69
Setting SNMP parameters . . . . .	71
snmp-server command . . . . .	72
no snmp-server command . . . . .	73
default snmp-server command . . . . .	73
show snmp-server . . . . .	74
snmp trap link-status command . . . . .	75
no snmp trap link-status command . . . . .	76
default snmp trap link-status command . . . . .	76
Configuring remote network monitoring (RMON) . . . . .	77
show rmon alarm . . . . .	77
show rmon event . . . . .	78
show rmon history . . . . .	78
show rmon stats . . . . .	79
rmon alarm . . . . .	80
rmon event . . . . .	81
rmon history . . . . .	82
rmon stats . . . . .	82

Setting the system event log .....	83
show logging .....	83
logging .....	85
no logging .....	86
default logging .....	86
clear logging command .....	86
Displaying port statistics .....	87
show port-statistics command .....	87
clear-stats command .....	90
Enabling or disabling a port .....	90
shutdown command .....	90
no shutdown command .....	91
default shutdown command .....	92
Naming ports .....	92
name command .....	92
no name command .....	93
default name command .....	94
Setting port speed .....	94
speed command .....	94
default speed command .....	95
duplex command .....	96
default duplex command .....	97
Enabling Autopology .....	98
autotopology command .....	98
no autotopology command .....	99
default autotopology command .....	99
show autotopology .....	99
Enabling flow control .....	100
flowcontrol command .....	100
no flowcontrol command .....	101
default flowcontrol command .....	102
Single fiber fault detection .....	103
Far End Fault Indication (FEFI) .....	103
CLI commands for SFFD .....	103
SNMPv3 Commands .....	105

---

show snmp-server command	106
snmp-server authentication-trap command	106
no snmp-server authentication-trap command	107
default snmp-server authentication-trap command	107
snmp-server community for read/write command	108
snmp-server community command	109
no snmp-server community command	110
default snmp-server community command	111
snmp-server contact command	112
no snmp-server contact command	112
default snmp-server contact command	112
snmp-server command	113
no snmp-server command	113
snmp-server host for old-style table command	114
snmp-server host for new-style table command	115
no snmp-server host for old-style table command	116
no snmp-server host for new-style table command	116
default snmp-server host command	117
snmp-server location command	117
no snmp-server location command	118
default snmp-server location command	118
snmp-server name command	118
no snmp-server name command	119
default snmp-server name command	119
snmp-server user command	119
no snmp-server user command	121
snmp-server view command	121
no snmp-server view command	122
snmp trap link-status command	123
no snmp trap link-status command	124
default snmp trap link-status command	124
snmp-server bootstrap command	125
show running-config	126
Setting Class of Service	126
show cos-dscp	127

cos-dscp .....	128
no cos-dscp .....	129
default cos-dscp .....	129

### **Chapter 3**

#### **Security..... 131**

Using MAC address security .....	131
show mac-security command .....	132
mac-security command .....	133
mac-security mac-address-table address command .....	134
no mac-security command .....	134
default mac-security command .....	135
no mac-security mac-address-table command .....	135
mac-security command for specific ports .....	136
Using RADIUS authentication .....	137
show radius-server command .....	137
radius-server command .....	138
no radius-server command .....	139
default radius-server command .....	139

### **Chapter 4**

#### **Spanning Tree, MLT, and Port-Mirroring..... 141**

Using spanning tree .....	141
show spanning-tree command .....	142
spanning-tree command .....	144
default spanning-tree command .....	145
spanning-tree command by port .....	146
default spanning-tree command by port .....	147
no spanning-tree command by port .....	148
Using MLT .....	149
show mlt command .....	149
mlt command .....	150
no mlt command .....	151
Using port-mirroring .....	151
show port-mirroring command .....	152

---

port-mirroring command	152
no port-mirroring command	153
<b>Chapter 5</b>	
<b>VLANs and IGMP</b>	<b>155</b>
Configuring and displaying VLANs	155
show vlan interface info command	156
show vlan interface vids command	157
vlan mgmt command	158
default vlan mgmt command	159
vlan create command	159
vlan delete command	160
no vlan command	161
vlan name command	161
auto-pvid command	162
no auto-pvid command	162
vlan ports command	162
vlan members command	163
show vlan command	164
Displaying multicast membership	165
show vlan multicast membership command	165
Using IGMP snooping	166
show vlan igmp command	167
vlan igmp command	168
default vlan igmp command	169
<b>Appendix A</b>	
<b>Command List</b>	<b>171</b>
<b>Index</b>	<b>177</b>



---

## Figures

---

Figure 1	CLI command mode hierarchy	27
Figure 2	BayStack 380 banner	30
Figure 3	Main Menu for BayStack 380 console interface	31
Figure 4	help command output in privExec mode	36
Figure 5	show sys-info command output	41
Figure 6	show mac-address-table command output	43
Figure 7	show terminal command output	47
Figure 8	ping command responses	49
Figure 9	show config-network command	52
Figure 10	show ip command output	56
Figure 11	show telnet-access command output	58
Figure 12	show tftp-server command output	63
Figure 13	download message	68
Figure 14	show interfaces names command output	70
Figure 15	show interfaces command output	71
Figure 16	show rmon alarm command output	78
Figure 17	show rmon event command output	78
Figure 18	show rmon history command output	79
Figure 19	show rmon stats command output	80
Figure 20	show logging informational command output	85
Figure 21	show port-statistics command output	89
Figure 22	show cos-dscp config command output	128
Figure 23	show mac-security command output	133
Figure 24	show radius-server command output	138
Figure 25	show spanning-tree command output by port	143
Figure 26	show spanning-tree command output for spanning tree config	144
Figure 27	show mlt command output	150
Figure 28	show port-mirroring command output	152
Figure 29	show vlan interface info output	157

Figure 30	show vlan interface vids output . . . . .	158
Figure 31	show vlan command output . . . . .	165
Figure 32	show vlan multicast membership command output . . . . .	166
Figure 33	show vlan igmp command output . . . . .	168



---

## Tables

---

Table 1	Command mode prompts and entrance/exit commands . . . . .	28
Table 2	cli password command parameters and variables . . . . .	32
Table 3	Keystroke navigation . . . . .	34
Table 4	configure command parameters and variables . . . . .	38
Table 5	interface command parameters and variables . . . . .	39
Table 6	show mac-address-table command parameters and variables . . . . .	42
Table 7	mac-address-table aging-time command parameters and variables . . . . .	44
Table 8	terminal command parameters and variables . . . . .	47
Table 9	ping command parameters and variables . . . . .	48
Table 10	show cli command parameters and variables . . . . .	49
Table 11	configure network command parameters and variables . . . . .	51
Table 12	ip address command parameters and variables . . . . .	53
Table 13	no ip address command parameters and variables . . . . .	54
Table 14	ip default-gateway command parameters and variables . . . . .	54
Table 15	show ip command parameters and variables . . . . .	56
Table 16	telnet-access command parameters and variables . . . . .	59
Table 17	no telnet-access command parameters and variables . . . . .	60
Table 18	boot command parameters and variables . . . . .	61
Table 19	ip bootp server command parameters and variables . . . . .	62
Table 20	tftp-server command parameters and variables . . . . .	64
Table 21	copy config tftp command parameters and variables . . . . .	65
Table 22	copy tftp config command parameters and variables . . . . .	66
Table 23	download command parameters and variables . . . . .	67
Table 24	LED Indications during the software download process . . . . .	68
Table 25	show interfaces command parameters and variables . . . . .	69
Table 26	snmp-server command parameters and variables . . . . .	72
Table 27	no snmp-server command parameters and variables . . . . .	73
Table 28	default snmp-server command parameters and variables . . . . .	74
Table 29	show snmp-server parameters and variable . . . . .	75

---

Table 30	snmp trap link-status command parameters and variables . . . . .	75
Table 31	no snmp trap link-status command parameters and variables . . . . .	76
Table 32	default snmp trap link-status command parameters and variables . . . . .	77
Table 33	rmon alarm command parameters and variables . . . . .	80
Table 34	rmon event command parameters and variables . . . . .	81
Table 35	rmon history command parameters and variables . . . . .	82
Table 36	rmon stats command parameters and variables . . . . .	83
Table 37	show logging command parameters and variables . . . . .	84
Table 38	logging command parameters and values . . . . .	85
Table 39	clear logging command parameters and values . . . . .	87
Table 40	show port-statistics command parameters and variables . . . . .	88
Table 41	clear-stats command parameters and variables . . . . .	90
Table 42	shutdown command parameters and variables . . . . .	91
Table 43	no shutdown command parameters and variables . . . . .	91
Table 44	default shutdown command parameters and variables . . . . .	92
Table 45	name command parameters and variables . . . . .	93
Table 46	no name command parameters and variables . . . . .	93
Table 47	default name command parameters and variables . . . . .	94
Table 48	speed command parameters and variables . . . . .	95
Table 49	default speed command parameters and variables . . . . .	96
Table 50	duplex command parameters and variables . . . . .	97
Table 51	default duplex command parameters and variables . . . . .	98
Table 52	flowcontrol command parameters and variables . . . . .	101
Table 53	no flowcontrol command parameters and variables . . . . .	102
Table 54	default flowcontrol command parameters and variables . . . . .	102
Table 55	show snmp-server command parameters and variables . . . . .	106
Table 56	snmp-server authentication-trap command parameters and variables . .	107
Table 57	snmp-server community for read/write command parameters and variables 108	
Table 58	snmp-server community command parameters and variables . . . . .	109
Table 59	no snmp-server community command parameters and variables . . . . .	111
Table 60	default snmp-server community command parameters and variables . .	111
Table 61	snmp-server contact command parameters and variables . . . . .	112
Table 62	snmp-server command parameters and variables . . . . .	113
Table 63	snmp-server host for old-style table command parameters and variables	114

---

Table 64	snmp-server host for new-style table command parameters and variables	115
Table 65	no snmp-server host for old-style table command parameters and variables	116
Table 66	no snmp-server host for new-style command parameters and variables	117
Table 67	snmp-server location command parameters and variables	118
Table 68	snmp-server name command parameters and variables	119
Table 69	snmp-server user command parameters and variables	120
Table 70	no snmp-server user command parameters and variables	121
Table 71	snmp-server view command parameters and variables	122
Table 72	no snmp-server view command parameters and variables	123
Table 73	snmp trap link-status command parameters and variables	123
Table 74	no snmp trap link-status command parameters and variables	124
Table 75	default snmp trap link-status command parameters and variables	125
Table 76	snmp-server bootstrap command parameters and variables	126
Table 77	show cos-dscp command parameters and variables	127
Table 78	cos-dscp command parameters and values	128
Table 79	show mac-security command parameters and variables	132
Table 80	mac-security command parameters and values	133
Table 81	mac-security mac-address-table address command parameters and values	134
Table 82	default mac-security	135
Table 83	no mac-security mac-address-table command parameters and values	136
Table 84	mac-security command for a single port parameters and variables	136
Table 85	radius-server command parameters and variables	138
Table 86	show spanning-tree command parameters and variables	143
Table 87	spanning-tree command parameters and variables	145
Table 88	default spanning-tree command parameters and variables	145
Table 89	spanning-tree command by port parameters and variables	146
Table 90	default spanning-tree command by port parameters and variables	147
Table 91	no spanning-tree command by port parameters and variables	148
Table 92	show mlt command parameters and variables	149
Table 93	mlt command parameters and variables	150
Table 94	no mlt command parameters and variables	151
Table 95	port-mirroring command parameters and variables	153
Table 96	show vlan command interface info parameters and variables	157
Table 97	show vlan command interface vids parameters and variables	158

---

Table 98	vlan mgmt command parameters and variables .....	159
Table 99	vlan create command parameters and variables .....	160
Table 100	vlan delete command parameters and variables .....	160
Table 101	no vlan command parameters and variables .....	161
Table 102	vlan name command parameters and variables .....	161
Table 103	vlan ports command parameters and variables .....	163
Table 104	vlan members command parameters and variables .....	164
Table 105	show vlan command parameters and variables .....	164
Table 106	show vlan multicast membership command parameters and variables .	166
Table 107	show vlan igmp command parameters and variables .....	167
Table 108	vlan igmp command parameters and variables .....	168
Table 109	default vlan igmp command parameters and variables .....	169
Table 110	CLI command list .....	171

---

## Preface

---

The Nortel Networks\* BayStack 380 10/100/1000 Switch\* command line interface (CLI) is one tool used to configure and manage a BayStack 380 Switch. The CLI allows you to set up, configure, and manage your BayStack 380.

You can also use the Java\* Device Manager graphical user interface (GUI), the Web-based management system GUI, and the console interface (CI) menus to configure and manage the switch. For more information on these management systems, refer to *Reference for the BayStack 380 10/100/1000 Switch Management Software Version 3.0*, *Using Web-based Management for the BayStack 380 10/100/1000 Switch Software Version 3.0*, and *Using the BayStack 380 10/100/1000 Switch Software Version 3.0*.

For general information on using and configuring the BS 380, refer to *Using the BayStack 380 10/100/1000 Switch Software Version 3.0*.

## About this guide

This guide provides information about using the features and capabilities of the CLI to manage switching operations in the BayStack 380, as well as a complete list of CLI commands.

## Before you begin

This guide is intended for network administrators with the following background:

- Basic knowledge of networks, bridging, and IP
- Familiarity with networking concepts and terminology
- Basic knowledge of network topologies

Before using this guide, you must complete the procedures discussed in the *BayStack 380 10/100/1000 Switch Installation Instructions*.

## Text conventions

angle brackets (< >)	<p>Indicate that you choose the text to enter based on the description inside the brackets. Do not type the brackets when entering the command.</p> <p>Example: If the command syntax is <code>ip default-gateway &lt;XXX.XXX.XXX.XXX&gt;</code>, you enter <code>ip default-gateway 192.32.10.12</code></p>
braces ({} )	<p>Indicate required elements in syntax descriptions where there is more than one option. You must choose only one of the options. Do not type the braces when entering the command.</p> <p>Example: If the command syntax is: <code>http-server {enable disable}</code> the options for are <code>enable</code> or <code>disable</code>.</p>
brackets ([ ] )	<p>Indicate optional elements in syntax descriptions. Do not type the brackets when entering the command.</p> <p>Example: If the command syntax is: <code>show ip [bootp]</code>, you can enter either: <code>show ip</code> or <code>show ip bootp</code>.</p>
plain Courier text	<p>Indicates command syntax and system output.</p> <p>Example: TFTP Server IP Address: 192.168.100.15</p>
vertical line	<p>Separates choices for command keywords and arguments. Enter only one of the choices. Do not type the vertical line when entering the command.</p> <p>Example: If the command syntax is: <code>cli password &lt;serial telnet&gt;</code>, you must enter either <code>cli password serial</code> or <code>cli password telnet</code>, but not both.</p>
H.H.H.	<p>Enter a MAC address in this format (XXXX.XXXX.XXXX).</p>

## Related publications

For more information about managing or using BayStack 380 Switch, refer to the following publications:

- *Release Notes for the BayStack 380 10/100/1000 Switch Software Version 3.0* (part number 212864-C)
- *Installing the BayStack 380-24T 10/100/1000 Switch* (part number 212794-A)
- *Using the BayStack 380 10/100/1000 Switch Software Version 3.0* (part number 212791-C)
- *Getting Started with the BayStack 380 10/100/1000 Switch Management Software Operations* (part number 213909-A)
- *Reference for the BayStack 380 10/100/1000 Switch Management Software Version 3.0* (part number 212789-C)
- *Using Web-based Management for the BayStack 380 10/100/1000 Switch Software Version 3.0* (part number 212792-C)
- *Installing Gigabit Interface Converters and Small Form Factor Pluggable Interface Converters* (part number 312865-B)

You can print selected technical manuals and release notes free, directly from the Internet. Go to the [www.nortelnetworks.com/documentation](http://www.nortelnetworks.com/documentation) URL. (The product family for the BayStack 380 is Data and Internet.) Find the product for which you need documentation. Then locate the specific category and model or version for your hardware or software product. Use Adobe\* Acrobat Reader\* to open the manuals and release notes, search for the sections you need, and print them on most standard printers. Go to Adobe Systems at the [www.adobe.com](http://www.adobe.com) URL to download a free copy of the Adobe Acrobat Reader.

## How to get help

If you purchased a service contract for your Nortel Networks product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

If you purchased a Nortel Networks service program, contact one of the following Nortel Networks Technical Solutions Centers:

<b>Technical Solutions Center</b>	<b>Telephone</b>
Europe, Middle East, and Africa	(33) (4) 92-966-968
North America	(800) 4NORTEL or (800) 466-7835
Asia Pacific	(61) (2) 9927-8800
China	(800) 810-5000

Additional information about the Nortel Networks Technical Solutions Centers is available from the [www.nortelnetworks.com/help/contact/global](http://www.nortelnetworks.com/help/contact/global) URL.

An Express Routing Code (ERC) is available for many Nortel Networks products and services. When you use an ERC, your call is routed to a technical support person who specializes in supporting that product or service. To locate an ERC for your product or service, go to the <http://www130.nortelnetworks.com/cgi-bin/eserv/common/essContactUs.jsp> URL.



---

# Chapter 1

## CLI Basics

---

You can manage the BayStack 380 with a number of tools. You can use either graphical user interface (GUI), the Java Device Manager (DM) or the Web-based management system. You can use the console interface (CI menus), or you can use the command line interface (CLI). (For more information on using the DM, refer to *Reference for the BayStack 380 10/100/1000 Switch Management Software Version 3.0*. For more information on using the Web-based management system, refer to *Using Web-based Management for the BayStack 380-24T 10/100/1000 Switch Software Version 3.0*. For more information on using the CI menus, refer to *Using the BayStack 380 10/100/1000 Switch Software Version 3.0*.)

The BayStack 380 command line interface (CLI) is a management tool that provides methods for configuring, managing, and monitoring the operational functions of the switch. You access the CLI through a direct connection to the switch console port, or remotely using Telnet. For a complete, alphabetical list of CLI commands, refer to Appendix A.

You can use the CLI interactively, or you can load and execute CLI “scripts.” CLI scripts are loaded in one of the following ways:

- By downloading a CLI script file from a tftp server.
- By pasting a series of CLI commands into the terminal emulator window.

This chapter discusses the following CLI topics:

- [“CLI command modes” on page 26](#)
- [“Port numbering” on page 29](#)
- [“IP notation” on page 29](#)
- [“Accessing the CLI” on page 30](#)
- [“Setting the CLI password” on page 31](#)
- [“Getting help” on page 33](#)

- [“Basic navigation” on page 33](#)
- [“Managing basic system information” on page 40](#)
- [“Managing MAC address forwarding database table” on page 41](#)

## CLI command modes

Most CLI commands are available only under a certain command mode. The BayStack 380 has the following four command modes:

- User EXEC
- Privileged EXEC
- Global Configuration
- Interface Configuration

The User EXEC mode is the default mode; it is also referred to as exec. This command mode is the initial mode of access upon first powering-up the BayStack 380. In this command mode, the user can access only a subset of the total CLI commands; however, the commands in this mode are available while the user is in any of the other four modes. The commands in this mode are those you would generally need, such as ping and logout.

Commands in the Privileged EXEC mode are available to all other modes but not to the User EXEC mode. The commands in this mode allow you to perform basic switch-level management tasks, such as downloading the software image and booting the BayStack 380. The Privileged EXEC mode is also referred to as privExec mode.


The last two command modes, Global Configuration and Interface Configuration, allow you to change the configuration of the BayStack 380. Changes made in these command modes are immediately applied to the switch configuration and saved to non-volatile memory.

The Global Configuration commands allow you to set and display general configurations for the switch, such as the IP address, SNMP parameters, the Telnet access, and VLANs. The Global Configuration mode is also referred to as config mode.

The Interface Configuration commands allow you to configure parameters for each port, such as speed and duplex mode. The Interface Configuration mode is also referred to as config-if mode.

Figure 1 provides an illustration of the hierarchy of BayStack 380 CLI command modes.

**Figure 1** CLI command mode hierarchy



10194EA

You see a specific value for each command mode at the prompt line, and you use specific commands to enter or exit each command mode (Table 1). Additionally, you can only enter command modes from specific modes and only exit to specific command modes.

**Table 1** Command mode prompts and entrance/exit commands

Command mode	Prompt	Enter/exit command
User EXEC (exec)	BS380>	<ul style="list-style-type: none"><li>• Default mode, automatically enter</li><li>• <code>logout</code> or <code>exit</code> to quit CLI</li></ul>
Privileged EXEC (privExec)	BS380#	<ul style="list-style-type: none"><li>• <code>enable</code> to enter from User EXEC mode</li><li>• <code>logout</code> or <code>exit</code> to quit CLI</li></ul>
Global Configuration (config)	BS380 (config) #	<ul style="list-style-type: none"><li>• <code>configure</code> to enter from Privileged EXEC mode</li><li>• <code>logout</code> to quit CLI; <code>end</code> or <code>exit</code> to exit to Privileged EXEC mode</li></ul>
Interface Configuration (config-if)	BS380 (config-if) #	<ul style="list-style-type: none"><li>• <code>interface Fast Ethernet {&lt;portnum&gt; all}</code> to enter from Global Configuration mode</li><li>• <code>logout</code> to quit CLI; <code>end</code> to exit to Privileged EXEC mode; <code>exit</code> to exit to Global Configuration mode</li></ul>

The prompt displays the switch name, BayStack 380, and the current CLI command mode:

- User EXEC—BS380>
- Privileged EXEC—BS380#
- Global Configuration—BS380 (config) #
- Interface Configuration—BS380 (config-if) #

Refer to Appendix A, for a complete, alphabetical list of all CLI commands and where they are explained.

The initial command mode in CLI depends on your access level when you logged into the BayStack 380 CI menus:

- With no password protection, you enter the CLI in userExec mode, and use the `enable` command to move to the privExec command mode.
- If you logged into the CI menus with read-only access, you enter the CLI in userExec mode and cannot access any other CLI command modes.

- If you logged into the CI menus with read-write access, you enter the CLI in `privExec` mode and use the commands to move to the other command modes.

## Port numbering

The BayStack 380 operates in standalone mode. The BayStack 380 has 24 10/100/1000 Mb/s or 24 1000 Mb/s ports on the front. Thus, you have a maximum of 24 ports on one BayStack 380.

The CLI uses the variable `<portlist>` when a command specifies one or more ports for the command.

### Port numbering in standalone mode

In standalone mode, use the `<portlist>` variable in the following formats:

- A single port number—an integer between 1 through 24
  - Example: `7` means port 7
- A range of port numbers—a pair of port numbers between 1 and 24 separated by a dash
  - Example: `1-3` means ports 1, 2, and 3
  - Example: `5-24` means all ports from port 5 through port 24
- A list of port numbers and/or port ranges, separated by commas
  - Example: `1, 3, 7` means ports 1, 3, and 7
  - Example: `1-3, 9-11` means ports 1, 2, 3, 9, 10, and 11
  - Example: `1, 3-5, 9-11, 15` means ports 1, 3, 4, 5, 9, 10, 11, and 15
- `none` means no ports (not case-sensitive)
- `all` means all the ports on the standalone BayStack 380 (not case-sensitive)

## IP notation

You enter IP addresses and subnet masks in dotted decimal notation (`XXX.XXX.XXX.XXX`), specifying both the IP address and the subnet mask in dotted-decimal notation.

## Accessing the CLI

You access the CLI menus using Telnet or a direct connection to the switch from a terminal or personal computer (PC). You can use any terminal or PC with a terminal emulator as the CLI command station. Be sure the terminal has the following features:

- 9600 bits per second (b/s), 8 data bits, 1 stop bit, no parity, no flow control
- Serial terminal-emulation program such as Terminal or Hyperterm for Windows NT\* or Hyperterm for Windows\* 95 or Windows 98
- Cable and connector to match the male DTE connector (DB-9) on the BayStack 380 console port, with the DCE/DTE switch on the switch management module set to DTE
- VT100 Arrows checked in the Terminal Preferences window under Terminal Options, and Block Cursor unchecked; VT-100/ANSI checked under Emulation

To access the CLI:


- 1 When you access the BayStack 380, the banner appears (Figure 2).

**Figure 2** BayStack 380 banner

```
*****  
* Nortel Networks  
* Copyright (c) 1996 - 2003  
* All Rights Reserved  
* BayStack 38024T 10/100/1000 Switch  
* Ver: HW:Rev X   FW:3.0.0.5   SW:v3.0.0.28  
*****
```

Enter Ctrl-Y to begin.

- 2 Press [Ctrl]+Y, and the Main Menu appears on the console screen (Figure 3) with the top line highlighted.

**Figure 3** Main Menu for BayStack 380 console interface

- 3 Using the Down Arrow key, scroll down to Command Line Interface, and press [Enter]. The CLI cursor appears:

```
BS380>
```

The > sign at the end of the name of the switch indicates that the CLI opens in User EXEC mode. Refer to [“CLI command modes” on page 26](#), to select the command mode you want to use (and are authorized to use).

## Setting the CLI password

You can set passwords for access through the serial console port or telnet access using the `cli password` command for selected types of access using the local or RADIUS security.

For more information on Telnet access, refer to Chapter 3. For more information on using RADIUS security with the CLI, refer to Chapter 3.

## cli password command

The `cli password` is in two forms and performs the following functions for the switch:

- Changes the password for access through the serial console port and Telnet
- Specifies changing the password for serial console port or Telnet access and whether to authenticate password locally or with the RADIUS server

The syntax for the `cli password` commands are:

```
cli password {ro|rw} <WORD> <WORD>
```

```
cli password {serial|telnet} {none|local|radius}
```

The `cli password` command is in the config command mode.

[Table 2](#) describes the parameters and variables for the `cli password` command.

**Table 2** cli password command parameters and variables

Parameters and variables	Description
rolrw	Specifies you are modifying the read-only (ro) password or the read-write (rw) password.
<username> <password>	Enter your username for the first variable, and your password for the second variable. The username is not used, but it must be present.
serialtelnet	Specifies you are modifying the password for serial console access or for Telnet access.
nonellocalradius	Specifies the password you are modifying: <ul style="list-style-type: none"> <li>• none—disables the password</li> <li>• local—use the locally defined password for serial console or Telnet access</li> <li>• radius—use RADIUS authentication for serial console or Telnet access</li> </ul>



## Getting help

When you navigate through the CLI, online help is available at all levels. Entering a portion of the command, space, and a question mark (?) at the prompt results in a list of all options for that command.

Refer to [“help command” on page 35](#) for more information about the specific types of online help.

## Basic navigation

This section discusses basic navigation around the CLI and between the command modes. As you see, the CLI incorporates various shortcut commands and keystrokes to simplify its use. The following topics are covered in this section:

- [“General navigation commands,” next](#)
- [“Keystroke navigation” on page 34](#)
- [“help command” on page 35](#)
- [“no command” on page 36](#)
- [“default command” on page 36](#)
- [“logout command” on page 37](#)
- [“enable command” on page 37](#)
- [“configure command” on page 38](#)
- [“interface command” on page 38](#)
- [“disable command” on page 39](#)
- [“end command” on page 39](#)
- [“exit command” on page 39](#)

## General navigation commands

When you enter ? at any point in the CLI session, the system retrieves help information for whatever portion of the command you entered thus far. Refer to [“help command” on page 35](#) for more information.

The system records the last command in a CLI session. However, the last command is not saved across reboots.

Add the word `no` to the beginning of most CLI configuration commands to clear or remove the parameters of the actual command. Refer to Appendix A for an alphabetical list of `no` commands.

Add the word `default` to the beginning of most CLI configuration commands returns the parameters of the actual command to the factory default values. Refer to Appendix A for an alphabetical list of `default` commands.

When you enter a portion of the command and the [Tab] key, the system finds the first unambiguous match of a command and displays that command. For example, if you enter `down+[Tab]`, the system displays `download`.

## Keystroke navigation

You change the location of the cursor using the key combinations shown in Table 3.

**Table 3** Keystroke navigation

Key combination	Function
[Ctrl]+A	Start of line
[Ctrl]+B	Back 1 character
[Ctrl]+C	Abort command
[Ctrl]+D	Delete the character indicated by the cursor
[Ctrl]+E	End of line
[Ctrl]+F	Forward 1 character
[Ctrl]+H	Delete character left of cursor (Backspace key)
[Ctrl]+I &	Command/parameter completion
[Ctrl]+K & [Ctrl]+R	Redisplay line
[Ctrl]+N or [Down arrow]	Next history command
[Ctrl]+P or [Up arrow]	Previous history command
[Ctrl]+T	Transpose characters

**Table 3** Keystroke navigation

Key combination	Function
[Ctrl]+U	Delete entire line
[Ctrl]+W	Delete word left of cursor
[Ctrl]+X	Delete all characters to left of cursor
[Ctrl]+z	Exit Global Configuration mode (to Privileged EXEC mode)
?	Context-sensitive help
[Esc]+c & [Esc]+u	Capitalize character at cursor
[Esc]+l	Change character at cursor to lowercase
[Esc]+b	Move back 1 word
[Esc]+d	Delete 1 word to the right
[Esc]+f	Move 1 word forward

## help command

The `help` command is in all command modes and displays a brief message about using the CLI help system. The syntax for the `help` command is:

```
help
```

The `help` command has no parameters or variables.

[Figure 4](#) shows the output from the `help` command.

**Figure 4** help command output in privExec mode

```
BS380#help
Help may be requested at any point in a command by entering
a question mark '?'. If nothing matches, the help list will
be empty and you must backup until entering a '?' shows the
available options.
Two styles of help are provided:
1. Full help is available when you are ready to enter a command argument
(e.g. 'show ?') and describes each possible argument.
2. Partial help is provided when an abbreviated argument is entered and you
want to know what arguments match the input (e.g. 'show pr?'.)
```

## no command

The `no` command is always used as a prefix to a configuration command, and it negates the action performed by that command. The effect of the `no` command is to remove or to clear the configuration controlled by the specified command. Various `no` commands are in the `config` and `config-if` command modes.

Refer to Appendix A for an alphabetical listing of all `no` commands.



**Note:** Not all configuration commands support the `no` prefix command.

---

## default command

The `default` command is always used as a prefix to a configuration command, and it restores the configuration parameters to default values. The default values are specified by each command.

Refer to Appendix A for an alphabetical listing of all `default` commands.



**Note:** Not all commands support the `default prefix` command.

---

## logout command

The `logout` command logs you out of the CLI session and returns you to the Main Menu of the console interface (CI) menus (Figure 3). The syntax for the `logout` command is:

```
logout
```

The `logout` command is in all command modes.

The `logout` command has no parameters or variables.

## enable command

The `enable` command changes the command mode from User EXEC to `privExec` mode. The syntax for the `enable` command is:

```
enable
```

The `enable` command is in the `exec` command mode.

The `enable` command has no parameters.



**Note:** You must have read-write access to the BayStack 380 switch to be able to use the `enable` command.

---

## configure command

The `configure` command moves you to the Global Configuration (`config`) command mode or identifies the source for the configuration commands. The syntax for the `configure` command is:

```
configure {terminal|network}
```

The `configure` command is in the `privExec` command mode.

[Table 4](#) describes the parameters and variables for the `configure` command.

**Table 4** configure command parameters and variables

Parameters and variables	Description
terminal network	Specifies the source for the configuration commands for the BayStack 380: <ul style="list-style-type: none"><li>terminal—allows you to enter config mode to enter configuration commands</li><li>network—allows you to set up parameters for auto-loading a script at boot-up or for loading and executing a script immediately</li></ul>

## interface command

The `interface` command moves you to the Interface Configuration (`config-if`) command mode. The syntax for the `interface` command is:

```
interface FastEthernet {<portlist>}
```

The `interface` command is in the `config` command mode.

[Table 5](#) describes the parameters and variables for the `interface` command.

**Table 5** interface command parameters and variables

Parameters and variables	Description
<portlist>	Specifies the portlist you want to be affected by all the commands issued in the config-if command mode.

## disable command

The `disable` command returns you to the User EXEC (`exec`) command mode. The syntax for the `disable` command is:

```
disable
```

The `disable` command is in the `privExec` command mode.

The `disable` command has no parameters.

## end command

The `end` command moves you to the `priv Exec` mode from either the Global Configuration (`config`) mode or the Interface Configuration (`config-if`) mode.

The syntax for the `end` command is:

```
end
```

The `end` command has no parameters or variables.

## exit command

The `exit` command moves you around the command modes:

- In User EXEC (`exec`) and Privileged EXEC (`privExec`) command modes, `exit` allows you to quit the CLI session.
- In Global Configuration (`config`) mode, `exit` moves you back to the `privExec` command mode.

- In Interface Configuration (config-if) command mode, `exit` moves you back to the config mode.

The syntax for the `exit` command is:

```
exit
```

The `exit` command has no parameters or variables.

## Managing basic system information

This section shows you how to view basic system information, such as the current software version. The following topic is covered:

- “[show sys-info command](#),” next

### show sys-info command

The `show sys-info` command displays the current system characteristics. The syntax for the `show sys-info` command is:


```
show sys-info
```

The `show sys-info` command is in the `privExec` command mode.

The `show sys-info` command has no parameters or variables.

[Figure 5](#) displays sample output from the `show sys-info` command.



**Figure 5** show sys-info command output

```
Select C:\WINNT\system32\telnet.exe
BS380-24T>en
BS380-24T#show sys-info
Operation Mode:      Switch
MAC Address:        00-04-38-D2-6F-20
Reset Count:        7
Last Reset Type:    Software Download
Power Status:       Primary Power
Autotopology:       Enabled
sysDescr:           BayStack 380-24T
                    HW:R0C      FW:3.0.0.2   SW:v3.0.0.33
                    Mfg Date:02082002
Serial #:           70855534
sysObjectID:        1.3.6.1.4.1.45.3.45.1
sysUpTime:          48 days, 01:37:12
sysServices:        ?
sysContact:
sysName:            BS380-24T
sysLocation:        SC100-06 LAB
BS380-24T#
```

To change the system contact, name, or location, refer to the `snmp-server` command in Chapter 2.

## Managing MAC address forwarding database table

This section shows you how to view the contents of the MAC address forwarding database table, as well as setting the age-out time for the addresses. The following topics are covered:

- “[show mac-address-table command](#),” next
- “[mac-address-table aging-time command](#)” on page 43
- “[default mac-address-table aging-time command](#)” on page 44

## show mac-address-table command

The `show mac-address-table` command displays the current contents of the MAC address forwarding database table. The syntax for the `show mac-address-table` command is:

```
show mac-address-table [vid <1-4094>] [aging-time] [address <H.H.H>]
```

The `show mac-address-table` command is in the `privExec` command mode.

[Table 6](#) describes the parameters and variables for the `show mac-address-table` command.

**Table 6** show mac-address-table command parameters and variables

Parameters and variables	Description
vid <1-4094>	Enter the number of the VLAN you want to display the forwarding database of. Default is to display the management VLAN's database.
aging-time	Displays the time in seconds after which an unused entry is removed from the forwarding database.
address <H.H.H>	Displays a specific MAC address if it exists in the database. Enter the MAC address you want displayed.

[Figure 6](#) displays sample output from the `show mac-address-table` command.

**Figure 6** show mac-address-table command output

```

BayStack 380 3.0#show mac-address-table
Mac Address Table Aging Time: 300
Number of addresses: 61

      MAC Address      Port      MAC Address      Port
-----
00-00-81-bc-ea-81  14      00-00-81-c1-9b-81  14
00-00-81-c1-f6-81  14      00-00-a2-8d-7b-9b  14
00-00-a2-f8-4d-c0  14      00-03-4b-40-6b-f4  14
00-04-dc-72-c3-f4  14      00-04-dc-72-cf-f4  14
00-04-dc-72-db-f4  14      00-04-dc-74-33-f4  14
00-08-c7-20-29-8e  14      00-60-f3-20-15-9b  14
00-80-2d-06-e5-39  14      00-80-2d-06-f3-1c  14
00-80-2d-0a-03-f4  14      00-80-2d-22-0c-40  14
00-80-2d-22-0e-00  14      00-80-2d-22-23-f4  14
00-80-2d-22-4f-f6  14      00-80-2d-22-87-f4  14
00-80-2d-22-93-f6  14      00-80-2d-39-7b-f4  14
00-80-2d-39-f0-c7  14      00-80-2d-39-f2-01  14
00-80-2d-39-f7-f4  14      00-80-2d-3a-7b-f4  14
00-80-2d-3f-b3-f4  14      00-80-2d-8c-48-c0  14
00-80-2d-ac-db-f4  14      00-80-2d-ad-9b-f4  14

```

## mac-address-table aging-time command

The `mac-address-table aging-time` command sets the time that the switch retains unseen MAC addresses. The syntax for the `mac-address-table aging-time` command is:

```
mac-address-table aging-time <time>
```

The `mac-address-table aging-time` command is in the config command mode.

[Table 7](#) describes the parameters and variables for the `mac-address-table aging-time` command.

**Table 7** mac-address-table aging-time command parameters and variables

Parameters and variables	Description
<time>	Enter the aging time in seconds that you want for MAC addresses (10-1000000) before they are flushed.

## default mac-address-table aging-time command

The default `mac-address-table aging-time` command sets the time that the switch retains unseen MAC addresses to 300 seconds. The syntax for the `default mac-address-table aging-time` command is:

```
default mac-address aging-time
```

The default `mac-address-table aging-time` command is in the config command mode.

The default `mac-address-table aging-time` command has no parameters or variables.

## Setting the default management system

The `cmd_interface` command allows you to set the default management interface when you use the console port or Telnet.

The syntax for the `cmd-interface` command is:

```
cmd-interface [cli|menu]
```

The `cmd-interface` command is in the `privExec` command mode.

---

## Chapter 2

# General CLI commands

---

In the BayStack 380 Switch, the Command Line Interface (CLI) commands allows you to display and modify the switch configuration while the switch is operating.

This chapter includes information about general switch maintenance, such as setting up access parameters, upgrading the software, and setting the speed. This chapter covers the following topics:

- [“Setting the terminal,” next](#)
- [“Pinging” on page 47](#)
- [“Assigning and clearing IP addresses” on page 52](#)
- [“Assigning and clearing IP addresses for specific units” on page 56](#)
- [“Setting Telnet access” on page 57](#)
- [“Setting boot parameters” on page 60](#)
- [“Setting boot parameters” on page 60](#)
- [“Setting TFTP parameters” on page 63](#)
- [“Upgrading software” on page 66](#)
- [“Displaying interfaces” on page 69](#)
- [“Setting SNMP parameters” on page 71](#)
- [“Configuring remote network monitoring \(RMON\)” on page 77](#)
- [“Setting the system event log” on page 83](#)
- [“Displaying port statistics” on page 87](#)
- [“Enabling or disabling a port” on page 90](#)
- [“Naming ports” on page 92](#)
- [“Setting port speed” on page 94](#)
- [“Enabling Autopology” on page 98](#)
- [“Single fiber fault detection” on page 103](#)

- [“SNMPv3 Commands” on page 105](#)

## Setting the terminal

You can view the terminal settings, set them to default settings, or customize the terminal settings. This section covers:

- [“show terminal command,” next](#)
- [“terminal command” on page 47](#)

### show terminal command

The `show terminal` command displays the current serial port information, which includes connection speed, as well as the terminal width and length in number of characters. The syntax for the `show terminal` command is:

```
show terminal
```

The `show terminal` command is in the exec command mode.

The `show terminal` command has no parameters or variables.

[Figure 7](#) displays the output from the `show terminal` command.

**Figure 7** show terminal command output

```
BS380_24#show terminal
Terminal speed: 9600
Terminal width: 79
Terminal length: 23
BS380_24#
```

## terminal command

The `terminal` command configures the settings for the terminal. These settings are transmit and receive speeds, terminal length, and terminal width. The syntax of the `terminal` command is:

```
terminal speed {2400|4800|9600|19200|38400} |length
<1-132> |width <1-132>
```

The `terminal` command is in the exec mode.

[Table 8](#) describes the parameters and variables for the `terminal` command.

**Table 8** terminal command parameters and variables

Parameters and variables	Description
speed {2400 4800 9600 19200 38400}	Sets the transmit and receive baud rates for the terminal. You can set the speed at one of the five options shown; default is 9600.
length <1-132>	Sets the length of the terminal display in characters; default is 24.
width <1-132>	Sets the width of the terminal displaying characters; default 79.

## Pinging

To ensure that the BayStack 380 has connectivity to the network, ping a device you know is connected to this network.

## ping command

The `ping` command tests the network connection to another network device. The command sends an Internet Control Message Protocol (ICMP) packet from the switch to the target device. The local IP address must be set before issuing the `ping` command.



**Note:** Refer to [“Assigning and clearing IP addresses” on page 52](#) for information on setting IP addresses.

---

The syntax for the `ping` command is:

```
ping <XXX.XXX.XXX.XXX>
```

The `ping` command is in the `exec` command mode.

[Table 9](#) describes the parameters and variables for the `ping` command.

**Table 9** ping command parameters and variables

Parameters and variables	Description
<XXX.XXX.XXX.XXX>	Specify the IP address of the target device in dotted-decimal notation.

If the device receives the packet, it sends a ping reply. When the switch receives the reply, it displays a message indicating that the specified IP address is alive. If no reply is received, a message indicates that the address is not responding.

[Figure 8](#) displays sample ping responses.



**Figure 8** ping command responses

```
BS380_24#ping 10.10.40.29
Host is reachable
BS380_24#ping 10.10.41.29
Host is not reachable
```

## show cli

The `show cli` command displays the CLI command modes and the type of password required for each mode. The syntax for the `show cli` command is:

```
show cli [info] [password [type]]
```

The `show cli` command is in the config command mode.

The `show cli` command has the following parameters.

[Table 10](#) describes the parameters and variables for the `show cli` command.

**Table 10** show cli command parameters and variables

Parameters and variables	Description
info	Displays general CLI settings.
password (type)	Displays CLI user names, passwords, and password types.

## show gbic-info

The `show gbic-info` command displays the type of GBIC used in the GBIC port. The syntax for the `show gbic-info` is:

```
show gbic-info
```

The `show gbic-info` command is in the config command mode.

There are no parameters or variables for the `show gbic-info` command.

## Automatically loading configuration file

This section discusses how to download a configuration file when the system boots. You use standard CLI commands to modify the configuration file you want to download. This section covers these commands:

- “[configure network command](#),” next
- “[show config-network command](#)” on page 51

### configure network command

The `configure network` command allows you to load and execute a script immediately and to configure parameters to automatically download a configuration file when you reboot the switch. The syntax for the `configure network` command is:

```
configure network [load-on-boot  
{disable|use-bootp|use-config}] [filename <WORD>] [address  
<XXX.XXX.XXX.XXX>]
```

The `configure network` command is in the exec mode.



**Note:** When you enter `configure network` with no parameters, the system prompts you for the script file name and TFTP server address and then downloads the script.

---

[Table 11](#) describes the parameters and variables for the `configure network` command.

**Table 11** configure network command parameters and variables

Parameters and variables	Description
load-on-boot {disable use-boot use-config}	<p>Specifies the settings for automatically loading a configuration file when the system boots:</p> <ul style="list-style-type: none"> <li>• <code>disable</code>—disables the automatic loading of config file</li> <li>• <code>use-boot</code>—specifies using the BootP file as the automatically loaded config file</li> <li>• <code>use-config</code>—specifies using the ASCII configuration file as the automatically loaded config file</li> </ul> <p>Note: If you omit this parameter, the system immediately downloads and runs the ASCII config file.</p>
filename <WORD>	<p>Specifies the file name.</p> <p>Note: If you omit this parameter and do not specify BootP, the system uses the configured file name.</p>
address <XXX.XXX.XXX.XXX>	<p>Specifies the TFTP server from which to load the file. Enter the IP address in dotted-decimal notation.</p> <p>Note: If you omit this parameter and do not specify BootP, the system uses the configured address.</p>



**Note:** When you specify the file name or address, these parameters will be used at the next reboot, even if you do not specify `load-on-boot`.

## show config-network command

The `show config-network` command displays information regarding the automatic loading of the configuration file, including the current status of this feature, the file name, the TFTP server address, and the status of the previous automatic configuration command. The syntax for the `show config-network` command is:


```
show config-network
```

The `show config-network` command is in the `privExec` mode.

The `show config-network` command has no parameters or values.

The output for the `show config-network` command is shown in [Figure 9](#),

**Figure 9** `show config-network` command

A screenshot of a telnet window titled "Select C:\WINNT\system32\telnet.exe". The window shows a command-line interface with the following text:

```
BS380-24I>enable
BS380-24I#show config-network
Auto-Load Configuration On Boot: Disabled
Configuration Filename:
TFTP Server IP Address: 47.80.33.101
Last Auto Configuration Status: Passed
Last Manual Configuration Status: Passed
BS380-24I#
```

## Assigning and clearing IP addresses

Using the CLI, you can assign IP addresses and gateway addresses, clear these addresses, and view configured IP addresses. This section covers these topics:

- [“ip address command,”](#) next
- [“no ip address command”](#) on page 53
- [“ip default-gateway command”](#) on page 54
- [“no ip default-gateway command”](#) on page 55
- [“show ip command”](#) on page 55

## ip address command

The `ip address` command sets the IP address and subnet mask for the switch. The syntax for the `ip address` command is:

```
ip address <XXX.XXX.XXX.XXX> [netmask <XXX.XXX.XXX.XXX>]
```

The `ip address` command is in the config command mode.

[Table 12](#) describes the parameters and variables for the `ip address` command.

**Table 12** ip address command parameters and variables

Parameters and variables	Description
<XXX.XXX.XXX.XXX>	Enter IP address in dotted decimal notation; netmask is optional.
netmask	Set the IP subnet mask for the switch.



**Note:** When you change the IP address or subnet mask, you may lose connection to Telnet and the Web.

## no ip address command

The `no ip address` command clears the IP address and subnet mask. This command sets the IP address and subnet mask for a switch to all zeros (0). The syntax for the `no ip address` command is:

```
no ip address {switch}
```

The `no ip address` command is in the config command mode.

[Table 13](#) describes the parameters and variables for the `no ip address` command.

**Table 13** no ip address command parameters and variables

Parameters and variables	Description
switch	Prompts you with “Are you sure you want to delete the switch IP address and subnet mask Y/N?” If you enter Y, this command zeroes out the IP address and subnet mask for the switch.



**Note:** When you change the IP address or subnet mask, you may lose connection to Telnet and the Web. You also disable any new Telnet connection, and you must connect to the serial console port to configure a new IP address.

---

## ip default-gateway command

The `ip default-gateway` command sets the IP default gateway address for a switch. The syntax for the `ip default-gateway` command is:

```
ip default-gateway <XXX.XXX.XXX.XXX>
```

The `ip default-gateway` command is in the config command mode.

[Table 14](#) describes the parameters and variables for the `ip default-gateway` command.

**Table 14** ip default-gateway command parameters and variables

Parameters and variables	Description
<XXX.XXX.XXX.XXX>	Enter the dotted-decimal IP address of the default IP gateway.



**Note:** When you change the IP gateway, you may lose connection to Telnet and the Web.

---

## no ip default-gateway command

The `no ip default-gateway` command sets the IP default gateway address to zeros (0). The syntax for the `no ip default-gateway` command is:

```
no ip default-gateway
```

The `no ip default-gateway` command is in the config command mode.

The `no ip default-gateway` command has no parameters or variables.



**Note:** When you change the IP gateway address, you may lose connection to Telnet and the Web. You also may disable any new Telnet connection be required to connect to the serial console port to configure a new IP gateway address.

---

## show ip command

The `show ip` command displays the IP configurations, specifically BootP mode, switch address, subnet mask, and gateway address. This command displays the these parameters for what is configured, what is in use, and the last BootP. The syntax for the `show ip` command is:

```
show ip [bootp] [default-gateway] [address]
```

The `show ip` command is in the exec command mode. If you do not enter any parameters, this command displays all the IP-related configuration information.

[Table 15](#) describes the parameters and variables for the `show ip` command.

**Table 15** show ip command parameters and variables

Parameters and variables	Description
bootp	Displays BootP-related IP information.
default-gateway	Displays the IP address of the default gateway.
address	Displays the current IP address.

[Figure 10](#) displays a sample output of the `show ip` command.

**Figure 10** show ip command output

```
BS380_24#show ip
BootP Mode: BootP Disabled

                Configured          In Use          Last BootP
-----
Switch IP Address: 10.30.31.200          0.0.0.0
Subnet Mask:       255.255.255.0    255.255.255.0  0.0.0.0
Default Gateway:  10.20.30.1        10.20.30.1    0.0.0.0
BS380_24#
```

## Assigning and clearing IP addresses for specific units

You can assign IP addresses for a specific unit. This section covers the topic:

- [“default ip address command” on page 57](#)



## default ip address command

The `default ip address` command sets the IP address for the specified unit to all zeros (0). The syntax for the `default ip address` command is:

```
default ip address
```

The `default ip address` command is in the config command mode.

There are no parameters and variables for the `default ip address` command.



**Note:** When you change the IP gateway, you may lose connection to Telnet and the Web.

---

## Setting Telnet access

You can also access the CLI through a Telnet session. To access the CLI remotely, the management port must have an assigned IP address and remote access must be enabled. You can log on to the switch using Telnet from a terminal that has access to the BayStack 380.



**Note:** Multiple users can access the CLI system simultaneously, through the serial port, Telnet, and modems. The maximum number of users is 5. All users can configure simultaneously.

---

You can view the Telnet allowed IP addresses and settings, change the settings, or disable the Telnet connection. This section covers the following topics:

- [“show telnet-access command,”](#) next
- [“telnet-access command”](#) on page 58
- [“no telnet-access command”](#) on page 59
- [“default telnet-access command”](#) on page 60

## show telnet-access command

The `show telnet-access` command displays the current settings for Telnet access. The syntax for the `show telnet-access` command is:

```
show telnet-access
```

The `show telnet-access` command is in the `privExec` command mode.

The `show telnet-access` command has no parameters or variables.

Figure 11 displays sample output from the `show telnet-access` command.

**Figure 11** show telnet-access command output

```
BS380_24#show telnet-access
TELNET Access:      Enabled
Login Timeout:     1 minute(s)
Login Retries:     3
Inactivity Timeout: 15 minute(s)
Event Logging:     All
Allowed Source IP Address  Allowed Source Mask
-----
0.0.0.0            0.0.0.0
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
BS380_24#
```

## telnet-access command

The `telnet-access` command allows you to configure the Telnet connection used to manage the switch. The syntax for the `telnet-access` command is:

```
telnet-access [enable|disable] [login-timeout <1-10>] [retry
<1-100>] [inactive-timeout <0-60>] [logging
{none|access|failures|all}] [source-ip <1-10>
<XXX.XXX.XXX.XXX> [mask <XXX.XXX.XXX.XXX>]]
```

The `telnet-access` command is in the config command mode.

[Table 16](#) describes the parameters and variables for the `telnet-access` command.

**Table 16** telnet-access command parameters and variables

Parameters and variables	Description
enable/disable	Enables or disables Telnet connections.
login-timeout <1-10>	Specifies the time in minutes you want to wait between initial Telnet connection and accepted password before closing the Telnet connection; enter an integer between 1 and 10.
retry <1-100>	Specifies the number of times the user can enter an incorrect password before closing the connection; enter an integer between 1 and 100.
inactive-timeout <0-60>	Specifies in minutes how long to wait before closing an inactive session; enter an integer between 0 and 60.
logging {none access failures all}	Specifies what types of events you want to save in the event log: <ul style="list-style-type: none"> <li>• none—do not save access events in the log</li> <li>• access—save access events in the log</li> <li>• failure—save failed access events in the log</li> <li>• all—save all access events in the log</li> </ul>
source-ip <1-10> <XXX.XXX.XXX.XXX>[mask <XXX.XXX.XXX.XXX>]	Specifies the source IP address from which connections are allowed. Enter the IP address in dotted-decimal notation. Specifies the subnet mask from which connections are allowed; enter IP mask in dotted-decimal notation.  Note: These are the same source IP addresses as in the IP Manager list. For more information on the IP Manager list, refer to Chapter 3.

## no telnet-access command

The `no telnet-access` command allows you to disable the Telnet connection. The syntax for the `no telnet-access` command is:

```
no telnet-access [source-ip [<1-10>]]
```

The `no telnet-access` command is in the config mode.

[Table 17](#) describes the parameters and variables for the `no telnet-access` command.

**Table 17** no telnet-access command parameters and variables

Parameters and variables	Description
source-ip [<1-10>]	<p>Disables the Telnet access.</p> <p>When you do <i>not</i> use the optional parameter, the source-ip list is cleared, meaning the 1st index is set to 0.0.0.0./0.0.0.0. and the 2nd to 10th indexes are set to 255.255.255.255/255.255.255.255. When you <i>do</i> specify a source-ip value, the specified pair is set to 255.255.255.255/255.255.255.255.</p> <p>Note: These are the same source IP addresses as in the IP Manager list. For more information on the IP Manager list, refer to Chapter 3.</p>

## default telnet-access command

The `default telnet-access` command sets the Telnet settings to the default values. The syntax for the `default telnet-access` command is:

```
default telnet-access
```

The `default telnet-access` command is in the config command mode.

The `default telnet-access` command has no parameters or values.

## Setting boot parameters

You can reboot the switch and configure BootP. The topics covered in this section are:

- [“boot command,”](#) next
- [“ip bootp server command”](#) on page 61

- [“no ip bootp server command” on page 62](#)
- [“default ip bootp server command” on page 62](#)

## boot command

The `boot` command performs a soft-boot of the switch. The syntax for the `boot` command is:

```
boot [default]
```

The `boot` command is in the `privExec` command mode.

[Table 18](#) describes the parameters and variables for the `boot` command.

**Table 18** boot command parameters and variables

Parameters and variables	Description
default	Restores switch to factory-default settings after rebooting.



**Note:** When you reset to factory defaults, the switch retains the last reset count, and reason for last reset; these parameters are not defaulted to factory defaults.

## ip bootp server command

The `ip bootp server` command configures BootP on the current instance of the switch or server. The syntax for the `ip bootp server` command is:

```
ip bootp server {last|needed|disable|always}
```

The `ip bootp server` command is in the `config` command mode.

[Table 19](#) describes the parameters and variables for the `ip bootp server` command.

**Table 19** `ip bootp server` command parameters and variables

Parameters and variables	Description
<code>lastneeded disable always</code>	Specifies when to use BootP: <ul style="list-style-type: none"><li>• <code>last</code>—use BootP or the last known address</li><li>• <code>needed</code>—use BootP only when needed</li><li>• <code>disable</code>—never use BootP</li><li>• <code>always</code>—Always use BootP</li></ul>

## no ip bootp server command

The `no ip bootp server` command disables the BootP server. The syntax for the `no ip bootp server` command is:

```
no ip bootp server
```

The `no ip bootp server` command is in the config command mode.

The `no ip bootp server` command has no parameters or values.

## default ip bootp server command

The `default ip bootp server` command disables the BootP server. The syntax for the `default ip bootp server` command is:

```
default ip bootp server
```

The `default ip bootp server` command is in the config command mode.

The `default ip bootp server` command has no parameters or values.

## Setting TFTP parameters

You can display the IP address of the TFTP server, assign an IP address you want to use for a TFTP server, copy a configuration file to the TFTP server, or copy a configuration file from the TFTP server to the switch to use to configure the switch. This section covers:

- “[show tftp-server command](#),” next
- “[tftp-server command](#)” on page 64
- “[no tftp-server command](#)” on page 64
- “[default tftp-server command](#)” on page 64
- “[copy config tftp command](#)” on page 65
- “[copy tftp config command](#)” on page 65

### show tftp-server command

The `show tftp-server` command displays the IP address of the server used for all TFTP-related transfers. The syntax for the `show tftp-server` command is:

```
show tftp-server
```

The `show tftp-server` command is in the `privExec` command mode.

The `show tftp-server` command has no parameters or variables.

[Figure 12](#) displays a sample output of the `show tftp-server` command.

**Figure 12** show tftp-server command output

```
BS380_24#show tftp-server
TFTP Server IP address : 192.168.100.15
BS380_24#
```

## tftp-server command

The `tftp-server` command assigns the address for the switch to use for TFTP services. The syntax of the `tftp-server` command is:

```
tftp-server <XXX.XXX.XXX.XXX>
```

The `tftp-server` command is in the config command mode.

[Table 20](#) describes the parameters and variables for the `tftp-server` command.

**Table 20** tftp-server command parameters and variables

Parameters and variables	Description
<XXX.XXX.XXX.XXX>	Enter the dotted-decimal IP address of the server you want to use for TFTP services.

## no tftp-server command

The `no tftp-server` command specifies a default address for the switch to use for TFTP services. The syntax of the `no tftp-server` command is:

```
no tftp-server
```

The `no tftp-server` command is in the EXEC command mode.

The `no tftp-server` command has no parameters or values.

## default tftp-server command

The `default tftp server` command restores the table to defaults (0.0.0.0). The syntax for the `default tftp server` is:

```
default tftp server
```

The `default tftp server` command is in the config command mode.



There are no parameters or variables for the default `tftp server` command.

## copy config tftp command

The `copy config tftp` command copies the current configuration file onto the TFTP server. The syntax for the `copy config tftp` command is:

```
copy config tftp [address <XXX.XXX.XXX.XXX>] filename <WORD>
```

The `copy config tftp` command is in the `privExec` command mode.

[Table 21](#) describes the parameters and variables for the `copy config tftp` command.

**Table 21** copy config tftp command parameters and variables

Parameters and variables	Description
<address>	Specifies the TFTP server IP address; enter in dotted-decimal notation.
filename <WORD>	Specifies that you want to copy the configuration file onto the TFTP server. Enter the name you want the configuration file to have on the TFTP server.

## copy tftp config command

The `copy tftp config` command retrieves the system configuration file from the TFTP server and uses the retrieved information as the current configuration on the system. The syntax for the `copy tftp config` command is:

```
copy tftp config [address <XXX.XXX.XXX.XXX>] filename <WORD>
```

The `copy tftp config` command is in the `privExec` command mode.

[Table 22](#) describes the parameters and variables for the `copy tftp config` command.

**Table 22** copy tftp config command parameters and variables

Parameters and variables	Description
<address> <XXX.XXX.XXX.XXX>	Specifies the TFTP server IP address; enter in dotted-decimal notation.
filename <WORD>	Enter the name of the configuration file you want to copy from the TFTP server.

## Upgrading software

You can download the BayStack 380 software image that is located in non-volatile flash memory. To download the BayStack 380 software image, a properly configured Trivial File Transfer Protocol (TFTP) server must be present in your network, and the policy switch must have an IP address. To learn how to configure the switch IP address, refer to [“Assigning and clearing IP addresses” on page 52](#).



**Caution:** Do not interrupt power to the device during the software download process. A power interruption can corrupt the firmware image.

---

This section covers the following topics:

- [“download command,”](#) next
- [“Observing LED indications” on page 68](#)
- [“Upgrading software images” on page 69](#)

### download command

The `download` command upgrades the software for the BayStack 380. You can upgrade both the software image and the diagnostics image.



**Note:** The system resets after downloading a new image.

The syntax for the `download` command is:

```
download [address <ip>] {image <image-name>|image-if-newer
<image-name>| diag <filename>}
```

The `download` command is in the `privExec` command mode.

[Table 23](#) describes the parameters and variables for the `download` command.

**Table 23** download command parameters and variables

Parameters and variables	Description
address <ip>	Specifies the TFTP server you want to use.  Note: If this parameter is omitted, the system goes to the server specified by the <code>tftp-server</code> command.
image <image-name>	Enter the name of the BS 380 software image you want to download.
image-if-newer <image-name>	Enter the name of the BS 380 software image that you want to download if it is newer than the current running image.
diag <filename>	Enter the name of the BS 380 diagnostics image you want to download.

The software download process automatically completes without user intervention. The process erases the contents of flash memory and replaces it with a new software image. Take care not to interrupt the download process until after it runs to completion (the process can take up to 10 minutes, depending on network conditions).

When the download process is complete, the switch automatically resets and the new software image initiates a self-test. The system returns a message after successfully downloading a new image. [Figure 13](#) displays a sample output of the download command.

**Figure 13** download message

```
Download Image [/]
Saving Image [-]
Finishing Upgrading Image
```

During the download process, the BayStack 380-24T Switch is not operational. You can monitor the progress of the download process by observing the LED indications.

## Observing LED indications

[Table 24](#) describes the LED indications during the software download process.

**Table 24** LED Indications during the software download process

Phase	Description	LED Indications
1	The switch downloads the new software image.	<b>Port status LEDs ports 1 to 24:</b> The LEDs blink in succession from both ends and criss-cross at the center of the switch.
2	The switch erases the flash memory.	<b>LEDs for ports 1 and 24 stay lit.</b>
3	The switch programs the new software image into the flash memory.	<b>Same as phase 1.</b>
4	The switch resets automatically.	After the reset completes, the new software image initiates the switch self-test, which comprises various diagnostic routines and subtests.  The LEDs display various patterns to indicate that the subtests are in progress.

## Upgrading software images

To download, or upgrade, software in a BayStack 380 switch:

- 1 Enter `download [address <ip>] image BS380_24.img`.

The system resets and opens to the 380 banner. Refer to [“Accessing the CLI” on page 30](#) to return to the CLI.

- 2 Enter `download [address <ip>] diag BS380_24diags.bin`.

The system resets and opens to the 380 banner. Refer to [“Accessing the CLI” on page 30](#) to return to the CLI.

## Displaying interfaces

You can view the status of all interfaces on the switch, including MultiLink Trunk membership, link status, autonegotiation, and speed.

### show interfaces command

The `show interfaces` command displays the current configuration and status of all interfaces. The syntax for the `show interfaces` command is:

```
show interfaces [names] [<portlist>]
```

The `show interfaces` command is in the `exec` command mode.

[Table 25](#) describes the parameters and variables for the `show interfaces` command.

**Table 25** show interfaces command parameters and variables

Parameters and variables	Description
names <portlist>	Displays the interface names; enter specific ports if you want to see only those.

Figure 14 displays a sample output of the `show interfaces names` command.

**Figure 14** show interfaces names command output

```
BS380_24 SW 3.0 in SC2-02 LAB>show interfaces names 1-3
Port Name
-----
1      LabBldg4
2      Testing
3      Floor1Bldg2
```

Figure 15 displays a sample output of the `show interfaces` command without the `names` variable.

**Figure 15** show interfaces command output

```

BayStack 380 3.0#show interfaces
                Status                Auto
Flow
Port Trunk Admin   Oper Link LinkTrap Negotiation Speed
Duplex Control
-----
1          Enable Down Down Enabled Enabled
2          Enable Down Down Enabled Enabled
3          Enable Down Down Enabled Enabled
4          Enable Down Down Enabled Enabled
5          Enable Down Down Enabled Enabled
6          Enable Down Down Enabled Enabled
7          Enable Down Down Enabled Enabled
8          Enable Down Down Enabled Enabled
9          Enable Down Down Enabled Enabled
10         Enable Down Down Enabled Enabled
11         Enable Down Down Enabled Enabled
12         Enable Down Down Enabled Enabled
13         Enable Down Down Enabled Enabled
14         Enable Up   Up   Enabled Enabled      10M
15         Enable Down Down Enabled Enabled
16         Enable Down Down Enabled Enabled
17         Enable Down Down Enabled Enabled
18         Enable Down Down Enabled Enabled
19         Enable Down Down Enabled Enabled
--More--

```

## Setting SNMP parameters

You can set various SNMP parameters and traps, as well as disable SNMP traps. This section covers:

- [“snmp-server command,”](#) next
- [“no snmp-server command”](#) on page 73
- [“snmp trap link-status command”](#) on page 75
- [“no snmp trap link-status command”](#) on page 76
- [“default snmp trap link-status command”](#) on page 76

## snmp-server command

The `snmp-server` command configures various SNMP parameters. The syntax for the `snmp-server` command is:

```
snmp-server {authentication-trap|community
<community-string> contact <text>|host <host-ip>
<community-string>|location <text>|name <text>}
```

The `snmp-server` command is in the config command mode.

[Table 26](#) describes the parameters and variables for the `snmp-server` command.

**Table 26** snmp-server command parameters and variables

Parameters and variables	Description
authentication-trap	Enables or disables generation of SNMP authentication failure trap.
bootstrap	Generates the SNMP bootstrap parameters.
community <community-string>	Changes the read-only (ro) or read-write (rw) community strings for SNMP v1 and SNMPv2c access. Enter a community string that works as a password and permits access to the SNMP protocol.
contact <text>	Specifies the SNMP sysContact value; enter an alphanumeric string.
host <host-ip> <community-string>	Configures an SNMP trap destination: <ul style="list-style-type: none"> <li>host-ip—enter a dotted-decimal IP address of a host that will be the trap destination</li> <li>community-string—enter a community string that works as a password and permits access to the SNMP protocol</li> </ul>
location <text>	Specifies the SNMP sysLocation value; enter an alphanumeric string.
name <text>	Specifies the SNMP sysName value; enter an alphanumeric string.
user	Creates an SNMPv3 user
view	Creates or changes an SNMP access view.



## no snmp-server command

The `no snmp-server` command disables SNMP or clears the configuration. If you omit the parameters, this command disables SNMP access. The syntax for the `no snmp-server` command is:

```
no snmp-server [authentication-trap|community|contact|host
[<host-ip> <community-string>]|location |name]
```

The `no snmp-server` command is in the config command mode.

[Table 27](#) describes the parameters and variables for the `snmp-server` command.

**Table 27** no snmp-server command parameters and variables

Parameters and variables	Description
authentication-trap	Disables authentication failure traps.
community	Disables the community string.
contact <text>	Clears the SNMP sysContact value.
sysContact value	Specifies the SNMP sysContact value; enter an alphanumeric string.
host <host-ip> <community-string>	Removes an SNMP trap destination or all destinations.
location	Clears the SNMP sysLocation value.
name	Clears the SNMP sysName value



**Note:** Disabling SNMP access will also lock you out of the DM management system.

## default snmp-server command

The `default snmp-server` command specifies using the default SNMP configuration parameter. The default parameter is 0.0.0.0. The syntax for the `default snmp-server` is:

```
default snmp-server enable|disable
[authentication-trap|community [ro|rw] contact|host
 [<host-ip> <community-string>]|location |name]
```

The default `snmp-server` command is in the global configuration command mode.

[Table 28](#) describes the parameters and variables for the `snmp-server` command.

**Table 28** default snmp-server command parameters and variables

Parameters and variables	Description
enable disable	With no parameters, disables SNMP access.
authentication-trap	Disables authentication failure traps.
community	Disables the community string.
contact <text>	Clears the SNMP sysContact value.
host <host-ip> <community-string>	Removes an SNMP trap destination or all destinations.
location	Clears the SNMP sysLocation value.
name	Clears the SNMP sysName value

## show snmp-server

The `show snmp-server` command displays the defaults for the `snmp-server` command. The syntax for the `show snmp-server` is:

```
show snmp-server
```

The `show snmp-server` command is in the config command mode.

[Table 29](#) describes the parameters and variables for the `snmp-server` command.

**Table 29** show snmp-server parameters and variable

Parameters and variables	Description
community	Displays SNMP community strings.
host	Displays SNMP trap destinations.
user	Displays SNMP users.
view	Displays SNMP views

## snmp trap link-status command

The `snmp trap link-status` command enables the linkUp/linkDown traps for the port. The syntax of the command is:

```
snmp trap link-status enable|disable [port <portlist>]
```

The `snmp trap link-status` command is in the config-if command mode.

[Table 30](#) describes the parameters and variables for the `snmp trap link-status` command.

**Table 30** snmp trap link-status command parameters and variables

Parameters and variables	Description
disable	Disables generation of linkUp/Down traps.
enable	Enables generation of linkUp/Down traps.
port <portlist>	Specifies the port numbers to enable the linkUp/linkDown traps on. Enter the port numbers or all.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## no snmp trap link-status command

The `no snmp trap link-status` command disables the linkUp/linkDown traps for the port. The syntax of the command is:

```
no snmp trap link-status [port <portlist>]
```

The `no snmp trap link-status` command is in the config-if command mode.

[Table 31](#) describes the parameters and variables for the `no snmp trap link-status` command.

**Table 31** no snmp trap link-status command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to disable the linkUp/linkDown traps on. Enter the port numbers or all.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## default snmp trap link-status command

The `default snmp trap link-status` command disables the linkUp/linkDown traps for the port. The default values are 0.0.0.0. The syntax of the command is:

```
default snmp trap link-status [port <portlist>]
```

The `default snmp trap link-status` command is in the config-if command mode.

[Table 32](#) describes the parameters and variables for the default `snmp trap link-status` command.

**Table 32** default snmp trap link-status command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to disable the linkUp/linkDown traps on. Enter the port numbers or all.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## Configuring remote network monitoring (RMON)

This section covers the RMON commands available and includes the following topics:

- [“show rmon alarm,”](#) next
- [“show rmon event”](#) on page 78
- [“show rmon history”](#) on page 78
- [“show rmon stats”](#) on page 79
- [“rmon alarm”](#) on page 80
- [“rmon event”](#) on page 81
- [“rmon history”](#) on page 82
- [“rmon stats”](#) on page 82

### show rmon alarm

The `show rmon alarm` command displays information for RMON alarms. The syntax for the `show rmon alarm` command is:

```
show rmon alarm
```

The `show rmon alarm` command is in the `privExec` mode.

The `show rmon alarm` command has no parameters or variables. [Figure 16](#) displays a sample output of the `show rmon alarm` command.

**Figure 16** show rmon alarm command output

```
BS380_24#show rmon alarm
```

Index	Interval	Variable	Sample Type	Rising Threshold	Event	Falling Threshold	Event
1	30	ifInOctets.1	delta	500	1	10	1

## show rmon event

The `show rmon event` command displays information regarding RMON events. The syntax for the `show rmon event` command is:

```
show rmon event
```

The `show rmon event` command is in the `privExec` mode.

The `show rmon event` command has no parameters or variables. [Figure 17](#) displays a sample output of the `show rmon event` command.

**Figure 17** show rmon event command output

```
BS380_24#show rmon event
```

Index	Log	Trap	Description
1	Yes	Yes	'Rising or Falling alarm on received octets'

## show rmon history

The `show rmon history` command displays information regarding the configuration of RMON history. The syntax for the `show rmon history` command is:

```
show rmon history
```

The `show rmon history` command is in the `privExec` mode.

The `show rmon history` command has no parameters or variables.

[Figure 18](#) displays a sample output of the `show rmon history` command.

**Figure 18** `show rmon history` command output

```

Select C:\WINNT\system32\telnet.exe
BS380-24T>en
BS380-24T#show rmon history
Index Port Buckets Requested Buckets Granted Interval
-----
1      1      15                15                30
2      2      15                15                30
3      3      15                15                30
4      4      15                15                30
5      5      15                15                30
6      6      15                15                30
7      7      15                15                30
8      8      15                15                30
9      9      15                15                30
10     10     15                15                30
11     11     15                15                30
12     12     15                15                30
13     13     15                15                30
14     14     15                15                30
15     15     15                15                30
16     16     15                15                30
17     17     15                15                30
18     18     15                15                30
19     19     15                15                30
20     20     15                15                30
----More (q=Quit, space/return=Continue)----

```

## show rmon stats

The `show rmon stats` command displays information regarding the configuration of RMON statistics. The syntax for the `show rmon stats` command is:

```
show rmon stats
```

The `show rmon stats` command is in the `privExec` mode.

The `show rmon stats` command has no parameters or variables. [Figure 19](#) displays a sample output of the `show rmon stats` command.

**Figure 19** show rmon stats command output


```

Select C:\WINNT\system32\telnet.exe
BS380-24T>en
BS380-24T#show rmon stats
Index Port
-----
1      1
2      2
3      3
4      4
5      5
6      6
7      7
8      8
9      9
10     10
11     11
12     12
13     13
14     14
15     15
16     16
17     17
18     18
19     19
20     20
----More (q=Quit, space/return=Continue)----

```

## rmon alarm

The `rmon alarm` command allows you to set RMON alarms and thresholds. The syntax for the `rmon alarm` command is:

```

rmon alarm <1-65535> <WORD> <1-2147483647> {absolute|delta}
rising threshold <-2147483648-2147483647> [<1-65535>]
falling-threshold <-2147483648-2147483647> [<1-65535>]
[owner <LINE>]

```

The `rmon alarm` command is in the config command mode.

[Table 33](#) describes the parameters and variables for the `rmon alarm` command.

**Table 33** rmon alarm command parameters and variables

Parameters and variables	Description
<1-65535>	Unique index for the alarm entry.
<WORD>	The MIB object to be monitored. This is an OID, and for most available objects, an English name may be used.



**Table 33** rmon alarm command parameters and variables

Parameters and variables	Description
<1-2147483647>	The sampling interval, in seconds.
absolute	Use absolute values (value of the MIB object is compared directly with thresholds).
delta	Use delta values (change in the value of the MIB object between samples is compared with thresholds).
rising-threshold <-2147483648-2147483647> [<1-65535>]	The first integer value is the rising threshold value. The optional second integer specifies the event entry to be triggered when the rising threshold is crossed. If omitted, or if an invalid event entry is referenced, no event will be triggered.
falling-threshold <-2147483648-2147483647> [<1-65535>]	The first integer value is the falling threshold value. The optional second integer specifies the event entry to be triggered when the falling threshold is crossed. If omitted, or if an invalid event entry is referenced, no event will be triggered.
[owner <LINE>]	Specify an owner string to identify the alarm entry.

## rmon event

The `rmon event` allows you to configure RMON event log and trap settings. The syntax for the `rmon event` command is:

```
rmon event <1-65535> [log] [trap] [description <LINE>]
[owner <LINE>]
```

The `rmon event` command is in the config command mode.

[Table 34](#) describes the parameters and variables for the `rmon event` command.

**Table 34** rmon event command parameters and variables

Parameters and variables	Description
<1-65535>	Unique index for the event entry.
[log]	Record events in the log table.
[trap]	Generate SNMP trap messages for events.

**Table 34** rmon event command parameters and variables

Parameters and variables	Description
[description <LINE>]	Specify a textual description for the event.
[owner <LINE>]	Specify an owner string to identify the event entry

## rmon history

The `rmon history` allows you to configure RMON history settings. The syntax for the `rmon history` command is:

```
rmon history <1-65535> <port> <1-65535> <1-3600> [owner <LINE>]
```

The `rmon history` command is in the config command mode.

[Table 35](#) describes the parameters and variables for the `rmon history` command.

**Table 35** rmon history command parameters and variables

Parameters and variables	Description
<1-65535>	Unique index for the history entry.
<port>	Specify the port number to be monitored.
<1-65535>	The number of history buckets (records) to keep.
<1-3600>	The sampling rate (how often a history sample is collected).
[owner <LINE>]	Specify an owner string to identify the history entry.

## rmon stats

The `rmon stats` command allows you to configure RMON statistics settings. The syntax for the `rmon stats` command is:

```
rmon stats <1-65535> <LINE> [owner <LINE>]
```

The `rmon stats` command is in the `privExec` command mode.

[Table 36](#) describes the parameters and variables for the `rmon stats` command.

**Table 36** rmon stats command parameters and variables

Parameters and variables	Description
<1-65535>	Unique index for the stats entry.
[owner <LINE>]	Specify an owner string to identify the stats entry.

## Setting the system event log

You can set the system event log to log different levels of events. This section covers:

- [“show logging,” next](#)
- [“logging” on page 85](#)
- [“no logging” on page 86](#)
- [“default logging” on page 86](#)
- [“clear logging command” on page 86](#)

### show logging

The `show logging` command displays the current contents of the system event log. The syntax for the `show logging` command is:

```
show logging config
```

```
show logging [critical] [serious] [informational]
```

The `show logging` command is in the `privExec` command mode.

[Table 37](#) describes the parameters and variables for the `show logging` command.

**Table 37** show logging command parameters and variables

<b>Parameters and variables</b>	<b>Description</b>
config	Displays the current logging settings.
critical	Displays critical log messages.
serious	Displays serious log messages.
informational	Displays informational log messages.

[Figure 20](#) shows the output of the `show logging informational` command.

**Figure 20** show logging informational command output

```

Select C:\WINNT\system32\telnet.exe
BS380-24T#show logging informational
Type Time Index Src Message
-----
I 00:06:58:49 22 Inactivity logout, IP address: 134.177.152.102,
access mode: no security
I 00:06:58:49 23 Inactivity logout, IP address: 134.177.152.102,
access mode: no security
I 00:07:13:49 24 Inactivity logout, IP address: 134.177.152.102,
access mode: no security
I 00:07:13:49 25 Inactivity logout, IP address: 134.177.152.102,
access mode: no security
I 01:06:01:18 26 Successful connection from IP address: 134.177.1
52.102, access mode: no security
I 01:06:55:15 27 Inactivity logout, IP address: 134.177.152.102,
access mode: no security
I 01:06:55:15 28 Inactivity logout, IP address: 134.177.152.102,
access mode: no security
I 01:06:56:54 29 Successful connection from IP address: 134.177.1
52.102, access mode: no security
I 01:07:22:28 30 Inactivity logout, IP address: 134.177.152.102,
access mode: no security
I 01:07:22:28 31 Inactivity logout, IP address: 134.177.152.102,
access mode: no security
----More <q=Quit, space/return=Continue>----

```

## logging

The logging command configures the system settings for the system event log. The syntax for the logging command is:

```

logging [enable|disable] [level
critical|serious|informational] [nv-level
critical|serious|none]

```

The logging command is in the config command mode.

[Table 38](#) describes the parameters and variables for the logging command.

**Table 38** logging command parameters and values

Parameters and variables	Description
enable disable	Enables or disables the event log (default is enabled).
level critical serious informational	Specifies the level of logging stored in DRAM.
nv-level critical serious none	Specifies the level of logging stored in non-volatile memory.

## no logging

The `no logging` command disables the system event log. The syntax for the `no logging` command is:

```
no logging
```

The `no logging` command is in the config command mode.

The `no logging` command has no parameters or values.

## default logging

The `default logging` command configures the system settings as the factory default settings for the system event log. The syntax for the `default logging` command is:

```
default logging
```

The `default logging` command is in the config command mode.

The `default logging` command has no parameters or values.

## clear logging command

The `clear logging` command clears all log messages in DRAM. The syntax for the `clear logging` command is:

```
clear logging [nv]
```

The `clear logging` command is in the `privExec` command mode.

[Table 39](#) shows the parameters and values for the `clear logging` command.

**Table 39** clear logging command parameters and values

Parameters and values	Description
nv	Clears all log messages in both DRAM and non-volatile memory.

## Displaying port statistics

You can display the statistics for a port for both received and transmitted traffic. This section covers:

- [“show port-statistics command,”](#) next
- [“clear-stats command”](#) on page 90

### show port-statistics command

The `show port-statistics` command displays the statistics for the port on both received and transmitted traffic. The syntax for the `show port-statistics` command is:

```
show port-statistics [port <portlist>]
```

The `show port-statistics` command is in the config-if command mode.

[Table 40](#) describes the parameters and variables for the `show port-statistics` command.

**Table 40** show port-statistics command parameters and variables

<b>Parameters and variables</b>	<b>Description</b>
port <portlist>	Specifies the port numbers to configure to display statistics on; enter the port numbers.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

[Figure 21](#) displays sample output from the `show port-statistics` command.



**Figure 21** show port-statistics command output

```
BS380_24 (config-if)#show port-statistics
Received
Packets:          1117620
Multicasts:       112524
Broadcasts:       996989
Total Octets:     75698837
Packets 64 bytes: 1106427
  65-127 bytes:   2143
  128-255 bytes: 1731
  256-511 bytes: 2977
  512-1023 bytes: 3662
  1024-1518 bytes: 680
Jumbo 1519-9216 bytes: 0
Control Packets: 0
FCS Errors:       0
Undersized Packets: 0
Oversized Packets: 0
Filtered Packets: 0
Flooded Packets: 1004751
Transmitted
Packets:          32451
Multicasts:       31643
Broadcasts:       0
Total Octets:     2183060
Packets 64 bytes: 32030
  65-127 bytes:   161
  128-255 bytes: 107
  256-511 bytes: 62
  512-1023 bytes: 85
  1024-1518 bytes: 6
Jumbo 1519-9216 bytes: 0
Control Packets: 0
Collisions:       0
Single Collisions: 0
Multiple Collisions: 0
Excessive Collisions: 0
Late Collisions: 0
```

## clear-stats command

The `clear-stats` command clears all statistical information for the specified port. All counters are set to zero (0). The syntax for the `clear-stats` command is:

```
clear-stats [port <portlist>]
```

The `clear-stats` command is in the `config-if` command mode.

[Table 41](#) describes the parameters and variables for the `clear-stats` command.

**Table 41** clear-stats command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to clear of statistical information; enter the port numbers.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## Enabling or disabling a port

You can enable or disable a port using the CLI. This section covers the following commands:

- [“shutdown command,”](#) next
- [“no shutdown command”](#) on page 91

## shutdown command

The `shutdown` command disables the port. The syntax for the `shutdown` command is:

```
shutdown [port <portlist>]
```

The `shutdown` command is in the `config-if` command mode.

[Table 42](#) describes the parameters and variables for the `shutdown` command.

**Table 42** shutdown command parameters and variables

Parameters and variables	Description
<code>port &lt;portlist&gt;</code>	Specifies the port numbers to shut down or disable. Enter the port numbers you want to disable.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## no shutdown command

The `no shutdown` command enables the port. The syntax for the `no shutdown` command is:

```
no shutdown [port <portlist>]
```

The `no shutdown` command is in the `config-if` command mode.

[Table 43](#) describes the parameters and variables for the `no shutdown` command.

**Table 43** no shutdown command parameters and variables

Parameters and variables	Description
<code>port &lt;portlist&gt;</code>	Specifies the port numbers to enable. Enter the port numbers you want to enable.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## default shutdown command

The `default shutdown` command specifies shutdown of a port or ports based on the default configuration. The syntax for the `default shutdown` is:

```
default shutdown [port <portlist>]
```

The `default shutdown` command is in the interface configuration command mode.

[Table 44](#) describes the parameters and variables for the `default shutdown` command.

**Table 44** default shutdown command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to shut down or disable. Enter the port numbers you want to disable.

## Naming ports

You can name a port using the CLI. This section covers the following commands:

- [“name command,”](#) next
- [“no name command”](#) on page 93
- [“default name command”](#) on page 94

### name command

The `name` command allows you to name ports or to change the name. The syntax for the `name` command is:

```
name [port <portlist>] <LINE>
```

The `name` command is in the config-if command mode.

[Table 45](#) describes the parameters and variables for the `name` command.

**Table 45** name command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to name.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.
<LINE>	Enter up to 26 alphanumeric characters.

## no name command

The `no name` command clears the port names; it resets the field to an empty string. The syntax for the `no name` command is:

```
no name [port <portlist>]
```

The `no name` command is in the config-if command mode.

[Table 46](#) describes the parameters and variables for the `no name` command.

**Table 46** no name command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to clear of names.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## default name command

The `default name` command clears the port names; it resets the field to an empty string. The syntax for the `default name` command is:

```
default name [port <portlist>]
```

The `default name` command is in the `config-if` command mode.

[Table 47](#) describes the parameters and variables for the `default name` command.

**Table 47** default name command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to clear of names.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## Setting port speed

You can set the speed and duplex mode for a port. This section covers:

- [“speed command,”](#) next
- [“default speed command”](#) on page 95
- [“duplex command”](#) on page 96
- [“default duplex command”](#) on page 97

### speed command

The `speed` command sets the speed of the port. The syntax for the `speed` command is:

```
speed [port <portlist>] {10|100|1000|auto}
```

The `speed` command is in the `config-if` command mode.



**Note:** Fiber optic ports can only be set to 1000.

Table 48 describes the parameters and variables for the `speed` command.

**Table 48** speed command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to configure the speed. Enter the port numbers you want to configure.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.
10 100 1000 auto	Sets speed to: <ul style="list-style-type: none"> <li>• 10—10 Mb/s</li> <li>• 100—100 Mb/s</li> <li>• 1000—1000 Mb/s or 1 GB/s</li> <li>• auto—autonegotiation</li> </ul>



**Note:** When you set the port speed for autonegotiation, ensure that the other side of the link is also set for autonegotiation.

## default speed command

The `default speed` command sets the speed of the port to the factory default speed. The syntax for the `default speed` command is:

```
default speed [port <portlist>]
```

The `default speed` command is in the `config-if` command mode.

[Table 49](#) describes the parameters and variables for the `default speed` command.

**Table 49** default speed command parameters and variables

Parameters and variables	Description
<code>port &lt;portlist&gt;</code>	Specifies the port numbers to set the speed to factory default. Enter the port numbers you want to set.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## duplex command

The `duplex` command specifies the duplex operation for a port. The syntax for the `duplex` command is:

```
duplex [port <portlist>] {full|half|auto}
```

The `duplex` command is in the `config-if` command mode.



**Note:** Fiber optic ports can only be set to 1000.

---

[Table 50](#) describes the parameters and variables for the `duplex` command.



**Table 50** duplex command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port number to configure the duplex mode. Enter the port number you want to configure, or all to configure all ports simultaneously.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.
fullhalfauto	Sets duplex to: <ul style="list-style-type: none"><li>• full—full-duplex mode</li><li>• half—half-duplex mode</li><li>• auto—autonegotiation</li></ul>



**Note:** When you set the duplex mode for autonegotiation, ensure that the other side of the link is also set for autonegotiation, and that duplex matches on both sides: full or half.

## default duplex command

The `default duplex` command sets the duplex operation for a port to the factory default duplex value. The syntax for the `default duplex` command is:

```
default duplex [port <portlist>]
```

The `default duplex` command is in the `config-if` command mode.

[Table 51](#) describes the parameters and variables for the `default duplex` command.

**Table 51** default duplex command parameters and variables

Parameters and variables	Description
<code>port &lt;portlist&gt;</code>	<p>Specifies the port numbers to reset the duplex mode to factory default values. Enter the port numbers you want to configure, or all to configure all ports simultaneously. The default value is autonegotiation.</p> <p>Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.</p>

## Enabling Autopology

You can enable the Optivity\* Autopology\* protocol using the CLI. Refer to the [www.nortelnetworks.com/documentation](http://www.nortelnetworks.com/documentation) URL for information on Autopology. (The product family for Optivity and Autotopology is Data and Internet.). This section covers the following commands:

- “[autotopology command](#),” next
- “[no autotopology command](#)” on page 99
- “[default autotopology command](#)” on page 99

### autotopology command

The `autotopology` command enables the Autotopology protocol. The syntax for the `autotopology` command is:

```
autotopology
```

The `autotopology` command is in the `config` command mode.

The `autotopology` command has no parameters or values.

## no autotopology command

The `no autotopology` command disables the Autotopology protocol. The syntax for the `no autotopology` command is:

```
no autotopology
```

The `no autotopology` command is in the config command mode.

The `no autotopology` command has no parameters or values.

## default autotopology command

The `default autotopology` command enables the Autotopology protocol. The syntax for the `default autotopology` command is:

```
default autotopology
```

The `default autotopology` command is in the config command mode.

The `default autotopology` command has no parameters or values.

## show autotopology

The `show autotopology` command displays the default autotopology values. The syntax for the `show autotopology` is:

```
show autotopology
```

The `show autotopology` command is in the config command mode.

There are no parameters or variables for the `show autotopology` command.

## Enabling flow control

If you use a Gigabit Interface Connector (GBIC) with the BayStack 380, you control traffic on this port using the `flowcontrol` command. This section covers the following commands:

- [“flowcontrol command,” next](#)
- [“no flowcontrol command” on page 101](#)
- [“default flowcontrol command” on page 102](#)

### flowcontrol command

The `flowcontrol` command is used only on Gigabit Interface Connector ports and controls the traffic rates during congestion. The syntax for the `flowcontrol` command is:

```
flowcontrol [port <portlist>]
{asymmetric | symmetric | auto | disable}
```

The `flowcontrol` command is in the config-if mode.

[Table 52](#) describes the parameters and variables for the `flowcontrol` command.

**Table 52** flowcontrol command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to configure for flow control.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.
asymmetric symmetric auto disable	Sets the mode for flow control: <ul style="list-style-type: none"> <li>• asymmetric—enables the local port to perform flow control on the remote port</li> <li>• symmetric—enables the local port to perform flow control on the remote end and allows the remote end to perform flow control at the local end</li> <li>• auto—sets the port to automatically determine the flow control mode (default)</li> <li>• disable—disables flow control on the port</li> </ul>

## no flowcontrol command

The `no flowcontrol` command is used only on Gigabit Ethernet ports and disables flow control. The syntax for the `no flowcontrol` command is:

```
no flowcontrol [port <portlist>]
```

The `no flowcontrol` command is in the config-if mode.

[Table 53](#) describes the parameters and variables for the `no flowcontrol` command.

**Table 53** no flowcontrol command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to disable flow control.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## default flowcontrol command

The `default flowcontrol` command is used only on Gigabit Ethernet ports and sets the flow control to auto, which automatically detects the flow control. The syntax for the `default flowcontrol` command is:

```
default flowcontrol [port <portlist>]
```

The `default flowcontrol` command is in the config-if mode.

[Table 54](#) describes the parameters and variables for the `default flowcontrol` command.

**Table 54** default flowcontrol command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to default to auto flow control.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## Single fiber fault detection

When a partial fiber break occurs, data is lost on one side of a link. Single Fiber Fault Detection (SFFD) detects this error condition, and causes the port that is losing data to go down. This stops the loss of data.

The Single Fiber Fault Detection feature is enabled on a port by port basis for the BPS 2000 2GE MDA, and BayStack 380 and BayStack 470-48T and 470-24T GBIC ports. At present, you can access this feature through the NNCLI.

Single Fiber Fault Detection (SFFD) has the following requirements and limitations:

- SFFD must be implemented on both sides of a link. For example:
  - Passport 8600 and BoSS 3.0
- SFFD must be enabled on a per-port basis
- By default, SFFD is disabled on all ports
- SFFD takes about 50 seconds to detect a fault
- Once a link is repaired, the link recovers automatically

## Far End Fault Indication (FEFI)

When a fiber optic transmission link to a remote device fails, the remote device indicates the failure and the port is disabled. To use FEFI, the user must enable autonegotiation on the port.

## CLI commands for SFFD

This section lists the CLI commands that will be used on the BayStack products to support the SFFD feature.

### **show sffd**

This command shows the SFFD configuration information for all ports where the SFFD feature is applicable. The output shows if the SFFD feature is enabled or disabled.

The command works in ALL of the NNCLI modes (e.g., User EXEC, Privileged EXEC, Global Configuration, and Interface Configuration).

### **sffd [port <portlist>] enable**

This command enables the SFFD feature on specified ports, and is only available in the NNCLI using interface configuration mode.

The argument `port <portlist>` specifies the port number(s) to enable the SFFD feature. If not specified, the system will use the port number specified in the interface command.

### **no sffd [port <portlist>] enable**

This command disables the SFFD feature on specified ports, and is only available in the NNCLI interface configuration mode.

The argument `port <portlist>` specifies the port number(s) to disable the SFFD feature. If not specified, the system will use port number specified in the interface command.

### **default sffd [port <portlist>] enable**

This command changes the SFFD setting for the specified ports to the factory setting. The factory default setting is disabled.

The argument `port <portlist>` specifies the port number(s) to default the SFFD feature setting. If not specified, the system will use port number specified in the interface command.



---

## SNMPv3 Commands

BayStack 380 provides the following CLI commands for SNMPv3:

- “show snmp-server command,” next
- “snmp-server authentication-trap command” on page 106
- “no snmp-server authentication-trap command” on page 107
- “default snmp-server authentication-trap command” on page 107
- “snmp-server community for read/write command” on page 108
- “snmp-server community command” on page 109
- “no snmp-server community command” on page 110
- “default snmp-server community command” on page 111
- “snmp-server contact command” on page 112
- “no snmp-server contact command” on page 112
- “default snmp-server contact command” on page 112
- “snmp-server command” on page 113
- “no snmp-server command” on page 113
- “snmp-server host for old-style table command” on page 114
- “snmp-server host for new-style table command” on page 115
- “snmp-server host for old-style table command” on page 114
- “snmp-server host for new-style table command” on page 115
- “default snmp-server host command” on page 117
- “snmp-server location command” on page 117
- “no snmp-server location command” on page 118
- “default snmp-server location command” on page 118
- “snmp-server name command” on page 118
- “no snmp-server name command” on page 119
- “default snmp-server name command” on page 119
- “snmp-server user command” on page 119
- “no snmp-server user command” on page 121
- “snmp-server view command” on page 121
- “no snmp-server view command” on page 122
- “snmp trap link-status command” on page 123

- [“no snmp trap link-status command” on page 124](#)
- [“default snmp trap link-status command” on page 124](#)
- [“snmp-server bootstrap command” on page 125](#)

## show snmp-server command

The `show snmp-server` command displays SNMP configuration. The syntax for the `show snmp-server` command is:

```
show snmp-server {community|host|user|views}
```

The `show snmp-server` command is in the `privExec` command mode.

[Table 55](#) describes the parameters and variables for the `show snmp-server` command.

**Table 55** show snmp-server command parameters and variables

Parameters and variables	Description
community host user view	Displays SNMPv3 configuration information: <ul style="list-style-type: none"><li>• community strings as configured in SNMPv3 MIBs</li><li>• trap receivers as configured in SNMPv3 MIBs</li><li>• SNMPv3 users, including views accessible to each user</li><li>• SNMPv3 views</li></ul>
view/views	Displays SNMPv3 views.

## snmp-server authentication-trap command

The `snmp-server authentication-trap` command enables or disables the generation of SNMP authentication failure traps. The syntax for the `snmp-server authentication-trap` command is:

```
snmp-server authentication-trap {enable|disable}
```

The `snmp-server authentication-trap` command is in the `config` command mode.

Table 56 describes the parameters and variables for the `snmp-server authentication-trap` command.

**Table 56** `snmp-server authentication-trap` command parameters and variables

Parameters and variables	Description
<code>enable/disable</code>	Enables or disables the generation of authentication failure traps.

## no snmp-server authentication-trap command

The `no snmp-server authentication-trap` command disables generation of SNMP authentication failure traps. The syntax for the `no snmp-server authentication-trap` command is:

```
no snmp-server authentication-trap
```

The `no snmp-server authentication-trap` command is in the `config` command mode.

There are no parameters or variables for the `no snmp-server authentication-trap` command.

## default snmp-server authentication-trap command

The `default snmp-server authentication-trap` command restores SNMP authentication trap configuration to the default settings. The syntax for the `default snmp-server authentication-trap` command is:

```
default snmp-server authentication-trap
```

The `default snmp-server authentication-trap` command is in the `config` command mode.

There are no parameters for the `default snmp-server authentication-trap` command.

## snmp-server community for read/write command

The `snmp-server community` command for read/write modifies the community strings for SNMP v1 and SNMPv2c access. The syntax for the `snmp-server community for read/write` command is:

```
snmp-server community <community-string> [ro|rw]
```

The `snmp-server community for read/write` command is in the config command mode.

This command configures a single read-only or a single read-write community. A community configured using this command does not have access to any of the SNMPv3 MIBs. The community strings created by this command are controlled by the SNMP Configuration screen in the console interface.

This command affects community strings that were created prior to BoSS 3.0. These community strings will have a fixed MIB view.

[Table 57](#) describes the parameters and variables for the `snmp-server community for read/write` command.

**Table 57** snmp-server community for read/write command parameters and variables

Parameters and variables	Description
community-string	Changes community strings for SNMP v1 and SNMPv2c access. Enter a community string that works as a password and permits access to the SNMP protocol. If you set the value to 'NONE' it will be disabled.
rolrw	Specifies read-only or read-write access. Stations with ro access can only retrieve MIB objects, and stations with rw access can retrieve and modify MIB objects.  <b>Note:</b> If neither ro nor rw is specified, ro is assumed (default).

## snmp-server community command

The `snmp-server community` command allows you to create community strings with varying levels of read, write, and notification access based on SNMPv3 views. These community strings are separate from those created using the `snmp-server community` for read/write command.

This command affects community strings stored in the SNMPv3 `snmpCommunityTable`, which allows several community strings to be created. These community strings may have any MIB view.

The syntax for the `snmp-server community` command is:

```
snmp-server community <community-string> {read-view
<view-name>|write-view <view-name>|notify-view <view-name>}
```

The `snmp-server community` command is in the config command mode.

[Table 58](#) describes the parameters and variables for the `snmp-server community` command.

**Table 58** snmp-server community command parameters and variables

Parameters and variables	Description
community-string	Enter a community string to be created with access to the specified views.
read-view <view-name>	Changes the read view used by the new community string for different types of SNMP operations. <ul style="list-style-type: none"> <li>view-name—specifies the name of the view which is a set of MIB objects/instances that can be accessed; enter an alphanumeric string.</li> </ul>

**Table 58** snmp-server community command parameters and variables (continued)

Parameters and variables	Description
write-view <view-name>	Changes the write view used by the new community string for different types of SNMP operations. <ul style="list-style-type: none"> <li>view-name—specifies the name of the view which is a set of MIB objects/instances that can be accessed; enter an alphanumeric string.</li> </ul>
notify-view <view-name>	Changes the notify view settings used by the new community string for different types of SNMP operations. <ul style="list-style-type: none"> <li>view-name—specifies the name of the view which is a set of MIB objects/instances that can be accessed; enter an alphanumeric string.</li> </ul>

## no snmp-server community command

The `no snmp-server community` command clears the `snmp-server` community configuration. The syntax for the `no snmp-server community` command is:

```
no snmp-server community [ro|rw|<community-string>]
```

The `no snmp-server community` command is in the config command mode.

If you do not specify a read-only or read-write community parameter, all community strings are removed, including all communities controlled by the `snmp-server community` command and the `snmp-server community` for read-write command.

If you specify read-only or read-write, then just the read-only or read-write community is removed. If you specify the name of a community string, then the community string with that name is removed.

[Table 59](#) describes the parameters and variables for the `no snmp-server community` command.

**Table 59** no snmp-server community command parameters and variables

Parameters and variables	Description
rolrw<community-string>	Changes the settings for SNMP: <ul style="list-style-type: none"> <li>rolrw—sets the specified old-style community string's value to 'NONE', thereby disabling it.</li> <li>community-string—deletes the specified community string from the SNMPv3 MIBs (that is, from the new-style configuration).</li> </ul>

## default snmp-server community command

The default `snmp-server community` command restores the community string configuration to the default settings. The syntax for the `default snmp-server community` command is:

```
default snmp-server community [ro|rw]
```

The `default snmp-server community` command is in the `config` command mode.

If the read-only or read-write parameter is omitted from the command, then all communities are restored to their default settings. The read-only community is set to `Public`, the read-write community is set to `Private`, and all other communities are deleted.

[Table 60](#) describes the parameters and variables for the `default snmp-server community` command.

**Table 60** default snmp-server community command parameters and variables

Parameters and variables	Description
rolrw	Restores the read-only community to 'public', or the read-write community to 'private'.

## snmp-server contact command

The `snmp-server contact` command configures the SNMP `sysContact` value. The syntax for the `snmp-server contact` command is:

```
snmp-server contact <text>
```

The `snmp-server contact` command is in the config command mode.

[Table 61](#) describes the parameters and variables for the `snmp-server contact` command.

**Table 61** snmp-server contact command parameters and variables

Parameters and variables	Description
text	Specifies the SNMP <code>sysContact</code> value; enter an alphanumeric string.

## no snmp-server contact command

The `no snmp-server contact` command clears the `sysContact` value. The syntax for the `no snmp-server contact` command is:

```
no snmp-server contact
```

The `no snmp-server contact` command is in the config command mode.

There are no parameters or variables for the `no snmp-server contact` command.

## default snmp-server contact command

The `default snmp-server contact` command clears `sysContact`. The syntax for the `default snmp-server contact` command is:

```
default snmp-server contact
```



The default `snmp-server contact` command is in the `config` command mode.

There are no parameters or variables for the default `snmp-server contact` command.

## snmp-server command

The `snmp-server` command enables or disables the SNMP server. The syntax for the `snmp-server` command is:

```
snmp-server {enable|disable}
```

The `snmp-server` command is in the `config` command mode.

[Table 62](#) describes the parameters and variables for the `snmp-server` command.

**Table 62** snmp-server command parameters and variables

Parameters and variables	Description
enable/disable	Enables or disables the SNMP server.

## no snmp-server command

The `no snmp-server` command disables SNMP access. The syntax for the `no snmp-server` command is:

```
no snmp-server
```

The `no snmp-server` command is in the `config` command mode.

There are no parameters or variables for the `no snmp-server` command.



**Note:** If you disable SNMP access to the switch, you will not be able to use Device Manager for the switch.

---

## snmp-server host for old-style table command

The `snmp-server host for old-style table` command adds a trap receiver to the old-style trap-receiver table. The table has a maximum of four entries, and the entries can generate only SNMPv1 traps. This command controls the contents of the `s5AGTrpRcvrTable` which is the set of trap destinations controlled by the SNMP Configuration screen in the console interface.

The syntax for the `snmp-server host for old-style table` command is:

```
snmp-server host <host-ip> <community-string>
```

The `snmp-server host for old-style table` command is in the config command mode.

[Table 63](#) describes the parameters and variables for the `snmp-server host for old-style table` command.

**Table 63** snmp-server host for old-style table command parameters and variables

Parameters and variables	Description
<host-ip>	Enter a dotted-decimal IP address of a host that will be the trap destination.
<community-string>	Enter a community string that works as a password and permits access to the SNMP protocol.

## snmp-server host for new-style table command

The `snmp-server host` for new-style table command adds a trap receiver to the new-style configuration (that is, to the SNMPv3 tables) You can create several entries in this table, and each can generate v1, v2c, or v3 traps. Note that you must have previously configured the community string or user that is specified, with a `notify-view`. The syntax for the `snmp-server host` for new-style table command is:

```
snmp-server host <host-ip> {v1 <community-string>|v2c
<community-string>|v3 {auth|no-auth|auth-priv}<username>}
```

The `snmp-server host` for new-style table command is in the config command mode.

[Table 64](#) describes the parameters and variables for the `snmp-server host` for new-style table command.

**Table 64** snmp-server host for new-style table command parameters and variables

Parameters and variables	Description
<host-ip>	Enter a dotted-decimal IP address of a host that will be the trap destination.
v1 <community-string>	Using v1 creates trap receivers in the SNMPv3 MIBs. Multiple trap receivers with varying access levels may be created.
v2c <community-string>	Using v2c creates trap receivers in the SNMPv3 MIBs. Multiple trap receivers with varying access levels may be created.
v3 {auth no-auth auth-priv}	Using v3 creates trap receivers in the SNMPv3 MIBs. Multiple trap receivers with varying access levels may be created: Enter the following variables: <ul style="list-style-type: none"> <li>• <code>auth no-auth</code>—specifies whether SNMPv3 traps should be authenticated</li> <li>• <code>auth-priv</code>—this parameter is only available if the image has full SHA/DES support.</li> </ul>
<username>	Specifies the SNMPv3 username for trap destination; enter an alphanumeric string.

## no snmp-server host for old-style table command

The `no snmp-server host` for old-style table command deletes trap receivers from the old-style table. The syntax for the `no snmp-server host` for old-style table command is:

```
no snmp-server host <host-ip> <community-string>
```

The `no snmp-server host` for old-style table command is in the config command mode.

[Table 65](#) describes the parameters and variables for the `no snmp-server host` for old-style table command.

**Table 65** no snmp-server host for old-style table command parameters and variables

Parameters and variables	Description
<host-ip> <community-string>	Enter the following variables: <ul style="list-style-type: none"> <li>• <code>host-ip</code>—the IP address of a trap destination host.</li> <li>• <code>community-string</code>—the community string that works as a password and permits access to the SNMP protocol.</li> </ul>

## no snmp-server host for new-style table command

The `no snmp-server` for new-style table command deletes trap receivers from the new-style table (SNMPv3 MIB). Any trap receiver matching the IP address and SNMP version will be deleted. The syntax for the `no snmp-server host` for new-style table command is:

```
no snmp-server host <host-ip> {v1|v2c|v3}
```

The `no snmp-server host` for new-style table command is in the config command mode.

[Table 66](#) describes the parameters and variables for the `no snmp-server host` for new-style table command.

**Table 66** no snmp-server host for new-style command parameters and variables

Parameters and variables	Description
<host-ip>	Enter the IP address of a trap destination host.
v1lv2clv3	Specifies trap receivers in the SNMPv3 MIBs.

## default snmp-server host command

The default `snmp-server host` command restores the old-style table to defaults (that is, it clears the table). The syntax for the `default snmp-server host` is:

```
default snmp-server host
```

The `default snmp-server host` command is in the config command mode.

There are no parameters or variables for the `default snmp-server host` command.

## snmp-server location command

The `snmp-server location` command configures the SNMP `sysLocation` value. The syntax for the `snmp-server location` command is:

```
snmp-server location <text>
```

The `snmp-server location` command is in the config command mode.

[Table 67](#) describes the parameters and variables for the `snmp-server location` command.

**Table 67** snmp-server location command parameters and variables

Parameters and variables	Description
<text>	Specify the SNMP sysLocation value; enter an alphanumeric string of up to 255 characters.

## no snmp-server location command

The `no snmp-server location` command clears the SNMP sysLocation value. The syntax for the `no snmp-server location` command is:

```
no snmp-server location
```

The `no snmp-server location` command is in the config command mode.

There are no parameters or variables for the `no snmp-server location` command.

## default snmp-server location command

The `default snmp-server location` command restores sysLocation to the default value. The syntax for the `default snmp-server location` command is:

```
default snmp-server location
```

The `default snmp-server location` command is in the config command mode.

## snmp-server name command

The `snmp-server name` command configures the SNMP sysName value. The syntax for the `snmp-server name` command is:

```
snmp-server name <text>
```

The `snmp-server name` command is in the config command mode.

[Table 68](#) describes the parameters and variables for the `snmp-server name` command.

**Table 68** snmp-server name command parameters and variables

Parameters and variables	Description
<text>	Specify the SNMP sysName value; enter an alphanumeric string of up to 255 characters..

## no snmp-server name command

The `no snmp-server name` command clears the SNMP sysName value. The syntax for the `no snmp-server name` command is:

```
no snmp-server name
```

The `no snmp-server name` command is in the config command mode.

There are no parameters or variables for the `no snmp-server name` command.

## default snmp-server name command

The `default snmp-server name` command restores sysName to the default value. The syntax for the `default snmp-server name` command is:

```
default snmp-server name
```

The `default snmp-server name` command is in the config command mode.

## snmp-server user command

The `snmp-server user` command creates an SNMPv3 user. The syntax for the `snmp-server user` command is:

```
snmp-server user <username> [read-view view-name]
[write-view <view-name>] [notify-view <view-name>] [{md5|sha}
<password>] [read-view <view-name>] [write-view <view-name>]
[notify-view <view-name>] [des <password>] [read-view
<view-name>] [write-view <view-name>] [notify-view
<view-name>]]]
```

The `snmp-server user` command is in the config command mode.

The `sha` and `des` parameters are only available if the switch image has full SHA/DES support.

There are three sets of read/write/notify views shown in the command. The first set specifies unauthenticated access. The second set specifies authenticated access. The third set specifies authenticated and encrypted access.

You can only specify authenticated access if the `md5` or `sha` parameter is included. Likewise, and you can only specify authenticated and encrypted access if the `des` parameter is included.

If you omit the authenticated view parameters, authenticated access uses the views specified for unauthenticated access. If you omit all of the authenticated and encrypted view parameters, the authenticated and encrypted access uses the same views used for authenticated access. These will be the unauthenticated views if all the authenticated ones were also omitted.

[Table 69](#) describes the parameters and variables for the `snmp-server user` command.

**Table 69** snmp-server user command parameters and variables

Parameters and variables	Description
<username>	Specifies the user name; enter an alphanumeric string of up to 255 characters.
md5 <password>	Specifies the use of an md5 password. <password> specifies the new user md5 password; enter an alphanumeric string. If this parameter is omitted, the user will be created with only unauthenticated access rights.



**Table 69** snmp-server user command parameters and variables

Parameters and variables	Description
read-view <view-name>	Specifies the read view to which the new user has access: <ul style="list-style-type: none"> <li>view-name—specifies the viewname; enter an alphanumeric string of up to 255 characters.</li> </ul>
write-view <view-name>	Specifies the write view to which the new user has access: <ul style="list-style-type: none"> <li>view-name—specifies the viewname; enter an alphanumeric string of up to 255 characters.</li> </ul>
notify-view <view-name>	Specifies the notify view to which the new user has access: <ul style="list-style-type: none"> <li>view-name—specifies the viewname; enter an alphanumeric string of up to 255 characters.</li> </ul>
SHA	Specifies SHA authentication or DES privacy encryption..
DES	Specifies DES privacy encryption..

## no snmp-server user command

The `no snmp-server user` command deletes the specified user. The syntax for the `no snmp-server user` command is:

```
no snmp-server user <username>
```

The `no snmp-server user` command is in the config command mode.

[Table 70](#) describes the parameters and variables for the `no snmp-server user` command.

**Table 70** no snmp-server user command parameters and variables

Parameters and variables	Description
<username>	Specifies the user to be removed.

## snmp-server view command

The `snmp-server view` command creates an SNMPv3 view. The view is a set of MIB object instances which may be accessed. The syntax for the `snmp-server view` command is:

```
snmp-server view <view-name> <OID> [<OID> [<OID> [<OID>
<OID> [<OID> [<OID> [<OID> [<OID> [<OID>]]]]]]]]]]]
```

The `snmp-server view` command is in the config command mode.

[Table 71](#) describes the parameters and variables for the `snmp-server view` command.

**Table 71** snmp-server view command parameters and variables

Parameters and variables	Description
<viewname>	Specifies the name of the new view; enter an alphanumeric string.
<OID>	<p>Specifies Object identifier. OID may be entered as a MIB object English descriptor, a dotted form OID, or a mix of the two. Each OID should be preceded by a '+' or '-' sign (if this is omitted, a '+' sign is implied). For the dotted form, a sub-identifier can be a '*' indicating a wildcard. Here are some examples of valid OID parameters:</p> <ul style="list-style-type: none"><li>• sysName</li><li>• +sysName</li><li>• -sysName</li><li>• +sysName.0</li><li>• +ifIndex.1</li><li>• -ifEntry.*.1 (this matches all objects in the ifTable with an instance of 1, i.e., the entry for interface #1)</li><li>• 1.3.6.1.2.1.1.1.0 (the dotted form of sysDescr)</li></ul> <p>The '+' or '-' indicates whether the specified OID is included in or excluded from, respectively, the set of MIB objects that are accessible using this view. For example, if you create a view like this:</p> <ul style="list-style-type: none"><li>• snmp-server view myview +system -sysDescr</li></ul> <p>And you use that view for the read-view of a user, then the user can read only the system group except for sysDescr.</p>

## no snmp-server view command

The `no snmp-server view` command deletes the specified view. The syntax for the `no snmp-server view` is:

```
no snmp-server view <viewname>
```

The `no snmp-server view` is in the config command mode.

[Table 72](#) describes the parameters and variables for the `no snmp-server view` command.

**Table 72** no snmp-server view command parameters and variables

Parameters and variables	Description
<viewname>	Specifies the name of the view to be removed. If no view is specified, all views are removed.

## snmp trap link-status command

The `snmp trap link-status` command enables the linkUp/linkDown traps for the port. The syntax of the command is:

```
snmp trap link-status {enable|disable} [port <portlist>]
```

The `snmp trap link-status` command is in the config-if command mode.

[Table 73](#) describes the parameters and variables for the `snmp trap link-status` command.

**Table 73** snmp trap link-status command parameters and variables

Parameters and variables	Description
enable disable	Enables or disables SNMP link-status.
port <portlist>	Specifies the port numbers to enable the linkUp/linkDown traps on. Enter the port numbers or all.  <b>Note:</b> If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## no snmp trap link-status command

The `no snmp trap link-status` command disables the linkUp/linkDown traps for the port. The syntax of the command is:

```
no snmp trap link-status [port <portlist>]
```

The `no snmp trap link-status` command is in the config-if command mode.

[Table 74](#) describes the parameters and variables for the `no snmp trap link-status` command.

**Table 74** no snmp trap link-status command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to disable the linkUp/linkDown traps on. Enter the port numbers or all.  <b>Note:</b> If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## default snmp trap link-status command

The `default snmp trap link-status` command disables the linkUp/linkDown traps for the port. The syntax of the command is:

```
default snmp trap link-status [port <portlist>]
```

The `default snmp trap link-status` command is in the config-if command mode.

[Table 75](#) describes the parameters and variables for the `default snmp trap link-status` command.

**Table 75** default snmp trap link-status command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to disable the linkUp/linkDown traps on. Enter the port numbers or all.  <b>Note:</b> If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## snmp-server bootstrap command

The `snmp-server bootstrap` command allows you to specify how you wish to secure SNMP communications, as described in the SNMPv3 standards. It creates an initial set of configuration data for SNMPv3. This configuration data follows the conventions described in the SNMPv3 standard (in RFC 3414 and 3415). It consists of a set of initial users, groups, and views. This command deletes ALL existing SNMP configurations, so it should be used with care.

The syntax for the `snmp-server bootstrap` command is:

```
snmp-server bootstrap <minimum-secure> | <semi-secure>
|<very-secure>
```

The `snmp-server bootstrap` command is in the config command mode.

[Table 76](#) describes the parameters and variables for the `snmp-server bootstrap` command.

**Table 76** snmp-server bootstrap command parameters and variables

Parameters and variables	Description
<minimum-secure>	Specifies a minimum security configuration that allows read access to everything via noAuthNoPriv, and write access to everything via authNoPriv.
<semi-secure>	Specifies a partial security configuration that allows read access to a small subset of system information using noAuthNoPriv, and read and write access to everything using authNoPriv.
<very-secure>	Specifies a maximum security configuration that allows no access.

## show running-config

The `running-config` command displays the current running configuration for the switch. The syntax for the `show running-config` is:

```
show running-config
```

The `show running-config` command is in the `config` command mode.

There are no parameters or variables for the `show running-config` command.

## Setting Class of Service

The BayStack 380 may prioritize traffic based on the Class of Service/Diffserv Code Point (CoS/DSCP) of IP packets. It allows you to map all 64 possible DSCP values in the IPv4 frame to any of four (4) priority queues. The IPv4 frames will be forwarded according to the COS queue priorities.

This section covers:

- [“show cos-dscp,”](#) next
- [“cos-dscp”](#) on page 128
- [“no cos-dscp”](#) on page 129
- [“default cos-dscp”](#) on page 129

## show cos-dscp

The `show cos-dscp` command displays the current class of service mapping. The syntax for the `show cos-dscp` command is:

```
show cos-dscp config
```

The `show cos-dscp` command is in the config command mode.

[Table 77](#) describes the parameters and variables for the `show cos-dscp` command.

**Table 77** show cos-dscp command parameters and variables

Parameters and variables	Description
config	Displays the current cos-dscp settings.

[Figure 22](#) shows the output of the `show cos-dscp` command.

**Figure 22** show cos-dscp config command output

```

Select C:\WINNT\system32\telnet.exe
Enter configuration commands, one per line. End with CNTL/Z.
BS380-24T(config)#show cos-dscp config
DiffServ Mapping: Enabled

DiffServ Codepoint          Traffic Class
-----
0                            Low
1                            Low
2                            Low
3                            Low
4                            Low
5                            Low
6                            Low
7                            Low
8                            Low
9                            Low
10                           Low
11                           Low
12                           Low
13                           Low
14                           Low
15                           Low
16                           Low
17                           Low

---More (q=Quit, space/return=Continue)---

```

## cos-dscp

The `cos-dscp` command configures the system settings for the system event log. The syntax for the `cos-dscp` command is:

```
cos-dscp [enable|disable] [map-set]
```

The `cos-dscp` command is in the config command mode.

[Table 38](#) describes the parameters and variables for the `cos-dscp` command.

**Table 78** cos-dscp command parameters and values

Parameters and variables	Description
enable/disable	Enables or disables cos-dscp mapping.
map-set	Specifies the mapping values for cos-dscp



## **no cos-dscp**

The `no cos-dscp` command disables class of service mapping. The syntax for the `no cos-dscp` command is:

```
no cos-dscp
```

The `no cos-dscp` command is in the config command mode.

The `no cos-dscp` command has no parameters or values.

## **default cos-dscp**

The `default cos-dscp` command configures the system settings as the factory default settings for class of service. The syntax for the `default cos-dscp` command is:

```
default cos-dscp
```

The `default cos-dscp` command is in the config command mode.

The `default cos-dscp` command has no parameters or values.



---

## Chapter 3

# Security

---

This chapter describes the security commands available with the CLI.

Refer to *Using the BayStack 380 10/100/1000 Switch Software Version 3.0* for more information on the security features, as well as using the console interface (CI) menus. Refer to *Using Web-based Management for the BayStack 380 10/100/1000 Switch Software Version 3.0* for information on configuring these features using the Web-based management system, and refer to *Reference for the BayStack 380 10/100/1000 Switch Management Software Version 3.0* for information on configuring with the Device Manager.

## Using MAC address security

You configure the BaySecure\* application using MAC addresses with the following commands:

- [“show mac-security command,”](#) next
- [“mac-security command”](#) on page 133
- [“mac-security mac-address-table address command”](#) on page 134
- [“no mac-security command”](#) on page 134
- [“no mac-security mac-address-table command”](#) on page 135
- [“mac-security command for specific ports”](#) on page 136

## show mac-security command

The `show mac-security` command displays configuration information for the BaySecure application. The syntax for the `show mac-security` command is:

```
show mac-security {config|mac-address-table [address  
<macaddr>] |port}
```

The `show mac-security` command is in the `privExec` command mode.

[Table 79](#) describes the parameters and variables for the `show mac-security` command.

**Table 79** show mac-security command parameters and variables

Parameters and variables	Description
config	Displays general BaySecure configuration.
mac-address-table [address <macaddr>]	Displays contents of BaySecure table of allowed MAC addresses: <ul style="list-style-type: none"><li>• address—specifies a single MAC address to display; enter the MAC address</li></ul>
port	Displays the BaySecure status of all ports.

[Figure 23](#) displays sample output from the `show mac-security` command.

**Figure 23** show mac-security command output

```
BS380_24#show mac-security config
MAC Address Security: Disabled
MAC Address Security SNMP-Locked: Disabled
Current Learning Mode: Disabled
Learn by Ports:
```

## mac-security command

The `mac-security` command modifies the BaySecure configuration. The syntax for the `mac-security` command is:

```
mac-security [disable|enable] [learning-ports <portlist>]
[learning {enable|disable}] [snmp-lock {enable|disable}]
```

The `mac-security` command is in the `config` command mode.

[Table 80](#) describes the parameters and variables for the `mac-security` command.

**Table 80** mac-security command parameters and values

Parameters and variables	Description
disable enable	Disables or enables MAC address-based security.
learning-ports <portlist>	Specifies MAC address learning. Learned addresses are added to the table of allowed MAC addresses. Enter the ports you want to learn; it can be a single port, a range of ports, several ranges, all, or none.
learning {enable disable}	Specifies MAC address learning: <ul style="list-style-type: none"> <li>enable—enables learning by ports</li> <li>disable—disables learning by ports</li> </ul>
snmp-lock {enable disable}	Enables or disables a lock on SNMP write-access to the BaySecure MIBs.

## mac-security mac-address-table address command

The `mac-security mac-address-table address` command assigns either a specific port or a security list to the MAC address. This removes any previous assignment to the specified MAC address and creates an entry in the BaySecure table of allowed MAC addresses. The syntax for the `mac-security mac-address-table address` command is:

```
mac-security mac-address-table address <H.H.H.> {port
<portlist>}
```



**Note:** In this command, `portlist` must specify only a single port

The `mac-security mac-address-table address` command is in the `config` command mode.

[Table 81](#) describes the parameters and variables for the `mac-security mac-address-table address` command.

**Table 81** mac-security mac-address-table address command parameters and values

Parameters and variables	Description
<H.H.H>	Enter the MAC address in the form of H.H.H.
port <portlist> security-list <1-32>	Enter the port number or the security list number.

## no mac-security command

The `no mac-security` command disables MAC source address-based security. The syntax for the `no mac-security` command is:

```
no mac-security
```

The `no mac-security` command is in the `config` command mode.

The `no mac-security` command has no parameters or values.

## default mac-security command

The `default mac-security` command specifies the use of the default BaySecure configuration by a specific port or list of ports. The syntax for the `default mac-security` is:

```
default mac-security [port <portlist>]
```

The `default mac-security` command is in the secure interface configuration mode.

[Table 82](#) describes the parameters and variables for the `mac-security` command.

**Table 82** default mac-security

Parameters and variables	Description
port <portlist>	Specifies the port or the list of ports using the default BaySecure configuration.

## no mac-security mac-address-table command

The `no mac-security mac-address-table` command clears entries from the MAC address security table. The syntax for the `no mac-security mac-address-table` command is:

```
no mac-security mac-address-table {address <H.H.H.> |port <portlist>}
```

The `no mac-security mac-address-table` command is in the config command mode.

[Table 83](#) describes the parameters and variables for the `no mac-security mac-address-table` command.

**Table 83** no mac-security mac-address-table command parameters and values

Parameters and variables	Description
address <H.H.H>	Enter the MAC address in the form of H.H.H.
port <portlist>	Enter a list or range of port numbers.

## mac-security command for specific ports

The `mac-security` command for specific ports configures the BaySecure status of specific ports. The syntax for the `mac-security` command for specific ports is:

```
mac-security [port <portlist>] {disable|enable|learning}
```

The `mac-security` command for specific ports is in the config-if command mode

[Table 84](#) describes the parameters and variables for the `mac-security` command for specific ports.

**Table 84** mac-security command for a single port parameters and variables

Parameters and variables	Description
port <portlist>	Enter the port numbers.
disable enable learning	Directs the specific port: <ul style="list-style-type: none"><li>• <code>disable</code>—disables BaySecure on the specified port and removes the port from the list of ports for which MAC address learning is being performed</li><li>• <code>enable</code>—enables BaySecure on the specified port and removes the port from the list of ports for which MAC address learning is being performed</li><li>• <code>learning</code>—disables BaySecure on the specified port and adds these port to the list of ports for which MAC address learning is being performed</li></ul>



## Using RADIUS authentication

Using a the RADIUS protocol and a server, you can configure the BayStack 380 for authentication. With the CLI system, you use the following commands:

- “[show radius-server command](#),” next
- “[radius-server command](#)” on page 138
- “[no radius-server command](#)” on page 139

### show radius-server command

The `show radius-server` command displays the RADIUS server configuration. The syntax for the `show radius-server` command is:

```
show radius-server
```

The `show radius-server` command is in the `privExec` command mode.

The `show radius-server` command has no parameters or variables.

[Figure 24](#) displays sample output from the `show radius-server` command.

**Figure 24** show radius-server command output

```

BS380_24#show radius-server
host: 0.0.0.0
Secondary-host: 0.0.0.0
port: 1645
key:
BS380_24#

```

## radius-server command

The `radius-server` command changes the RADIUS server settings. The syntax for the `radius-server` command is:

```
radius-server host <address> [secondary-host <address>] port
<num> key <string>
```

The `radius-server` command is in the config command mode.

[Table 85](#) describes the parameters and variables for the `radius-server` command.

**Table 85** radius-server command parameters and variables

Parameters and variables	Description
host <address>	Specifies the primary RADIUS server. Enter the IP address of the RADIUS server.
secondary-host <address>	Specifies the secondary RADIUS server. Enter the IP address of the secondary RADIUS server.
port <num>	Enter the port number of the RADIUS server.
key <string>	Specifies a secret text string that is shared between the switch and the RADIUS server. Enter the secret string, which is an alphanumeric string up to 16 characters.

## no radius-server command

The `no radius-server` command clears the RADIUS server settings. The syntax for the `no radius-server` command is:

```
no radius-server
```

The `no radius-server` command is in the config command mode.

The `no radius-server` command has no parameters or values.

## default radius-server command

The `default radius-server` command specifies the use of the default RADIUS server setting. The syntax for the `default radius-server` is:

```
default radius-server
```

The `default radius-server` command is in the config command mode.

There are no parameters or variables for the `default radius-server` command.



---

## Chapter 4

# Spanning Tree, MLT, and Port-Mirroring

---

This chapter describes how to configure the Spanning Tree Protocol, spanning tree groups, Multi-Link Trunking (MLT), and port-mirroring. This chapter covers the following topics:

- [“Using spanning tree,”](#) next
- [“Using MLT”](#) on page 149
- [“Using port-mirroring”](#) on page 151

Refer to the *Using the BayStack 380 10/100/1000 Switch Software Version 3.0* for more information on a spanning tree, MLT, and port-mirroring, as well as configuration directions using the console interface (CI) menus. Refer to *Using Web-based Management for the BayStack 380 10/100/1000 Switch Software Version 3.0* for information on configuring these features using the Web-based management system, and refer to *Reference for the BayStack 380 10/100/1000 Switch Management Software Version 3.0* for configuration information for the Device Manager.

## Using spanning tree



**Note:** For detailed information on spanning tree parameters, spanning tree groups, and configuration guidelines, refer to *Using the BayStack 380 10/100/1000 Switch Software Version 3.0*.

---

With the BayStack 380 with software version 3.0, you can configure a spanning tree group (STG). The CLI allows you to configure a spanning tree group, to add or remove VLANs to the spanning tree group, and to configure the usual spanning tree parameters and FastLearn. This section covers the following topics:

- [“show spanning-tree command,” next](#)
- [“spanning-tree command” on page 144](#)
- [“default spanning-tree command” on page 145](#)
- [“spanning-tree command by port” on page 146](#)
- [“default spanning-tree command by port” on page 147](#)
- [“no spanning-tree command by port” on page 148](#)



**Note:** When you omit the spanning tree group parameter (stp <1-8>) in the any of the spanning tree commands, the commands operate on the default spanning tree group (spanning tree group 1).

---

## show spanning-tree command

The `show spanning-tree` command displays spanning tree configuration information that is specific to either the spanning tree group or to the port. The syntax for the `show spanning-tree` command is:

```
show spanning-tree {config|port}
```

The `show spanning-tree` command is in the `privExec` command mode,

[Table 86](#) describes the parameters and variables for the `show spanning-tree` command.

**Table 86** show spanning-tree command parameters and variables


Parameters and variables	Description
configport	Displays spanning tree configuration for: <ul style="list-style-type: none"> <li>• config—the specified (or default) spanning tree group</li> <li>• port—the ports within the spanning tree group</li> </ul>

[Figure 25](#) shows the spanning tree parameters by port. [Figure 26](#) displays sample output from the `show spanning-tree` command for the spanning tree group (STP1).

**Figure 25** show spanning-tree command output by port

```

Select C:\WINNT\system32\telnet.exe
BS380-24T>en
BS380-24T#show spanning-tree port
Port Trunk Participation Priority Path Cost State
-----
1 Normal Learning 128 1 Forwarding
2 Normal Learning 128 1 Forwarding
3 Normal Learning 128 1 Forwarding
4 Normal Learning 128 1 Forwarding
5 Normal Learning 128 1 Forwarding
6 Normal Learning 128 1 Forwarding
7 Normal Learning 128 1 Forwarding
8 Normal Learning 128 1 Forwarding
9 Normal Learning 128 1 Forwarding
10 Normal Learning 128 1 Forwarding
11 Normal Learning 128 1 Forwarding
12 Normal Learning 128 1 Forwarding
13 Normal Learning 128 1 Forwarding
14 Normal Learning 128 1 Forwarding
15 Normal Learning 128 1 Forwarding
16 Normal Learning 128 1 Forwarding
17 Normal Learning 128 1 Forwarding
18 Normal Learning 128 1 Forwarding
19 Normal Learning 128 1 Forwarding
20 Normal Learning 128 1 Forwarding
---More (q=Quit, space/return=Continue)---
  
```

**Figure 26** show spanning-tree command output for spanning tree configA screenshot of a telnet window titled "Select C:\WINNT\system32\telnet.exe". The window shows a command-line interface for a switch. The user enters "en" to enter enable mode, then "show spanning-tree config". The output displays various STP parameters: Bridge Priority (hex) is 8000, Designated Root is 7FFF00E07BCC7E81, Root Port is 3, Root Path Cost is 20, Hello Time is 2 seconds, Maximum Age Time is 20 seconds, Forward Delay is 15 seconds, Bridge Hello Time is 2 seconds, Bridge Maximum Age Time is 20 seconds, and Bridge Forward Delay is 15 seconds. The prompt returns to "BS380-24T#" after the command.

```
BS380-24T>en
BS380-24T#show spanning-tree config
Bridge Priority (hex):      8000
Designated Root:          7FFF00E07BCC7E81
Root Port:                 3
Root Path Cost:           20
Hello Time:                2 seconds
Maximum Age Time:         20 seconds
Forward Delay:            15 seconds
Bridge Hello Time:        2 seconds
Bridge Maximum Age Time:  20 seconds
Bridge Forward Delay:     15 seconds
BS380-24T#
BS380-24T#
BS380-24T#_
```

## spanning-tree command

The `spanning-tree` command sets STP values. The syntax for the `spanning-tree` command is:

```
spanning-tree [forward-time <4-30>] [hello-time <1-10>]
[max-age <6-40>] [priority <0-65535>] [
```

The `spanning-tree` command is in the config command mode.

[Table 87](#) describes the parameters and variables for the `spanning-tree` command.



**Table 87** spanning-tree command parameters and variables

Parameters and variables	Description
forward-time <4-30>	Enter the forward time of the STG in seconds; range is 4-30. Default value is 15.
hello-time <1-10>	Enter the hello time of the STG in seconds; range is 1-10. Default value is 2.
max-age <6-40>	Enter the max-age of the STG in seconds; range is 6-40. Default value is 20.
priority <0-65535>	Enter the priority of the STG in seconds; range is 0-65535. Default value is 0x8000.

## default spanning-tree command

The `default spanning-tree` command restores the default spanning tree values for the spanning tree group. The syntax for the `default spanning-tree` command is:

```
default spanning-tree [forward-time] [hello-time] [max-age]
[priority]
```

The `default spanning-tree` command is in the config command mode.

[Table 88](#) describes the parameters and variables for the `default spanning-tree` command.

**Table 88** default spanning-tree command parameters and variables

Parameters and variables	Description
forward-time	Sets the forward time to default value—15 seconds.
hello-time	Sets the hello time to default value—2 seconds.
max-age	Sets the maximum age time to default value—20 seconds.
priority	Sets the priority to default value—0x8000.

## spanning-tree command by port



**Note:** For guidelines for configuring STGs, VLANs, and MLTs, refer to Chapter 1 of the *Using the BayStack 380 10/100/1000 Switch, Software Version 3.0*.

The `spanning-tree` command by port sets Spanning Tree Protocol (STP) and multiple spanning tree group (STG) participation for the ports within the specified spanning tree group. The syntax for the `spanning-tree` command by port is:

```
spanning-tree [port <portlist>] [learning
{disable|normal|fast}] [cost <1-65535>] [priority
<00|10|20|...|F0>]
```

The `spanning-tree` command by port is in the `config-if` command mode.

[Table 89](#) describes the parameters and variables for the `spanning-tree` command by port.

**Table 89** spanning-tree command by port parameters and variables

Parameters and variables	Description
port <portlist>	Enables spanning tree for the specified port or ports; enter port or ports you want enabled for spanning tree.  Note: If you omit this parameter, the system uses the port number you specified when you issued the <code>interface</code> command.
learning {disable normal fast}	Specifies the STP learning mode: <ul style="list-style-type: none"> <li>• <code>disable</code>—disables FastLearn mode</li> <li>• <code>normal</code>—changes to normal learning mode</li> <li>• <code>fast</code>—enables FastLearn mode</li> </ul>

**Table 89** spanning-tree command by port parameters and variables

Parameters and variables	Description
cost <1-65535>	Enter the path cost of the spanning tree; range is 1-65535.
priority <00 10 20 ...  F0>	Enter the priority value of the port; range is 00 10 20 ... F0.

## default spanning-tree command by port

The `default spanning-tree` command by port sets the spanning tree values for the ports within the specified spanning tree group to the factory default settings. The syntax for the `default spanning-tree` command by port is:

```
default spanning-tree [port <portlist>] [learning] [cost]
[priority]
```

The `default spanning-tree` command by port is in the config-if command mode.

[Table 90](#) describes the parameters and variables for the `default spanning-tree` command by port.

**Table 90** default spanning-tree command by port parameters and variables

Parameters and variables	Description
port <portlist>	Enables spanning tree for the specified port or ports; enter port or ports you want set to factory spanning tree default values.  Note: If you omit this parameter, the system uses the port number you specified when you issued the <code>interface</code> command.
learning	Sets the spanning tree learning mode to factory default value. Default value for learning is normal mode.

**Table 90** default spanning-tree command by port parameters and variables

Parameters and variables	Description
cost	Sets the path cost to factory default value. Default value for path cost depends on the type of port.
priority	Sets the priority to factory default value. Default value for the priority is 0x80.

## no spanning-tree command by port

The `no spanning-tree` command by port disables spanning tree for a port in a specific spanning tree group. The syntax for the `no spanning-tree` command by port is:

```
no spanning-tree [port <portlist>]
```

The `no spanning-tree` command by port is in the config-if command mode.

[Table 91](#) describes the parameters and variables for the `no spanning-tree` command by port.

**Table 91** no spanning-tree command by port parameters and variables

Parameters and variables	Description
port <portlist>	Disables spanning tree for the specified port or ports; enter port or ports you want enabled for STP.  Note: If you omit this parameter, the system uses the port number you specified when you issued the <code>interface</code> command.

## Using MLT



**Note:** For guidelines for configuring STGs, VLANs, and MLTs, refer to Chapter 1 of the *Using the BayStack 380 10/100/1000 Switch Software Version 3.0*.

You configure Multi-Link Trunking (MLT) using the following commands:

- “[show mlt command](#),” next
- “[mlt command](#)” on page 150
- “[no mlt command](#)” on page 151

### show mlt command

The `show mlt` command displays the Multi-Link Trunking (MLT) configuration and utilization. The syntax for the `show mlt` command is:

```
show mlt [utilization <1-6>]
```

The `show mlt` command is in the `privExec` command mode.

[Table 92](#) describes the parameters and variables for the `show mlt` command.

**Table 92** show mlt command parameters and variables

Parameters and variables	Description
utilization <1-6>	Displays the utilization of the specified enabled MLT(s) in percentages.

[Figure 27](#) displays sample output from the `show mlt` command.

**Figure 27** show mlt command output

```

BS380_24#show mlt
Trunk Name          Members          STP Learning      Mode  Status
-----
1      Trunk #1              Normal            Basic  Disabled
2      Trunk #2              Normal            Basic  Disabled
3      Trunk #3              Normal            Basic  Disabled
4      Trunk #4              Normal            Basic  Disabled
5      Trunk #5              Normal            Basic  Disabled
6      Trunk #6              Normal            Basic  Disabled
BS380_24#

```

## mlt command

The `mlt` command configures a Multi-Link Trunk (MLT). The syntax for the `mlt` command is:

```
mlt <id> [name <trunkname>] [enable|disable] [member
<portlist>]
```

The `mlt` command is in the config command mode.

[Table 93](#) describes the parameters and variables for the `mlt` command.

**Table 93** mlt command parameters and variables

Parameters and variables	Description
<id>	Enter the trunk ID; range is 1 to 6.
name <trunkname>	Specifies a text name for the trunk; enter up to 16 alphanumeric characters.
enable disable	Enables or disables the trunk.
member <portlist>	Enter the ports that you want as members of the trunk.



**Note:** You can modify an MLT when it is enabled or disabled.

## no mlt command

The `no mlt` command disables a Multi-Link Trunk (MLT), clearing all the port members. The syntax for the `no mlt` command is:

```
no mlt [<id>]
```

The `no mlt` command is in the config command mode.

[Table 94](#) describes the parameters and variables for the `no mlt` command.

**Table 94** no mlt command parameters and variables

Parameters and variables	Description
<id>	Enter the trunk ID to disable the trunk and to clear the port members of the specified trunk.

## Using port-mirroring

You use port-mirroring to monitor traffic. Refer to *Using the BayStack 380 10/100/1000 Switch Software Version 3.0* for configuration guidelines for port-mirroring. This section covers the following commands:

- [“show port-mirroring command,”](#) next
- [“port-mirroring command”](#) on page 152
- [“no port-mirroring command”](#) on page 153

## show port-mirroring command

The `show port-mirroring` command displays the port-mirroring configuration. The syntax for the `show port-mirroring` command is:

```
show port-mirroring
```

The `show port-mirroring` command is in the `privExec` command mode.

The `show port-mirroring` command has no parameters or variables.

[Figure 28](#) displays sample output from the `show port-mirroring` command.

**Figure 28** show port-mirroring command output

```
BayStack 380 (config)#show port-mirroring
Monitoring Mode: Xrx ( -> Port X )
Monitor Port:    1/3
Port X:          1/1
```

## port-mirroring command

The `port-mirroring` command sets the port-mirroring configuration. The syntax of the `port-mirroring` command is:

```
port-mirroring mode
{disable |
Xrx monitor-port <port#> mirror-port-X <port#> |
Xtx monitor-port <port#> mirror-port-X <port#>}
```



**Note:** In this command, `portlist` must specify only a single port

---

The `port-mirroring` command is in the `config` command mode.



Table 95 describes the parameters and variables for the `port-mirroring` command.

**Table 95** port-mirroring command parameters and variables

Parameters and variables	Description
<code>disable</code>	Disables port-mirroring.
<code>monitor-port</code>	Specifies the monitor port.
<code>mirror-port-X</code>	Specifies the mirroring port X.
<code>portlist</code>	Enter the port numbers.
<code>Xrx</code>	Mirror packets received on port X.
<code>Xtx</code>	Mirror packets transmitted on port X.
<code>XrxOrXtx</code>	Mirror packets received or transmitted on port X.

## no port-mirroring command

The `no port-mirroring` command disables port-mirroring. The syntax of the `no port-mirroring` command is:

```
no port-mirroring
```

The `no port-mirroring` command is in the config command mode.

The `no port-mirroring` command has no parameters or variables.



---

## Chapter 5

# VLANs and IGMP

---

This chapter describes how to configure virtual LANs and IGMP snooping parameters. This chapter covers the following topics:

- [“Configuring and displaying VLANs” on page 155](#)
- [“Displaying multicast membership” on page 165](#)
- [“Using IGMP snooping” on page 166](#)

Refer to the *Using the BayStack 380 10/100/1000 Switch Software Version 3.0* for more information on VLANs, IGMP snooping, and multicast groups, as well as configuration directions using the console interface (CI) menus. Refer to *Using Web-based Management for the BayStack 380 10/100/1000 Switch Software Version 3.0* for information on configuring these features using the Web-based management system, and refer to *Reference for the BayStack 380 10/100/1000 Switch Management Software Version 3.0* for configuration information for the DM.

## Configuring and displaying VLANs

You configure and display VLANs using a variety of command modes, depending on whether you are working with ports, protocol-based VLANs, or MAC source address-based VLANs. You can also enable or disable the automatic PVID feature. This section covers the following topics:

- [“show vlan interface info command,” next](#)
- [“show vlan interface vids command” on page 157](#)
- [“vlan mgmt command” on page 158](#)
- [“default vlan mgmt command” on page 159](#)
- [“vlan create command” on page 159](#)

- “vlan delete command” on page 160
- “no vlan command” on page 161v
- “vlan name command” on page 161
- “auto-pvid command” on page 162
- “no auto-pvid command” on page 162
- “vlan ports command” on page 162
- “vlan members command” on page 163
- “show vlan command” on page 164

Refer to Appendix A for an alphabetical list of the VLAN commands.



**Note:** For guidelines for configuring VLANs, spanning tree, and MLTs, refer to Chapter 1 of the *Using the BayStack 380 10/100/1000 Switch Software Version 3.0*.

---

## show vlan interface info command

The `show vlan interface info` command displays VLAN settings associated with a port, including tagging information, PVID number, priority, and filtering information for tagged, untagged, and unregistered frames. The syntax for the `show vlan interface info` command is:

```
show vlan interface info [<portlist>]
```

The `show vlan interface info` command is in the `privExec` command mode.

[Table 96](#) describes the parameters and variables for the `show vlan interface info` command.

**Table 96** show vlan command interface info parameters and variables

Parameters and variables	Description
<portlist>	Enter the list of ports you want the VLAN information for, or enter all to display all ports.

**Figure 29** displays sample output from the `show vlan interface info` command.

**Figure 29** show vlan interface info output

```

Select C:\WINNT\system32\telnet.exe
BS380-24T#
BS380-24T#
BS380-24T#
BS380-24T#show vlan interface info 1-14
Filter
  Untagged
Port  Frames  PUID  Priority  Tagging  Name
-----
1     No       1     0         Disabled Port 1
2     No       1     0         Disabled Port 2
3     No       1     0         Disabled Port 3
4     No       1     0         Disabled Port 4
5     No       1     0         Disabled Port 5
6     No       1     0         Disabled Port 6
7     No       1     0         Disabled Port 7
8     No       1     0         Disabled Port 8
9     No       1     0         Disabled Port 9
10    No       1     0         Disabled Port 10
11    No       1     0         Disabled Port 11
12    No       1     0         Disabled Port 12
13    No       1     0         Disabled Port 13
14    No       1     0         Disabled Port 14
BS380-24T#
BS380-24T#
BS380-24T#

```

## show vlan interface vids command

The `show vlan interface vids` command displays the VLANs assigned to ports. The syntax for the `show vlan interface vids` command is:

```
show vlan interface vids [<portlist>]
```

The `show vlan interface vids` command is in the `privExec` command mode.

Table 96 describes the parameters and variables for the `show vlan interface vids` command.

**Table 97** show vlan command interface vids parameters and variables

Parameters and variables	Description
<portlist>	Enter the list of ports you want the VLAN information for, or enter all to display all ports.

Figure 30 displays sample output from the `show vlan interface vids` command.

**Figure 30** show vlan interface vids output

```

Select C:\WINNT\system32\telnet.exe
BS380-24T>en
BS380-24T#show vlan interface vids 1-10
Port  VLAN  VLAN Name          VLAN  VLAN Name          VLAN  VLAN Name
-----
1      1      the main vlan      -----
2      1      the main vlan      -----
3      1      the main vlan      -----
4      1      the main vlan      -----
5      1      the main vlan      -----
6      1      the main vlan      -----
7      1      the main vlan      -----
8      1      the main vlan      -----
9      1      the main vlan      -----
10     1      the main vlan      -----
BS380-24T#_

```

## vlan mgmt command

The `vlan mgmt` command allows you to set a VLAN as the management VLAN. The syntax for the `vlan mgmt` command is:

```
vlan mgmt <1-4094>
```

The `vlan mgmt` command is in the config command mode.

[Table 99](#) describes the parameters and variables for the `vlan mgmt` command.

**Table 98** `vlan mgmt` command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the number of the VLAN you want to serve as the management VLAN.

## default vlan mgmt command

The `default vlan mgmt` command resets the management VLAN to VLAN1. The syntax for the `default vlan mgmt` command is:

```
default vlan mgmt
```

The `default vlan mgmt` command is in the config command mode.

The `default vlan mgmt` command has no variables or parameters.

## vlan create command



**Note:** For guidelines for configuring VLANs and MLTs, refer to Chapter 1 of the *Using the BayStack 380 10/100/1000 Switch Software Version 3.0*.

The `vlan create` command allows you to create a VLAN. You create a VLAN by setting the state of a previously non-existent VLAN.

The syntax for the `vlan create` command is:

```
vlan create <2-4094>] [name <line>] type {port}
```

The `vlan create` command is in the config command mode.

[Table 99](#) describes the parameters and variables for the `vlan create` command.

**Table 99** `vlan create` command parameters and variables

Parameters and variables	Description
<2-4094>	Enter the number of the VLAN to create.
name <line>	Enter the name of the VLAN to create.
type	Enter the type of VLAN to create: <ul style="list-style-type: none"><li>• port—port-based</li></ul>



**Note:** This command fails if the VLAN already exists.

---

## vlan delete command

The `vlan delete` command allows you to delete a VLAN. The syntax for the `vlan delete` command is:

```
vlan delete <2-4094>
```

The `vlan delete` command is in the config command mode.

[Table 99](#) describes the parameters and variables for the `vlan delete` command.

**Table 100** `vlan delete` command parameters and variables

Parameters and variables	Description
<2-4094>	Enter the number of the VLAN to delete.



## no vlan command

The `no vlan` command allows you to delete a VLAN. The syntax for the `no vlan` command is:

```
no vlan <2-4094>
```

The `no vlan` command is in the config command mode.

[Table 99](#) describes the parameters and variables for the `no vlan` command.

**Table 101** no vlan command parameters and variables

Parameters and variables	Description
<1-4094>2	Enter the number of the VLAN to delete.

## vlan name command

The `vlan name` command allows you to change the name of an existing VLAN. The syntax for the `vlan name` command is:

```
vlan name <1-4094> <line>
```

The `vlan name` command is in the config command mode.

[Table 99](#) describes the parameters and variables for the `vlan name` command.

**Table 102** vlan name command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the number of the VLAN you want to change the name of.
<line>	Enter the new name you want for the VLAN.

## auto-pvid command

The `auto-pvid` command allows you to enable the automatic PVID feature. The syntax for the `auto-pvid` command is:

```
auto-pvid
```

The `auto-pvid` command is in the config command mode.

The `auto-pvid` command has no parameters or variables.

For more information on the automatic PVID feature, refer to *Using the BayStack 380 10/100/1000 Switch*.

## no auto-pvid command

The `no auto-pvid` command allows you to disable the automatic PVID feature. The syntax for the `no auto-pvid` command is:

```
no auto-pvid
```

The `no auto-pvid` command is in the config command mode.

The `no auto-pvid` command has no parameters or variables.

For more information on the automatic PVID feature, refer to *Using the BayStack 380 10/100/1000 Switch*.

## vlan ports command

The `vlan ports` command configures the VLAN-related settings for a port. The syntax for the `vlan ports` command is:

```
vlan ports <portlist> [tagging {enable|disable}]  
[pvid <1-4094>] [filter-untagged-frame {enable|disable}]  
[priority <0-7>] [name <line>]
```

The `vlan ports` command is in the config command mode.

[Table 103](#) describes the parameters and variables for the `vlan ports` command.

**Table 103** `vlan ports` command parameters and variables

Parameters and variables	Description
<portlist>	Enter the port number(s) you want to configure for a VLAN.
tagging {enable disable}	Enables or disables the port as a tagged VLAN member for egressing packet.
pvid <1-4094>	Sets the PVID for the port list.
filter-untagged-frame {enable disable}	Enables or disables the port to filter received untagged packets.
priority <0-7>	Sets the priority for the switch to use when it forwards packets received on the ports in <portlist>.
name <line>	Enter the name you want for this port.  Note: This option can only be used if a single port is specified in the <portlist>.

## vlan members command

The `vlan members` command adds a port to or deletes a port from a VLAN. The syntax for the `vlan members` command is:

```
vlan members [add|remove] <2-4094> <portlist>
```

The `vlan members` command is in the config mode.

[Table 104](#) describes the parameters and variables for the `vlan members` command.

**Table 104** vlan members command parameters and variables

Parameters and variables	Description
addremove	Adds a port to or removes a port from a VLAN.  Note: If you omit this parameter, you are setting the exact port membership for the VLAN; the prior port membership of the VLAN is discarded and replaced by the new list of ports.
<2-4094>	Specifies the target VLAN.
portlist	Enter the list of port(s) you are adding, removing, or assigning to the VLAN.

## show vlan command

The `show vlan` command displays the configured VLANs. The syntax for the `show vlan` command is:

```
show vlan
```


The `show vlan` command is in the `privExec` mode.

[Table 105](#) describes the parameters and variables for the `show vlan` command.

**Table 105** show vlan command parameters and variables

Parameters and variables	Description
<2-4094>	Enter the number of the VLAN you want to display MAC source addresses for.

[Figure 31](#) displays sample output from the `show vlan` command.

**Figure 31** show vlan command output


```

Select C:\WINNT\system32\telnet.exe
BS380-24T>en
BS380-24T#show vlan
Id  Name                Type      Protocol  User PID Active Mgmt
-----
1   the main vlan       Port      None      0x0000   Yes   Yes
    Port Members: ALL
2   VLAN #2             Port      None      0x0000   No    No
    Port Members: NONE
BS380-24T#
BS380-24T#
BS380-24T#
BS380-24T#

```

## Displaying multicast membership

You can display the membership of multicast groups using the CLI.

### show vlan multicast membership command

The `show vlan multicast membership` command displays the IP multicast sessions in the network. The syntax for the `show vlan multicast membership` command is:

```
show vlan multicast membership <1-4094>
```

The `show vlan multicast membership` command is in the `privExec` mode.

[Table 106](#) describes the parameters and variables for the `show vlan multicast membership` command.

**Table 106** show vlan multicast membership command parameters and variables

Parameters and variables	Description
<1-4094>	Specifies a VLAN to display its IP multicast sessions.

Figure 32 displays sample output from the `show vlan multicast membership` command.

**Figure 32** show vlan multicast membership command output

```
BS380(config)#sh vlan multicast membership 1
Multicast Group Address Port
-----
225.0.0.192          23
225.0.0.183          22
225.0.0.174          21
225.0.0.93           12
225.0.0.84           11
225.0.0.75           10
225.0.0.165          20
225.0.0.156          19
225.0.0.66           9
225.0.0.57           8
225.0.0.147          18
225.0.0.138          17
225.0.0.48           7
225.0.0.94           12
```

## Using IGMP snooping

You can configure and display IGMP snooping parameters using the CLI. This section covers:

- “[show vlan igmp command](#),” next
- “[vlan igmp command](#)” on page 168
- “[default vlan igmp command](#)” on page 169

---

## show vlan igmp command

The `show vlan igmp` command displays the IGMP snooping configuration. The syntax for the `show vlan igmp` command is:

```
show vlan igmp <1-4094>
```

The `show vlan igmp` command is in the `privExec` mode.

[Table 107](#) describes the parameters and variables for the `show vlan igmp` command.

**Table 107** show vlan igmp command parameters and variables

Parameters and variables	Description
<1-4094>	Specifies the VLAN to display IGMP snooping configuration.

[Figure 33](#) displays sample output from the `show vlan igmp` command.

**Figure 33** show vlan igmp command output

```

BS380_24#show vlan igmp 1
Snooping: Enabled
Proxy: Enabled
Robust Value: 2
Query Time: 125 seconds
IGMPv1 Static Router Ports:
IGMPv2 Static Router Ports:

```

## vlan igmp command

The `vlan igmp` command configures IGMP snooping parameters. The syntax for the `vlan igmp` command is:

```

vlan igmp {<1-4094> [snooping {enable|disable}]
[proxy {enable|disable}] [query-interval <time>] }

```

The `vlan igmp` command is in the config mode.

[Table 108](#) describes the parameters and variables for the `vlan igmp` command.

**Table 108** vlan igmp command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the VLAN to configure for IGMP.
snooping {enable disable}	Enables or disables the VLAN for IGMP snooping.
proxy {enable disable}	Enables or disables the VLAN for IGMP proxy.
query-interval <time>	Enter the number of seconds you want for the query interval of IGMP.



**Table 108** vlan igmp command parameters and variables

Parameters and variables	Description
v2-members <portlist>	Enter the list of ports for port membership for IGMP v2.
unknown-mcast-no-flood	Enables or disables the flooding of packets with unknown multicast addresses.

## default vlan igmp command

The `default vlan igmp` command sets all IGMP snooping parameters to the factory default settings. The syntax for the `default vlan igmp` command is:

```
default vlan igmp <1-4094>
```

The `default vlan igmp` command is in the config mode.

[Table 108](#) describes the parameters and variables for the `default vlan igmp` command.

**Table 109** default vlan igmp command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the VLAN to configure for IGMP.



## Appendix A

# Command List

This appendix provides the complete CLI command list in alphabetical order, with approximate page references for the beginning pages of further explanations.



**Note:** This information is presented for reference only and should not be considered to be an exact representation.

**Table 110** CLI command list

Command	Page No.
auto-pvid	<a href="#">page 162</a>
autotopology	<a href="#">page 98</a>
boot [default]	<a href="#">page 61</a>
clear logging [nv]	<a href="#">page 86</a>
clear-stats [port<portlist>]	<a href="#">page 90</a>
cli-password {rolrw} <WORD> <WORD> cli-password {serialltelnet} {nonellocalradius}	<a href="#">page 32</a>
configure {terminallnetworklmemory}	<a href="#">page 38</a>
configure network [load-on-boot {disableluse-bootpluse-config}] configure network [filename <WORD>] configure network [address <XXX.XXX.XXX.XXX>]	<a href="#">page 50</a>
copy config tftp [address <XXX.XXX.XXX.XXX>] filename <WORD>	<a href="#">page 65</a>
copy tftp config [address <XXX.XXX.XXX.XXX>] filename <WORD>	<a href="#">page 65</a>
default autotopology	<a href="#">page 99</a>
default duplex [port <portlist>]	<a href="#">page 97</a>
default flowcontrol [port <portlist>]	<a href="#">page 102</a>
default ip address	<a href="#">page 57</a>
default ip bootp server	<a href="#">page 62</a>

**Table 110** CLI command list (continued)

<b>Command</b>	<b>Page No.</b>
default mac-address-table aging-time	<a href="#">page 44</a>
default name [port <port.ist>]	<a href="#">page 94</a>
default logging	<a href="#">page 86</a>
default snmp trap link-status [port <portlist>]	<a href="#">page 76</a>
default spanning-tree [forward-time] [hello-time] [max-age] [priority] [tagged-bpdu]	<a href="#">page 145</a>
default spanning-tree [port <portlist>] [stp <1-8>] [learning] [cost] [priority]	<a href="#">page 147</a>
default speed [port <portlist>]	<a href="#">page 95</a>
default telnet-access	<a href="#">page 60</a>
default vlan igmp {<1-4094>}	<a href="#">page 169</a>
default vlan mgmt <1-4094>	<a href="#">page 159</a>
disable	<a href="#">page 39</a>
download [address <ip>] {image <image-name>   image-if-newer <image name>   diag <filename>}	<a href="#">page 66</a>
duplex [port <portlist>] {full half auto}	<a href="#">page 96</a>
enable	<a href="#">page 37</a>
end	<a href="#">page 39</a>
exit	<a href="#">page 39</a>
flowcontrol [port <portlist>] {asymmetric symmetric disable}	<a href="#">page 100</a>
help	<a href="#">page 35</a>
interface FastEthernet {<portlist>}	<a href="#">page 38</a>
ip address[switch] <XXX.XXX.XXX.XXX> [netmask <XXX.XXX.XXX.XXX>]	<a href="#">page 53</a>
ip bootp server {last needed disable always}	<a href="#">page 61</a>
ip default-gateway <XXX.XXX.XXX.XXX>	<a href="#">page 54</a>
logout	<a href="#">page 37</a>
mac-address-table aging-time <time>	<a href="#">page 43</a>
mac-security [disable enable] [learning-ports <portlist>] [learning {enable disable}] [snmp-lock {enable disable}]	<a href="#">page 133</a>
mac-security [port <portlist>] {disable enable learning}	<a href="#">page 136</a>
mac-security mac-address-table address <H.H.H.> {port <portlist>}	<a href="#">page 134</a>
mlt <id> [name <trunkname>] [enable disable] [member <portlist>] [learning {disable   fast   normal} ]	<a href="#">page 150</a>

**Table 110** CLI command list (continued)

<b>Command</b>	<b>Page No.</b>
name [port <portlist>] <LINE>	<a href="#">page 92</a>
no auto-pvid	<a href="#">page 162</a>
no autotopology	<a href="#">page 99</a>
no flowcontrol [port <portlist>]	<a href="#">page 101</a>
no ip address {switch}	<a href="#">page 53</a>
no ip address unit <1-8>	<a href="#">page 57</a>
no ip bootp server	<a href="#">page 62</a>
no ip default-gateway	<a href="#">page 55</a>
no mac-security	<a href="#">page 134</a>
no mac-security mac-address-table {address <H.H.H> port <portlist> security-list <1-32>}	<a href="#">page 135</a>
no mlt [<id>]	<a href="#">page 151</a>
no name [port <portlist>]	<a href="#">page 93</a>
no port-mirroring	<a href="#">page 153</a>
no radius-server	<a href="#">page 139</a>
no set logging	<a href="#">page 86</a>
no shutdown [port <portlist>]	<a href="#">page 91</a>
no snmp server [authentication-trap community [rolrw] contact host [<host-ip> <community-string>] [location name]	<a href="#">page 73</a>
no snmp trap link-status [port <portlist>]	<a href="#">page 76</a>
no telnet-access [source-ip [<1-10>]]	<a href="#">page 59</a>
no tftp-server	<a href="#">page 64</a>
ping <XXX.XXX.XXX.XXX>	<a href="#">page 48</a>
port-mirroring mode disable	<a href="#">page 152</a>
port-mirroring mode Xrx monitor-port <portlist> mirror-port X <portlist>	
radius-server host <address> [secondary-host <address>] port <num> key <string>	<a href="#">page 138</a>
set logging [enable disable] [level critical serious informational] [nv-level critical serious informational none]	<a href="#">page 85</a>
show config-network	<a href="#">page 51</a>
show interfaces [names] [<portlist>]	<a href="#">page 69</a>
show ip [bootp] [default-gateway] [address [switch]]	<a href="#">page 55</a>

**Table 110** CLI command list (continued)

<b>Command</b>	<b>Page No.</b>
show logging [critical] show logging [serious] show logging [informational]	<a href="#">page 83</a>
show mac-address-table [aging-time] show mac-address-table [vid <1-4094>] [address <H.H.H.>]	<a href="#">page 42</a>
show mac-security {config mac-address-table [addr <macaddr>] port security-lists}	<a href="#">page 132</a>
show mlt [utilization <1-6>]	<a href="#">page 149</a>
show port-mirroring	<a href="#">page 152</a>
show port-statistics [port <portlist>]	<a href="#">page 87</a>
show radius-server	<a href="#">page 137</a>
show rmon alarm	<a href="#">page 77</a>
show rmon event	<a href="#">page 78</a>
show rmon history	<a href="#">page 78</a>
show rmon stats	<a href="#">page 79</a>
show spanning-tree {config port}	<a href="#">page 142</a>
show sys-info	<a href="#">page 40</a>
show telnet-access	<a href="#">page 58</a>
show terminal	<a href="#">page 46</a>
show tftp-server	<a href="#">page 63</a>
show vlan igmp <1-4094>   unknown-mcast-no-flood	<a href="#">page 167</a>
show vlan interface info [<portlist>]	<a href="#">page 156</a>
show vlan interface vids [<portlist>]	<a href="#">page 157</a>
show vlan mac-address <1-4094> [<H.H.H.>]	<a href="#">page 164</a>
show vlan multicast membership <1-4094>	<a href="#">page 164</a>
shutdown [port <portlist>]	<a href="#">page 90</a>
snmp trap link-status [port <portlist>]	<a href="#">page 75</a>
snmp-server {{enable disable} authentication-trap community <community-string> [rolrw] contact <text> host <host-ip> <community-string> location >text> name <text>}	<a href="#">page 72</a>
spanning-tree [forward-time <4-30>] [hello-time <1-10>] [max-age <6-40>] [tagged-bpdu {enable disable}] [tagged-bpdu-vid <1-4094>] [multicast-address<H.H.H.>]	<a href="#">page 144</a>
spanning-tree [port <portlist>] [learning {disable normal fast}] [cost <1-65535>]	<a href="#">page 146</a>

**Table 110** CLI command list (continued)

Command	Page No.
spanning-tree [forward-time <4-30>] [hello-time <1-10>] [max-age <6-40>] [priority <0-65535>] [tagged-bpdu {enable disable}] [tagged-bpdu-vid <1-4094>]	<a href="#">page 144</a>
spanning-tree [port <portlist>] [learning {disable normal fast}] [cost <1-65535>] [priority <0-255>]	<a href="#">page 147</a>
speed [port <portlist>] {10 100 1000 auto}	<a href="#">page 94</a>
telnet-access [enable disable] [login-timeout <1-10>] [retry <1-100>] [inactive-timeout <0-60>] [logging {none access failures all}] [source-ip <1-10> <XXX.XXX.XXX.XXX> [mask <XXX.XXX.XXX.XXX>]]	<a href="#">page 58</a>
terminal {2400 4800 9600 19200 38400} length <1-132> width <1-132>	<a href="#">page 47</a>
tftp-server <XXX.XXX.XXX.XXX>	<a href="#">page 64</a>
vlan create <1-4094> type port	<a href="#">page 159</a>
vlan create <1-4094> type port learning	<a href="#">page 159</a>
vlan delete <1-4094>	<a href="#">page 160</a>
vlan igmp <1-4094> [snooping {enable disable}] [proxy {enable disable}] [robust-value <value>] [query-interval <time>] [v1-members <portlist>] [v2-members <portlist>]	<a href="#">page 168</a>
vlan members <1-4094> <portlist> vlan members add <1-4094> <portlist> vlan members remove <1-4094> <portlist>	<a href="#">page 163</a>
vlan mgmt <1-4094>	<a href="#">page 158</a>
vlan name <1-4094> <line>	<a href="#">page 161</a>
vlan ports [<portlist>] [tagging {enable disable}] [pvid <1-4094>] [filter-untagged-frame {enable disable}] [priority <0-7>] [name <line>]	<a href="#">page 162</a>





---

# Index

---

## A

access 30, 58, 131, 137  
accessing the CLI 30  
age-out time 41  
alphabetical list of commands 171  
ASCII config file 50  
authentication 137  
automatic configuration 50  
automatic PVID feature 155  
autonegotiation 69, 94  
auto-pvid command 162  
autotopology command 98

## B

BaySecure 131  
boot command 61  
booting the switch 60  
BootP 55, 60  
    modes 61

## C

CI Main Menu 31  
CI menus 21  
clear logging command 86  
clear-stats command 90  
CLI 30  
CLI command list, alphabetical 171  
cli password command 32  
command modes 26, 38

community string 71  
configuration 21, 45  
configure command 38  
configure network command 50  
connectivity 48  
console port 30  
conversation steering 151  
copy config tftp command 65  
copy configuration file 63  
copy tftp config command 65  
customer support 23

## D

DA filtering 131  
default autotopology command 99  
default command 34, 36  
default duplex command 97  
default flowcontrol command 102  
default ip address unit command 57  
default ipbootp server command 62  
default mac-address-table aging-time  
    command 44  
default name command 94  
default set logging command 86, 129  
default snmp trap link-status command 76, 124  
default snmp-server authentication-trap  
    command 107  
default snmp-server community command 111  
default snmp-server contact command 112

default snmp-server host command 49, 64, 73, 74, 92, 99, 117, 126, 135, 139  
default snmp-server name command 119  
default spanning-tree command 145, 147  
default speed command 95  
default telnet-access command 60  
default vlan igmp command 169  
default vlan mgmt command 159  
Device Manager 21  
diagnostics 66  
disable command 39  
displaying logs 83, 126  
download command 66  
downloaded configuration file 50  
duplex command 96  
duplex mode 69, 94

## E

enable command 37  
end command 39  
Ethernet statistics 87  
event logs 83, 126  
exit command 39

## F

FastLearn for spanning tree 142  
flow control 100  
flowcontrol command 100  
format 29  
forwarding table 41

## G

gateway 52  
Gigabit Ethernet 100

## H

help 33, 34  
hybrid mode 29

## I

IGMP 166  
interface command 38  
interfaces 38  
IP 29  
IP address 52, 53  
    per unit 56  
ip address command 53  
ip bootp server command 61  
ip default-gateway command 54

## L

link status 90  
logging 83, 126  
logout command 37

## M

MAC address 40, 41  
MAC address forwarding database table 41  
MAC DA filtering 131  
MAC security  
    DA filtering 131  
    source-address based 131  
mac-address-table aging-time command 43  
mac-security command 133  
mac-security command for a single port 136  
mac-security mac-address-table address  
    command 134  
mac-security mad-address-table address  
    command 134, 135  
management 21  
MLT 69, 149

---

mlt command 150  
monitoring 151  
multicast traffic 165  
MultiLink Trunking 149  
multiple spanning tree groups 142

## N

name command 92  
naming ports 92  
netmask 29, 53  
network configuration 50  
no auto-pvid command 162  
no autotopology command 99  
no command 34  
no flowcontrol command 101  
no ip address command 53  
no ip bootp server command 62  
no ip default-gateway 55  
no mac-security command 134  
no mac-security mac-address-table command 135  
no mlt command 151  
no name command 93  
no port-mirroring command 153  
no radius-server command 139  
no set logging command 86, 129  
no shutdown command 91  
no snmp-server command 73, 113  
no snmp trap link-status command 76, 124  
no snmp-server authentication-trap command 107  
no snmp-server command 121  
no snmp-server community command 110  
no snmp-server contact command 112  
no snmp-server host 116  
no snmp-server location command 118  
no snmp-server name command 119

no snmp-server view command 122  
no spanning-tree command 148  
no telnet-access command 59  
no tftp-server command 64  
no vlan command 161

## P

passwords 32  
ping command 48  
port number and port list 29  
port statistics 87  
port, enabling or disabling 90  
portlist 29  
port-mirroring 151  
port-mirroring command 152  
portnum 29  
ports 94  
    naming 69, 92  
product support 23  
protocol VLANs 155  
publications 23  
PVID 155

## Q

quit 37

## R

RADIUS access 32  
RADIUS authentication 137  
radius-server command 138  
remote access requirements 57  
requirements 30  
    accessing the CLI 30  
    remote access 57  
    terminal 30

**S**

scripts 25, 38, 50  
security 32, 58, 131, 137  
security lists 131  
serial port 30  
set logging command 85, 128  
show config-network command 51  
show interfaces command 69  
show ip command 55  
show logging command 83, 127  
show mac-address-table command 42  
show mac-security command 132  
show mlt command 149  
show port-mirroring command 152  
show port-statistics command 87  
show radius-server command 137  
show snmp-server command 106  
show spanning-tree command 142  
show sys-info command 40  
show telnet-access command 58  
show terminal command 46  
show tftp-server command 63  
show vlan igmp command 167  
show vlan interface info command 156, 157  
show vlan interface vids command 157  
show vlan mac-address command 164  
show vlan multicast membership command 165  
shutdown command 90  
SNMP 71  
snmp trap link-status command 75, 123  
snmp-server authentication-trap command 106  
snmp-server command 72, 113  
snmp-server community command 108, 109  
snmp-server contact command 112  
snmp-server host command 114, 115

snmp-server location command 117  
snmp-server name command 118, 125  
snmp-server user command 119  
snmp-server view command 121  
snooping 166  
software download  
    LED indication descriptions 68  
    process 67  
software versions 40  
software, downloading 66  
spanning tree 142  
spanning-tree command 144, 146  
speed 69, 94  
speed command 94  
standalone mode 29  
statistics 87  
STG 142  
subnet mask 29, 53  
support, Nortel Networks 23  
system contact 71  
system information 40  
system location 71  
system name 71

**T**

Tab key navigation 34  
tagged frames 155  
technical publications 23  
technical support 23  
Telnet 30, 32, 57, 58  
telnet-access command 58  
terminal command 47  
terminal 38  
    requirements 30  
    settings 46  
TFTP 63

---

tftp-server command 64  
traffic  
    Gigabit Ethernet 100  
traps 71, 75, 123  
troubleshooting 29, 134, 152  
    access 37, 53, 57, 131, 137  
    autonegotiation 95, 96  
    ping 48  
    port numbers 29  
    port-mirroring 151  
    ports 38  
    spanning tree 141, 142  
    spanning tree groups 142  
    STG 142  
    VLANs 156, 160  
trunks 149

## U

unregistered frames 155  
untagged frames 155  
upgrading diagnostics 66  
upgrading software 66  
utilizing trunks 149

## V

vlan create command 159  
vlan delete command 160  
vlan igmp command 168  
vlan members command 163  
vlan mgmt command 158  
vlan name command 161  
vlan ports command 162  
VLANs 155  
    creating 159  
    learning 159  
    MAC SA-based 164  
    management VLAN 155  
    ports 155  
    protocol-based 159

spanning tree groups 142  
type 159

## W

Web-based management system 21