

# UPS Power Monitor User's Manual\_Ver 1.17\_C

---

---

## Contents

Introduction .....	1
1. Hardware Connection of UPS and PC .....	2
1.1 Serial Communication Introduction.....	2
1.2 Connection between UPS and PC.....	4
1.2.1 RS_232 Connection of UPS- PC Monitoring System .....	4
1.2.2 RS_485 Connection of UPS- PC Monitoring System .....	5
1.2.3 USB Connection of UPS- PC Monitoring System.....	6
2. Using UPS-Power-Monitor Software .....	7
2.1 Software Introduction .....	7
2.2 UPS Setting on the LCD.....	7
2.2.1 Color Touch Screen.....	7
2.2.2 Monochrome Touch Screen .....	9
2.2.3 Small LCD.....	10
2.2.4 1/1T (1-3KVA) series Setting .....	11
2.3 Connecting UPS with Power MTR.....	12
2.4 UPS Power MTR system setting .....	13
3 Function selection menu .....	14
3.1 Introduction .....	14
3.2 Home .....	14
3.3 BypassData .....	15
3.4 MainIpData.....	15
3.5 OutputData.....	16
3.6 BatteryData.....	16
3.7 CabStatus .....	17
3.8 UnitStatus .....	18
3.9 Hislog Down.....	19
3.10 ScodeDown.....	20
3.11 RateSetting.....	22
3.11.1 RateSettings .....	22
3.11.2 Syscode setting 1.....	22
3.11.3 Syscode setting 2.....	23
3.11.4 UPS information setting.....	24
3.12 ServSetting.....	25
3.12.1 System Setting .....	25
3.12.2 Battery Setting .....	27
3.12.3 Customization.....	28
3.12.4 WarningSet.....	30
3.12.5 DryContactSet.....	30
3.12.6 Shutdown Setting.....	31

3.13 DetectAdjust .....	32
3.14 ControlCmd .....	32
3.15 FWProgram .....	32
3.16 Help .....	32
3.17 About .....	33

## **Introduction**

This software is designed for monitoring and setting UPS. There are two ways to connect with UPS: RS\_232 & RS\_485. If using RS\_485 communication, a “485-232-adaptor” is necessary to connect 485 port of UPS and computer’s Serial port. If using RS\_232 communication, a serial cable can be connected directly from UPS 232 port to the computer’s Serial port.

# 1. Hardware Connection of UPS and PC

## 1.1 Serial Communication Introduction

### 1.1.1 Serial Communication Interface Introduction

There are two types 9 cores serial interfaces, one is 9 pins (Male type) interface, another one is 9 holes (Female type) interface. Their Figures as below:



Fig 1-1. Male type interface (for RM060/120/200)



Fig 1-2. Female type interface (For the other products)

### 1.1.2 RS\_232 Definition

1) Male type pins definition of RS\_232 Port is shown in Fig 1-3.




Fig 1-3. Male type pins definition of RS\_232 Port

pin2--- RXD  
pin3--- TXD  
pin5--- GND

2) Female type holes definition of RS\_232 Port is shown in Fig 1-4.




Fig 1-4. Female type holes definition of RS\_232 Port

pin2--- TXD  
 pin3--- RXD  
 pin5 --- GND

### 1.1.3 RS\_485 Definition

The 9 cores RS\_485 interfaces definition is shown in Fig 1-5.



Fig 1-5. RS\_485 definition (For RM060/120/200)

pin2--- 485+/A  
 pin3--- 485-/B  
 pin5 --- GND

The 3 pins and 2 pins pluggable terminal block definition are shown in Fig 1-6.




Fig 1-6. RS\_485 definition (For the other products)

## 1.2 Connection between UPS and PC

### 1.2.1 RS\_232 Connection of UPS- PC Monitoring System

As usual, the desktop computer's serial communication port as shown on Fig 1-7. There is no serial communication port on the notebook computer. The users need a USB-RS\_232 cable and install relative drive program at PC, as shown on Fig 1-8.




Fig 1-7. Desktop computer serial communication port



Fig 1-8. USB-RS\_232 cable and drive program

(1) To communicate with standard RS\_232 cable

The standard RS\_232 cable as shown on the Fig 1-9. As usual, computer's serial communication port is male type. If your UPS's serial communication port is also male type, you can connect the computer and UPS with a **crossed** female-to-female terminal RS\_232 cable. If your UPS's serial communication port is female type, you need a **directly connected** RS\_232 cable with female-to-male terminal.



Fig 1-9. RS\_232 cable

(2) To communicate with lead wire

The detailed way is shown on Fig 1-10:




Fig 1-10. PC RS\_232 port to UPS RS\_232 port

For example, if the PC RS\_232 port is male type, UPS RS\_232 is female type, the connection way is shown as below:




Fig 1-11. PC RS\_232 port to UPS RS\_232 port

### 1.2.2 RS\_485 Connection of UPS- PC Monitoring System

The connection of **UPS- PC monitoring system** is shown in Fig. 1-12.

1) Connect the **485-232 adaptor** to **485-port of UPS** using a customized serial cable, which is an accessory of UPS.

**NOTE: Pins definition of this Serial cable is different from a normal one.**

2) Connect the **serial port of PC** to **232 port of 485-232-adaptor** using a normal serial cable.




Fig 1-12. UPS and PC monitoring system connection

3) If there are more than one UPS connected, the communication bus of RS485 could be applied as below, please set the UPS with different address, and choose the right address when starting the software connection.




Fig 1-13. UPS and PC monitoring system connection via RS485 bus

### 1.2.3 USB Connection of UPS- PC Monitoring System

RMX series provide a USB (type B) interface, you can connect the computer and UPS with a standard USB cable.



## 2. Using UPS-Power-Monitor Software

### 2.1 Software Introduction

After Decompressing, the software can be used directly, need not install it. Please make sure that all 4 files should be put in the same directory, which are described as follows:

UPSPowerMTR.exe: Executable file

UPSPowerMTR.CHS: Language file

UPSPowerMTR.ENU: Language file

CLOSEAPP.EXE: Close application

As hardware connection finished, double click “UPS Power MTR.exe” to start it. Then Home is visible as shown in Fig 2-1. Left side of software window is **function selection menu**, right side is the **energy-flow-diagram**.




Fig 2-1. Home

### 2.2 UPS Setting on the LCD

**It is necessary to set the UPS communication protocol as Modbus before using UPSPowerMTR.**

Different UPS have different LCD, the setting is also different, detailed way as below:



#### 2.2.1 Color Touch Screen

Color touch screen display as shown on Fig 2-2, communication setting way as below:



Fig 2-2. Color touch screen display



**a. Setting for RS\_232:**

Click the button , you will get setting manual, then click the button  to enter communication setting page, as shown on Fig 2-2, and set each item step by step:

- 1) RS\_232 Protocol Selection: Modbus;
- 2) Baudrate: 9600 or any other value, but it must is the same as monitoring software;
- 3) Modbus Mode: ASCII or RTU, but it must is the same as monitoring software;
- 4) Modbus Parity: None;
- 5) Device Address: 1;

Then click , setting finished.

**b. Setting for RS\_485:**

Click the button , you will get setting manual, then click the button  to enter communication setting page, as shown on Fig 2-2, and set each item step by step:

- 1) RS\_232 Protocol Selection: SNT;
- 2) Baudrate: 9600 or any other value, but it must is the same as monitoring software;
- 3) Modbus Mode: ASCII or RTU, but it must is the same as monitoring software;
- 4) Modbus Parity: None;
- 5) Device Address: 1 (If there are more than one UPS, please set the address to different number);

Then click , setting finished.

**c. Setting for USB:**

The setting method of USB communication in the same way with RS\_485, so the setting method of RS\_485 can be referred.

**Note: USB and RS\_485 cannot be used at the same time.**

## 2.2.2 Monochrome Touch Screen

Monochrome touch screen display as shown on Fig 2-3, communication setting way as below:





Fig 2-3. Monochrome touch screen display


### a. Setting for RS\_232:

Note 1: UPS monitoring firmware version should be higher than 003.018.












Note 2: It is not allowed to use RS\_232 and RS\_485 at same time.

The UPS monitoring firmware version can be gotten by: click  first at LCD display home page, then click **SysInfo**, you will see it.

The detailed setting as below:

- 1) click  at the home page of UPS LCD display, then click **Comm Set**, then click **Modbus** to set communication protocol as "Modbus".
- 2) click **ProtoSet** to enter protocol setting manual;
- 3) click **Mode** to enter Modbus setting manual, then click **ASCII** to set Modbus communication mode as "ASCII" mode, you can also choose "RTU" mode, but it must be the same as monitoring software;
- 4) back to protocol setting manual, click **Address** to set Modbus device address as "1" (If there are more than one UPS, please set the address to different number);
- 5) back to protocol setting manual, click **BaudRate** to set Modbus Baud rate as "9600", you can also choose other value, but it must be the same as monitoring software;
- 6) back to protocol setting manual, click **Parity** to set Modbus parity bit as "None".

**b. Setting for RS\_485:**

- 1) click  at the home page of UPS LCD display, then click , then click  to set communication protocol as “Modbus”.
- 2) click  to enter protocol setting manual;
- 3) click  to enter Modbus setting manual, then click  to set Modbus communication mode as “ASCII” mode , you can also choose “RTU” mode, but it must is the same as monitoring software;
- 4) back to protocol setting manual, click  to set Modbus device address ;
- 5) back to protocol setting manual, click  to set Modbus Baud rate as “9600”, you can also choose other value, but it must is the same as monitoring software;
- 6) back to protocol setting manual, click  to set Modbus parity bit as “None”.
- 7) click , back to protocol choose page, click  to set current RS\_232 communication protocol as “SNT”.

**c. Setting for USB:**

The setting method of USB communication in the same way with RS\_485, so the setting method of RS\_485 can be referred.

**Note:**

- 1. USB and RS\_485 cannot be used at the same time.**
- 2. Only RMX series have USB interface.**

**2.2.3 Small LCD**

The LCD display as shown Fig 2-4:




Fig 2-4 Small LCD


**Note 1: Your UPS rectifier version must be advanced than Version 001.001 when using RS\_232.**

**Note 2: Port RS\_485 is forbidden to use when using RS\_232.**

Select  icon in the main display interface of UPS LCD, then enter “Version” interface, then you will see

UPS REC version.

**a. The way to set Port RS\_232 of UPS as below:**

- 1) Select  icon in the LCD of UPS to enter “COMM. SET” interface;
- 2) In the “COMM. SET” interface, set current communication protocol to “ModBus”;
- 3) In the “MODBUS SET” interface, set Modbus communication mode to “ASCII” or “RTU”, set device address to “1”, set baud rate to “9600” or other, as shown on Fig 2-5:





Fig 2-5 Modbus Setting

**b. The way to set Port RS\_485 of UPS**

The way to set Port RS\_485 of UPS as below:

- 1) Select  icon in the LCD of UPS to enter “COMM. SET” interface;
- 2) In the “COMM. SET” interface, set current communication protocol to “SNT”;
- 3) In the “MODBUS SET” interface, set Modbus communication mode to “ASCII” or “RTU”, set device address to “1”, set baud rate to “9600” or other, as shown on Fig 2-5:

**Note: No RS\_485 interface on the HT31 10~20kVA and HT11 6~20kVA UPS.**

**2.2.4 1/1T (1-3KVA) series Setting**


1/1T (1-3KVA) UPS LCD display as shown on Fig 2-6:



Fig 2-6. 1/1T (1-3KVA) LCD Display

### Setting for RS\_232 interface of 1/1T (1-3KVA) UPS

1) Press “ON/OFF” and “FUNC” at same time for 5 seconds, then will enter UPS function setting manual;

2) Press “ON/OFF” to select , press “FUNC” to modify the number to be “0CC”, it means that the current communication protocol is “Modbus”.

**Note: No RS\_485 interface on 1/1T (1-3KVA) UPS.**

## 2.3 Connecting UPS with Power MTR

To start monitoring UPS, UPS type, Protocol, Address, Baud rate, Serial port number need be set correctly, Click the button “Connect” to make the software communicate with UPS.

After a few seconds, if hardware connection and the software setting are correct, status bar at the bottom of the window should display “UPS connected”, as shown in Fig 2-7. If not, please check hardware and your setting.

When connected, clicking the button ‘disconnect’ will make the software disconnect with UPS.

The settings are as follows:

**UPS type:** Auto or choose a type according to your UPS.(Note, some old UPS do not support auto choose)

**Baud rate:** Auto , you can also choose other value, but it must is the same as UPS

**Protocol:** MODBUS\_ASCII or MODBUS\_RTU, it must is the same as UPS

**Address:** set to the same address as the equipment being accessed.

**Note 1: “UPS type” must be set correctly.**

**Note 2: The software can scan serial port numbers of computer. If there is only one serial port for computer, no need to choose.**






Fig 2-7. UPS connected

Once UPS is connected, UPS status and data are shown on PC. Clicking the menu items on the left side of the window, corresponding data will be shown.

## 2.4 UPS Power MTR system setting

Click the button  at the top-right corner of UPS Power MTR or right click system tray icon and choose 'Setting' , then a system setting dialog will popup, as shown in Fig 2-8. In this dialog, you can set the action when click close button, and you also can set the password if you like, the initial password is 12345678.





Fig 2-8. Setting

## 3 Function selection menu

### 3.1 Introduction

The MTR software has the functions of monitoring , setting and control of the UPS, the functions are shown as below.



### 3.2 Home

Home Page display the **energy-flow-diagram** and information of main input voltage, bypass voltage, output voltage and battery voltage. The interface appears to be two different types according to the UPS model selected. Type A with 1/1T(1-3KVA)、1/1T (6-20KVA)、3/1T (10-20KVA) selected as is shown in Fig.3-1; Type B with other type selected as is shown in Fig.3-2.






Fig.3-1 Homepage-Type A




Fig.3-2 Homepage-Type B

### 3.3 BypassData

This page is to show the data of **UPS bypass input**, including voltage, current, frequency and power factor, as shown in Fig.3-3.




Fig.3-3 Bypass Data

### 3.4 MainIpData

This page is to show the data of **UPS main input**, also including voltage, current, frequency and power factor, as shown in Fig.3-4.




Fig.3-4 Main Input Data

### 3.5 OutputData

This page is to show the data of **UPS output**, including voltage, current, frequency, power factor, power, and load percents, as shown in Fig.3-5.




Fig.3-5 Output Data

### 3.6 BatteryData

This page is to show the data of **UPS Battery**, including voltage, charge/discharge current, capacity and remind time. The capacity and remind time data are effective when UPS is discharge, as shown in Fig.3-6.




Fig.3-6 Battery Data

### 3.7 CabStatus

This page is to show the status for the cabinet. As it's shown in Fig 3-7, the description in the yellow frame indicates the status listed in the red frame. Take the first row as an example, the 'By UPS' in the yellow frame indicate the power supply source is UPS.




Fig.3-7 Cabinet Status



#### Cabinet status items explanation:

Display Items	Means
SupplySrc	System power supply source. Available states: None, By UPS, Bypass.

BattSts	The work status of battery. Available states: Not Work, Float, Boost, Discharge.
EPO	Emergency power off. Available states: Not EPO, EPO.
OnUpsBanned	Whether UPS power on is banned. Available states: No, Yes.
ManualalByp	Whether transfer to bypass mode manually. Available states: No, Yes.
BattVoltLow	Whether battery voltage is low. Available states: No, Yes.
BattReverse	Whether battery reversed connected. Available states: No, Yes.
BattEOD	Whether battery End Of Discharge occurred. Available states: No, Yes.
BypOvLd	Whether bypass over load. Available states: No, Yes.
BypOvLdTout	Whether bypass over load timeout. Available states: No, Yes.
BypUntrack	Whether bypass frequency untrack occurred. Available states: No, Yes.
TxTimeLmt	Whether the times of transfer to bypass reach its limit. Available states: No, Yes.
OpShorted	Whether Output short circuit occurred. Available states: No, Yes.
GenInput	Whether generator input. Available states: No, Yes.
InputFail	Whether input fail occurred. Available states: No, Yes.
BypSeqFail	Whether bypass sequence fail. Available states: No, Yes.
BypVoltFail	Whether bypass voltage fail. Available states: No, Yes.
BattTestSts	Battery test status. Available states: No, Ok., Fail, Testing
BattMaintSts	Battery maintenance status. Available states: No, Ok., Fail, Maintaining
MaintCbSts	Maintain CB status. Available states:Open, Close.
InvOnLess	Whether Inverter Capacity is less than required. Available states: No, Yes.
IpNeutralLost	Whether input neutral lost. Available states: No, Yes.
BypFanFail	Whether bypass fan fail. Available states: No, Yes.

### 3.8 UnitStatus

As shown in Fig 3-8, by selecting the button of 'Unit Status' and 'Module Data', users can see the status information and analog value of the online module respectively.

The 'Unit Status' page can up to show 30 modules. By dragging the horizontal scroll bar, user can view all the information of the modules. For the mark, the “” indicates the normal operation; the mark” ”, indicates fault occur.




Fig3-8 Status Unit page

The “Module Data” displays the analog value of the current selected module As is shown in Fig 3-9,the number in the red frame is the selected module. By pulling-down menu in the yellow frame and confirm click, users can change the information displayed for different module.




Fig 3-9 Module Data

### 3.9 Hislog Down

UPS history log can be downloaded to PC on this page. Click ‘Download’ to download history log from UPS

which then would be displayed on PC. Click 'Save' to save history log to PC as a file. It's shown in Fig.3-11.




Fig.3-11 Hislog Down

### 3.10 SCodeDown

“SCode download” interface is shown in Fig 3-12. The SCode can be downloaded to the grid on the left by simply clicking the “Download” button, and click “Save” to save the SCode to the local computer.

If you want to analyze the SCode that was download from UPS, you can input it to the box on the right and click the button “Analyze” then the “Analyze dialog window” will show as Fig3-13.

There are three methods to input the SCode into the SCode box :

- Double-click the SCode title on the left, the SCode will be copy to the SCode box, as shown in Fig 3-12.
- Save the SCode to the local file and copy it to the SCode box.

(c) Directly type the SCode to the SCode box, make sure the format is as same as the one on the left box.

Normally you can copy and paste from the SCode file.




Fig 3-12 Scode Download

“Analyze dialog window” as shown in Fig 3-13, the failure will be shown in red in order to attract attention. For the mark ?, it means the parameter is not detected, the mark X it indicates the data is out of range.

The screenshot shows the 'SCode Analyze' dialog window with a table of parameters. The table has 18 rows and 4 columns. The first column is a row number (1-18), the second is a group number (1, 2, 3, 4), the third is the parameter name, and the fourth is the status. The status values are: UPS, OFF, Normal Work, Abnormal, Discharging, Open, Open, Close, Open, Open, Connect, Connect, Disable, Supplying, Disconnect, No, and Enough.

1		Output Power Source	UPS
2		Rectifier Status	OFF
3	1	Inverter Status	Normal Work
4		Bypass Status	Abnormal
5		Battery Status	Discharging
6	2	Input CB Status	Open
7		Bypass CB Status	Open
8		Output CB Status	Close
9	S0	Maintenance CB Status	Open
10		Postive Battery String CB Status	Open
11	3	Negative Battery String CB Status	Open
12		Postive Battery String Connect Status	Connect
13		Negative Battery String Connect Status	Connect
14	4	Inverter On Allow Status	Disable
15		Inverter Working Status	Supplying
16		Generator Connect Status	Disconnect
17		Service Mode	No
18	1	Inverter Ready Capacity	Enough

Fig 3-13 Scode analyze

### 3.11 RateSetting

“RateSetting” page is for factory use. A password is needed for the access to the page.

#### 3.11.1 RateSettings

“RateSettings” menu can set the rated system voltage and frequency. The values in red rectangle are currently used by UPS, while in yellow rectangle are the new values to be set. Click button “set” can save the data to the UPS, as is shown in Fig.3-14.




Fig 3-14 RateSetting

The items are described as follows:

Contents	Description
InputVolt	The system rated input voltage(V)
InputFreq	The system rated input frequency(Hz)
OutputVolt	The system rated output voltage(V)
OutputFreq	The system rated output frequency(Hz)

#### 3.11.2 Syscode setting 1

The syscode setting 1 is set by bit. Different bit may has different meaning to different model of UPS. Users can check or uncheck the checkbox and click “Set” to save the setting to the UPS. As is shown in Fig3-15.






Fig3-15 Syscode setting1

System code is set by bit, described as follows:

Setting items	Choose (1)	Not choose (0)															
<b>Out 3/1</b>	Single phase output (Do not choose this function unless confirmed by manufacturer)	3 phase output															
<b>AutoBoost:</b>	Enable battery auto boost	Disable battery auto boost															
<b>AutoMaint:</b>	Enable battery auto maintenance	Disable battery auto maintenance															
<b>NotTxTLmt:</b>	No switching limit to bypass times	Switching limit to bypass (5 times per hour)															
<b>FreqSelfAdpt:</b>	Enable frequency self adaptive function	Disable frequency self adaptive function															
<b>PFFlag:</b>	Combine with PFExterm to set different output PF. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>PFFlag</th> <th>PFExterm</th> <th>PF</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0.8</td> </tr> <tr> <td>0</td> <td>1</td> <td>0.7</td> </tr> <tr> <td>1</td> <td>0</td> <td>0.9</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> </tr> </tbody> </table>	PFFlag	PFExterm	PF	0	0	0.8	0	1	0.7	1	0	0.9	1	1	1	
PFFlag	PFExterm	PF															
0	0	0.8															
0	1	0.7															
1	0	0.9															
1	1	1															
<b>PFExterm:</b>	See PFFlag	See PFFlag															
<b>OvLdToutExt(B)</b>	Long inverter overload time	Short inverter overload time															

Note: Different UPS model has different system code.

### 3.11.3 Syscode setting 2

The syscode setting 2 is set by bit. Different bit may have different meaning to different models of UPS. Users can check or uncheck the checkbox and click “Set” to save the setting to the UPS. As is shown in Fig3-15.




Fig 3-16 Syscode setting 2

System code is set by bit, described as follows:

Setting items	Choose (1)	Not choose (0)
<b>RB:</b>	Set UPS mode as RB( In-built battery pack)	Not RB mode
<b>ButtFncPwdL1:</b>	Set monochrome touch LCD function page password for 1 level	Set monochrome touch LCD function page password for 2 level
<b>DispLLVolt:</b>	Display line voltage	Not display line voltage
<b>NeutralLostClr:</b>	Neutral line lost auto clear faults	Normal logic
<b>EpoNormClose:</b>	Epo terminal normal close	Epo terminal normal open
<b>PFExterm:</b>	See System code 1 PFFlag	See System code 1 PFFlag

### 3.11.4 UPS information setting

The UPS information setting include : UPS Mode , UPS Type, Company Name, as is shown in Fig3-17. You can set the UPS Type and Company Name by input it in right edit, then click set button.




Fig 3-17 UPS information setting

### 3.12 ServSetting

In the “ServSetting” menu, a password is needed before entering. The submenu “System Setting”, “Battery Setting”, “Customization”, “DryContactSet” are for factory use, the “Warning Set” and “Shutdown setting” are for customer use.

#### 3.12.1 System Setting

“System Setting” interface is shown as Fig3-18. The values in red rectangle are currently used by UPS, while in yellow rectangle are the new values to be set. Click “Set” to send new values to UPS. In the system Settings page, click the “SaveAll” button can save all the data and setting to the local disk, also the data can be restored to the monitoring software from the local disk by clicking the “Recover”.




Fig 3-18 System Setting

The items of System Setting are described as follows(Different UPS type may have different items):

Setting item	Description
System Mode	<p>Set the operation modes of UPS.</p> <p><b>Single</b> : Single mode</p> <p><b>Parallel</b> : Parallel mode</p> <p><b>SingleECO</b>: ECO mode in single unit</p> <p><b>ParallelECO</b>: ECO mode in parallel system</p> <p><b>LBS</b> : Load Bus Synchronizer installed for dual bus system, see more detail of the technical doc of LBS.</p> <p><b>ParallelLBS</b> : Dual bus system built up with parallel units, see more detail of the technical doc of LBS</p> <p><b>Selfaging</b> : Selfaging mode, see more detail of technical doc of selfaging.</p> <p><b>The selected operation mode could be active after confirmed by the button of “Set”.</b></p>
United Number	Set the number of UPS in parallel system

System ID	Set the ID of UPS in parallel system <b>For parallel system, the ID starts from 0.</b>
Adjusted Output Voltage	Adjusted output voltage, Unit: V
Frequency Slew Rate	Slew rate of track, Unit: Hz/s
Frequency Synchronization Window	Frequency Synchronization window, Unit: Hz
LCD Time(Min)	Set the time of LCD screen saver, Unit: Min
Logo Show Time(s)	Set logo page show time
Redundant Module Number	Set the number of N+X redundant modules If the redundant modules are less than the set number, there could be an alarm of “Lost Redundancy”. For example, if 5 modules installed ,the redundant module number is set to 2, if the load rate is higher than 60%, there could be an alarm.
Bypass Voltage UP Limited (%)	Set bypass voltage up limited
Bypass Voltage Down Limited (%)	Set bypass voltage down limited
Bypass Frequency Limited (Hz)	Set the range of frequency fluctuation, Unit: Hz
Battery Transfer to Main Delay(s)	Set the delay time from battery transfer to main
System Auto Start Mode After EOD	Set system auto start mode after EOD, that means, after battery EOD, when the AC input recover ,the system should behave as below: <b>Normal:</b> auto restart and transfer to inverter mode <b>ByOnly:</b> auto restart of rectifier, but the inverter does not start, the system stay on bypass <b>NoneOp:</b> no any action with just the controller and LCD are active
Aging Current(%)	Used in Aging mode to set aging current from 30%-100% of nominal current. See more detail of the technical doc of selfaging.
Fan Speed 3 Level Enable	Enable or disable fan speed 3 level <b>Yes:</b> There are 3 levels of fan speed according to the load rate (slow, medium, fast) <b>No:</b> There are 2 levels of fan speed according to the load rate (medium, fast)
Allow Lost Phase Work	Enable or disable UPS lost phase work <b>Yes:</b> If one of the phases lost, rectifier could continue to work if only the current is lower than the set limit. <b>No:</b> Rectifier will stop if one phase lost.
Temperature Rise Limit Level	Set temperature rise (outlet temperature to inlet temperature) limit level, there are different settings according to the product, please do not change the value unless confirmed by the manufacturer.
Inlet Temperature Level	Set inlet temperature level. It’s about the internal control logic and please do not change this setting.
Motor Mode	Enable or disable motor mode. This function is used for motor application. <b>Yes:</b> System start with inverter (not bypass), with a current limit and different control algorism. <b>No:</b> System start with bypass as normal.

Frequency Convertor Mode	Enable or disable frequency convertor mode, this allow the system operates as a frequency converter. <b>Yes:</b> Operates as a frequency converter and disable the alarm of bypass frequency fail. <b>No:</b> Normal mode
Bypass Backfeed Protected Enable	Enable or disable bypass backfeed protected <b>Yes :</b> Enable the bypass Backfeed detection <b>No :</b> Disable the bypass Backfeed detection
Input Overvolt Fast Check Enable	Enable or disable input overvoltage fast detection. This function is used for the applications that unexpected transient spike of input presents in the input. It could be more sensitive to the spike and transfer to battery mode in case of any abnormal voltage.
Charger Fail Alarm Enable	Enable or disable charger fail alarm
Module Fan Maintenance Period	Set the maintenance period of module fan
Bypass Fan Maintenance Period	Set the maintenance period of bypass fan
Module Capacitor Maintenance Period	Set the maintenance period of module capacitor
Generator In Charger Off Enable	Set if disable charger when generator switch in <b>Yes :</b> Disable the charger if a generator is connected <b>No :</b> Enable the charger if a generator is connected
System Time	Launch the system time of PC to the controller, it's only available for the monochrome LCD.

### 3.12.2 Battery Setting

“Battery Setting” interface is shown in Fig3-19. The values in red rectangle are the current parameter of UPS, while in yellow rectangle are the new values to be set. Click “Set” to send new values to UPS.




Fig3-19 Battery Setting

The items of Battery Setting are described as follows(Different UPS type may have different items):

Setting item	Description
--------------	-------------

Battery Type	Set the type of battery used by your UPS. VLR or Lithium-ion battery is available.
Battery Number	Set battery number
Battery AH	Set battery AH Pay attention that the max charging current is limited to 0.2*AH
Float Charge Voltage /Cell(V)	Set the float charge voltage of battery cell Calculate the charging voltage as below, $V_{chg} = \text{cell voltage} * 6 * \text{battery number}$
Boost Charge Voltage/Cell(V)	Set the boost charge voltage of battery cell Normally it's recommended no higher than 2.35V/cell.
EOD Voltage/Cell, @ 0.6C Current(V)	EOD voltage of Battery cell at 0.6c
EOD Voltage/Cell, @ 0.15C Current(V)	EOD voltage of Battery cell at 0.15c
Charge Current Percent Limit %	Set charge current limit. Calculate the charging current as below $I_{chg} = \text{Set Percentage \%} * P_{out} / (2.35 * 6 * \text{battery number})$
Battery Temperature Compensate	Battery temperature compensate, unit: mV/°C Optional battery temperature sensor is needed.
Boost Charge Time Limit	Boost charge time limit, unit: hour
Auto Boost Period	Auto boost period, unit: hour. The parameter is only valid after enable the function of Auto Boost.
Auto Maintenance Discharge Period	Auto maintenance discharge period, unit: hour The parameter is only valid after enable the function of Auto Maintenance.
Deep Discharge Time	Deep discharge time, unit: hour <b>It's only valid for single phase UPS.</b>
No Battery Detect Period	No battery detect period, unit: minute <b>It's only valid for single phase UPS.</b>
No Battery Detect Time	<b>No battery detect time, unit: minute</b> <b>It's only valid for single phase UPS.</b>
Critical Battery Temperature	Critical battery temperature, unit: °C Set the battery temperature limit for alarm.
Critical Battery Ambient Temperature	Critical battery ambient temperature, unit: °C Set the ambient temperature for alarm.
Charge module current limit	Set the max charging current of each charging module, unit:A.

### 3.12.3 Customization

“Customization” interface is shown in Fig3-20. The CustomCode on the left is set by bit, check or uncheck the box and click the “Set” button can send the data to the UPS; CustomCode on the right set the load level and rotation time of sleeping and waking.




Fig3-20 Customization

c	Checked	Unchecked
<b>Tx2InvIntEnable</b>	This function enable interrupt transfer to inverter, it should be manually operated and may lead to an interruption during transfer.	Disable interrupt transfer to inverter
<b>ModOnOffEnable</b>	Enable the individual operations of module power on/off. With this setting, operations shown in “ControlCmd-->Module operation command” could be available.	Disable module power on/off
<b>SleepEnable</b>	Enable sleep mode.	Disable sleep mode.
<b>DeepSleepEnable</b>	Enable deep sleep mode. This setting should be enabled together with the “SleepEnable” setting.	Disable deep sleep
<b>KoreaEco</b>	Enable KoreaEco(Korea nonstandard) This is an option for special model.	Disable KoreaEco
<b>SciLcdEnable</b>	Configurate Lcd as serial port screen	Configurate Lcd as blue and white screen
<b>2PhasOut</b>	Enable two phase output It’s only valid for special model.	Disable two phase output
<b>usedAsOne</b>	Enable used as one phase output It’s only valid for special model.	Disable used as one phase output
<b>ForbidTx2Byp</b>	Forbid transfer to bypass	Not forbid transfer to bypass
<b>EpoDisable</b>	Disable EPO	Enable EPO
<b>LocalEpoDisable</b>	Disable local EPO	Enable local EPO
<b>RemoteEPODisable</b>	Disable remote EPO	Enable remote EPO
<b>BypOvTmpForbidByp</b>	Forbidden the bypass output if bypass	Bypass over temperature not forbid bypass

	over temperature.	
<b>NoBattery</b>	Disable the detection of “Battery not connected”	Enable the detection of “Battery not connected”

CustomCode on the right is described as the following table

Contents	Meaning	Note
Sleeping Load Rate	Setting the sleeping load rate	
Interval Time for sleeping	Setting the interval for the sleeping	The period of rotation for the sleep modules.

### 3.12.4 WarningSet

The “WarningSet” is shown in Fig 3-21. If the selected event occurs, there appears a warning window of the PC. The switch of beeper can control the buzzing. Click the “SelectAll” button to select all the events and click the “ClearAll” to uncheck all the events.

**Notes: This warning setting is only about the warning of the PC, NOT THE HISTORY LOG OF UPS ITSELF.**




Fig 3-21 WarningSet

### 3.12.5 DryContactSet

“DryContactSet” interface is shown in Fig 3-22, The values in red rectangle are currently used by UPS, while in yellow rectangle are the new values to be set. Click “Set” to send new values to UPS.






Fig 3-22 DryContactSet

Notes: The list of dry contact signals is subject to change with the upgrade of firmware, for more details, contact your technical support from factory.

### 3.12.6 Shutdown Setting

Shutdown setting page include “Shutdown Setting” and “Shutdown time setting”, this function only be allowed by the single phase 1-20K UPS.

**Do not change the setting unless it’s confirmed by the manufacturer.**




Fig 3-23 Shutdown Setting

### 3.13 DetectAdjust

This function is only for factory setting

### 3.14 ControlCmd

In the “ControlCmd” menu, a password is needed before entering. This page include “Function Key”, “Test Command” and “Module Operation Command”. For “Function Key” and “Test Command” parts, you can click the red button to execute corresponding command, then the command will be send to UPS. For “Module Operation Command” part, you can choose a module and choose a action then click “Done” button, so the command can be sent to UPS module.




Fig.3-24 ControlCmd

### 3.15 FWProgram

This function is only for factory setting, disabled for users.

### 3.16 Help

Brief description of the software, as shown in Fig.3-25.




Fig.3-25 Help

### 3.17 About

Version information of the software, as shown in Fig.3-26.




Fig.3-26 About