

---

# **SERVICE MANUAL**

**HT series 6~20K**

---

---

## CONTENT

<b>1. GENERAL INFORMATION OF THIS DOCUMENT.....</b>	<b>3</b>
<b>1.1 GETTING START.....</b>	<b>3</b>
<b>1.2 CONVENTIONS.....</b>	<b>3</b>
<b>1.3 IMPORTANT SAFETY INSTRUCTIONS.....</b>	<b>4</b>
<b>2. CHARACTERISTIC OF THE PRODUCT.....</b>	<b>5</b>
<b>3. PRINCIPLE OF OPERATION.....</b>	<b>6</b>
<b>3.1 ELECTRIC SPECIFICATIONS.....</b>	<b>6</b>
<b>3.2 FUNCTIONAL BLOCK OF THE PRODUCT.....</b>	<b>8</b>
<b>3.3 OPERATING PRINCIPLE OF THE MAJOR FUNCTIONAL BLOCK.....</b>	<b>9</b>
<b>3.3.1 The basic circuit of power supply .....</b>	<b>9</b>
<b>3.3.2 PFC/Boost circuit .....</b>	<b>10</b>
<b>3.3.3 IP SCR Board .....</b>	<b>11</b>
<b>3.3.4 Inverter circuit .....</b>	<b>12</b>
<b>3.3.5 Standard Charger and Super Charger .....</b>	<b>12</b>
<b>3.3.6 EMI Board .....</b>	<b>13</b>
<b>3.3.7 Control circuit .....</b>	<b>14</b>
<b>4. LED DISPLAY .....</b>	<b>15</b>
<b>5. TROUBLE SHOOTING .....</b>	<b>16</b>
<b>5.1 CHECKING UPS STATUS .....</b>	<b>16</b>
<b>5.2 ADJUST THE FACTORS CAUSED THE PROBLEM .....</b>	<b>17</b>
<b>5.3 Trouble shooting in else cases .....</b>	<b>20</b>
<b>5.4 FAILURE DIAGNOSIS .....</b>	<b>20</b>
<b>5.4.1 Maintenance tools .....</b>	<b>20</b>
<b>5.4.2 The Setting Method of Single UPS .....</b>	<b>21</b>
<b>5.4.3 Quick Start .....</b>	<b>24</b>

---

---

# 1. General Information of This Document

## 1.1 Getting start

This is a service manual for HT series 6K~20K Tower UPS, intend to help service personal perform a maintenance and repair service.

If you want to know:

**What is special for this UPS from service point of view;** please refer to section characteristic of the product.

**Functional block of the UPS, and operating principle thereof,** please refer to Principle of Operation.

**What's wrong with the UPS and How to solve the problem,** please refer to Trouble Shooting.

**Basic information about the product, install and operation instruction,** you may please refer to USER MANUAL

## 1.2 Conventions

This service manual uses the following conventions to alert you some important information for safe operation and quick working.



**Warning:** Denotes a procedure or operation, which, if not perform correctly, may result in personal injury. **Be sure not to continue operation until indicated conditions are fully understood and met.**



**Caution:** Denotes a procedure or operation, which, if not perform correctly, may cause damage to the UPS. **Be sure not to continue operation until indicated conditions are fully understood and met.**



**Information and Tips:** There are some tips and skills after this symbol. During service operations, these skills may help you quickly finish your work.

---

---

## 1.3 Important Safety Instructions



1. **For qualified service personnel only.**
2. **DO NOT** perform any internal service or adjustment of this product unless another person is capable of rendering first aid and resuscitation is present.
3. Dangerous voltage exists at several points in this product. To avoid personal injury, don't touch any exposed connections or components while UPS is active.
4. Turn off the UPS and disconnect input power cord before removing outside protective cover.
5. AC voltage is always present if the input AC power is still available.
6. High voltage may present at DC capacitors. Before opening the outside cover, wait for at least five minutes after turning off the UPS.
7. Verify input source (voltage and frequency) is within the maximum range before service.

---

---

## 2. Characteristic of the Product

The HT series UPS are utilizing most advantage and mature technologies, provides the basal performance, and most cost-performance ratio in the industrial. Following benefit the product has:

- High output Power Factor; provides real power capability to the user.
- Perfect output sine waveform, suitable almost all critical equipment.
- High Input Power Factor, save for power, wiring expense for user. Low input current distortion, which avoid power pollution.
- Two or three phases input.
- Outstanding adaptability to the worst mains input condition, Extra Wide Input voltage, Frequency range and waveform, avoid excessive dissipating limited battery energy,
- Compact size; occupy minimum install space, saving real estate expense
- Most functional sub-circuit become modular, easy to identify the problem and repair by replacing an appropriate module

### 3. PRINCIPLE OF OPERATION

#### 3.1 Electric Specifications

1106S 1110S 1106L 1110L 1115L 1120L 3310L 3315L 3320L

##### INPUT

<b>Cold Start</b>	YES, default frequency=50Hz or settable
<b>Acceptable Input Voltage</b>	50%~125%(220VAC/230VAC/240VAC)
	100% load@80%~125%
	90% load@70%~80%
	80% load@60%~70%
	65% load@50%~60%
<b>Transfer Voltage Range</b>	
-Line low transfer	110VAC/115VAC/120VAC
-Line low recovery	116VAC/122VAC/127VAC
-Line high transfer	275VAC/288VAC/300VAC
-Line high recovery	268VAC/279VAC/291VAC
<b>Input Power Factor</b>	$\geq 0.99$
<b>Input Frequency Range</b>	40Hz - 70Hz
<b>Generator</b>	Support Any Generator.

##### OUTPUT

<b>Frequency adaptable</b>	Settable
<b>Power</b>	
<b>Output Voltage</b>	
-Waveform	Pure sine wave
-Nominal voltage	220/230/240VAC
-Voltage regulation	$\pm 1\%$
-Transient response	$\leq 5\%$ (50% - 100% -50%)
-Transient recovery	$\leq 15\text{ms}$ (0% - 100% -0%)
-Voltage distortion	$\leq 1\%$ THD, linear load
	$\leq 5\%$ THD, non-linear load

<b>Output Frequency</b>	
-Synchronization range	settable,±3Hz default
-Slew rate	0.5~5Hz/s,2 Hz/s default
-Battery mode	(50±0.05) Hz
<b>Transfer Time</b>	
-Line mode to battery mode	0
-Inverter to bypass	0
<b>Efficiency</b>	
-Line mode with battery full charged	93.0%
-ECO mode	98.0%
-Battery mode	92.0%
<b>Noise</b>	<48dB@<70%load,<58dB@>70%load;1m away
<b>Overload Capability (Line Mode)</b>	110%: Transfer to bypass after 10 mins.
	130%: Transfer to bypass after 1 min
	150%: Transfer to bypass after 30s, shutdown after 1 min.(Line mode)
<b>Overload Capability (Battery Mode)</b>	110%: Shutdown after 10mins (Battery mode)
	125%:Shutdown after 10s(Battery mode)
	>125%: Shutdown after 1s (Battery mode)
<b>Crest Ratio</b>	3:1

#### BATTERY

<b>Rating/Type</b>	12VDC/7Ah	Depend on the capacity of external batteries
<b>Quantity</b>	16	
<b>DC Voltage</b>	192VDC	192/240VDC
<b>Back-up Time</b>	4mins @80% load	Depend on the capacity of external batteries
<b>Battery-Low Voltage</b>	(176±3)VDC	
<b>Charger</b>		


-Charging voltage	(220±1%)VDC	
-Charging current (max)	1A	5A (8A optional)
-Charging time	7h recharge to 90%	Depend on the capacity of external batteries
Leakage current	<1mA	

**INDICATOR & ALARM**

Display	LED+LCD
---------	---------

**3.2 Functional Block of the Product**

As a true online UPS, the product employ a double conversion topology, comprise following functional blocks, as shown in Figure 3.2



**Figure 3.2.1 Function block Diagram of the product**

In which:

The CNTL controls the operation of the whole UPS, the CNTL also provides communication interface for receiving and executing command from user via the panel or a preset protocol. When the UPS become abnormal, in most case, the CNTL can provide comprehensive information indicating the status of the UPS.

The rectifier is the input stage of the UPS, The Rectifier block converts the two phases AC mains input power into a pair of stable DC power storing on the DC-BUS. In means time, Power Factor Correction is performed, the input current tracking the reference waveform



---

---

which is given by DSP, and the input power factor can be very close to 1, achieve maximum efficiency and product lowest power pollution to the power supply system.

The DC/DC module, called also Booster, used to converse the low level DC power into higher level and more stable DC power, storing on the DC-BUS also.

The inverter is the output stage of the UPS, used to converse the DC power from the DC-BUS into clean sine wave AC output power.

When the mains is within the tolerance range, the UPS use the mains input, at this time, the Rectifier work; In case the mains supply is output tolerance range, due to either the voltage or the frequency, the UPS will stop the Rectifier working and start the Battery Booster. In case the input mains supply interrupts suddenly, the controller can detect the interruption in very short time, and in the interval before detecting the interruption, the output power will be maintain by energy stored in the DC-BUS capacitor, there will never be appear interruption on output.

The battery charger charges the battery when the BUS Voltage is normal. The battery charger module converse the BUS input into DC power for recharging the Battery. Two type of charger can be available, one is for the standard model, and another is for long backup time model that connects external battery.

The Input or Output EMI part provides EMI filter function. The input EMI filter and output EMI filter are used for two purpose, the first one is to prevent the UPS being interference by external electronic/magnetic noise which generated by the other electronic system, the second is to prevent the noise generated inside the UPS system interference other system.


The SPS generates DC power supply needed by operation of the circuit of the UPS itself.

The internal Bypass provides an alternative path in case the power conversion stage become out of order, to maintain the continuity of output supply.

### **3.3 Operating Principle of the Major Functional Block**

#### **3.3.1 The basic circuit of power supply**

The Power Supply (SPS) module supplies DC power for UPS operation. The input of the SPS is the battery, or the output of the charger.



**Figure 3.3.1 Basic circuit of power supply**


This is a flyback converter topology. When the MOSFET is on, all rectifier diodes are reverse-biased and all output capacitors supply currents to the load. The primary winding acts like a pure inductor and load current builds up linearly in it to a peak  $I_p$ . When the MOSFET is off, the primary stored energy is delivered to the secondary to supply load current and replenish the charge on output capacitors that they had lost when the MOSFET was on. This circuit has some output voltages as follows:  $\pm 15V$ ,  $+12V$ ,  $+5V$ ,  $12V$  (Fan). The  $\pm 15V$ ,  $+12V$ ,  $+5V$  supply a steady voltage for all kinds of IC and other device. The  $12V$  (Fan) is supplied for fans and relays.

### 3.3.2 PFC/Boost circuit

PFC: Power Factor Correction

Because the SCR will be ON only if its positive voltage is higher than its negative voltage, after the utility power is rectified by the full waveform, the current waveform of the diode will appear characteristics of high and sine. Thus current waveform not only contains a great number of harmonics, but also makes the UPS input power factor lower.


Add a DC/DC PFC after rectifying and correct the input current as a sine wave to make the input power factor is close to 1.



**Figure 3.3.2 PFC circuit**

As shown in the diagram, when the IGBT is on and the DIODE is off, the CHOKE will store energy and the current crossing the choke will increase by degrees with time pass. When the IGBT is off, the choke releases energy and the DIODE is on, the current of the choke will be descending with time pass. Therefore, we can control the current waveform of chokes (input current) by regulating the time of IGBT on and off.

### 3.3.3 IP SCR Board




**Figure 3.3.3 Frame diagram of the SCR board**

The input of IP SCR board is connected to the another two phases. The input utility power were rectified by 4 SCRs. And the output send to the rectifier +/- on the PFC board.

---

---

### 3.3.4 Inverter circuit



**Figure 3.3.4 Half-bridge inverter topology**

The input of the half-bridge inverter topology is DC voltage, and the output is AC voltage. Half-bridge topology major advantage is that it subjects their transistors on the off state to a voltage stress equal to the DC input voltage and not twice that as do the push-pull and singled forward converter. An additional valuable feature of the half-bridge topology is that leakage inductance spikes are easily clamped to the DC supply bus and any energy stored in the leakage inductance is returned to the input bus instead of having to be dissipated in some resistive element.

The topology works as follows. Q1 and Q2 are switched on at alternate half cycles. The junction voltage of up and down bridges is a high frequency rectangular waveform. This rectangular wave through the LC filter will become a standard sine wave.

### 3.3.5 Standard Charger and Super Charger


The utility of charger is to recharge and maintain the batteries at fully charged condition. The charger charges the batteries with a constant current at initial stage and as the battery voltage keep increasing, the charge current decreases accordingly until the batteries come to the floating charge voltage point .In general, the charger will control the output voltage at a constant level ( $220 \pm 1\% V_{dc}$  ) In this way, to make the battery full recharged but not over recharged, protects and prolongs the lifetime of charged batteries.

As shown in the following diagram; the battery charger employed a Flyback topology,

---

---

under controlling of the controller mainly comprise an ASIC TL3845, when the MOSFET is turned on, the current in the transformer increases, and a certain amount of energy is stored in the transformer, when the MOSFET is turned off, the energy stored in the transformer start to be released from the secondary side of the transformer and to charge the output capacitor, by controlling the duty cycle, energy transfer to secondary side of the Flyback circuit can be controlled, and so on the output voltage.



**Figure 3.3.5 Topology of the standards and supper charger**


NOTE:

There are two kinds of charger for standard model UPS and long backup time model UPS. Both operating in the same principle, but difference in output capacity, the one for standard model UPS capable of outputting 1.2A current, A super charger module with maximum 5A charge current capacity, is used in the long backup time model UPS.

### 3.3.6 EMI Board


Input EMI choke board is connected between mains and the input of Rectifier.

Output EMI choke board is connected between the output of Inverter and output terminal block.



**Figure 3.3.6 I/P EMI circuit**


**3.3.7 Control circuit**



**Figure 3.3.7 Utility power sense circuit**

The sense signals adopt difference input signals through some multiple attenuation, which can get a new signal. The new signal send to the I/O port of DSP via a protect circuit.

## 4. LED Display



### 1) LED definition

There are total 6 LEDs to indicate the status of UPS.

STATUS	UPS status: green--normal mode, red--UPS is abnormal
REC	Rectifier indicator: green--rectifier is normal, green flicker--rectifier is starting, red--rectifier fault, red flicker--rectifier alarm, dark—rectifier is not working
INV	Inverter indicator: green--inverter is normal, green flicker--inverter is starting or tracking with bypass(ECO), red—inverter fault and load is not on inverter, red flicker—inverter fault and load is on inverter, dark—inverter is not working
BYP	Bypass indicator: green—bypass is normal, dark—UPS is in normal mode and bypass is normal, red—bypass fault, red flicker—bypass alarm
BAT	Battery indicator: green—battery charge, green flicker—battery discharge, dark—battery is connected, red—battery fault, red flicker—battery alarm
OUTPUT	Output indicator: green—output is normal, red—output alarm
















Fig 8. LCD Main Menu

Description of Main Menu

Display	Function	Submenu
---------	----------	---------

Display	Function	Submenu
	Input information	Main input: voltage, current, frequency, PF Bypass input: Voltage, current, frequency, PF
	Battery information	Battery: voltage, discharge current, battery status, battery temperature, capacity DCbus voltage
	Output information	Output information: Voltage, current, frequency, PF Load information: Active power, apparent power, percent
	Status of UPS	Alarms, S-code, firmware version, system information
	Set and function	Set: language, contrast, communication set(SNT, Modbus), Modbus set Function: function 1(transfer to bypass/escape, fault clear, mute on/off), function 2(battery test, maintenance test, stop test)
	History log	/
	Rated capacity: 10KVA 1phase in/out: 1/1	/
	Input voltage	/
	Battery voltage and capacity remained	/
	Output voltage and load percent	/
	System working mode	S--single mode, E--ECO mode, P-parallel mode, 2-the unit ID is 2 in system, the units ID in parallel system should be different
	Mute on, mute off	

## 5. TROUBLE SHOOTING

This section describes checking the UPS's status. This section also indicates various UPS symptoms a user may encounter and provides a troubleshooting guide in the event the UPS develops a problem. Use the following information to determine whether external factors caused the problem and how to remedy the situation.

### 5.1 Checking UPS status

It recommended that checking the UPS operation status every six months.


- Check whether the UPS is faulty: Is the Fault Indicator on? Is the UPS sounding an alarm?
- Check whether the UPS is operating in Bypass mode. Normally, the UPS operates in Normal Mode. If it is operating in Bypass Mode, stop and contact your local representative, or Channel Support.
- Check whether the battery is discharging. When the utility input is normal, the battery should not discharge. If the UPS is operating in Battery Mode, stop and contact your local



representative, or Channel Support.

## 5.2 Adjust the factors caused the problem



When the fault indicator is on, press  button to get S-code. So, S1 indicates status and A0-A5 indicates the exact fault of UPS, S-code list is shown as follow:

Description of S-Code

Seq.		Items	0	1	Solution
1	A0	Synchronous Fault	Sync	Not sync.	Check whether bypass voltage/frequency is normal
2		Main Input Fault	OK	Fault	Check whether input is normal
3		REC Fault	OK	Fault	REC over temperature, bus over voltage, input current unbalance, soft start fail
4		INV Fault	OK	Fault	INV over temperature, INV IGBT broken, INV relay fault
5		Reserved			
6		Reserved			
7		Reserved			
8		Reserved			
9		Reserved			
10		Reserved			
11		Reserved			
12		Reserved			
13		A1	Input phase A over current	OK	Fault
14	Input phase B over current		OK	Fault	
15	Input phase C over current		OK	Fault	
16	Output voltage Fault		OK	Fault	Check if inverter IGBT is broken, IGBT drivers are lost
17	Reserved				
18	Reserved				
19	Reserved				
20	Reserved				
21	Reserved				
22	Reserved				
23	Reserved				
24	Reserved				
25		Input voltage Fault	OK	Fault	Input voltage out of range
26		Input Frequency Fault	OK	Fault	Input frequency out of range
27		Input Sequence Fault	OK	Fault	Input sequence is wrong, check whether input wires connection is ok.
28		REC soft-start Fault	OK	Fault	Check whether rectifier SCR is broken, or SCR drivers are lost.
29		Reserved			

Seq.			Items	0	1	Solution
30		14	Reserved			
31		15	REC over temperature	OK	Fault	Check if the environmental temperature is over 40, if rectifier IGBTs is properly installed.
32		16	Positive bus over voltage	OK	Fault	UPS requires service
33	A2	1	Negative bus over voltage	OK	Fault	UPS requires service
34		2	Fan Fault	OK	Fault	At least one of fans fail.
35		3	Reserved			
36		4	Reserved			
37		5	Positive bus under voltage	OK	Fault	UPS requires service
38		6	Negative bus under voltage	OK	Fault	UPS requires service
39		7	Battery reversed	OK	Fault	Check if the battery wires connection is OK
40		8	Reserved			
41		9	Reserved			
42		10	Reserved			
43		11	Reserved			
44		12	Reserved			
45		13	Battery over temperature	OK	Fault	Check if environmental temp is too high or batteries life is over
46		14	Reserved			
47		15	Reserved			
48		16	Reserved			
49	A3	1	Battery voltage low	OK	Fault	
50		2	Reserved			
51		3	Battery EOD	OK	Fault	
52		4	Reserved			
53		5	Reserved			
54		6	Reserved			
55		7	BYP voltage Fault	OK	Fault	Check if bypass input voltage is normal
56		8	Bypass SCR or relay fault	OK	Fault	UPS requires service.
57		9	Reserved			
58		10	Reserved			
59		11	BYP frequency over track range	OK	Fault	Check if bypass input frequency is abnormal
60		12	Reserved			
61		13	Reserved			
62		14	Over load time out	OK	Fault	
63		15	Reserved			
64		16	Reserved			
65	A4	1	Manual shutdown	normal	shutdow n	

Seq.		Items	0	1	Solution
66		2 INV protect	OK	Fault	
67		3 Transfer times limit in one hour	OK	Fault	Transfer times between inverter and bypass is over 5 times in one hour
68		4 Reserved			
69		5 Reserved			
70		6 Reserved			
71		7 Reserved			
72		8 INV over temperature Fault	OK	Fault	Check if environmental temp is over 40°C, or fans are abnormal
73		9 Reserved			
74		10 Reserved			
75		11 Over load	OK	Over load	Check load level indicator and remove non-essential load. Recalculate the load and remove number of loads connected to UPS.
76		12 INV relay or fuse Fault	OK	Fault	Check if inverter relay is shorted or opened.
77		13 Reserved			
78		14 Parallel connection fault	OK	Fault	Check whether parallel connection cable disconnect.
79		15 Reserved			
80		16 Reserved			
81		1 Reserved			
82		2 Output shorted	OK	Fault	Shutdown UPS and open output breaker, check if load is effective or short internally, check if output connector is shorted.
83		3 Battery test	None	OK	2--Fault
84		4 Battery maintenance	None	OK	2--Fault
85		5 Reserved			
86		6 Reserved			
87	A5	7 Reserved			
88		8 Reserved			
89		9 Reserved			
90		10 Reserved			
91		11 Reserved			
92		12 Reserved			
93		13 Reserved			
94		14 Reserved			
95		15 Reserved			
96		16 Reserved			

### 5.3 Trouble shooting in else cases

Problem	Possible cause	Action
Battery discharging time diminishes	Battery not yet been fully charged.	Keep UPS connected to utility power persistently for more than 10 hours to recharge the batteries.
	UPS overloaded.	Check the loads and remove some non-critical loads.
	Battery aged.	Replace the batteries.
	Charger failed	Check the charger.
The UPS cannot power on after pressing the button	The button is pressed too briefly.	Press the button continuously for more than 2 seconds.
	Battery is not connected or battery voltage is too low, or Charger failed.	Check the charger and battery.

### 5.4 Failure Diagnosis

In this section, some debug skills are listed to help you finding the failure components and problems as soon as possible. Before continuing the following steps listed, we suggest that you should read problem shooting chart in previous section then check the components listed in **Quick Start** to find out which block is out of order, in order to shorten the service time

#### 5.4.1 Maintenance tools

- 1、 A computer with a serial port and a standard RS232 cable;
- 2、 A suitcase or a toolbox;
- 3、 Wire cutters and clamps;
- 4、 Balance equipments, current limiting resistors, a electric soldering iron, tubes and clamp terminals with different specifications;
- 5、 A multimeter and a oscilloscope (or current meter) ;

6、 Other tools in common use: Diagonal pliers、 Snipe nose pliers、 Cross screw drivers (150mm/75mm length), Straight screwdrivers (75mm length) and PVC insulating tapes etc;

7、 PCB and some other materials.

## 5.4.2 The Setting Method of Single UPS

Equipment:


One computer with a serial port;

One standard RS232 serial cable;

One multimeter;


### Parameter Setting Method:

1. Connect the RS232 port of the UPS to the serial port of the computer with a serial cable. The COM port is set "COM1" automatically and the other settings as Fig.1




**Fig.1**

2. After you chose UPS type, press "Connect", then UPS is connected with computer.




3. INV output voltage tiny regulation: Set "AdjustedOpVolt" values, then press the "ENTER" key, output voltage will rise (drop) .



4. INV output voltage setting: Type "OutputVoltXXX" command (XXX is 220/230/240), then press the "ENTER" key, INV output voltage will be set to 220V/230V/240V.

### Regulation Process for Single UPS



INV output voltage regulation: When the UPS run into the Inverter mode, measure the output voltage with the multimeter. Then regulate the output voltage to  $220 \pm 0.5V$  by using output voltage regulation command. (INV output voltage can be regulated about 0.8V every point by using output voltage regulation command).

#### Notes:

1. be sure the ground of the UPS connect earth safely while parameter regulation.
2. The new assembly UPS must be regulated.
3. The UPS who have been replaced CNTL/PSDR must be regulated again.
4. All the commands use capital letters.
5. All the above parameter regulation cannot be accumulated.
6. All the regulation will be saved in CPU of the CNTL. So if you want to re-regulate the CNTL, you should reset the CPU and clean all the parameters setting by the following commands:

---

---

BUSP+00

BUSN+00

V+0

After all the commands have been executed, CPU be reset and then we can re-regulate the UPS according to the above regulation process.

7. If you are not sure whether the CNTL has been regulated, reset before your regulation

### 5.4.3 Quick Start

Before any detail check of UPS, please check the components listed in the following table. This action could help you find problem quickly and make following debug procedures go smoothly.

**Note:** Make sure that the capacitor voltage is lower than the safety voltage before disassembling any parts before any checking operation.

<b>Related Circuit Block</b>	<b>Components to be checked</b>	<b>Component Type</b>	<b>Fail condition</b>
BAT FUSE	F2	Fuse	Open
I/P FUSE (on PSDR)	F1	Fuse	Open
PFC	D1,D2	Diode	Short or open
	Q3, Q4, Q5, Q6, Q7, Q8	IGBT	C-E short or open
	Q1,Q2	SCR	short
INV	6K slave board: Q4, Q6	IGBT	C-E short or open
	10K(S)/20K/15K master board: Q2, Q4, Q5,Q6		
Charger	Q1	MOSFET	D-S short or open



	D1, D2	Power Diode	Short or open
	D3	Rectifier	Short or open
	F1,F2,F3	Fuse	Open
SPS	Q10	MOSFET	D-S short or open
	D32, D47	Power Diode	Short or open
	F1	Fuse	Open



If the fuse is open, replacing fuse only **DOES NOT** mean you have solved the problem.

In most case, open of fuse is caused by other failure of components; therefore, before restart that UPS, you must find the real failure components and replace them!

## 1 . PFC Analysis:

Most problem of PFC can result to component damage: I/P Fuse, the IGBT, the DIODE, and the SCR and the driver resistor. When checked PFC Part, directly checked the IGBT with resistor probe or the DIODE with voltage probe with multimeter.

Item	Checked components		Instrument function	Reference Value	Failed condition
1	F1,F2		Resistance	About 0.4 $\Omega$	Open
2	Q1, Q2	(A, K)	Resistance	$\approx 1.4M\Omega$	Short
		(G, K)	Resistance	$\approx 30\Omega$	Short
	Q3, Q4, Q5, Q6, Q7, Q8	(E, C)	Resistance	$\approx 800k\Omega$	Short
		(G, E)	Resistance	47.5 k $\Omega$ (6KS) 15.8K $\Omega$	Short or open
3	Q3, Q4, Q5, Q6, Q7, Q8		Body Diode Voltage Droop	About 0.35V	Short or open
4	R120		Resistance	About 40 $\Omega$	Short

5	R118,R119		Resistance	About 33Ω	Short
6	D1, D2		Diode Voltage Droop	About 0.35V	Short or open
7	R8,R9,R11,R12,R13,R14		Resistance	10Ω	Infinite or value change
	R85,R86,R87,R88,R89,R90		Resistance	51KΩ	
8	Q14	(A, K)	Resistance	≈2.5MΩ	Short
		(G, K)	Resistance	≈30Ω	Short

## 2 . Inverter Analysis

The most likely problems occur on the INV Part includes: IGBT broken, and lead to damage of relative Snubber circuit, and output relay stick.

Item	Checked components		Instrument function	Reference Value	Failed Condition
1	D16, D17, D18		Diode Voltage Droop	About 0.36V	Short or open
2	6K(S): Q4, Q6	(C, E)	Resistance	100 KΩ	Short
		(G, E)	Resistance	51KΩ	
	10K(S): Q2, Q4, Q5, Q6	(C, E)	Resistance	100 KΩ	
		(G, E)	Resistance	25.5KΩ	
3	6K(S):	R50	Resistance	10Ω	Infinite or value change
		R49,R55, R56	Resistance	20Ω	
4	10K(S):	R50,R52	Resistance	10Ω	Infinite or value change
		R49,R51,R55, R56, R57, R58	Resistance	20Ω	
5	D9,D10		Diode Voltage Droop	About 0.36V	Short or open



If fail condition stated in item 3 occurs, it is very possible that the corresponding IGBT driver module is damaged, so please try to change the IGBT driver module.

### 3. SPS Analysis

Item	Checked components	Instrument function	Reference Value	Failed condition
1	Q10 (S, D)	Body Diode Voltage Droop	About 0.42V	Short or open
2	Q10 (G, S)	Resistance	About 46.8K $\Omega$	Short
3	F1,F2	Resistance	About 0.4 $\Omega$	Open
4	D38,D39,D59	Diode Voltage Droop	About 0.48V	Short or open
5	U11,U12,U13,U14	Resistance	About 1.44M $\Omega$	Short

### 4 . 1A Charger Module Analysis

Item	Checked components	Instrument function	Reference Value	Failed condition
1	Q1 (S, D)	Body Diode Voltage Droop	About 0.48V	Short or open
2	Q1	(G, S) Resistance	About 32.8K $\Omega$	Short
		(D, S) Resistance	About 10M $\Omega$	Short
3	F1, F2, F3	Resistance	About 0.4 $\Omega$	Open
4	D3,D5	Diode Voltage Droop	About 0.43V	Short or open

### 5 . 5A Charger Module Analysis

Ite m	Checked components	Instrument function	Reference Value	Failed condition
1	F1.F2.F3	Resistance	About 0.4 $\Omega$	Open

<b>Ite m</b>	<b>Checked components</b>		<b>Instrument function</b>	<b>Reference Value</b>	<b>Failed condition</b>
2	D1, D2, D3, D5,		Diode Voltage Droop	About 0.5V	Open/Short
3	Q1 (S→D)		Body Diode Voltage Droop	About 0.45V	Open/Short
4	Q1	(G, S)	Resistance	About 45KΩ	Short
		(D, S)	Resistance	About 3MΩ	Short

## 6. Test and Finish

After replace all defected components on power stage, following test the steps can be adopted to verify the repair result and the reliability of the UPS.

1. Connect all of boards, cable, and connector right to place.
2. Check the Wiring
3. Apply DC Power from power source with current limitation function to the BAT terminal on the PSDR
4. Press the ON-switch on front panel for more than 2 seconds until you hear the note ringing and loosen the button, you will see "current limit" for a short time on the DC power supply for about only 2 seconds, then UPS should be DC started, If UPS does not start successfully, no LED indicator is lightened. Please try diagnosing procedure again.
5. If UPS does not start up for several trying or DC power supply is on current-limit state continuously, there must be some defected components exists. Please follow trouble-shooting chart to debug again.
6. Stop the UPS; apply AC mains to the UPS module. Try on the UPS. If fail you may have start one new round of trouble shooting
7. Check and adjust Charging Voltage

- 
- 
8. Check the output voltage waveform and DC-offset voltage, at no-load and full load condition.