

# IP ACL Application Configuration

# Table of Contents

Chapter 1 Application of IP Access Control List .....	1
1.1 Applying the IP Access Control List .....	1
1.1.1 Applying ACL on Ports .....	1

# Chapter 1 Application of IP Access Control List

## 1.1 Applying the IP Access Control List

### 1.1.1 Applying ACL on Ports

After an ACL is established, it can be applied on one or many slots or globally.

Run the following command in global or port configuration mode:

Command	Purpose
<b>config</b>	Enters the global configuration mode.
<b>interface g0/1</b>	Enters the to-be-configured port.
<b>[no] {ip   ipv6} access-group name [egress   vlan {word   add word remove word}]</b>	<p>Applies the established IP/IPv6 access list to an interface or cancels it on the interface.</p> <p><b>Egress</b> means that the ACL is applied in an outbound direction.</p> <p><b>Vlan</b> means that the ACL is applied in an inbound VLAN.</p> <p><b>Word</b> stands for the VLAN range table.</p> <p><b>Add</b> means to add the VLAN range table.</p> <p><b>Remove</b> means to delete the VLAN range table.</p>
<b>exit</b>	Goes back to the global configuration mode.
<b>exit</b>	Goes back to the EXEC mode.
<b>write</b>	Saves the settings.