



Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router Hardware Installation Guide

First Published: 2016-10-17

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2017 Cisco Systems, Inc. All rights reserved.



CONTENTS

Preface

Preface ix

Document Revision History ix

Document Objectives ix

Audience ix

Document Organization x

Conventions xi

Related Documentation xii

Obtaining Documentation and Submitting a Service Request xii

CHAPTER 1

Overview 1

Hardware Features 1

Front View 3

Slot Numbering 4

Built-In SFP and SFP+ Ports 5

Management and Storage Connections 6

LEDs 7

Rear View 10

Cisco Product Identification Standard 11

Unique Device Identifier 11

Serial Number and PID/VID Label Location 14

CHAPTER 2

Supported Hardware Components 15

Supported EPAs 15

Supported NIMs 17

Supported Transceivers 17

Supported Crypto Module 20

Supported DIMM Upgrade 20

Power Supplies	21
AC Power Supply	22
DC Power Supply	23
Power Supply LEDs	25
Power Supply Fans	26
Power Cords	26

CHAPTER 3

Preparing Your Site for Installation	29
Prerequisites and Preparation	29
Site Planning Checklist	30
Safety Guidelines	30
Safety Warnings	31
Safety Recommendations	31
Cautions and Regulatory Compliance Statements for NEBS	31
Standard Warning Statements	32
General Safety Warnings	33
Site Planning	36
General Precautions	36
Site Selection Guidelines	37
Site Environmental Requirements	37
Physical Characteristics	38
Site Power Guidelines	39
Electrical Circuit Requirements	40
Site Cabling Guidelines	40
Console Port Connections	41
USB Serial Console	41
Interference Considerations	42
Electromagnetic Interference	42
Radio Frequency Interference	42
Lightning and AC Power Fault Interference	43
Rack-Mounting Guidelines	43
Precautions for Rack-Mounting	43
General Rack-Selection Guidelines	43
Guidelines for 23-in. (Telco) Racks	44
Equipment Rack Guidelines	44

- Locating for Safety 44
- Locating for Easy Maintenance 45
- Locating for Proper Airflow 45
- Preventing Electrostatic Discharge Damage 45
- Electrical Safety 46
- Chassis-Lifting Guidelines 47
- Tools and Equipment 47
- Unpacking and Verifying Shipping Contents 48
 - Checking the Shipping Container Contents 48
- Installation Checklist 49

CHAPTER 4**Installing the Router 51**

- Installation Methods 51
- Guidelines for a Standalone Equipment Shelf or Tabletop Installation 52
- Installing the Router on a Standalone Equipment Shelf or Tabletop 53
- Guidelines for Rack Installation 53
 - Verifying Rack Dimensions 55
- Attaching the Front Rack-Mount Brackets 55
- Attaching the Rear Rack-Mount Brackets 57
- Mounting the Router in the Rack 59
 - Two-Post Rack Installation 59
 - Four-Post Rack Installation 61
- Attaching the Cable Management Bracket 64
- Chassis Ground Connection 66
 - Recommended Tools and Supplies 66
 - Attaching a Chassis Ground Connection 67
- Connecting Cables 69
 - Connecting the Console and Auxiliary Port Cables 70
 - Connecting to the Mini USB Console Port 71
 - Management Ethernet Port Cable Connection 71

CHAPTER 5**Power Up and Initial Configuration 73**

- Checking Conditions Prior to System Startup 73
- Powering Up the Router 74
- Performing the Initial Configuration on the Router 76

Using the Cisco setup Command Facility	76
Completing the Configuration	79
Using the Cisco IOS-XE CLI—Manual Configuration	80
Configuring the Router Hostname	81
Configuring the Enable and Enable Secret Passwords	82
Configuring the Console Idle Privileged EXEC Timeout	83
Gigabit Ethernet Management Interface Overview	84
Default Gigabit Ethernet Configuration	84
Configuring Gigabit Ethernet Interfaces	84
Saving Your Router Configuration	86
Verifying the Initial Configuration	86
Powering Off the Router Safely	87
Environmental Monitoring and Reporting Functions	87
Alarm Monitoring	88
Environmental Monitoring	89
Fan Failures	89
Reporting Functions	90

CHAPTER 6**License Verification 97**

Viewing the Cisco IOS License Level	97
Viewing License Information	98
Port Licensing	103
Port Licensing for the Cisco ASR 1001-HX Router	103
Licensing Scenarios for Cisco ASR 1001-HX Router	105
Port Licensing for the Cisco ASR 1002-HX Router	106
Licensing Scenarios for Cisco ASR 1002-HX Router	108
Evaluation License Features	109
Configuring the Crypto Throughput Level	109

CHAPTER 7**Removing and Replacing FRUs 111**

Removing and Replacing the Crypto Modules	111
Removing and Replacing the Crypto Module in a Cisco ASR 1001-HX Router	112
Removing and Replacing the Crypto Module in a Cisco ASR 1002-HX Router	114
Removing AC Power Supplies	115
Installing AC Power Supplies	116

Removing DC Input Power Supplies	116
Installing DC Input Power Supplies	117
Wiring the DC Input Power Source	118
Removing and Replacing USB Flash Memory Stick	120
Removing and Replacing a DIMM	120
Removing a DIMM from a Cisco ASR 1001-HX Router	121
Replacing a DIMM in a Cisco ASR 1001-HX Router	124
Removing a DIMM from a Cisco ASR 1002-HX Router	126
Replacing a DIMM in a Cisco ASR 1002-HX Router	129
Removing and Replacing an EPA	131
Electrostatic Discharge Prevention	131
Removing an EPA	132
Replacing an EPA	133
Removing and Replacing a NIM	133
Removing a NIM	134
Replacing a NIM	135
Removing and Replacing Fans	135
Removing the Fans from a Cisco ASR 1001-HX Router	135
Replacing the Fans in a Cisco ASR 1001-HX Router	138
Removing the Fans from a Cisco ASR 1002-HX Router	140
Replacing the Fans in a Cisco ASR 1002-HX Router	143
Repacking the Router	144

APPENDIX A**Technical Specifications 145**

Cisco ASR 1001-HX Router Specifications	145
Cisco ASR 1002-HX Router Specifications	146

APPENDIX B**Port Signals and Pinouts 147**

Management Ethernet Port Signals and Pinouts	147
Console Port Signals and Pinouts	147
Auxiliary Port Signals and Pinouts	148



Preface

- [Document Revision History](#), page ix
- [Document Objectives](#), page ix
- [Audience](#), page ix
- [Document Organization](#), page x
- [Conventions](#), page xi
- [Related Documentation](#), page xii
- [Obtaining Documentation and Submitting a Service Request](#), page xii

Document Revision History

The following table records the changes made to this document.

Date	Change Summary
October 2016	Added the Cisco ASR 1001-HX Router.
May 2016	First version of the document.

Document Objectives

This publication describes the installation of the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router and replacement or upgrade of field-replaceable units (FRUs).

Audience

This publication is primarily designed for persons responsible for installing, maintaining, and troubleshooting the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router. The users of this guide should:

- Be familiar with electronic circuitry and wiring practices.
- Have experience working as electronic or electromechanical technicians.
- Have experience in installing high-end networking equipment.

**Note**

Certain procedures described in this guide require a certified electrician.

Document Organization

The following table describes the chapters and appendixes in this installation guide:

Chapter and Appendix		Description
1	Overview	Provides an overview of the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router
2	Supported Hardware Components	Provides an overview of the hardware components for the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router
3	Preparing Your Site for Installation	Provides site preparation guidelines for installing the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router
4	Installing the Router	Provides information about the installation methods and steps to install the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router
5	Power Up and Initial Configuration	Provides basic system startup and initial configuration information
6	License Verification	Provides information about the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router licenses
7	Removing and Replacing FRUs	Provides instructions for removing and replacing the various FRUs in the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router
A	Technical Specifications	Provides router specifications for the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router
B	Port Signals and Pinouts	Lists pinout specifications for the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router

Conventions

Text Type	Indication
User input	Text the user should enter exactly as shown or keys a user should press appear in this font.
Document titles	Document titles appear in <i>this font</i> .
System output	Terminal sessions and information that the system displays appear in <i>this font</i> .
CLI commands	CLI command keywords appear in this font . Variables in a CLI command appear in <i>this font</i> .
[]	Elements in square brackets are optional.
{x y z}	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
< >	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
! #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.


Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the document.


Tip

Means *the following information will help you solve a problem*. The tips information might not be troubleshooting or even an action, but could be useful information, similar to a Timesaver.


Caution

Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.

**Timesaver**

Means *the described action saves time*. You can save time by performing the action described in the paragraph.

**Warning****IMPORTANT SAFETY INSTRUCTIONS**

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

SAVE THESE INSTRUCTIONS

Related Documentation

See the following documentation for Cisco ASR 1001-HX Router:

- *Release Notes for Cisco ASR 1000 Series, Cisco IOS XE Denali 16.3*
- *Open Source Used In Cisco ASR 1001-HX Router*
- *Cisco IOS XE Denali 16.3 Migration Guide for Access and Edge Routers*

See the following documentation for Cisco ASR 1002-HX Router:

- *Release Notes for Cisco ASR 1000 Series, Cisco IOS XE Denali 16.2*
- *Open Source Used In Cisco ASR 1002-HX Router*
- *Cisco IOS XE Denali 16.2 Migration Guide for Access and Edge Routers*

The [Documentation Roadmap for Cisco ASR 1000 Series, Cisco IOS XE Denali 16.x](#) provides links to all Cisco ASR 1000 Series product documentation.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly [What's New in Cisco Product Documentation](#), which also lists all new and revised Cisco technical documentation.

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.



Overview

The Cisco ASR 1000 Series Aggregation Services Routers are mid-range edge routers that establish a new price-to-performance class offering benefits to both enterprise and service providers alike. The Cisco ASR 1000 Series Aggregation Services Routers portfolio is based on an innovative custom-built ASIC called Quantum Flow Processor that aggregates services at scale.

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router are a part of the Cisco ASR 1000 Series and offers a compact form factor that consumes less rack space and power while offering 100 Gbps forwarding throughput. The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router support all the general-purpose routing and security features of the Cisco ASR 1000 Series Aggregation Services Routers.

- [Hardware Features, page 1](#)
- [Cisco Product Identification Standard, page 11](#)
- [Serial Number and PID/VID Label Location, page 14](#)

Hardware Features

The Cisco ASR 1001-HX Router supports:

- Up to 16 GB (8 GB in the base configuration) of DDR3 error-correcting code-protected field-replaceable memory, with single-bit error correction and multi-bit error detection.
- A fixed forwarding processor with up to 60 Gbps sustained forwarding data traffic through the chassis.
- Up to 20 Gbps security and crypto processing through a dedicated security processor.
- RJ-45 console ports and auxiliary ports, and a mini USB console port.
- 32 GB internal bootflash storage.
- One copper Ethernet 10/100/1000 Mbps network management port.
- An embedded USB (eUSB) flash module that supports 32 GB of nonvolatile Flash storage.
- Two USB 2.0 ports for USB flash sticks.
- Eight built-in 1 GE SFP ports in Bay 0; eight built-in 10 GE SFP+ ports in Bay 1 (capable of SyncE and MACsec); and the last four ports in Bay 1 can be used as 1 GE by inserting a 1 GE SFP port.
- Stratum 3E network clocking per GR-1244-CORE, using 10 GE, or 1 GE interfaces as timing sources.

- Software redundancy using Dual IOS, similar to all the other non-hardware redundant routers from the Cisco ASR 1000 Series Aggregation Services Router family.
- LED indicators for Ethernet and console status, as well as visual system state indications.
- Command-line interface (CLI), alarm, network management, logging, statistics aggregation, and on-board failure logging (OBFL).
- Environmental chassis management.
- 80 Mb ternary content-addressable memory (TCAM).
- Field-replaceable units (FRU).
See Chapter 2, [Supported Hardware Components](#) for information on supported FRUs.
- Field-replaceable Crypto Processor.


The Cisco ASR 1002-HX Router supports:

- Up to 32 GB (16 GB in the base configuration) of DDR3 error-correcting code-protected field-replaceable memory, with single-bit error correction and multi-bit error detection.
- A fixed forwarding processor with up to 100 Gbps sustained forwarding data traffic through the chassis.
- Up to 25 Gbps security and crypto processing through a dedicated security processor.
- RJ-45 console ports and auxiliary ports, and a mini USB console port.
- 32 GB internal bootflash storage.
- One copper Ethernet 10/100/1000 Mbps network management port.
- An embedded USB (eUSB) flash module that supports 32 GB of nonvolatile Flash storage.
- Two USB 2.0 ports for USB flash sticks.
- Eight built-in 1 GE SFP-only interfaces, and eight built-in 10 GE SFP+ interfaces that support SyncE.
- One Ethernet Port Adapter (EPA) bay.
- One Network Interface Module (NIM) bay (supports one single-wide or one double-wide NIM).
- Stratum 3E network clocking per GR-1244-CORE, using 1 GE, 10 GE, or EPA interfaces as timing sources.
- Software redundancy using Dual IOS, similar to all the other non-hardware redundant routers from the Cisco ASR 1000 Series Aggregation Services Router family.
- LED indicators for Ethernet and console status, as well as visual system state indications.
- Command-line interface (CLI), alarm, network management, logging, statistics aggregation, and on-board failure logging (OBFL).
- Environmental chassis management.
- 80 Mb ternary content-addressable memory (TCAM).
- Field-replaceable units (FRU) with online insertion and removal (OIR).
See Chapter 2, [Supported Hardware Components](#) for information on supported FRUs.

Front View

The following figure shows the front of the Cisco ASR 1001-HX Router.

Figure 1: Cisco ASR 1001-HX Router Front View



1	AUX—RJ-45/RS-232 compatible auxiliary port	5	MGMT—RJ-45 10/100/1000 management Ethernet port
2	CON—RJ-45/RS-232 compatible console port	6	Bay 0—1GE SFP ports
3	CON—Mini USB console port	7	Bay 1—The first four ports are strictly 10GE SFP+ ports. The last four ports can be used as 1GE SFP or 10GE SFP+ ports
4	USB ports 0 and 1		




Note

For the Cisco ASR 1001-HX Router, the power supplies (PEM 0 and PEM1), are located in the rear of the chassis. See [Rear View](#), on page 10.

The following figure shows the front of the Cisco ASR 1002-HX Router.

Figure 2: Cisco ASR 1002-HX Router Front View



1	Power supply (PEM 0)	8	AUX—RJ-45/RS-232 compatible auxiliary port
2	Power supply (PEM 1)	9	BITS—RJ-48 Building Integrated Timing Supply port Note The BITS port is not supported in this software release.
3	Power (PWR) switch	10	Bay 3—NIM slot
4	USB ports 0 and 1	11	Bay 2—EPA slot
5	CON—Mini USB console port	12	Bay 1—10GE SFP+ ports
6	CON—RJ-45/RS-232 compatible console port	13	Bay 0—1GE SFP ports
7	MGMT—RJ-45 10/100/1000 management Ethernet port		

Two power supplies (AC or DC) are accessed from the front of the router and are hot-swappable.



Caution


The Cisco ASR 1002-HX Router can support two AC or two DC power supplies. Do not install mixed AC and DC power supply units in the same chassis.

Slot Numbering

The Cisco ASR 1002-HX Router supports one Ethernet port adapter (EPA) in Bay 2 and one NIM in Bay 3 (for one single-wide or one double-wide NIM).

The following figure shows slot numbering on the Cisco ASR 1002-HX Router.

Figure 3: Cisco ASR 1002-HX Router Slot Numbering




1	Bay 0—Subslot 0/0/n connected to the built-in 1GE SFP interfaces	3	Bay 2—Subslot 0/2/n connected to the EPA interfaces See Supported EPAs , on page 15.
2	Bay 1—Subslot 0/1/n connected to the built-in 10GE SFP+ interfaces	4	Bay 3—Subslot 0/3 connected to the NIM interfaces

Built-In SFP and SFP+ Ports


The following figure shows the port numbering for the built-in ports.

Figure 4: Cisco ASR 1001-HX Router Port Numbering



1	Bay 0—The ports in Bay 0 use 1GE SFP transceivers and are labeled GE0 - GE7.	2	Bay 1—Ports TE4 - TE7 use 1GE SFP and ports TE0 - TE3 use 10GE SFP+ transceivers.
---	--	---	---

Figure 5: Cisco ASR 1002-HX Router Port Numbering



1	Bay 0—The ports in Bay 0 use 1GE SFP transceivers and are labeled GE0 - GE7.	2	Bay 1— The ports in Bay 1 use 10GE SFP+ transceivers and are labeled TE0 - TE7.
3	Bay 2—EPA Slot		



Note

Interfaces from 0 - 3 on both Bay 0 and Bay 1 on the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router are enabled by default. Interfaces from 4 - 7 can be enabled by purchasing the Paired Port License.


The port LEDs behave as follows:

- Off—Indicates the port is not enabled by software.
- Amber—Indicates the port is enabled by software but there is a problem with the link.
- Green—Indicates the port is enabled by software and there is valid link.

Management and Storage Connections

The following figure shows the management and storage connections for the ASR 1001-HX Router.


Figure 6: Management and Storage Connections for the Cisco ASR 1001-HX Router



1	AUX—RJ-45/RS-232 compatible auxiliary port.	4	USB port 1
2	CON—RJ-45/RS-232 compatible console port.	5	USB port 0
3	CON—Mini USB connector console port.	6	MGMT—RJ-45 10/100/1000 management Ethernet port.

The following figure shows the management and storage connections for the ASR 1002-HX Router.

Figure 7: Management and Storage Connections for the Cisco ASR 1002-HX Router




1	USB port 0	4	MGMT—RJ-45 10/100/1000 management Ethernet port.
2	USB port 1	5	CON—RJ-45/RS-232 compatible console port.
3	CON—Mini USB connector console port.	6	AUX—RJ-45/RS-232 compatible auxiliary port.

LEDs

The following figure shows the LEDs on the front panel of the Cisco ASR 1001-HX Router.


Figure 8: Cisco ASR 1001-HX LEDs



No.	LED Label	Description	Color	Behavior
1	STATUS	Status	Green	Cisco IOS has successfully booted.
			Amber	The system is at ROMMON.
			Red	System failure.
2	PWR	Power	Green	All the power supplies are within operational limits.
3	MAJ	Major alarm	Red	Major alarm indicator.
4	CRIT	Critical alarm	Red	Critical alarm indicator.
5	MIN	Minor alarm	Amber	Minor alarm indicator.
6	EN	USB console enable	Green	Indicates that the mini USB connector is used as the console.
			Off	Indicates that the RJ-45 connector is being used as the console.
7	LINK	Management	Blinking green	Indicates the negotiated Ethernet speed (1 blink equals 10 Mbps, 2 blinks equals 100 Mbps, 3 blinks equals 1000 Mbps).
			Off	Not connected.
8	IP-SEC	Crypto module	Green	Indicates the crypto module is present and operational.
			Amber	Indicates the crypto module is present but inoperable.
			Off	Indicates the crypto module is not installed.

The following figure shows the LEDs on the front panel of the Cisco ASR 1002-HX Router.

Figure 9: Cisco ASR 1002-HX LEDs




No.	LED Label	Description	Color	Behavior
1	STATUS	Status	Green	Cisco IOS has successfully booted.
			Amber	The system is at ROMMON.
			Red	System failure.
2	PWR	Power	Green	All the power supplies are within operational limits.
3	CRIT	Critical alarm	Red	Critical alarm indicator.
4	MAJ	Major alarm	Red	Major alarm indicator.
5	MIN	Minor alarm	Amber	Minor alarm indicator.
6	EN	USB console enable	Green	Indicates that the mini USB connector is used as the console.
			Off	Indicates that the RJ-45 connector is being used as the console.
7	LINK	Management	Blinking green	Indicates the negotiated Ethernet speed (1 blink equals 10 Mbps, 2 blinks equals 100 Mbps, 3 blinks equals 1000 Mbps).
			Off	Not connected.
8	BITS	Building Integrated Timing Supply (BITS)	Off	The BITS port is not supported in this software release.

No.	LED Label	Description	Color	Behavior
9	IP-SEC	Crypto module	Green	Indicates the crypto module is present and operational.
			Amber	Indicates the crypto module is present but inoperable.
			Off	Indicates the crypto module is not installed.

Rear View

The following figure shows the rear of the Cisco ASR 1001-HX Router.

Figure 10: Cisco ASR 1001-HX Router Rear View



1	Fans	3	Power supply (PEM 0)
2	Power supply (PEM 1)	4	Power/standby switch


The chassis has a front-to-rear airflow. Six internal fans draw cooling air into the chassis and across internal components to maintain an acceptable operating temperature. The fans are numbered from 0 to 5, right to left. Two power supplies (AC or DC) are accessed from the rear of the router and are hot-swappable.

**Caution**

The Cisco ASR 1001-HX Router can support two AC or two DC power supplies. Do not install mixed AC and DC power supply units in the same chassis.

The following figure shows the rear of the Cisco ASR 1002-HX Router.

Figure 11: Cisco ASR 1002-HX Router Rear View



The chassis has a front-to-rear airflow. Four internal fans draw cooling air in through the front of the chassis and across internal components to maintain an acceptable operating temperature. The fans are located at the rear of the chassis. The fans are numbered from 0 to 3, right to left.

**Caution**

The power supplies used in Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router are different and they should not be mixed or swapped. The size and structural dimensions are the same, therefore they both look alike. It would be hazardous if you accidentally inserted the wrong power supply into the PEM slot.

Cisco Product Identification Standard

This section describes the Cisco products and services product identification standard. This feature provides you with the ability to effectively integrate and manage Cisco products in your network and business operations.

Unique Device Identifier

The Unique Device Identifier (UDI) is the Cisco product identification standard for hardware products. A product identification standard removes barriers to enterprise automation and can help you reduce operating expenses.

The UDI provides a consistent electronic, physical, and associated business-to-business information product identification standard.

The UDI is a combination of five data elements. The following table lists the UDI elements.

Table 1: UDI Elements

UDI Data Element	Electronic Visibility	Physical Visibility	Description
PID	Yes	Yes	Product ID, also known as product name, model name, product number
VID	Yes	Yes	Version ID
SN	Yes	Yes	Serial number, the unique instance of the PID
Entity Name	Yes	—	Type, such as chassis, slot, or power supply
Product Description	Yes	—	Additional product information

The combination of serial number and product ID (PID) is unique and consistent across all Cisco products. The PID that is coded on hardware is called a base product identifier.

Additional orderable PIDs can be associated to a base PID. For instance, an orderable PID may describe a packaging configuration for a product or a bundled group of products sold, tested, and shipped together. Specific unique device identifier (UDI) benefits include the following:

- Identifies:
 - Individual Cisco products in your networks
 - PIDs and serial numbers for service and replaceable products
 - Version IDs (VIDs) for product version visibility
- Facilitates discovery of products subject to recall or upgrade
- Enhances inventory automation of Cisco products

The Cisco product identification standard provides the following features:

- Version visibility—Cisco continuously improves products through feature additions. Product changes are indicated by incrementing the VID, which provides version visibility to help you understand and manage product changes. VID management ensures consistency of changes from product to product.
- Operating expense reduction—Cisco UDIs provide accurate and detailed network inventory information; identifying each Cisco product in a network element through a standard interface. Cisco operating systems can view and use this data, allowing you to automate your electronic inventory.
- Consistency across product layers—The UDIs are embedded in the hardware products and cannot be overwritten. Operating and management systems discover UDIs through standard interfaces and display UDIs in standard outputs. Standard interfaces include the IETF standard ENTITY-MIB.

show diag chassis eeprom detail Command

The **show diag chassis eeprom** command displays the PID, VID, PCB serial number, hardware revision, and other such information.

The following is sample output from the **show diag chassis eeprom** command:

```
Router# show diag chassis eeprom
MIDPLANE EEPROM data:

    Product Identifier (PID) : ASR1002-HX
    Version Identifier (VID) : V00
    PCB Serial Number       : JAE1931098U
    Top Assy. Part Number   : 68-5448-02
    Hardware Revision       : 0.3
    Asset ID                :
    CLEI Code               : SAMPL00XYZ
```

**Note**

Common Language Equipment Identification (CLEI) code is a ten-digit character code that identifies a specific product. A CLEI code is applied to each part within a Cisco ASR1002-HX Router as they are programmed in manufacturing for shipment to customers.

show license udi Command

The **show license udi** command displays UDI information.

The following is sample output from the **show license udi** command:

```
Router# show license udi

SlotID  PID                SN                UDI
-----
*       ASR1002-HX          JAE1931098U      ASR1002-HX:JAE1931098U
```


**Note**

For complete information on the product identification standard, see <http://www.cisco.com/go/udi/>.

Serial Number and PID/VID Label Location


The following figures show the location of the serial number and the PID/VID label on the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router.

Figure 12: Cisco ASR 1001-HX Router Serial Number and PID/VID Label Location



1	Serial Number	2	PID/VID Label
---	---------------	---	---------------

Figure 13: Cisco ASR 1002-HX Router Serial Number and PID/VID Label Location



1	Serial Number	2	PID/VID Label
---	---------------	---	---------------



Supported Hardware Components

This chapter contains information about the supported hardware components on the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router, and contains the following sections:

- [Supported EPAs, page 15](#)
- [Supported NIMs, page 17](#)
- [Supported Transceivers, page 17](#)
- [Supported Crypto Module, page 20](#)
- [Supported DIMM Upgrade, page 20](#)
- [Power Supplies, page 21](#)

Supported EPAs

The following table lists the supported EPAs on the Cisco ASR 1002-HX Router.

PID	Description
EPA-18X1GE	Eighteen 1GE-ports that support small form-factor pluggable (SFP) optical transceivers to provide network connectivity. Ports are numbered 0 – 17. See Table 3: Supported SFP Transceivers, on page 18 for supported transceivers.
EPA-10X10GE	Ten 10GE-ports that support small form-factor pluggable (SFP+) optical transceivers to provide network connectivity. Ports are numbered 0 – 9. See Table 4: Supported SFP+ Transceivers, on page 19 for supported transceivers.

PID	Description
EPA-6X10GE	EPA-6X10GE uses small form-factor pluggable (SFP+) optical transceivers to provide network connectivity. Ports are numbered 0 – 5. See Table 4: Supported SFP+ Transceivers, on page 19 for supported transceivers.
EPA-1X100GE	EPA-1X100GE uses a CPAK module to provide network connectivity. See Table 5: Supported CPAK Interface, on page 19 for supported CPAKs.
EPA-CPAK-2X40GE	EPA-CPAK-2X40GE uses a CPAK module and a 2x40 GE breakout cable to provide network connectivity See Table 5: Supported CPAK Interface, on page 19 for supported CPAKs.

An EPA has two types of LEDs: an A/L (Active/Link) LED for each port on the EPA, and a STATUS LED, as shown in the following figure.

Figure 14: EPA-18X10GE LEDs





Figure 15: EPA-10X10GE LEDs



1	A/L	2	STATUS
---	-----	---	--------

Table 2: EPA LEDs

Function	Color or State	Description
A/L (Active/Link)	Green	Port is enabled and the link is up.
	Amber	Port is enabled and the link is down.
	Off	Port is not enabled.
Status	Green	EPA is ready and operational.
	Amber	EPA power is on and good, and the EPA is being configured.
	Off	EPA power is off.

Related Topics

[Removing and Replacing an EPA, on page 131](#)

Supported NIMs

The following table lists the supported NIMs on the Cisco ASR 1002-HX router.

PID	Description
NIM-SSD	The solid state drive (SSD) carrier card network interface module (NIM) enables SSD support on the platform NIM slot. It provides flash storage to the platform and supports dual 2.5" (7mm max) SATA SSDs. The carrier card fits into the NIM slot in the router. The router supports only a single SSD Carrier Card NIM.

Supported Transceivers

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router support the following small form-factor pluggable (SFP) and CPAK optical transceiver types:

Bay	Ports	Cisco ASR 1001-HX Router	Cisco ASR 1002-HX Router
Bay 0	Ports GE0 – GE7	SFP	SFP

Bay	Ports	Cisco ASR 1001-HX Router	Cisco ASR 1002-HX Router
Bay 1	Ports TE4 - TE7 use 1GE SFP Ports TE0 - TE3 use 10GE SFP+	SFP or SFP+	SFP+
Bay 2	EPA-18X1GE — Ports 0 – 17 EPA-10X10GE — Ports 0 – 9 EPA-1X100GE — Port 0 EPA-CPAK-2X40GE — Port 0 - 1	—	SFP SFP+ CPAK CPAK
Bay 3	NIM -SSD	—	Supported from Cisco IOS XE Fuji 16.7.1.

Table 3: Supported SFP Transceivers

PID	Description
GLC-GE-100FX	100BASE-FX SFP transceiver module, MMF, 1310nm
GLC-SX-MMD	1000BASE-SX SFP transceiver module, MMF, 850nm, DOM
GLC-LH-SMD	1000BASE-LX/LH SFP transceiver module, MMF/SMF, 1310nm, DOM
SFP-GE-T	1000BASE-T SFP (NEBS 3 ESD)
GLC-BX-U	1000BASE-BX SFP, 1310nm
GLC-BX-D	1000BASE-BX SFP, 1490nm
GLC-TE	1000BASE-T SFP transceiver module for category 5 copper wire
GLC-SX-MM	GE SFP, LC connector SX transceiver
GLC-LH-SM	GE SFP, LC connector LX/LH transceiver
GLC-EX-SMD	GE SFP, LC Connector, EX transceiver
GLC-ZX-SMD	1000BASE-ZX SFP transceiver module, SMF, 1550nm, DOM
DWDM-SFP	1000BASE DWDM
CWDM-SFP	1000BASE CWDM

Table 4: Supported SFP+ Transceivers

PID	Description
SFP-10G-SR	10GBASE-SR SFP+ Module for MMF
SFP-10G-SR-X	10GBASE-SR SFP+ Module for Extended Temp range
SFP-10G-LR	10GBASE-LR SFP+ Module for SMF
SFP-10G-LR-X	10GBASE-LR SFP+ Module for Extended Temp range
SFP-10G-ER	10GBASE-ER SFP+ Module for SMF
SFP-H10GB-ACU7M	10GBASE-CU SFP+ Cable 7 Meter, active
SFP-H10GB-ACU10M	10GBASE-CU SFP+ Cable 10 Meter, active
DWDM-SFP10G-C	10GBASE DWDM SFP+ Tunable Optic

The following table lists the supported CPAK transceivers that can be used in the EPA-1x100GE Ethernet port adapter.

Table 5: Supported CPAK Interface

PID	Description
CPAK-100G-SR10	<p>CPAK 100GBASE-SR10</p> <p>Delivers 100-Gbps links over 24-fiber ribbon cables terminated with MPO/MTP connectors. It supports link lengths of 100m and 150m on laser-optimized OM3 and OM4 multifiber cables. OTN rates are also supported.</p>
CPAK-100G-LR4	<p>CPAK 100GBASE-LR4</p> <p>Supports 100-Gbps optical links over standard single-mode fiber (SMF, G.652) terminated with SC connectors. Nominal power consumption is less than 5.5W.</p> <p>The LR4 module is IEEE 802.3ba-compliant and supports link lengths of up to 10 km over standard SMF, G.652. It delivers an aggregate data signal of 100-Gbps, carried over four wavelength-division multiplexing (WDM) wavelengths operating at a nominal 25 Gbps per lane in LAN mode. OTU4 rate is also supported. Optical multiplexing and demultiplexing of the four wavelengths are managed within the module.</p>

PID	Description
CPAK-100G-SR4	CPAK 100G-SR4 Delivers 100-Gbps links for multi mode fiber, short wavelength over 4 lanes, in the 850-nm wavelength window, MPO-12 connector with up to 70m on OM3 / 100m on OM4 reach per IEEE 802.3ba requirements

Supported Crypto Module

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router support the following crypto module:

PID	Description
ASR1001HX-IPSECHW	Cisco ASR1001-HX crypto module with no default crypto throughput. You can upgrade the throughput (8 Gbps or 16 Gbps) by applying a software-activated performance upgrade license.
ASR1002HX-IPSECHW	Cisco ASR1002-HX crypto module with no default crypto throughput. You can upgrade the throughput (8 Gbps, 16 Gbps, or 25 Gbps) by applying a software-activated performance upgrade license.

Related Topics

[Removing and Replacing the Crypto Module in a Cisco ASR 1001-HX Router, on page 112](#)

[Removing and Replacing the Crypto Module in a Cisco ASR 1002-HX Router, on page 114](#)

Supported DIMM Upgrade

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router support the following DIMM upgrade:

PID	Description
M-ASR1001HX-16GB	The Cisco ASR 1001-HX Router has two DIMM slots and supports 8-GB configuration by default (two 4-GB DIMMS), and can be upgraded to 16-GB (two 8-GB DIMMS) configuration.
M-ASR1002HX-32GB	The Cisco ASR 1002-HX Router has four DIMM slots and supports 16-GB configuration by default (two 8-GB DIMMS), and can be upgraded to 32-GB (four 8-GB DIMMS) configuration.

Related Topics

[Removing and Replacing a DIMM, on page 120](#)

Power Supplies

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router support AC or DC power supply options. The modular chassis configurations support the installation of two power supplies for redundancy. When an external power supply fails or is removed, the other power supply provides power requirements for the chassis. This allows you to hot-swap the power supply without impacting the functionality of the router.


Caution

A router can support two AC or two DC power supplies. Do not install mixed AC and DC power supply units in the same chassis.


Caution

The power supplies used in Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router are different and they should not be mixed or swapped. The size and structural dimensions are the same, therefore they both look alike. It would be hazardous if you accidentally inserted the wrong power supply into the PEM slot.

The power supplies are used in a 1 + 1 redundant configuration. There is no input switch on the faceplate of the power supplies. A power supply is switched from Standby to On by way of a system chassis power switch.

The following table lists the power supplies that you can order:

Part Number	Power Supply
ASR1000X-AC-750W	Cisco ASR 1002-HX Router power supply module with plug-side intake airflow, A/C, 750W, 85–264V
ASR1000X-AC-750W=	Cisco ASR 1002-HX Router power supply module with plug-side intake airflow, A/C, 750W, 85–264V, spare
ASR1000X-DC-950W	Cisco ASR 1002-HX Router power supply module with plug-side intake airflow, DC 950W
ASR1000X-DC-950W=	Cisco ASR 1002-HX Router power supply module with plug-side intake airflow, DC 950W, spare
ASR1000X-AC-750W-R	Cisco ASR 1001-HX Router power supply module with plug-side exhaust airflow, A/C, 750W, 85–264V
ASR1000X-AC-750W-R=	Cisco ASR 1001-HX Router power supply module with plug-side exhaust airflow, A/C, 750W, 85–264V, spare
ASR1000X-DC-950W-R	Cisco ASR 1001-HX Router power supply module with plug-side exhaust airflow, DC 950W
ASR1000X-DC-950W-R=	Cisco ASR 1001-HX Router power supply module with plug-side exhaust airflow, DC 950W, spare

**Caution**

The chassis has a front-to-rear airflow. All of the power supplies and fan modules in the chassis must use the same airflow direction or an error will occur with possible overheating and shut down of the router. If you power up the router with more than one airflow direction, you must power down the router and replace the modules with the wrong airflow direction before powering up the router.

Related Topics

[Removing and Replacing the Power Supplies](#)

AC Power Supply

**Caution**


The power supplies used in Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router are different and they should not be mixed or swapped. The size and structural dimensions are the same, therefore they both look alike. It would be hazardous if you accidentally inserted the wrong power supply into the PEM slot.

**Note**

The direction of the airflow is different for the Cisco ASR 1001-HX Router and the Cisco ASR 1002-HX Router as shown by the arrows in the illustrations below.

The following figure shows the Cisco ASR 1001-HX Router AC power supply.


Figure 16: ASR1000X-AC-750W AC Power Supply Used in the Cisco ASR 1001-HX Router



1	AC power connector	3	FAIL and OK LEDs
2	Handle		Retaining latch

The following figure shows the Cisco ASR 1002-HX Router AC power supply.

Figure 17: ASR1000X-AC-750W AC Power Supply Used in the Cisco ASR 1002-HX Router



1	AC power connector	3	FAIL and OK LEDs
2	Handle		Retaining latch

DC Power Supply

The ASR1000X-DC-950W input connector is a two-wire connector with connection polarity from left to right (when facing the unit) of positive (+) negative (-).

The power supply has a handle to be used for insertion and extraction. The module must be supported with one hand because of its length.



Caution

The power supplies used in Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router are different and they should not be mixed or swapped. The size and structural dimensions are the same, therefore they both look alike. It would be hazardous if you accidentally inserted the wrong power supply into the PEM slot.




Note

The direction of the airflow is different for the Cisco ASR 1001-HX Router and the Cisco ASR 1002-HX Router as shown by the arrows in the illustrations below.

The following figure shows the Cisco ASR 1001-HX Router DC power supply.


Figure 18: ASR1000X-DC-950W DC Power Supply Used in the Cisco ASR 1001-HX Router



1	DC power connections	3	FAIL and OK LEDs
2	Handle		Retaining latch

The following figure shows the Cisco ASR 1002-HX Router DC power supply.

Figure 19: ASR1000X-DC-950W DC Power Supply Used in the Cisco ASR 1002-HX Router



1	DC power connections	3	FAIL and OK LEDs
2	Handle		Retaining latch

Power Supply LEDs

The following table describes the power supply LEDs.

Table 6: AC and DC Power Supply LEDs

Power Supply Condition	Green (OK) LED Status	Amber (FAIL) LED Status
No AC power to all power supplies	OFF	OFF
Power Supply Failure (includes over voltage, over current, over temperature and fan failure)	OFF	ON
Power Supply Warning events where the power supply continues to operate (high temperature, high power and slow fan)	OFF	1Hz Blinking

Power Supply Condition	Green (OK) LED Status	Amber (FAIL) LED Status
AC Present/3.3VSB on (PSU OFF)	1Hz Blinking	OFF
Power Supply ON and OK	ON	OFF

Power Supply Fans

The fans in the power supply module are used for cooling the power supply module itself while system-level cooling is provided by fans within the chassis. The power supplies do not depend on the system-level fans for cooling. Fan failure is determined by fan-rotation sensors.



Note

The fans in the Cisco ASR 1001-HX Router power supplies have plug-side exhaust airflow. The fans in the Cisco ASR 1002-HX Router power supplies have plug-side intake airflow.



Caution

The chassis has a front-to-rear airflow. All of the power supplies and fan modules in the same chassis must use the same airflow direction or an error will occur with possible overheating and shut down of the router. If you power up the router with more than one airflow direction, you must power down the router and replace the modules with the wrong airflow direction before powering up the router.



Note

The fans in the power supply modules will run as soon as the power supply is plugged in, even if the power switch is in the Standby position.

Power Cords

The following table lists the supported power cords.

Power Cord Item Number	Description
CAB-AC	Power Cord, 110 V
CAB-ACA Plug	Power Cord, Australia, 10 A
CAB-ACC	Power Cord, China
CAB-ACE AC	Power Cord, Europe, C13, CEE 7, 1.5 M
CAB-ACI AC	Power Cord, Italy, C13, CEI 23-16, 2.5 m
CAB-ACR AC	Power Cord, Argentina, C13, EL 219 (IRAM 2073), 2.5m
CAB-ACS AC	Power Cord, Switzerland, C13, IEC 60884-1, 2.5 m

Power Cord Item Number	Description
CAB-ACU AC	Power Cord, UK, C13, BS 1363, 2.5 m
CAB-IND AC	Power Cord, India
CAB-JPN AC	Power Cord, Japan, C13, JIS C 8303, 2.5 m
CAB-L620P-C13-US	Power Cord, 250 VAC, 15A, NEMA L6-20 to C13, U.S.
CAB-L620P-C13-JPN	Power Cord, 250 VAC, 15A, NEMA L6-20 to C13, Japan
CAB-C13-CBN Cabinet Jumper	Power Cord, 250 VAC 10 A, C14-C13 Connectors
CAB-C13-C14-JMPR Cabinet Jumper	Power Cord, 250 VAC 13 A, C14-C15 Connector
CAB-C13-C14-2M	Power Cord Jumper, C13-C14 Connectors, 2-Meter Length
CAB-C13-C14-AC	Power Cord Jumper, C13-C14 Connectors, 3-Meter Length



Preparing Your Site for Installation

This chapter contains important safety information you should know before working with the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router, and guides you through the process of preparing your site for router installation.

- [Prerequisites and Preparation, page 29](#)
- [Safety Guidelines, page 30](#)
- [Cautions and Regulatory Compliance Statements for NEBS, page 31](#)
- [Standard Warning Statements, page 32](#)
- [Site Planning, page 36](#)
- [Preventing Electrostatic Discharge Damage, page 45](#)
- [Electrical Safety, page 46](#)
- [Chassis-Lifting Guidelines, page 47](#)
- [Tools and Equipment, page 47](#)
- [Unpacking and Verifying Shipping Contents, page 48](#)
- [Installation Checklist, page 49](#)

Prerequisites and Preparation

Before you perform the procedures in this guide, we recommend that you:

- Read the safety guidelines in the next section and review the electrical safety and ESD-prevention guidelines in this guide.
- Ensure that you have all of the necessary tools and equipment (see the "[Tools and Equipment](#)" section).
- Ensure that you have access to the *Cisco ASR 1000 Series Aggregation Services Routers Software Configuration Guide* (an online document that is available for viewing or download at Cisco.com) during the installation.
- Ensure that the power and cabling requirements are in place at your installation site.

- Ensure that the equipment required to install the router is available.
- Ensure that your installation site meets the environmental conditions to maintain normal operation.

Before installing the router, you must consider power and cabling requirements that must be in place at your installation site, special equipment for installing the router, and the environmental conditions your installation site must meet to maintain normal operation.

The shipping package for the router is engineered to reduce the chances of product damage associated with routine material handling experienced during shipment:

- Router should always be transported or stored in its shipping package in the upright position.
- Keep the router in the shipping container until you have determined the installation site.

**Note**

Inspect all items for shipping damage. If an item appears damaged, contact a Cisco customer service representative immediately.

Site Planning Checklist

Use the following checklist to perform and account for all the site-planning tasks described in this chapter:

- The site air conditioning system can compensate for the heat dissipation of the router.
- Electrical service to the site complies with the requirements.
- The electrical circuit servicing the router complies with the requirements.
- Consideration has been given to console port wiring and limitations of the cabling involved, according to TIA/EIA-232F.
- The Ethernet cabling distances are within limitations.
- The equipment rack in which you plan to install the router chassis complies with requirements. Careful consideration has been given to safety, ease of maintenance, and proper airflow in selecting the location of the rack.

Safety Guidelines

Before you begin the installation or replacement procedure, review the safety guidelines in this section to avoid injuring yourself or damaging the equipment.

**Note**

This section contains guidelines, and do not include every potentially hazardous situation. When you install a router, always use common sense and caution.

Safety Warnings

Safety warnings appear throughout this publication in procedures that, if performed incorrectly, might harm you. A warning symbol precedes each warning statement.

Before you install, configure, or perform maintenance on the router, review the documentation for the procedure you are about to perform, paying special attention to the safety warnings.



Note

Do not unpack the system until you are ready to install it. Keep the chassis in the shipping container to prevent accidental damage until you determine an installation site. Use the appropriate unpacking documentation included with the system.

Read the installation instructions in this document before you connect the system to its power source. Failure to read and follow these guidelines could lead to an unsuccessful installation and possibly damage the system and components.

Safety Recommendations

The following guidelines will help to ensure your own safety and protect your Cisco equipment. This list does not cover all potentially hazardous situations, so *be alert*.

- Cisco safety policy mandates that all its routers must conform to the requirements of IEC 60950, with appropriate national deviations, as a minimum. In addition, Cisco routers must also meet the requirements of any other normative documents, for example, standards, technical specifications, laws or regulations.
- Review the safety warnings listed in *Regulatory Compliance and Safety Information for the Cisco ASR 1000 Series Aggregation Services Routers* (available online at Cisco.com) before installing, configuring, or maintaining the router.
- Never attempt to lift an object that might be too heavy for you to lift by yourself.
- Always turn all power supplies off and unplug all power cables before opening the chassis.
- Always unplug the power cable before installing or removing a chassis.
- Keep the chassis area clear and dust free during and after installation.
- Keep tools and chassis components away from walk areas.
- Do not wear loose clothing, jewelry (including rings and chains), or other items that could get caught in the chassis. Fasten your tie or scarf and sleeves.
- The router operates safely when it is used in accordance with its marked electrical ratings and product-usage instructions.

Cautions and Regulatory Compliance Statements for NEBS

The following table lists cautions, regulatory compliance statements, and requirements for the Network Equipment Building System (NEBS) certification from the Telcordia Electromagnetic Compatibility and Electrical Safety – Generic Criteria for Network Telecommunications Equipment (A Module of LSSGR,

FR-64; TSGR, FR-440; and NEBSFR, FR-2063) Telcordia Technologies Generic Requirements, GR-1089-CORE.

Attach an ESD-preventive wrist strap to your wrist and to a bare metal surface.

Caution The intrabuilding ports of the equipment or subassembly are only suitable for connection to intrabuilding or unexposed wiring or cabling. The intrabuilding ports of the equipment or subassembly must not be metalically connected to interfaces that connect to the OSP or its wiring. These interfaces are designed for use only as intrabuilding interfaces (Type 2 or Type 4 ports as described in GR-1089-CORE), and require isolation from the exposed OSP cabling. The addition of primary protectors is not sufficient protection to connect these interfaces metalically to OSP wiring.

Products that have an AC power connection are intended for deployments where an external surge protective device (SPD) is used at the AC power service equipment as defined by the National Electric Code (NEC).

This product is designed for a common bonding network (CBN) installation.

This product can be installed in a network telecommunication facility or location where the NEC applies.

An electrical conducting path shall exist between the product chassis and the metal surface of the enclosure or rack in which it is mounted or to a grounding conductor. Electrical continuity shall be provided by using thread-forming type mounting screws that remove any paint or nonconductive coatings and establish a metal-to-metal contact. Any paint or other nonconductive coatings shall be removed on the surfaces between the mounting hardware and the enclosure or rack. The surfaces shall be cleaned and an antioxidant applied before installation.

The grounding architecture of this product is DC-isolated (DC-I).

DC-powered products have a nominal operating DC voltage of 48 VDC. Minimal steady-state DC operating voltage is 40.5 VDC. Reference American National Standards Institute (ANSI) T1.315, Table 1.

Standard Warning Statements



Note

The English warnings in this document are preceded by a statement number. To see the translations of a warning in other languages, look up its statement number in the *Regulatory Compliance and Safety Information for the Cisco ASR 1000 Series Aggregation Services Routers*.

This section describes the warning definition and then lists core safety warnings grouped by topic.

**Warning****Statement 1071—Warning Definition****IMPORTANT SAFETY INSTRUCTIONS**

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

SAVE THESE INSTRUCTIONS

General Safety Warnings

**Warning****Statement 1004—Installation Instructions**

Read the installation instructions before connecting the system to the power source.

**Warning****Statement 1040—Product Disposal**

Ultimate disposal of this product should be handled according to all national laws and regulations.

**Warning****Statement 1073—No User-Serviceable Parts**

No user-serviceable parts inside. Do not open.

**Warning****Statement 1074—Comply with Local and National Electrical Codes**

Installation of the equipment must comply with local and national electrical codes.

**Warning****Statement 1030—Equipment Installation**

Only trained and qualified personnel should be allowed to install, replace, or service this equipment.

**Warning****Statement 1005—Circuit Breaker**

This product relies on the building's installation for short-circuit (overcurrent) protection. Ensure that the protective device is rated not greater than:

AC:

- 20 A U.S. maximum (ASR 1001-HX Router and ASR 1002-HX Router)

DC:

- 20 A U.S. maximum (ASR 1001-HX Router)
- 30 A U.S. maximum (ASR 1002-HX Router)

**Warning****Statement 1045—Short-circuit Protection**

This product requires short-circuit (overcurrent) protection to be provided as part of the building installation. Install only in accordance with national and local wiring regulations.

**Warning****Statement 1028—More Than One Power Supply**

This unit might have more than one power supply connection. All connections must be removed to de-energize the unit.

**Warning****Statement 1017—Restricted Area**

This unit is intended for installation in restricted access areas. A restricted access area can be accessed only through the use of a special tool, lock and key, or other means of security.

**Warning****Statement 1019—Main Disconnecting Device**

The plug-socket combination must be accessible at all times, because it serves as the main disconnecting device.

**Warning****Statement 1086—Power Terminals, Replace Cover**

Hazardous voltage or energy may be present on power terminals. Always replace cover when terminals are not in service. Be sure uninsulated conductors are not accessible when cover is in place.

**Warning****Statement 1025—Use Copper Conductors Only**

Use copper conductors only.



Warning **Statement 1024**—Ground Conductor

This equipment must be grounded. Never defeat the ground conductor or operate the equipment in the absence of a suitably installed ground conductor. Contact the appropriate electrical inspection authority or an electrician if you are uncertain that suitable grounding is available.



Warning **Statement 1034**—Backplane Voltage

Hazardous voltage or energy is present on the backplane when the system is operating. Use caution when servicing.



Warning **Statement 1008**—Class 1 Laser Product

Class 1 laser product.



Warning **Statement 1027**—Class 1 LED Product

Class 1 LED product.



Warning **Statement 1009**—Laser Radiation

Laser radiation is present when the system is open.



Warning **Statement 1010**—Staring into Laser Beam

Do not stare into the laser beam.



Warning **Statement 1055**—Class I and Class 1M Laser

Class I (CDRH) and Class 1M (IEC) laser products.



Warning **Statement 1056**—Unterminated Fiber Cable

Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not view directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard.

**Warning****Statement 1015**—Battery Handling

There is the danger of explosion if the battery is replaced incorrectly. Replace the battery only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

**Warning****Statement 341**—Metal Contacts on the Battery

Do not touch or bridge the metal contacts on the battery. Unintentional discharge of the batteries can cause serious burns.

**Warning****Statement 1032**—Lifting the Chassis

To prevent personal injury or damage to the chassis, never attempt to lift or tilt the chassis using the handles on modules (such as power supplies, fans, or cards); these types of handles are not designed to support the weight of the unit.

**Warning****Statement 1047**—Overheating Prevention

To prevent the system from overheating, do not operate it in an area that exceeds the maximum recommended ambient temperature of:

104° F (40° C)

**Warning****Statement 1029**—Blank Faceplates and Cover Panels

Blank faceplates and cover panels serve three important functions: they prevent exposure to hazardous voltages and currents inside the chassis; they contain electromagnetic interference (EMI) that might disrupt other equipment; and they direct the flow of cooling air through the chassis. Do not operate the system unless all cards, faceplates, front covers, and rear covers are in place.

Site Planning

This section contains site-planning information, and will help you plan for the installation of the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router.

General Precautions

Observe the following general precautions when using and working with the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router:

- Keep your system components away from radiators and heat sources and do not block cooling vents.

- Do not spill food or liquids on your system components and never operate the product in a wet environment.
- Do not push any objects into the openings of your system components. Doing so can cause fire or electric shock by shorting out interior components.
- Position system cables and power supply cable carefully. Route system cables and power supply cable and plug such that they cannot be stepped on or tripped over. Be sure that nothing else rests on your system component cables or power cable.
- Do not modify power cables or plugs. Consult a licensed electrician or your power company for site modifications. Always follow your local and national wiring rules.
- If you turn off your system, wait at least 30 seconds before turning it on again to avoid system component damage.

Site Selection Guidelines

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router require specific environmental operating conditions. Temperature, humidity, altitude, and vibration can affect the performance and reliability of the router. The following sections provide specific information to help you plan for a proper operating environment.

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router are designed to meet the industry EMC, safety, and environmental standards described in the *Regulatory, Safety, and Compliance Information for Cisco ASR 1000 Series Aggregation Services Routers* document.

Site Environmental Requirements

Environmental monitoring protects the system and components from damage caused by excessive voltage and temperature conditions. To ensure normal operation and avoid unnecessary maintenance, plan and prepare your site configuration before installation. After installation, make sure the site maintains the environmental characteristics, as shown in the following table.

Table 7: Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router Environmental Tolerance

Environmental Characteristic	Minimum	Maximum
Operating temperature (nominal)	32° F (0° C)	104° F (40° C) (40° C up to 10,000 feet)
Operating temperature (short term)	32° F (0° C)	122° F (50° C)
Storage temperature	-4° F (-20° C)	158° F (70° C)
Operative humidity (nominal) (relative humidity)	10%	90%
Operative humidity (short term)	5%	90%
Storage humidity (relative humidity)	5%	95%

Environmental Characteristic	Minimum	Maximum
Altitude, operating: over allowable temperature range (0 to 50 degrees C)	–500 feet (–152.4 meters)	6,000 feet (1829 meters)
Altitude, nonoperating: over allowable temperature range	–1000 feet (–304.8 meters)	50,000 feet (15240 meters)
Thermal shock nonoperating with change over time of 3 minutes	–13° F (–25° C)	158° F (70° C)
Thermal Shock - Operating at 2.5 degree C per minute	32° F (0° C)	122° F (50° C)

Physical Characteristics

Be familiar with the physical characteristics of the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router to assist you in placing the system at a proper location.



Note

For information regarding rack widths supported for the router, see the following sections:

- [General Rack-Selection Guidelines](#), on page 43
- [Guidelines for 23-in. \(Telco\) Racks](#), on page 44

The following table shows the weight and dimensions of the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router:

Table 8: Physical Characteristics of the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router

Characteristic	Cisco ASR 1001-HX Router	Cisco ASR 1002-HX Router
Height	1.72 in. (43.69 mm)—1RU; rack-mount per EIA RS-310	3.5 in. (88.9 mm)—2RU; rack-mount per EIA RS-310
Width	17.3 in. (439.42 mm)	17.3 in. (439.42 mm)
Depth	21.78 in. (553.2 mm) Depth includes card handles, cable-management brackets, and power-supply handles	22.0 in. (558.8 mm) Depth includes card handles, cable-management brackets, and power-supply handles
Weight	23 lb (10.43 kg) fully loaded	34 lb (15.42 kg) fully loaded

The following list describes additional characteristics:

- Chassis height meets EIA-310 rack spacing, universal rack mount
 - Cisco ASR 1001-HX Router—1RU (1.75 in. or 44.45 mm)
 - Cisco ASR 1002-HX Router—2RU (3.5 in. or 88.9 mm)
- Chassis width meets EIA-310 19 in. (17.3 in. or 439.42 mm) wide with rack brackets
- Cable-management brackets allow a bend radius of 1.5 in. (38.1 mm) for cables
- Ships with forward rack-mount brackets installed and an extra set included in the accessory kit

Site Power Guidelines

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router has specific power and electrical wiring requirements. Adhering to these requirements ensures reliable operation of the system. Follow these precautions and recommendations when planning your site for the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router:

- The redundant power option provides a second, identical power supply to ensure that power to the chassis continues uninterrupted if one power supply fails or input power on one line fails.
- In systems configured with the redundant power option, connect each of the two power supplies to a separate input power source. If you fail to do this, your system might be susceptible to total power failure due to a fault in the external wiring or a tripped circuit breaker.
- To prevent a loss of input power, be sure the total maximum load on each circuit supplying the power supplies is within the current ratings of the wiring and breakers.
- Check the power at your site before installation, and periodically after installation, to ensure that you are receiving clean power. Install a power conditioner if necessary.
- Provide proper grounding to avoid personal injury and damage to the equipment due to lightning striking power lines or due to power surges. The chassis ground must be attached to a central office or other interior ground system.



Caution

This product requires short-circuit (overcurrent) protection to be provided as part of the building installation. Install only in accordance with national and local wiring regulations.



Note

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router installation must comply with all applicable codes and is approved for use with copper conductors only. The ground bond fastening hardware should be of compatible material and preclude loosening, deterioration, and electrochemical corrosion of hardware and joined material. Attachment of the chassis ground to a central office or other interior ground system must be made with an AWG #6 gauge wire, copper ground conductor at a minimum.

Electrical Circuit Requirements

Each Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router requires a dedicated electrical circuit. If you equip it with dual-power feeds, you must provide a separate circuit for each power supply to avoid compromising the power redundancy feature.

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router can be powered by a DC or AC source. Ensure that equipment grounding is present and observe power-strip ratings. Make sure that the total ampere rating of all the products plugged into the power strip does not exceed 80 percent of the rating.



Note

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router can support two AC or two DC power supplies. Do not install mixed AC and DC power supply units in the same chassis.

The following table contains specifications for DC-powered systems for the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router.

Table 9: Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router DC Power Supply System Input Requirements

System Input Rating (Amps)	Circuit Breaker Amps		AWG # Wire
	Minimum	Maximum	
26	35	50	10



Note

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router AC power supply requires a 20 A circuit breaker.

The following table lists AC and DC power supply system rating requirements for the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router.

Table 10: AC and DC Power Supply System Rating Specifications for the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router

Description	Specification
Power supply declared ratings	AC = 85–264 VAC DC = –40–72 VDC
Line frequency rating	50/60 Hz for AC power supplies

Site Cabling Guidelines

This section contains guidelines for wiring and cabling at your site. When preparing your site for network connections to the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router, consider the type of cable

required for each component, and the cable limitations. Consider the distance limitations for signaling, EMI, and connector compatibility. Possible cable types are fiber, thick or thin coaxial, foil twisted-pair cabling, or unshielded twisted-pair cabling.

Also consider any additional interface equipment you need, such as transceivers, hubs, switches, modems, channel service units (CSUs), or data service units (DSUs).

Before you install the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router, have all the additional external equipment and cables at hand. For ordering information, contact a Cisco customer service representative.

The extent of your network and the distances between network interface connections depend in part on the following factors:

- Signal type
- Signal speed
- Transmission medium

The distance and rate limits referenced in the following sections are the IEEE-recommended maximum speeds and distances for signaling purposes. Use this information as guidelines when planning your network connections prior to installing the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router.

If wires exceed recommended distances, or if wires pass between buildings, give special consideration to the effect of a lightning strike in your vicinity. The electromagnetic pulse caused by lightning or other high-energy phenomena can easily couple enough energy into unshielded conductors to destroy electronic devices. If you have had problems of this sort in the past, you may want to consult experts in electrical surge suppression and shielding.

Console Port Connections

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router provide console and auxiliary ports to connect a terminal or computer for local console access.

Both ports have RJ-45 connectors, support RS-232 asynchronous data, and have distance recommendations specified in the IEEE RS-232 standard.

USB Serial Console

The USB serial console port connects directly to the USB connector of a PC using a USB Type A to 5-pin mini USB Type-B cable. The USB Console supports full speed (12Mbps) operation. The console port does not support hardware flow control.



Note

- Always use shielded USB cables with a properly terminated shield. The USB serial console interface cable must not exceed 3 meters in length.
- Only one console port can be active at a time. When a cable is plugged into the USB console port, the RJ-45 port becomes inactive. Conversely, when the USB cable is removed from the USB port, the RJ-45 port becomes active.
- 4-pin mini USB Type-B connectors are easily confused with 5-pin mini USB Type-B connectors. Only 5-pin mini USB Type-B is supported.

Interference Considerations

When wires are run for a significant distance, there is a risk that stray signals will be induced on the wires as interference. If interference signals are strong, they can cause data errors or damage to the equipment.

The following sections describe sources of interference and how to minimize its effects on the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router.

Electromagnetic Interference

All the equipment powered by AC current can propagate electrical energy that can cause electromagnetic interference (EMI) and possibly affect the operation of other equipment. The typical sources of EMI are equipment power cords and power service cables from electric utility companies.

Strong EMI can destroy the signal drivers and receivers in the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router and even create an electrical hazard by causing power surges through power lines into installed equipment. These problems are rare, but could be catastrophic.

To resolve these problems, you need specialized knowledge and equipment, which could consume substantial time and money. However, you should ensure that you have a properly grounded and shielded electrical environment, paying special attention to the need for electrical surge suppression.

The following table lists electrode magnetic compliance standards for the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router.

Table 11: EMC and Safety Standards

EMC Standards	FCC 47 CFR Part 15 Class A VCCI Class A AS/NSZ Class A ICES-003 Class A EN55022/CISPR 22 Information Technology Equipment (Emissions) EN55024/CISPR 24 Information Technology Equipment (Immunity) EN300 386 Telecommunications Network Equipment (EMC) EN50082-1/EN61000-6-1 Generic Immunity Standard
Safety Standards	UL60950-1 CSA C22.2 No. 60950-1-03 EN 60950-1 IEC 60950-1 AS/NZS 60950.1

Radio Frequency Interference

When electromagnetic fields act over a long distance, radio frequency interference (RFI) can be propagated. Building wiring can often act as an antenna, receiving the RFI signals and creating more EMI on the wiring.

If you use twisted-pair cable in your plant wiring with a good distribution of grounding conductors, the plant wiring is unlikely to emit radio interference. If you exceed the recommended distances, use a high-quality twisted-pair cable with one ground conductor for each data signal.

Lightning and AC Power Fault Interference

If signal wires exceed recommended cabling distances, or if signal wires pass between buildings, you should consider the effect that a lightning strike in your vicinity might have on the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router.

The electromagnetic pulse (EMP) generated by lightning or other high-energy phenomena can couple enough energy into unshielded conductors to damage or destroy electronic equipment. If you have previously experienced such problems, you should consult with RFI/EMI experts to ensure that you have adequate electrical surge suppression and shielding of signal cables in your Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router operating environment.

Rack-Mounting Guidelines

This section describes guidelines on rack-mounting.

Precautions for Rack-Mounting

The following rack-mounting guidelines are provided to ensure your safety:

- Do not move large racks by yourself. Due to the height and weight of a rack, a minimum of two people are required to accomplish this task.
- Ensure that the rack is level and stable before extending a component from the rack.
- Ensure that proper airflow is provided to the components in the rack.
- Do not step or stand on any component or system when servicing other systems or components in a rack.
- When mounting the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.
- If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack.

General Rack-Selection Guidelines

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router can be mounted in most two-post or four-post, 19-in. equipment racks that comply with the Electronics Industries Association (EIA) standard for equipment racks (EIA-310-D 19-in.). The rack must have at least two posts with mounting flanges to mount the chassis.

**Caution**

When mounting a chassis in any type of rack equipment, ensure that the inlet air to the chassis does not exceed 131°F (55°C).

The distance between the center lines of the mounting holes on the two mounting posts must be 18.31 in. \pm 0.06 in. (46.50 cm \pm 0.15 cm). The rack-mounting hardware included with the chassis is suitable for most 19-in. (48.3-cm) equipment racks.

Consider installing the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router in a rack with the following features:

- NEBS-compliant, 19-in. (48.3-cm) wide rack.
- EIA or ETSI hole patterns in the mounting rails. Required mounting hardware is shipped with the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router. If the rack that you plan to install the system in has metric-threaded rails, you must provide your own metric-mounting hardware.
- Perforated top and open bottom for ventilation to prevent overheating.
- Leveling feet for stability.


Note

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router should *not* be installed in an enclosed rack because the chassis requires an unobstructed flow of cooling air to maintain acceptable operating temperatures for its internal components. Installing the router in any type of enclosed rack—even with the front and back doors removed—could disrupt the air flow, trap heat next to the chassis, and cause an overtemperature condition inside the router. If you use an enclosed rack, make certain that there are air vents on all sides of the rack and there is proper ventilation.

Guidelines for 23-in. (Telco) Racks

If needed, you can also install the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router in 23-in. (Telco) racks. For information on the adapters needed for 23 in. racks, contact the Newton Instrument Company:

<http://www.ewton.com>

111 East A Street, Butner NC, USA, 27509

919 575-6426

Equipment Rack Guidelines

The placement of racks can affect personnel safety, system maintenance, and the system's ability to operate within the environmental characteristics described in [Table 7: Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router Environmental Tolerance](#), on page 37. Choose a proper location for the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router by following the guidelines below.

Locating for Safety

If the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router is the heaviest or the only piece of equipment in the rack, consider installing it at or near the bottom to ensure that the rack's center of gravity is as low as possible.

For additional information about the proper placement of electronic equipment, see the document *GR-63-CORE, Network Equipment Building System (NEBS) Requirements: Physical Protection*.

Locating for Easy Maintenance

Keep at least 3 feet of clear space in front of and behind the rack. This space ensures that you can remove the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router components and perform routine maintenance and upgrades easily.

Avoid installing the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router in a congested rack and consider how the routing of cables from other pieces of equipment in the same rack might affect access to the routers cards.

The front and top of the chassis must remain unobstructed to ensure adequate airflow and prevent overheating inside the chassis.

Allow the following clearances for normal system maintenance:

- At the top of the chassis—At least 3 in. (7.6 cm)
- In front of the chassis—3 to 4 ft (91.44 cm to 121.92 cm)

To avoid problems during installation and ongoing operation, follow these general precautions when you plan the equipment locations and connections:

- Use the **show environment all** and the **show facility-alarm status** commands regularly to check the internal system status. The environmental monitor continually checks the interior chassis environment; it provides warnings for high temperature and creates reports on any occurrences. If warning messages are displayed, take immediate action to identify the cause and correct the problem. For more information on these commands, see the "[Environmental Monitoring and Reporting Functions](#)" section.
- Keep the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router off the floor and out of the areas that collect dust.
- Follow ESD-prevention procedures to avoid damage to equipment. Damage from static discharge can cause immediate or intermittent equipment failure.

Locating for Proper Airflow

Ensure that the location of the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router has enough airflow to keep the system operating within the environmental characteristics, and the air temperature is sufficient to compensate for the heat dissipated by the system.

Avoid locating the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router in a location in which the chassis air intake vents could draw in the exhaust air from adjacent equipment. Consider how the air flows through the router. The airflow direction is front to back with ambient air drawn in from the venting located on the chassis' front sides.

Preventing Electrostatic Discharge Damage

Electrostatic discharge (ESD) damage occurs when electronic cards or components are improperly handled resulting in complete or intermittent failures. Static electricity can harm delicate components inside your system. To prevent static damage, discharge static electricity from your body before you touch any of your system components, such as a microprocessor. As you continue to work on your system, periodically touch an unpainted metal surface on the computer chassis.

The following are guidelines for preventing ESD damage:

- Always use an ESD-preventive wrist or ankle strap and ensure that it makes good skin contact. Before removing a card from the chassis, connect the equipment end of the strap to the ESD plug at the bottom of the chassis below the power entry modules.
- Handle line cards by faceplates and carrier edges only; avoid touching the card components or connector pins.
- When removing a module, place the removed module component-side-up on an antistatic surface or in a static-shielding bag. If the module is to be returned to the factory, immediately place it in a static-shielding bag.
- Avoid contact between the modules and clothing. The wrist strap protects the card from ESD voltages only on the body; ESD voltages on clothing can still cause damage.
- When transporting a sensitive component, place it in an antistatic container or packaging.
- Handle all sensitive components in a static-safe area. If possible, use antistatic floor pads and workbench pads.

**Caution**

For safety, periodically check the resistance value of the antistatic strap. The measurement should be between 1 and 10 ohms.

**Caution**

Always tighten the captive installation screws on all the system components when you are installing them. These screws prevent accidental removal of the module, provide proper grounding for the system, and help ensure that the bus connectors are properly seated in the backplane.

Electrical Safety

All the system components are hot-swappable. They are designed to be removed and replaced while the system is operating, without presenting an electrical hazard or damage to the system.

Follow these basic guidelines when you are working with any electrical equipment:

- Before beginning any procedures requiring access to the chassis interior, locate the emergency power-off switch for the room in which you are working.
- Disconnect all power and external cables before installing or removing a chassis.
- Do not work alone when potentially hazardous conditions exist.
- Never assume that power has been disconnected from a circuit; always check.
- Do not perform any action that creates a potential hazard to people or makes the equipment unsafe. Never install equipment that appears damaged.
- Carefully examine your work area for possible hazards such as moist floors, ungrounded power extension cables, and missing safety grounds.

In addition, use the following guidelines when working with any equipment that is disconnected from a power source, but is still connected to telephone wiring or other network cabling:

- Never install telephone wiring during a lightning storm.

- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.

**Warning****Statement 1001—Work During Lightning Activity**

Do not work on the system or connect or disconnect cables during periods of lightning activity.

Chassis-Lifting Guidelines

The chassis is not intended to be moved frequently. Before you install the system, ensure that your site is properly prepared so that you can avoid having to move the chassis later to accommodate power sources and network connections.

Each time you lift the chassis or any heavy object, follow these guidelines:

- Ensure that your footing is solid, and balance the weight of the chassis between your feet.
- Lift the chassis slowly; never move suddenly or twist your body as you lift.
- Keep your back straight and lift with your legs, not your back. If you must bend down to lift the chassis, bend at the knees, not at the waist, to reduce the strain on your back muscles.
- Do not remove installed components from the chassis.
- Always disconnect all external cables before lifting or moving the chassis.

Tools and Equipment

The following tools and equipment are recommended as the minimum necessary equipment to install the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router. You may need additional tools and equipment to install associated equipment and cables. You may also require test equipment to check electronic and optical signal levels, power levels, and communications links.

- Phillips hand screwdriver
- 3.5-mm flat-blade screwdriver
- Tape measure (optional)
- Level (optional)
- Power drill
- 8-gauge wire
- Rack-mount brackets
- Cable-management brackets

Unpacking and Verifying Shipping Contents

When you receive your chassis, perform the following steps and use the shipping contents checklist in the following section.

Procedure

-
- Step 1** Inspect the box for any shipping damage. (If there is damage, contact your Cisco service representative).
- Step 2** Unpack the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router.
- Step 3** Perform a visual inspection of the chassis.
- Step 4** After you have unpacked the system, verify that you have received all of the required components, including all the accessory items. Using the packing list as a guide, verify that you have received all the equipment listed in your order, and ensure that the configuration matches the packing list.
-

Checking the Shipping Container Contents

Use the components list shown in the following table to check the contents of the Cisco ASR 1001-HX Router Cisco ASR 1002-HX Router shipping container. Do not discard the shipping container. You need the container if you move or have to ship the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router in the future.

Table 12: Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router Shipping Container Contents

Component	Description
Chassis	Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router are configured with dual AC or dual DC power supplies and an EPA and NIM blank panel if an EPA or NIM has not been ordered.
Accessories Kit	Front chassis rack-mount brackets that you will attach to the chassis with their respective screws
Note You must order the Accessories Kit separately if you order the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router chassis as a spare.	Two sets of screws, one each for: <ul style="list-style-type: none"> • Front rack-mount brackets (4 screws for each bracket) • Cable-management brackets (2 mounting screws for each ASR 1002-HX bracket. The ASR 1001-HX bracket has captive screws for mounting to the rack-mount brackets.
	Two cable-management brackets with U-feature design devices attached.
	1 RJ-45 to RJ-45 crossover cable 1 RJ-45 to DB-9 (female) adapter
ESD, Wrist Strap (disposable)	One disposable wrist strap

Component	Description
Documentation	Pointer Doc
Optional Equipment	Power cord if an AC power supply was shipped. There are none for the DC power supply units.

Installation Checklist

To assist you with your installation and to provide a historical record of what was done by whom, print or photocopy the Installation Checklist below. Use this to record when each procedure or verification is completed. When the checklist is completed, place it in your site log along with the other records for your new router.

Table 13: Installation Checklist

Task	Verified By	Date
Date chassis received		
Chassis and all accessories unpacked		
Types and numbers of interfaces verified		
Safety recommendations and guidelines reviewed		
Installation Checklist copied		
Site log established and background information entered		
Site power voltages verified		
Site environmental specifications verified		
Required passwords, IP addresses, device names, and so on, available		
Required tools available		
Network connection equipment available		
Cable-management brackets installed (optional, but recommended)		
AC power cable(s) connected to AC source(s) and router		

Task	Verified By	Date
DC power cable(s) connected to DC source(s) and router		
Network interface cables and devices connected		
System power turned on		
System boot complete (STATUS LED is on)		
Ethernet port adapters and NIMs (where applicable) are operational		
Correct hardware configuration displayed after system banner appears		
Correct licenses installed on the router		



Installing the Router

This chapter provides procedures for installing the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router on an equipment shelf, tabletop, or in an equipment rack.

- [Installation Methods, page 51](#)
- [Guidelines for a Standalone Equipment Shelf or Tabletop Installation, page 52](#)
- [Installing the Router on a Standalone Equipment Shelf or Tabletop, page 53](#)
- [Guidelines for Rack Installation, page 53](#)
- [Attaching the Front Rack-Mount Brackets, page 55](#)
- [Attaching the Rear Rack-Mount Brackets, page 57](#)
- [Mounting the Router in the Rack, page 59](#)
- [Attaching the Cable Management Bracket, page 64](#)
- [Chassis Ground Connection, page 66](#)
- [Connecting Cables, page 69](#)

Installation Methods

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router are designed for standalone, 2-rail 19-inch rack-mount (front rail only), and 4-rail 19-inch rack-mount (front and rear rail) installations.

Although rack-mounting is the preferred method of installation, you can mount the chassis on an equipment shelf or tabletop.

**Warning****Statement 1071**—Warning Definition

IMPORTANT SAFETY INSTRUCTIONS

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

SAVE THESE INSTRUCTIONS

**Warning****Statement 1004**—Installation Instructions

Read the installation instructions before connecting the system to the power source.

**Note**

Proceed with the installation if you have already unpacked your chassis and read all the site requirements for your new equipment.

Guidelines for a Standalone Equipment Shelf or Tabletop Installation

The chassis should already be in the area where you want to install it. If you have not determined where to install your chassis, see [Preparing Your Site for Installation](#) for information about site considerations.

When installing the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router on a sturdy equipment shelf or tabletop, ensure that the surface is clean and that you have considered the following:

- The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router require at least 3 inches (7.62 cm) of clearance at the inlet and exhaust vents (the front and rear sides of the chassis).
- The chassis should be installed off the floor. Dust that accumulates on the floor is drawn into the interior of the router by the cooling fans. Excessive dust inside the router can cause overtemperature conditions and component failures.
- There must be approximately 19 inches (48.3 cm) of clearance at the front and rear of the chassis to install and replace FRUs, or to access network cables and equipment.
- The chassis needs adequate ventilation. Do not install it in an enclosed cabinet where ventilation is inadequate.
- Keep the cable-management bracket ready if you plan to install it on the front of the chassis.
- Ensure that an adequate chassis ground (earth) connection exists for your router chassis (see the "[Attaching a Chassis Ground Connection](#)" section).

Installing the Router on a Standalone Equipment Shelf or Tabletop

Procedure

- Step 1** Remove any debris and dust from the tabletop or platform, as well as the surrounding area.
- Step 2** Lift the chassis into position on the equipment shelf or tabletop.
- Note** Step 3 through Step 9 are optional if you are installing the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router on a rack shelf. The chassis rack-mount brackets must be installed prior to installing the cable-management brackets. See the "[Attaching the Front Rack-Mount Brackets](#)" section.
- Step 3** Attach the front rack-mount brackets. Locate the threaded holes in the front sides of the chassis (first holes beyond the vent holes) and use the package of black screws that shipped with the chassis.
- Step 4** Align the front rack-mount bracket to one side of the chassis.
- Step 5** Insert and tighten the screws on one side.
- Step 6** Repeat Step 3 through Step 5 on the other side of the chassis. Use all the screws to secure the rack-mount brackets to the chassis.
- Step 7** Gather the two cable-management brackets and screws shipped with your chassis. See the "[Attaching the Cable Management Bracket](#)" section.
- Step 8** Screw a cable-management bracket to each side of the rack-mount brackets that are attached to the chassis. Use two screws for each cable-management bracket. Use a screw from the package of four screws.
- Note** Ensure that the cable-management U feature device has the open end pointing outwards when you attach it to the chassis.
- Step 9** Check that all the screws are securely tightened.
-

What to Do Next

Go to the "[Attaching a Chassis Ground Connection](#)" section for instructions about continuing the installation.

Guidelines for Rack Installation

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router can be installed in the following rack types:

- Two-post rack, either 19 inch or 23 inch. Inner clearance (the width between the inner sides of the two posts or rails) must be at least 19 inches (48.26 cm). Airflow through the chassis is from front to back.
- Four-post, 19-inch equipment rack. Inner clearance (the width between the inner sides of the two posts or rails) must be at least 19 inches (48.26 cm). Airflow through the chassis is from front to back.

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router can be installed with both front or rear rack-mount brackets.

When planning your rack installation, consider the following guidelines:

- The Cisco ASR 1001-HX Router requires a minimum of 1.75 inches or 4.45 cm rack units of vertical rack space. The Cisco ASR 1002-HX Router requires a minimum of 3.5 inches or 8.9 cm rack units of vertical rack space. Measure the proposed rack location before mounting the chassis in the rack.
- Before using a particular rack, check for obstructions (such as a power strip) that could impair rack-mount installation. If a power strip does impair a rack-mount installation, remove the power strip before installing the chassis, and then replace it after the chassis is installed.
- Allow sufficient clearance around the rack for maintenance. If the rack is mobile, you can push it back near a wall or cabinet for normal operation and pull it out for maintenance (installing or moving cards, connecting cables, or replacing or upgrading components). Otherwise, allow 19 inches (48.3 cm) of clearance to remove field-replaceable units.
- Maintain a minimum clearance of 3 inches on the front and back sides of the chassis for the cooling air inlet and exhaust ports, respectively. Avoid placing the chassis in an overly congested rack or directly next to another equipment rack; the heated exhaust air from other equipment can enter the inlet air vents and cause an overtemperature condition inside the router.

**Caution**

To prevent chassis overheating, never install a Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router in an enclosed space that is not properly ventilated or air conditioned.


- Always install heavier equipment in the lower half of a rack to maintain a low center of gravity to prevent the rack from falling over.
- Install and use the cable-management brackets included with the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router to keep cables organized and out of the way of the cards and processors. Ensure that cables from other equipment already installed in the rack do not impair access to the cards or require you to disconnect cables unnecessarily to perform equipment maintenance or upgrades.
- Provide an adequate chassis ground (earth) connection for your router chassis.

In addition to the preceding guidelines, review the precautions for avoiding excessive temperature conditions in the “[Physical Characteristics](#)” section and the “[Site Environmental Requirements](#)” section.

Verifying Rack Dimensions

Before you install the chassis, measure the space between the vertical mounting flanges (rails) on your equipment rack to verify that the rack conforms to the measurements shown in the following figure.

Figure 20: Verifying Equipment Rack Dimensions



Procedure

-
- Step 1** Mark and measure the distance between two holes on the left and right mounting rails. The distance should measure 18.31 inches \pm 0.06 inches (46.5 cm \pm 0.15 cm).
- Note** Measure for pairs of holes near the bottom, middle, and top of the equipment rack to ensure that the rack posts are parallel.
- Step 2** Measure the space between the inner edges of the left front and right front mounting flanges on the equipment rack. The space must be at least 17.7 inches (45 cm) to accommodate the chassis that is 17.25 inches (43.8 cm) wide and fits between the mounting posts on the rack.
-

Attaching the Front Rack-Mount Brackets

Before You Begin

Before installing the chassis in the rack, you must install the rack-mount brackets on each side of the chassis. Determine where in the rack you want the chassis to be mounted. If you are mounting more than one chassis in the rack, then start from the bottom up or the center of the rack. The following figure shows the brackets attached to the chassis. Depending on the bracket holes you use, the chassis may protrude in the rack.




Note The cable-management brackets are attached to the chassis after you install the chassis rack-mount brackets on the chassis and mount the chassis in the rack.

Procedure


- Step 1** Locate the threaded holes on the side of the chassis. Ensure that you hold the front rack-mount bracket with the ear and holes facing outward and towards the front of the chassis. The following figures show where to attach the front rack-mount brackets to the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router.

Figure 21: Attaching the Front Rack-Mount Brackets to the Cisco ASR 1001-HX Router



1	Front rack-mount bracket ear and holes	3	Front rack-mount bracket screws
2	Front rack-mount bracket		

Figure 22: Attaching the Front Rack-Mount Brackets to the Cisco ASR 1002-HX Router



1	Front rack-mount bracket ear and holes	3	Front rack-mount bracket screws
2	Front rack-mount bracket		

- Step 2** Position the front rack-mount bracket top hole with the chassis, first top hole behind the side vent holes.
- Step 3** Insert and tighten the black screws on one side.
- Step 4** Repeat Step 1 through Step 3 on the other side of the chassis. Use black screws to secure the rack-mount brackets to the chassis.

Attaching the Rear Rack-Mount Brackets

Before You Begin



Note

This procedure is not required if you are installing the chassis in a two-post rack.


Before installing the chassis in a four-post rack, you must install the rear rack-mount brackets on each side of the chassis.

Determine where in the rack you want the chassis to be mounted. If you are mounting more than one chassis in the rack, then start from the bottom up or the center of the rack. The following figure shows the brackets attached to the chassis.

Procedure


- Step 1** Locate the threaded holes on the side of the chassis. Ensure that you hold the rear rack-mount bracket with the ear and holes facing outward and towards the rear of the chassis. The following figures show where to attach the rear rack-mount brackets to the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router.

Figure 23: Attaching the Rear Rack-Mount Brackets to the Cisco ASR 1001-HX Router



1	Rear rack-mount bracket ear and holes	3	Rear rack-mount bracket screws
2	Rear rack-mount bracket		

Figure 24: Attaching the Rear Rack-Mount Brackets to the Cisco ASR 1002-HX Router



1	Rear rack-mount bracket ear and holes	3	Rear rack-mount bracket screws
2	Rear rack-mount bracket		

- Step 2** Position the rear rack-mount bracket with the chassis.
- Step 3** Insert the black screws on one side. Do not fully tighten the screws. The rear bracket holes are slotted to allow for adjustment. Do not fully tighten the screws until the chassis is installed in the four-post rack.
- Step 4** Repeat Step 1 through Step 3 on the other side of the chassis. Use black screws to secure the rack-mount brackets to the chassis.
-

Mounting the Router in the Rack

After installing the rack-mount brackets on the chassis, mount the chassis by securing the rack-mount brackets to two posts or mounting strips in the rack using the screws provided. Because the rack-mount brackets support the weight of the entire chassis, ensure that you use all the screws to fasten the two rack-mount brackets to the rack posts.

Two-Post Rack Installation



Warning

Statement 1006—Chassis Warning for Rack-Mounting and Servicing

To prevent bodily injury when mounting or servicing this unit in a rack, you must take special precautions to ensure that the system remains stable. The following guidelines are provided to ensure your safety:

- This unit should be mounted at the bottom of the rack if it is the only unit in the rack.
- When mounting this unit in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.
- If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack.


The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router can be installed on a two-post rack, either 19 inch or 23 inch. We recommend that you allow at least 1 or 2 inches (2.54 or 5.08 cm) of vertical clearance between the router and any equipment directly above and below it.

Procedure

- Step 1** On the chassis, ensure that all the screw fasteners on the installed components are securely tightened.
- Step 2** Make sure that your path to the rack is unobstructed. If the rack is on wheels, ensure that the brakes are engaged or that the rack is otherwise stabilized.
- Step 3** (Optional) Install a shelf in the rack to support the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router. If you use a shelf, it helps support the chassis while you secure it to the rack.
- Note** If you are using a shelf, place the chassis on the shelf and slightly raise the front of the chassis to align the mounting bracket holes with the rack post holes while allowing the bottom of the chassis to rest on the shelf.


- Step 4** With two people, lift the chassis into position between the rack posts.
- Step 5** Align the mounting bracket holes with the rack post holes and attach the chassis to the rack.
- Step 6** Position the chassis until the rack-mounting flanges are flush against the mounting rails on the rack.
- Tip** To allow space to attach the cable-management brackets to the chassis in the rack easily, use the rack-mount bracket ear holes mentioned in Steps 7 and 8.
- Step 7** Hold the chassis in position against the mounting rails in the equipment rack and follow these steps:
- Insert the bottom screw into the second hole up from the bottom of the rack-mount ear and use a hand-held screwdriver to tighten the screw to the rack rail.
- Tip** To make installation easier, insert one screw at the bottom of the chassis and the next screw at the top of the chassis diagonally from the first screw.
- Insert the top screw into the second hole from the top of the rack-mount ear diagonally from the bottom screw and tighten the screw to the rack rail.
 - Insert the rest of the screws to secure the chassis to the rack equipment.
- Step 8** Tighten all the screws on each side to secure the chassis to the equipment rack. The following figures show the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router on a two-post equipment rack.

Figure 25: Cisco ASR 1001-HX Router Installed on a Two-Post Equipment Rack



1	Rack equipment rail	2	Rack mount bracket ear and screws
---	---------------------	---	-----------------------------------

Figure 26: Cisco ASR 1002-HX Router Installed on a Two-Post Equipment Rack



1	Rack equipment rail	2	Rack mount bracket ear and screws
---	---------------------	---	-----------------------------------

What to Do Next

This completes the procedure for installing the chassis on a two-post rack. Proceed to the [“Attaching a Chassis Ground Connection”](#) section to continue the installation.

Four-Post Rack Installation

Procedure

- Step 1** (Optional) Install a shelf in the rack to support the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router. If you use a shelf, it helps support the chassis while you secure it to the rack.
- Note** If you are using a shelf, place the chassis on the shelf and slightly raise the front of the chassis to align the mounting bracket holes with the rack post holes while allowing the bottom of the chassis to rest on the shelf.
- Step 2** With two people, lift the chassis into position between the rack posts.
- Step 3** Position the chassis until the rack-mounting flanges are flush against the mounting rails on the rack.


Note Use the second hole up from the bottom of the rack-mount bracket and the second hole down from the top of the rack-mount bracket. This will make it easier to attach the cable-management bracket to the chassis in the equipment rack.

Step 4 Hold the chassis in position against the mounting rails while the second person finger-tightens a screw to the rack rails on each side of the chassis.

Step 5 Finger-tighten screws to the rack rails on each side of the chassis.


Step 6 Tighten all the screws on each side to secure the chassis to the equipment rack. The following figures show the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router on a four-post equipment rack.

Figure 27: Cisco ASR 1001-HX Router in a Four-Post Rack—Front and Rear Rack-Mounting



1	Rear rack equipment rail	3	Front rack mount bracket ear and screws
2	Rear rack mount bracket ear and screws	4	Front rack equipment rail

Figure 28: Cisco ASR 1002-HX Router in a Four-Post Rack—Front and Rear Rack-Mounting



1	Rear rack equipment rail	3	Front rack mount bracket ear and screws
2	Rear rack mount bracket ear and screws	4	Front rack equipment rail

Step 7 Use a level to verify that the tops of the two brackets are level, or use a measuring tape to verify that both brackets are the same distance from the top of the rack rails.

What to Do Next

This completes the procedure for installing the chassis in the rack. Proceed to the [“Attaching a Chassis Ground Connection”](#) section to continue the installation.

Attaching the Cable Management Bracket

The cable management brackets should be mounted to each rack-mount bracket on the chassis to provide cable management to both sides of the chassis (parallel with card orientation). These brackets are screw-mounted to the rack-mount brackets to allow easy installation and removal of cables.

The cable-management brackets for the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router contain one independent cable-management U-type feature with two screws for each bracket.



Note Make certain that the cable-management bracket "U" feature is facing upwards when you attach it to the chassis.

Procedure


Step 1 Align the cable-management bracket to the rack-mount bracket on one side of the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router. The cable-management bracket aligns to the top hole of the chassis rack-mount bracket.

Step 2 Using a Phillips screwdriver, insert one screw through the top screw hole of the cable-management bracket and into the chassis rack-mount bracket and tighten the screw.

Note Use the package of screws that came with your chassis containing four screws.


The following figures show where to attach the cable-management brackets to the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router.

Figure 29: Attaching the Cable-Management Brackets to the Cisco ASR 1001-HX Router



1	Cable-management bracket "RU" feature	3	Chassis front rack-mount bracket
2	Cable-management bracket screw		

Figure 30: Attaching the Cable-Management Brackets to the Cisco ASR 1002-HX Router



1	Cable-management bracket "U" feature	3	Chassis front rack-mount bracket
2	Cable-management bracket screw holes		

Step 3 Do one of the following as appropriate:

- Cisco ASR 1001-HX Router—Insert the cable management screw into the screw hole of the cable-management bracket and into the chassis rack-mount bracket and tighten the screw using a Phillips screwdriver.
- Cisco ASR 1002-HX Router—Insert one screw through the bottom screw hole of the cable-management bracket and into the chassis rack-mount bracket and tighten the screw using a Phillips screwdriver. Insert another screw through the top screw hole of the cable-management bracket and tighten the screw.

Step 4 Repeat Step 1 through Step 3 for the other side of the chassis.

Chassis Ground Connection

Connecting the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router chassis to ground is required for all DC powered installations and any AC powered installation where compliance with Telcordia grounding requirements is necessary.

**Warning****Statement 1024—Ground Conductor**

This equipment must be grounded. Never defeat the ground conductor or operate the equipment in the absence of a suitably installed ground conductor. Contact the appropriate electrical inspection authority or an electrician if you are uncertain that suitable grounding is available.

Before you connect power or turn on power to your chassis, you must provide an adequate chassis ground (earth) connection for the chassis. A chassis ground connector is provided on each Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router. There is a stud on the rear left side of the chassis.

**Caution**

The grounding wire should always be the first to be installed or connected and the last to be removed or disconnected.

Have the recommended tools and supplies available before you begin this procedure.

Recommended Tools and Supplies

The following tools, equipment, and supplies are necessary to connect the system ground to the chassis:


- Phillips screwdriver
- 3.5-mm flat blade screwdriver (Phoenix # 1205053 or equivalent 3.5-mm flat blade)
- Dual-lug chassis ground component
- Grounding wire

Attaching a Chassis Ground Connection

Procedure

- Step 1** Use the wire stripper to strip one end of the AWG #6 wire approximately 0.75 inches (19.05 mm).
- Step 2** Insert the AWG #6 wire into the open end of the grounding lug.


Figure 31: Attaching a Grounding Lug to the Chassis Ground Connector



1	Chassis ground lead wire	3	Ground screws
2	Grounding lug	4	Chassis ground connector holes


- Step 3** Use the crimping tool to carefully crimp the wire receptacle around the wire. This step is required to ensure a proper mechanical connection.
- Step 4** Locate the chassis ground connector on the side of your chassis.
- Step 5** Insert the two screws through the holes in the grounding lug.
The following figures show how to attach a grounding lug to the chassis ground connector.

Figure 32: Attaching the Grounding Lug to the Ground Connector of the Cisco ASR 1001-HX Router



1	Chassis ground lug	3	Ground connector on the chassis
2	Grounding screws	4	Ground symbol

Figure 33: Attaching the Grounding Lug to the Ground Connector of the Cisco ASR 1002-HX Router



1	Ground connector on the chassis	3	Grounding screws
2	Chassis ground lug	4	Ground symbol

- Step 6** Use the Number 2 Phillips screwdriver to carefully tighten the screws until the grounding lug is held firmly to the chassis. Do not over tighten the screws.
- Step 7** Connect the opposite end of the grounding wire to the appropriate grounding point at your site to ensure an adequate chassis ground.

Connecting Cables

Keep the following guidelines in mind when connecting any external cable to the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router:

- To reduce the chance of interference, avoid crossing high-power lines with any interface cables.
- Verify all the cabling limitations (particularly distance) before powering on the system.

Connecting the Console and Auxiliary Port Cables

The router uses RJ-45 ports for both auxiliary ports and console ports to attach a console terminal. The router has an asynchronous serial (EIA/TIA-232) RJ-45 console port labeled CON on its front panel. You can connect this port to most types of video terminals with a console cable kit that is included with your router. The console cable kit contains:

- One RJ-45-to-RJ-45 crossover cable
- One RJ-45-to-DB-9 (female) adapter

A crossover cable reverses pin connections from one end to the other. In other words, it connects pin 1 (at one end) to pin 8 (at the other end), pin 2 to pin 7, pin 3 to pin 6, and so on. You can identify a crossover cable by comparing the two modular ends of the cable. Hold the cable ends in your hand, side-by-side, with the tabs at the back. Ensure that the wire connected to the outside (left) pin of the left plug (pin 1) is the same color as the wire connected to the outside (right) pin of the right plug (pin 8).

Both the console and auxiliary ports are asynchronous serial ports; devices connected to these ports must be capable of asynchronous transmission.

Before connecting to the console interface on the router using a terminal or PC, perform the following steps:



Note Out of Band (OOB) access using a modem on the Auxiliary port is not tested or supported on the Cisco ASR 1001-HX Router and the Cisco ASR 1002-HX Router.

Procedure

- Step 1** Before connecting a terminal to the console port, configure the terminal to match the chassis console port as follows: 9600 baud, 8 data bits, no parity, 1 stop bits (9600 8N1).
- Step 2** Connect one end of the RJ-45 cable to the serial RJ-45 console port (CON) on the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router using the RJ-45 to DB-9 cable. Connect the DB-9 end to your terminal equipment.
- Note** For information about how to change the default settings to meet the requirements of your terminal or host, see the *Cisco IOS Terminal Services Configuration Guide*.
- Step 3** After you establish normal router operation, you can disconnect the terminal. Use the following procedure to connect a video terminal to the console port.
-

What to Do Next

Go to the "[Connecting to the Mini USB Console Port](#)" section to continue the installation.

Connecting to the Mini USB Console Port

The USB serial console port connects directly to the USB connector of a PC using a USB Type A to 5-pin mini USB Type-B cable. The USB Console supports full speed (12Mbps) operation. The console port does not support hardware flow control.

**Note**

- Always use shielded USB cables with a properly terminated shield. The USB serial console interface cable must not exceed 3 meters in length.
- Only one console port can be active at a time. When a cable is plugged into the USB console port, the RJ-45 port becomes inactive. Conversely, when the USB cable is removed from the USB port, the RJ-45 port becomes active.
- 4-pin mini USB Type-B connectors are easily confused with 5-pin mini USB Type-B connectors. Note that only the 5-pin mini USB Type-B is supported.

The default parameters for the console port are 9600 baud, 8 data bits, no parity, and 1 stop bit.

For operation with a Microsoft Windows OS version older than Windows 7, the Cisco Windows USB Console Driver must be installed on any PC connected to the console port. If the driver is not installed, prompts guide you through a simple installation process.

The Cisco Windows USB Console Driver allows plugging and unplugging the USB cable from the console port without affecting Windows HyperTerminal operations. No special drivers are needed for Mac OS X or Linux.

Baud rates for the USB console port are 1200, 2400, 4800, 9600, 19200, 38400, 57600, and 115200 bps.

Management Ethernet Port Cable Connection

**Caution**

To comply with Class A emission requirements, a shielded Ethernet cable must be used for the connection.

Procedure

- Step 1** Insert an Ethernet RJ-45 cable into the MGMT port.
- Step 2** Insert the other end of the RJ-45 cable to your management device or network.



Power Up and Initial Configuration

This chapter guides you through a basic router configuration, which is sufficient for you to access your network. Complex configuration procedures are beyond the scope of this publication and can be found in the modular configuration and modular command reference publications in the Cisco IOS software configuration documentation set that corresponds to the software release installed on your Cisco hardware.

- [Checking Conditions Prior to System Startup, page 73](#)
- [Powering Up the Router, page 74](#)
- [Performing the Initial Configuration on the Router, page 76](#)
- [Saving Your Router Configuration, page 86](#)
- [Verifying the Initial Configuration, page 86](#)
- [Powering Off the Router Safely, page 87](#)
- [Environmental Monitoring and Reporting Functions, page 87](#)

Checking Conditions Prior to System Startup

Ensure that all the card slots and compartments are closed. Install blank faceplates on empty slots. Always have power supply slots filled. If you leave a power supply slot uncovered, then you risk exposure to hazardous voltages on the power pins on the midplane.



Warning

Statement 1029—Blank Faceplates and Cover Panels

Blank faceplates and cover panels serve three important functions: they prevent exposure to hazardous voltages and currents inside the chassis; they contain electromagnetic interference (EMI) that might disrupt other equipment; and they direct the flow of cooling air through the chassis. Do not operate the system unless all cards, faceplates, front covers, and rear covers are in place.



Note

To view the boot sequence, you must have a console connection to the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router before it powers up.

Ensure that the following conditions are addressed before starting up the router:

- The network interface cable or the optional Management port cable is connected.
- The chassis is securely mounted and grounded.
- The power and interface cables are connected.
- Your PC with terminal emulation program (hyperTerminal or equivalent) is connected to the console port, powered up, and is configured for 9600 baud, 8 data bits, 1 stop bit, no parity, with flow control set to none.
- You have selected passwords for access control.
- Captive installation screws are tight on all removable components.
- The console terminal is turned on.
- You have determined the IP addresses for the network interfaces.
- The EPA and the NIM are inserted in their slots, if applicable.
- Empty card slots are filled with card blanks. This ensures proper air flow through the chassis and electromagnetic compatibility (EMC).

Powering Up the Router

You are now ready to power on the system for the first time. Follow these steps.

Before You Begin

Before you power on, make sure that:

- The power supply cord is plugged into the power supply inlet.
- All cables are connected.
- Your computer is powered up and connected.

Procedure

- Step 1** Move the chassis power switch to the ON position. Listen for the fans; you should immediately hear them operating. Ensure that the power supply LED OK is green and the FAIL LED is not illuminated. The front-panel indicator LEDs provide power, activity, and status information useful during bootup. For more detailed information about the LEDs, see the "[LEDs](#)" section.
- Step 2** Observe the initialization process. When the system boot is complete (the process takes a few seconds), the router begins to initialize.
-

Loading from ROMMON with a System Image in Bootflash

The following is an example of what is displayed during the system boot process:

```

Initializing Hardware ...

System integrity status: 00000610

System Bootstrap, Version 15.4(2r)S, RELEASE SOFTWARE (fc1)
Copyright (c) 1994-2014 by cisco Systems, Inc.

Current image running: Boot ROM0
Last reset cause: PowerOn

ASR1002-HX platform with 16777216 Kbytes of main memory

File size is 0x2b08ddf7
Located asr1000-universalk9.BLD_V163_THROTTLE_LATEST_20160728_000855.SSA.bin
Image size 722001399 inode num 277985, bks cnt 176270 blk size 8*512
#####
#####
#####
Validating dev_mode signature
done

Boot image size = 722001399 (0x2b08ddf7) bytes

ROM:RSA Self Test Passed
ROM:Sha512 Self Test Passed
Self Tests Latency: 58 mSec

Package header rev 1 structure detected
Calculating SHA-1 hash...done
validate_package_cs: SHA-1 hash:
    calculated ef1e9e3f:519cec63:1f14c20f:c3b39303:dbb4c3c5
    expected  ef1e9e3f:519cec63:1f14c20f:c3b39303:dbb4c3c5

RSA Signed DEVELOPMENT Image Signature Verification Successful.
Validating subpackage signatures
Image validated
Validating dev_mode signature
done

                Restricted Rights Legend

Use, duplication, or disclosure by the Government is
subject to restrictions as set forth in subparagraph
(c) of the Commercial Computer Software - Restricted
Rights clause at FAR sec. 52.227-19 and subparagraph
(c) (1) (ii) of the Rights in Technical Data and Computer
Software clause at DFARS sec. 252.227-7013.

                cisco Systems, Inc.
                170 West Tasman Drive
                San Jose, California 95134-1706

Cisco IOS Software, ASR1000 Software (X86_64_LINUX_IOSD-UNIVERSALK9-M), Experimental
Version Denali 16.2.20160120:005403 [v162_1_throttle-BLD-BLD_V162_1_THROTTLE_LATEST_
20160119_234422_127]
Copyright (c) 1986-2016 by Cisco Systems, Inc.
Compiled Tue 19-Jan-16 20:53 by mcpre

Cisco IOS-XE software, Copyright (c) 2005-2016 by cisco Systems, Inc.
All rights reserved. Certain components of Cisco IOS-XE software are
licensed under the GNU General Public License ("GPL") Version 2.0. The
software code licensed under GPL Version 2.0 is free software that comes
with ABSOLUTELY NO WARRANTY. You can redistribute and/or modify such
GPL code under the terms of GPL Version 2.0. For more details, see the

```

documentation or "License Notice" file accompanying the IOS-XE software, or the applicable URL provided on the flyer accompanying the IOS-XE software.

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at: <http://www.cisco.com/wvl/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to export@cisco.com.

```
cisco ASR1002-HX (2KH) processor (revision 2KH) with 3724092K/6147K bytes of memory.
Processor board ID FXS1922Q0LL
Crypto Hardware Module present
26 Gigabit Ethernet interfaces
8 Ten Gigabit Ethernet interfaces
32768K bytes of non-volatile configuration memory.
16777216K bytes of physical memory.
30056447K bytes of eUSB flash at bootflash:.
0K bytes of  at webui:.
```

Press RETURN to get started!

```
*Jan 21 17:57:38.704: %SMART_LIC-6-AGENT_READY: Smart Agent for Licensing is initialized
*Jan 21 17:57:39.462: %LICENSE-6-EULA_ACCEPT_ALL: The Right to Use End User License Agreement
is accepted
*Jan 21 17:57:39.482: %IOS_LICENSE_IMAGE_APPLICATION-6-LICENSE_LEVEL: Module name = asr1002hx

Next reboot level = advanterprise and License = advanterprise
*Jan 21 17:57:54.438: %SPANTREE-5-EXTENDED_SYSID: Extended SysId enabled for type vlan
*Jan 21 17:57:54.493: ***** plat:0 0 flag:1 ****
*Jan 21 17:57:58.264: %VOICE_HA-7-STATUS: CUBE HA-supported platform detected.
*Jan 21 17:58:04.623: %LINK-3-UPDOWN: Interface Lsmpi0, changed state to up
*Jan 21 17:58:04.624: %LINK-3-UPDOWN: Interface EOBC0, changed state to up
*Jan 21 17:58:04.624: %LINEPROTO-5-UPDOWN: Line protocol on Interface VoIP-Null0, changed
state to up
*Jan 21 17:58:04.624: %LINEPROTO-5-UPDOWN: Line protocol on Interface LI-Null0, changed
state to up
*Jan 21 17:58:04.624: %LINK-3-UPDOWN: Interface GigabitEthernet0, changed state to down

.
.
.
```

Performing the Initial Configuration on the Router

Using the Cisco setup Command Facility

The **setup** command facility prompts you to enter the information that is needed to configure a router quickly. The facility takes you through an initial configuration, including LAN and WAN interfaces.



Note The setup command facility is entered automatically if there is no configuration on the router when it is booted into Cisco IOS-XE.

For information on modifying the configuration after you create it, see the *Cisco IOS XE Configuration Guide* and the *Cisco IOS XE Command References*.

This section explains how to configure a host name for the router, set passwords, and configure an interface to communicate with the management network.



Note If you make a mistake while using the setup command facility, you can exit and run the setup command facility again. Press Ctrl-C, and enter the setup command in privileged EXEC mode (Router#).

Procedure

Step 1 From the Cisco IOS-XE CLI, enter the setup command in privileged EXEC mode:

```
Router> enable
Password: <password>
Router# setup
```

```
      --- System Configuration Dialog ---
Continue with configuration dialog? [yes/no]:
```

The prompts in the **setup** command facility vary depending on your router model, on the installed interface modules, and on the software image. The following steps and the user entries (in bold) are shown as examples only.

Step 2 To proceed using the setup command facility, enter **yes**.

```
Continue with configuration dialog? [yes/no]: yes
```

At any point you may enter a question mark '?' for help.

```
Use ctrl-c to abort configuration dialog at any prompt.
Default settings are in square brackets '[]'.
```

Step 3 Basic management setup configures only enough connectivity.

```
Would you like to enter basic management setup? [yes/no]: yes
```

Step 4 Enter a hostname for the router (this example uses myrouter):

```
Configuring global parameters:
Enter host name [Router]: myrouter
```

Step 5 Enter an enable secret password. This password is encrypted (for more security) and cannot be seen when viewing the configuration.

```
The enable secret is a password used to protect access to
privileged EXEC and configuration modes. This password, after
entered, becomes encrypted in the configuration.
Enter enable secret: cisco
```

Step 6 Enter an enable password that is different from the enable secret password. This password is not encrypted (and is less secure) and can be seen when viewing the configuration.

The enable password is used when you do not specify an enable secret password, with some older software versions, and some boot images.

Enter enable password: **cisco123**

Step 7 Enter the virtual terminal password, which prevents unauthenticated access to the router through ports other than the console port:

The virtual terminal password is used to protect access to the router over a network interface.

Enter virtual terminal password: **cisco**

Step 8 Respond to the following prompts as appropriate for your network:

Configure SNMP Network Management? [no]: **yes**
Community string [public]:

A summary of the available interfaces is displayed. The interface summary includes interface numbering, which is dependent on the router model and the installed modules and interface cards.

Current interface summary

Interface	IP-Address	OK?	Method	Status	Protocol
GigabitEthernet0/0/0	unassigned	YES	unset	down	down
GigabitEthernet0/0/1	unassigned	YES	unset	up	up
GigabitEthernet0/0/2	unassigned	YES	unset	down	down
GigabitEthernet0/0/3	unassigned	YES	unset	up	up
GigabitEthernet0/0/4	unassigned	YES	unset	up	up
GigabitEthernet0/0/5	unassigned	YES	unset	down	down
GigabitEthernet0/0/6	unassigned	YES	unset	up	up
GigabitEthernet0/0/7	unassigned	YES	unset	up	up
Te0/1/0	unassigned	YES	unset	down	down
Te0/1/1	unassigned	YES	unset	down	down
Te0/1/2	unassigned	YES	unset	down	down
Te0/1/3	unassigned	YES	unset	down	down
Te0/1/4	unassigned	YES	unset	up	up
Te0/1/5	unassigned	YES	unset	down	down
Te0/1/6	unassigned	YES	unset	up	up
Te0/1/7	unassigned	YES	unset	down	down
GigabitEthernet0	unassigned	YES	unset	up	up

Any interface listed with OK? value "NO" does not have a valid configuration

Step 9 Respond to the following prompts as appropriate for your network:

Configuring interface **GigabitEthernet0/0/1**:
Configure IP on this interface? [yes]: **yes**
IP address for this interface [**10.10.10.12**]:
Subnet mask for this interface [255.0.0.0] : **255.255.255.0**
Class A network is 10.0.0.0, 24 subnet bits; mask is /24

The following configuration command script is created:

```
hostname myrouter
enable secret 5 $1$t/Dj$yAeGKviLLZNOBX0b9eif00
enable password cisco123
line vty 0 4
password cisco
snmp-server community public
!
no ip routing

!
interface GigabitEthernet0/0/0
shutdown
no ip address
!
interface GigabitEthernet0/0/1
no shutdown
ip address 10.10.10.12 255.255.255.0
!
interface GigabitEthernet0/0/2
shutdown
no ip address
!
.
.
.
end
```

Step 10 Respond to the following prompts. Select [2] to save the initial configuration.

```
[0] Go to the IOS command prompt without saving this config.
[1] Return back to the setup without saving this config.
[2] Save this configuration to nvram and exit.
```

```
Enter your selection [2]: 2
Building configuration...
Use the enabled mode 'configure' command to modify this configuration.
```

```
Press RETURN to get started! RETURN
```

The following user prompt is displayed:

```
myrouter>
```

Completing the Configuration

When using the Cisco setup command facility, and after you have provided all the information requested by the facility as described in “Using the Cisco setup Command Facility” section, the final configuration appears. To complete your router configuration, follow these steps:

Procedure

Step 1 The facility prompts you to save the configuration.

- If you answer no, the configuration information you entered is *not* saved, and you return to the router enable prompt (Router#). Enter **setup** to return to the System Configuration dialog box.
- If you answer yes, the configuration is saved, and you are returned to the user EXEC prompt (Router>).

```
Use this configuration? {yes/no} : yes
Building configuration...
Use the enabled mode 'configure' command to modify this configuration.
```

```
%LINK-3-UPDOWN: Interface GigabitEthernet0/1/0, changed state to up
%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/1/0, changed state to up

<Additional messages omitted.>
```

Step 2 When messages stop appearing on your screen, press **Return** to get the Router> prompt.

Step 3 The Router> prompt indicates that you are now at the command-line interface (CLI) and you have just completed an initial router configuration. Note that this is not a complete configuration. At this point, you have two choices:

- Run the setup command facility again, and create another configuration:

```
Router> enable
Password: password
Router# setup
```

- Modify the existing configuration or configure additional features by using the CLI:

```
Router> enable
Password: password
Router# configure terminal
Router(config)#
```

Using the Cisco IOS-XE CLI—Manual Configuration

This section shows you how to access the CLI to perform the initial configuration on the router.

If the system configuration message does not appear, it means a default configuration file was installed on the router prior to shipping. Follow these steps to configure the router.

Procedure

Step 1 Enter **no** when the following system message appears on the router:

```
--- System Configuration Dialog ---
```

```
Would you like to enter the initial configuration dialog? [yes/no]: no
```

Step 2 Press **Return** and continue with the manual configuration:
Several log messages are displayed.

Step 3 Press **Return** to bring up the `Router>` prompt.

Step 4 Type **enable** to enter privileged EXEC mode:

```
Router> enable  
Router#
```

Configuring the Router Hostname

The hostname is used in CLI prompts and default configuration filenames. If you do not configure the router hostname, the router uses the factory-assigned default hostname **Router**.

Procedure

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. Note Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	hostname <i>name</i> Example: Router (config)# hostname myrouter	Specifies or modifies the hostname for the network server.
Step 4	end Example: myrouter# end	(Optional) Returns to privileged EXEC mode.

Configuring the Enable and Enable Secret Passwords

To provide an additional layer of security, particularly for passwords that cross the network or are stored on a TFTP server, you can use either the **enable password** command or **enable secret** command. Both commands accomplish the same thing—they allow you to establish an encrypted password that users must enter to access privileged EXEC (enable) mode.

We recommend that you use the **enable secret** command because it uses an improved encryption algorithm.



Note

If you configure the **enable secret** command, it takes precedence over the **enable password** command; the two commands cannot be in effect simultaneously.

For more information, see the “Configuring Passwords and Privileges” chapter in the *Cisco IOS Security Configuration Guide*. Also see the [Cisco IOS Password Encryption Facts](#) tech note and the [Cisco Guide to Harden Cisco IOS Devices](#) tech note.

Procedure

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. Note Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	enable secret password Example: Router(config)# enable secret greentree	Specifies an additional layer of security over the enable password command.
Step 4	end Example: Router(config)# end	Returns to privileged EXEC mode.
Step 5	enable Example: Router> enable	Enables privileged EXEC mode. Verify that your new enable or enable secret password works.
Step 6	end Example: Router(config)# end	(Optional) Returns to privileged EXEC mode.

Configuring the Console Idle Privileged EXEC Timeout

By default, the privileged EXEC command interpreter waits 10 minutes to detect user input before timing out.

When you configure the console line, you can also set communication parameters, specify autobaud connections, and configure terminal operating parameters for the terminal that you are using. For more information on configuring the console line, see the Cisco IOS Configuration Fundamentals and Network Management Configuration Guide. In particular, see the “Configuring Operating Characteristics for Terminals” and “Troubleshooting and Fault Management” chapters.

Procedure

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. Note Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	line console 0 Example: Router(config)# line console 0	Configures the console line and starts the line configuration command collection mode.
Step 4	exec-timeout minutes [seconds] Example: Router(config-line)# exec-timeout 0 0	Sets the idle privileged EXEC timeout, which is the interval that the privileged EXEC command interpreter waits until user input is detected. The example shows how to specify no timeout. Setting the exec-timeout value to 0 will cause the router to never log out once logged in. This could have security implications if you leave the console without manually logging out using the disable command.
Step 5	end Example: Router(config)# end	Returns to privileged EXEC mode.
Step 6	show running-config Example: Router# show running-config	Displays the running configuration file. Verify that you have configured the idle privileged EXEC timeout correctly.

The following example shows how to set the console idle privileged EXEC timeout to 2 minutes 30 seconds:

```
line console
exec-timeout 2 30
```

The following example shows how to set the console idle privileged EXEC timeout to 30 seconds:

```
line console
exec-timeout 0 30
```

Gigabit Ethernet Management Interface Overview

The router provides an Ethernet management port named GigabitEthernet0.

The purpose of this interface is to allow users to perform management tasks on the router; it is an interface that should not, and often cannot, forward network traffic, but can be used to access the router via Telnet and SSH to perform management tasks on the router. The interface is most useful before a router has begun routing, or in troubleshooting scenarios when other forwarding interfaces are inactive.

The following aspects of the management Ethernet interface should be noted:

- The router has one management Ethernet interface named GigabitEthernet0.
- IPv4, IPv6, and ARP are the only routed protocols supported for the interface.
- The interface provides a way to access the router even if forwarding interfaces are not functional, or the Cisco IOS is down.
- The management Ethernet interface is part of its own VRF. See the [Cisco ASR 1000 Series Aggregation Services Routers Software Configuration Guide](#) for more details.

Default Gigabit Ethernet Configuration

By default, a forwarding VRF is configured for the interface with a special group named Mgmt-intf. This cannot be changed. This isolates the traffic on the management interface away from the forwarding plane. Otherwise, the interface can be configured like other Gigabit Ethernet interfaces for most functions.

For example, the default configuration is as follows:

```
interface GigabitEthernet0
vrf forwarding Mgmt-intf
ip address 172.18.77.212 255.255.255.240
negotiation auto
```

Configuring Gigabit Ethernet Interfaces

This sections shows how to assign an IP address and interface description to an Ethernet interface on your router.

For comprehensive configuration information on Gigabit Ethernet interfaces, see the “Configuring LAN Interfaces” chapter of the Cisco IOS Interface and Hardware Component Configuration Guide.

For information on interface numbering, see the software configuration guide pertaining to your router.

Procedure

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.

	Command or Action	Purpose
	Example: Router> enable	Note Enter your password if prompted.
Step 2	show ip interface brief Example: Router# show ip interface brief	Displays a brief status of the interfaces that are configured for IP. Learn which type of Ethernet interface is on your router.
Step 3	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 4	interface gigabitethernet 0 Example: Router (config)# interface gigabitethernet 0	Specifies the Ethernet interface and enters interface configuration mode.
Step 5	ip address ip-address mask Example: Router (config-if)# ip address 172.16.74.3 255.255.255.0	Sets a primary IP address for an interface.
Step 6	no shutdown Example: Router (config-if)# no shutdown	Enables an interface.
Step 7	end Example: Router (config)# end	Returns to privileged EXEC mode.
Step 8	show ip interface brief Example: Router# show ip interface brief	Displays a brief status of the interfaces that are configured for IP. Verify that the interfaces are up and configured correctly.

**Note**

For comprehensive configuration information about IP routing and IP routing protocols, see the Configuring IP Routing Protocol-Independent Feature on Cisco.com.

Saving Your Router Configuration

This section describes how to avoid losing your configuration at the next system reload or power cycle by saving the running configuration to the startup configuration in NVRAM. The NVRAM provides 32 MB of storage on the router.



Note

To aid file recovery and minimize downtime in case of file corruption, we recommend that you save backup copies of the startup configuration file and the Cisco IOS-XE software system image file on a server.



Note

To avoid losing work you have completed, be sure to save your configuration occasionally as you proceed. Use the **copy running-config startup-config** command to save the configuration to NVRAM.

Procedure

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. Enter your password if prompted.
Step 2	copy running-config startup-config Example: Router# copy running-config startup-config	Saves the running configuration to the startup configuration.

Verifying the Initial Configuration

Enter the following commands in Cisco IOS-XE to verify the initial configuration on the router:

- **show version**—Displays the system hardware version, the installed software version, the names and sources of configuration files, the boot images, and the amount of installed DRAM, NVRAM, and flash memory.
- **show diag**—Lists and displays diagnostic information about the installed controllers, interface processors, and port adapters.
- **show interfaces**— Shows if interfaces are operating correctly and if interfaces and line protocols are in the correct state, either up or down
- **show ip interface brief**—Displays a summary of the interfaces configured for IP protocol.

- **show configuration**—Helps verify if you have configured the correct hostname and password.

After you have completed and verified the initial configuration, the specific features and functions are ready to be configured. See the Cisco ASR 1000 Series Aggregation Services Routers Software Configuration Guide.

Powering Off the Router Safely

Before You Begin

We recommend that before turning off all power to the chassis, you issue the reload command. This ensures that the operating system cleans up all the file systems.

Procedure

Step 1 Slip on the ESD-preventive wrist strap included in the accessory kit.

Step 2 Enter the **reload** command.

Step 3 Confirm the reload command:

```
Router# reload
```

```
Proceed with reload? [confirm]
```

```
Apr 21 03:42:45.619 EDT: %SYS-5-RELOAD: Reload requested by console. Reload Reason:
Reload Command.Apr 21 03:42:59.920 R0/0: %PMAN-5-EXITACTION: Process manager is
exiting: process exit with reload chassis code
```

Step 4 After confirming the reload command, wait until the system bootstrap message is displayed before powering off the system:

```
System Bootstrap, Version 15.4(2r)S, RELEASE SOFTWARE (fc1)
Copyright (c) 1994-2014 by cisco Systems, Inc.
```

```
Current image running: Boot ROM0
```

```
Last reset cause: LocalSoft
```

```
ASR1002-HX platform with 16777216 Kbytes of main memory
```

```
rommon 1 >
```

Step 5 Move the chassis power switch to the Standby position.

Note The fans in the power supply modules will continue to run even if the chassis power switch is in the Standby position.

Note After powering off the router, wait for a minimum of 30 seconds before powering it on again.

Environmental Monitoring and Reporting Functions

Environmental monitoring and reporting functions allow you to maintain normal system operation by identifying and resolving adverse conditions prior to loss of operation.

**Caution**

To prevent overheating of the chassis, ensure that your system is drawing cool inlet air. Over temperature conditions may occur if the system is drawing in the exhaust air of other equipment. Ensure adequate clearance around the sides of the chassis so that cooling air can flow through the chassis interior unimpeded and exhaust air exits the chassis and is not drawn into the inlet vent of another device.

Alarm Monitoring

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router display the CRIT, MAJ, and MIN alarm indicator LEDs. The three system alarm LEDs on the Cisco ASR 1002-HX Router provide visual alarm notification in the router. These LEDs indicate router status at all times, but you must directly observe these LEDs to become aware of a router alarm condition. Additionally, you can use the **show facility-alarm status** command to view the alarms.

```
Router# show facility-alarm status
```

```
System Totals Critical: 2 Major: 0 Minor: 0
```

Source	Time	Severity	Description [Index]
Power Supply Module 0	Jan 21 2016 18:06:16	CRITICAL	Power Supply Failure [0]
Power Supply Bay 1	Jan 21 2016 18:06:15	CRITICAL	Power Supply/FAN Module Missing [0]
GigabitEthernet0/0/0 State Down [2]	Jan 21 2016 18:08:21	INFO	Physical Port Administrative
GigabitEthernet0/0/1 State Down [2]	Jan 21 2016 18:08:21	INFO	Physical Port Administrative
xcvr container 0/0/2	Jan 21 2016 18:08:21	INFO	Transceiver Missing [0]
GigabitEthernet0/0/3 State Down [2]	Jan 21 2016 18:08:21	INFO	Physical Port Administrative
GigabitEthernet0/0/4 State Down [2]	Jan 21 2016 18:08:21	INFO	Physical Port Administrative
GigabitEthernet0/0/5 State Down [2]	Jan 21 2016 18:08:21	INFO	Physical Port Administrative
GigabitEthernet0/0/6 State Down [2]	Jan 21 2016 18:08:21	INFO	Physical Port Administrative
GigabitEthernet0/0/7 State Down [2]	Jan 21 2016 18:08:21	INFO	Physical Port Administrative
TenGigabitEthernet0/1/0 State Down [36]	Jan 21 2016 18:08:21	INFO	Physical Port Administrative
xcvr container 0/1/1	Jan 21 2016 18:08:21	INFO	Transceiver Missing [0]
TenGigabitEthernet0/1/2 State Down [36]	Jan 21 2016 18:08:21	INFO	Physical Port Administrative
xcvr container 0/1/3	Jan 21 2016 18:08:21	INFO	Transceiver Missing [0]
.			
.			
.			

**Note**

There is no external alarm monitoring facility on the Cisco ASR 1002-HX Router.

To clear a visual alarm, you must resolve the alarm condition. The **clear facility-alarm** command does not clear an alarm LED on the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router. For example, if a critical alarm LED is illuminated because an active EPA was removed without a graceful deactivation of the EPA, the only way to resolve that alarm is to replace the EPA.

Environmental Monitoring

The environmental monitoring functions use sensors to monitor the temperature of the cooling air as it moves through the chassis.

The local power supplies provide the ability to monitor:

- Input and output voltage
- Output current
- Outlet temperature

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router are expected to meet the following environmental operating conditions:

- Operating Temperature Nominal: 32° to 104° (0° to 40°C)
- Operating Temperature Short Term: 32° to 131° (0° to +55°C)
- Operating Humidity Nominal (relative humidity): 10 to 90% relative
- Operating Humidity Short Term: 5 to 90% relative
- Operating Altitude: -500 to 10,000 feet (-152.4 to 3048 meters)
- DC Input Range: -40 to -72 VDC
- AC Input Range: 85 to 264 VAC

In addition, the power supplies monitor internal power supply temperatures and voltages. A power supply is either within tolerance (normal) or out of tolerance (critical). If an internal power supply temperature or voltage reaches a critical level, the power supply shuts down without any interaction with the system processor.

The environmental monitoring functions use the following levels of status conditions to monitor the system:

- Normal—All monitored parameters are within normal tolerances.
- Warning—The system has exceeded a specified threshold. The system continues to operate, but operator action is recommended to bring the system back to a normal state.
- Critical—An out-of-tolerance temperature or voltage condition exists. The system continues to operate, but the system is approaching shutdown. Immediate operator action is required.
- Shutdown—Before any shutdown, the system logs the status of monitored parameters in NVRAM so that you can retrieve it later to help determine the cause of the problem.
- Power supply shutdown—The power supply detected an internal out-of-tolerance overvoltage, overcurrent, or temperature condition and shut itself down. All DC power remains disabled until you toggle the chassis power switch.

Fan Failures

Four internal fans draw cooling air in through the front of the chassis and across internal components to maintain an acceptable operating temperature. The fans are located at the rear of the chassis. The fans in the Cisco ASR 1001-HX Router are numbered from 0 to 5, right to left. The fans in the Cisco ASR 1002-HX

Routers are numbered from 0 to 3, right to left. When the system power is on, all fans should be operational. However, the system continues to operate even if a fan fails.

Use the **show platform hardware slot *slot* fan status** command to view the status of the fans, for example:

```
Router# show platform hardware slot P2 fan status
Fan group 1 speed: 60%
Fan 0: Normal
Fan 1: Normal
Fan 2: Normal
Fan 3: Fail
```

Reporting Functions

The chassis manager on the forwarding engine control processor manages the local resources of the forwarding processor. The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router display warning messages on the console if the chassis interface-monitored parameters exceed a threshold. You can also retrieve and display environmental status reports with the following commands:

- **show environment all**
- **show version**
- **show inventory**
- **show platform**
- **show platform software status control-processor**
- **show diag**

Parameters are measured and reporting functions are updated every 60 seconds. A brief description of each of these commands follows.

show environment all Command

The **show environment all** command displays temperature, voltage, fan, and power supply information.

The following is sample output from the **show environment all** command.

```
Router# show environment all

Sensor List:  Environmental Monitoring
Sensor      Location      State      Reading
Vin         P0           Normal    0 V AC
Iin         P0           Normal    0 A
Vout        P0           Normal    0 V DC
Iout        P0           Normal    1 A
Temp1       P0           Normal    18 Celsius
Temp2       P0           Normal    21 Celsius
Temp3       P0           Normal    24 Celsius
VPPB1: VX1  R0           Normal    1003 mV
VPPB1: VX2  R0           Normal    6937 mV
VPPB1: VX3  R0           Normal    758 mV
VPPB1: VX4  R0           Normal    1049 mV
VPPB1: VP1  R0           Normal    1784 mV
VPPB1: VP2  R0           Normal    1517 mV
VPPB1: VP3  R0           Normal    1510 mV
VPPB1: VP4  R0           Normal    5057 mV
VPPB1: VH   R0           Normal    11982 mV
VPPB2: VX2  R0           Normal    818 mV
VPPB2: VX3  R0           Normal    856 mV
VPPB2: VP2  R0           Normal    3312 mV
VPPB2: VH   R0           Normal    11977 mV
```

VPPB3: VX1	R0	Normal	969 mV
VPPB3: VX2	R0	Normal	1004 mV
VPPB3: VP1	R0	Normal	2500 mV
VPPB3: VP2	R0	Normal	1207 mV
VPPB3: VP3	R0	Normal	1518 mV
VPPB3: VP4	R0	Normal	1518 mV
VPPB3: VH	R0	Normal	11987 mV
Temp: PPB IN	R0	Normal	21 Celsius
Temp: PPB OUT	R0	Normal	37 Celsius
Temp: Yoda 0	R0	Normal	48 Celsius
Temp: Yoda 1	R0	Normal	49 Celsius
Temp: CPU Die	R0	Normal	27 Celsius
Temp: FC FANS	R0	Fan Speed 60%	21 Celsius
VLIB1: VX1	R0	Normal	1001 mV
VLIB1: VX2	R0	Normal	7070 mV
VLIB1: VX3	R0	Normal	949 mV
VLIB1: VP1	R0	Normal	1796 mV
VLIB1: VP2	R0	Normal	2508 mV
VLIB1: VP3	R0	Normal	3309 mV
VLIB1: VH	R0	Normal	5033 mV
VLIB2: VX2	R0	Normal	752 mV
VLIB2: VX3	R0	Normal	751 mV
VLIB2: VP1	R0	Normal	1010 mV
VLIB2: VP2	R0	Normal	986 mV
VLIB2: VP3	R0	Normal	1195 mV
VLIB2: VP4	R0	Normal	1517 mV
VLIB2: VH	R0	Normal	11977 mV
Temp: LIB IN	R0	Normal	22 Celsius
Temp: LIB OUT	R0	Normal	32 Celsius

show version Command

The **show version** command displays the system hardware configuration, software version, and names and sources of configuration files and boot images.

The following is sample output from the **show version** command:

```
Router# show version

Cisco IOS XE Software, Version BLD_V162_1_THROTTLE_LATEST_20160119_234422_V16_2_0_259
Cisco IOS Software, ASR1000 Software (X86_64_LINUX_IOSD-UNIVERSALK9-M), Experimental
Version Denali 16.2.20160120:005403 [v162_1_throttle-BLD-BLD_V162_1_THROTTLE_LATEST_
20160119_234422_127]
Copyright (c) 1986-2016 by Cisco Systems, Inc.
Compiled Tue 19-Jan-16 20:53 by mcpre

Cisco IOS-XE software, Copyright (c) 2005-2016 by cisco Systems, Inc.
All rights reserved. Certain components of Cisco IOS-XE software are
licensed under the GNU General Public License ("GPL") Version 2.0. The
software code licensed under GPL Version 2.0 is free software that comes
with ABSOLUTELY NO WARRANTY. You can redistribute and/or modify such
GPL code under the terms of GPL Version 2.0. For more details, see the
documentation or "License Notice" file accompanying the IOS-XE software,
or the applicable URL provided on the flyer accompanying the IOS-XE
software.

ROM: IOS-XE ROMMON

ASR1002-HX uptime is 6 minutes
Uptime for this control processor is 7 minutes
System returned to ROM by reload
System image file is "bootflash:asr1002hx-universalk9.BLD_V162_1_THROTTLE_LATEST_
20160119_234422_V16_2_0_259.SS"
Last reload reason: Reload Command
```

This product contains cryptographic features and is subject to United

States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at: <http://www.cisco.com/wvl/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to export@cisco.com.

License Type: EvalRightToUse
License Level: adventerprise
Next reload license Level: adventerprise

cisco ASR1002-HX (2KH) processor (revision 2KH) with 3724092K/6147K bytes of memory.
Processor board ID FXS1922Q0LL
Crypto Hardware Module present
26 Gigabit Ethernet interfaces
8 Ten Gigabit Ethernet interfaces
32768K bytes of non-volatile configuration memory.
16777216K bytes of physical memory.
30056447K bytes of eUSB flash at bootflash:.
0K bytes of at webui:.

Configuration register is 0x2142

Router#

show inventory Command

The **show inventory** command displays an extended report that includes the product inventory listing of all the Cisco products installed in the networking device.

The following is sample output from the **show inventory** command:

```
Router# show inventory
NAME: "Chassis", DESCR: "Cisco ASR1002-HX Chassis"
PID: ASR1002-HX          , VID: V00   , SN: FXS1922Q0LL

NAME: "Power Supply Module 0", DESCR: "Cisco ASR1002-HX AC Power Supply"
PID: ASR1000X-AC-750W   , VID: V01   , SN: ART183011C

NAME: "Fan Tray", DESCR: "Cisco ASR1002-HX Fan Tray"
PID: ASR1002-HX-FANTRAY, VID:         , SN:

NAME: "module 0", DESCR: "Cisco ASR1002-HX Modular Interface Processor"
PID: ASR1002-HX         , VID:         , SN:

NAME: "SPA subslot 0/2", DESCR: "18-port Gigabit Ethernet Port Adapter"
PID: EPA-18X1GE         , VID: V00   , SN: JAE192700QL

NAME: "subslot 0/2 transceiver 17", DESCR: "GE SX"
PID: SFP-GE-S           , VID: 06    , SN: AGM1418P1TB

NAME: "SPA subslot 0/0", DESCR: "8-port Built-in Gigabit Ethernet Port Adapter"
PID: BUILT-IN-EPA-8x1G , VID: N/A   , SN: JAE12345678

NAME: "subslot 0/0 transceiver 0", DESCR: "GE SX"
PID: SFP-GE-S           , VID: 06    , SN: AGM1633P0R8

NAME: "subslot 0/0 transceiver 1", DESCR: "100BASE FX-GE"
PID: GLC-GE-100FX      , VID: A1A   , SN: OPT17501515

NAME: "subslot 0/0 transceiver 3", DESCR: "GE SX"
PID: SFP-GE-S           , VID: B     , SN: FNS16270V0S
```



```

NAME: "subslot 0/0 transceiver 4", DESCR: "GE SX"
PID: GLC-SX-MMD          , VID: 001  , SN: AGJ1825R4H0

NAME: "subslot 0/0 transceiver 5", DESCR: "GE SX"
PID: SFP-GE-S          , VID: B   , SN: FNS16270V1T

NAME: "subslot 0/0 transceiver 6", DESCR: "GE SX"
PID: FTRJ8519P1BNL-C5  , VID:   , SN: FNS0928K33L

NAME: "subslot 0/0 transceiver 7", DESCR: "GE SX"
PID: GLC-SX-MMD          , VID: A   , SN: FNS170907MM

NAME: "SPA subslot 0/1", DESCR: "8-port Built-in 10-Gigabit Ethernet Port Adapter"
PID: BUILT-IN-EPA-8x10G, VID: N/A  , SN: JAE87654321

NAME: "subslot 0/1 transceiver 0", DESCR: "SFP+ 10GBASE-SR"
PID: SFP-10G-SR        , VID: A   , SN: FNS17241B6A

NAME: "subslot 0/1 transceiver 2", DESCR: "SFP+ 10GBASE-SR"
PID: SFP-10G-SR        , VID: A   , SN: SPC144701S6

NAME: "subslot 0/1 transceiver 4", DESCR: "SFP+ 10GBASE-SR"
PID: SFP-10G-SR        , VID: G4.1 , SN: AVD1828A6PH

NAME: "subslot 0/1 transceiver 6", DESCR: "SFP+ 10GBASE-SR"
PID: SFP-10G-SR        , VID: A   , SN: FNS16190YXT

NAME: "module R0", DESCR: "Cisco ASR1002-HX Route Processor"
PID: ASR1002-HX        , VID: V00  , SN: JAE1931098U

NAME: "module F0", DESCR: "Cisco ASR1002-HX Embedded Services Processor"
PID: ASR1002-HX        , VID:   , SN:

Router#

```

show platform Command

The **show platform** command displays platform information.

The following is sample output from the **show platform** command:

```

Router# show platform

Chassis type: ASR1001-HX

Slot      Type                State                Insert time (ago)
-----
0         ASR1001-HX             ok                   00:03:19
  0/0     BUILT-IN-EPA-8x1G     ok                   00:02:08
  0/1     BUILT-IN-8X10G/1G    ok                   00:02:10
R0        ASR1001-HX             ok                   00:03:19
  R0/0   ok, active             00:03:19
  R0/1   ok, standby            00:01:42
F0        ASR1001-HX             ok, active           00:03:19
P0        ASR1000X-AC-750W      ok                   00:03:00
P1        ASR1000X-AC-750W      ok                   00:03:00
P2        ASR1001HX-FAN         ok                   1                   00:03:00

Slot      CPLD Version          Firmware Version
-----
0         15081816              16.2(2r)
R0        15081816              16.2(2r)
F0        15081816              16.2(2r)

Router#

```

show platform software status control-processor Command

The **show platform software status control-processor** command displays the average load, memory usage, and CPU utilization levels at which the router is running. The output also specifies whether the levels of these system health parameters are within defined thresholds.

The following is sample output from the **show platform software status control-processor** command:

```
Router# show platform software status control-processor

RP0: online, statistics updated 4 seconds ago
Load Average: healthy
1-Min: 1.67, status: healthy, under 8.00
5-Min: 0.95, status: healthy, under 8.00
15-Min: 0.50, status: healthy, under 10.00
Memory (kb): healthy
Total: 8058196
Used: 3077968 (38%), status: healthy
Free: 4980228 (62%)
Committed: 3993016 (50%), under 95%
Per-core Statistics
CPU0: CPU Utilization (percentage of time spent)
User: 0.89, System: 3.29, Nice: 0.00, Idle: 95.70
IRQ: 0.00, SIRQ: 0.09, IOWait: 0.00
CPU1: CPU Utilization (percentage of time spent)
User: 0.20, System: 2.10, Nice: 0.00, Idle: 97.69
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU2: CPU Utilization (percentage of time spent)
User: 1.10, System: 1.60, Nice: 0.00, Idle: 97.30
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU3: CPU Utilization (percentage of time spent)
User: 0.19, System: 0.19, Nice: 0.00, Idle: 99.60
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU4: CPU Utilization (percentage of time spent)
User: 0.60, System: 0.40, Nice: 0.00, Idle: 98.99
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU5: CPU Utilization (percentage of time spent)
User: 0.30, System: 0.30, Nice: 0.00, Idle: 99.40
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU6: CPU Utilization (percentage of time spent)
User: 0.70, System: 7.70, Nice: 0.00, Idle: 91.59
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU7: CPU Utilization (percentage of time spent)
User: 0.30, System: 0.40, Nice: 0.00, Idle: 99.30
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
```

show diag chassis eeprom detail Command

The **show diag chassis eeprom detail** command displays the configuration hardware information, including power or fan module P0 and P1 EEPROM data.

The following is sample output from the **show diag chassis eeprom detail** command:

```
Router# show diag chassis eeprom detail
MIDPLANE EEPROM data:

EEPROM version           : 4
Compatible Type          : 0xFF
Controller Type          : 3236
Hardware Revision        : 0.3
PCB Part Number          : 73-16562-03
Board Revision           : 01
Deviation Number         : 0-0
Fab Version              : 03
PCB Serial Number        : JAE1931098L
RMA Test History         : 00
RMA Number               : 0-0-0-0
RMA History              : 00
Top Assy. Part Number    : 68-5448-02
CLEI Code                : SAMPL00XYZ
```

```

Product Identifier (PID) : ASR1002-HX
Version Identifier (VID) : V00
Manufacturing Test Data : 00 00 00 00 00 00 00 00
Field Diagnostics Data : 00 00 00 00 00 00 00 00
Chassis MAC Address     : 74a2.e624.fb00
MAC Address block size  : 256
Chassis Serial Number   : FXS1922Q0MJ
Environment Monitor Data : 00 06 00 FA
Asset ID                :
Power/Fan Module P0 EEPROM data:

```

```

EEPROM version          : 4
Compatible Type         : 0xFF
Hardware Revision       : 0.1
Version Identifier (VID) : V01
Product Identifier (PID) : ASR1000X-AC-750W
PCB Serial Number      : ART183011B
Top Assy. Part Number   : 341-00714-01
Board Revision          : A0
Deviation Number        : 0-0
RMA Test History        : 00
RMA Number              : 0-0-0-0
RMA History             : 00
CLEI Code               : TBD
Manufacturing Test Data : 00 00 00 00 00 00 00 00
Field Diagnostics Data  : 00 00 00 00 00 00 00 00
Unknown Field (type 00DA) : 00 00 00 00 00 00 00 00
                        : 00 00 00 00 00 00 00 00
Asset ID                :
Power Supply Type       : AC
Environment Monitor Data : 00 08 00 F8
Environment Monitor Data : 02 A5 2E E2 EE 00 5B
Environment Monitor Data : 05 02 03 50 03 58 00 4B
Platform features       : 00 00 03 56 1E 53 0F 2A
                        : 00 00 00 00 00 00 00 00
                        : FD

```

```
Power/Fan Module P1 EEPROM data:
```

```

EEPROM version          : 4
Compatible Type         : 0xFF
Hardware Revision       : 0.1
Version Identifier (VID) : V01
Product Identifier (PID) : ASR1000X-AC-750W
PCB Serial Number      : ART183011B
Top Assy. Part Number   : 341-00714-01
Board Revision          : A0
Deviation Number        : 0-0
RMA Test History        : 00
RMA Number              : 0-0-0-0
RMA History             : 00
CLEI Code               : TBD
Manufacturing Test Data : 00 00 00 00 00 00 00 00
Field Diagnostics Data  : 00 00 00 00 00 00 00 00
Unknown Field (type 00DA) : 00 00 00 00 00 00 00 00
                        : 00 00 00 00 00 00 00 00
Asset ID                :
Power Supply Type       : AC
Environment Monitor Data : 00 08 00 F8
Environment Monitor Data : 02 A5 2E E2 EE 00 5B
Environment Monitor Data : 05 02 03 50 03 58 00 4B
Platform features       : 00 00 03 56 1E 53 0F 2A
                        : 00 00 00 00 00 00 00 00
                        : FD

```




License Verification

This chapter provides information about verifying the Cisco IOS license level, viewing the Cisco ASR 1001-HX Router or Cisco ASR 1002-HX Router license, and configuring the port license and crypto throughput level.

- [Viewing the Cisco IOS License Level, page 97](#)
- [Viewing License Information, page 98](#)
- [Port Licensing, page 103](#)
- [Evaluation License Features, page 109](#)
- [Configuring the Crypto Throughput Level, page 109](#)

Viewing the Cisco IOS License Level

Use the show version command to determine the Cisco IOS license level in the router. For example:

```
Router# show version
.
.
.
License Level: adventerprise
License Type: RightToUse
Next reload license Level: adventerprise
.
.
.
```

Table 14: show version Command Output Description

Field Name	Description
License Level: adventerprise	Indicates the current Cisco IOS license code level.

Field Name	Description
License Type: RightToUse	Indicates the type of license that is used. This example shows that the Right-to-Use license is used, which means that the purchase of a license is required. Other license types could be: Permanent (purchased) license or an Evaluation 60-day license.
Next reload license Level: adventerprise	Indicates the startup configuration definition that will be used for the next reload instance.

Use the **show running-config** command or the **show startup-config** command to view the license-level information. The following example displays sample output from the **show running-config** command:

```
Router# show running-config
.
.
.
license boot level adventerprise
.
.
.
```

Table 15: show running-config Command Output Description

Field Name	Description
license boot level adventerprise	Indicates the current requested Cisco IOS license level to boot.

Viewing License Information

Use the **show license udi** command to determine the Universal Device Identifier (UDI) information of your chassis. This may be required at the time of purchasing a new license.

The following example displays sample output from the **show license udi** command:

```
Router# show license udi

SlotID   PID                               SN                               UDI
-----
*        ASR1002-HX                       JAE1931098U                     ASR1002-HX:JAE1931098U
```

Use the **show license all** command to display all the applicable licenses in both Primary License Storage and Built In License Storage.



Note Primary License Storage stores the currently purchased and installed licenses.

The following example displays sample output from the **show license all** command for the Cisco ASR 1001-HX Router:

```

Router# show license all

License Store: Primary License Storage
License Store: Built-In License Storage
StoreIndex: 0   Feature: adventerprise                               Version: 1.0
  License Type: EvalRightToUse
  License State: Active, In Use
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 5 weeks 2 days
    Period used: 3 weeks 1 day
    Transition date: Sep 02 2016 21:19:13
  License Count: Non-Counted
  License Priority: Low
StoreIndex: 1   Feature: advipservices                             Version: 1.0
  License Type: EvalRightToUse
  License State: Active, Not in Use, EULA not accepted
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 8 weeks 4 days
    Period used: 0 minute 0 second
  License Count: Non-Counted
  License Priority: None
StoreIndex: 2   Feature: avc                                       Version: 1.0
  License Type: EvalRightToUse
  License State: Active, Not in Use, EULA not accepted
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 8 weeks 4 days
    Period used: 0 minute 0 second
  License Count: Non-Counted
  License Priority: None
StoreIndex: 3   Feature: fwnat_red                                 Version: 1.0
  License Type: EvalRightToUse
  License State: Active, Not in Use, EULA not accepted
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 8 weeks 4 days
    Period used: 0 minute 0 second
  License Count: Non-Counted
  License Priority: None
StoreIndex: 4   Feature: ipsec                                       Version: 1.0
  License Type: EvalRightToUse
  License State: Active, Not in Use, EULA not accepted
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 8 weeks 4 days
    Period used: 0 minute 0 second
  License Count: Non-Counted
  License Priority: None
StoreIndex: 5   Feature: lawful_intr                               Version: 1.0
  License Type: EvalRightToUse
  License State: Active, Not in Use, EULA not accepted
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 8 weeks 4 days
    Period used: 0 minute 0 second
  License Count: Non-Counted
  License Priority: None
StoreIndex: 6   Feature: lisp                                       Version: 1.0
  License Type: EvalRightToUse
  License State: Active, Not in Use, EULA not accepted
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 8 weeks 4 days
    Period used: 0 minute 0 second
  License Count: Non-Counted
  License Priority: None
StoreIndex: 7   Feature: otv                                         Version: 1.0
  License Type: EvalRightToUse
  License State: Active, Not in Use, EULA not accepted
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 8 weeks 4 days
    Period used: 0 minute 0 second
  License Count: Non-Counted
  License Priority: None

```

```

StoreIndex: 8  Feature: sw_redundancy                      Version: 1.0
  License Type: EvalRightToUse
  License State: Active, In Use
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 7 weeks 4 days
    Period used: 6 days 7 hours
    Transition date: Sep 18 2016 23:31:13
  License Count: Non-Counted
  License Priority: Low
StoreIndex: 9  Feature: vpls                              Version: 1.0
  License Type: EvalRightToUse
  License State: Active, Not in Use, EULA not accepted
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 8 weeks 4 days
    Period used: 0 minute 0 second
  License Count: Non-Counted
  License Priority: None
StoreIndex: 10 Feature: FoundationSuiteK9                 Version: 1.0
  License Type: EvalRightToUse
  License State: Active, Not in Use, EULA not accepted
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 8 weeks 4 days
    Period used: 0 minute 0 second
  License Count: Non-Counted
  License Priority: None
StoreIndex: 11 Feature: AdvUCSuiteK9                     Version: 1.0
  License Type: EvalRightToUse
  License State: Active, Not in Use, EULA not accepted
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 8 weeks 4 days
    Period used: 0 minute 0 second
  License Count: Non-Counted
  License Priority: None
StoreIndex: 12 Feature: 1HXIPS8G                         Version: 1.0
  License Type: EvalRightToUse
  License State: Active, In Use
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 5 weeks 3 days
    Period used: 3 weeks 0 day
    Transition date: Sep 04 2016 03:48:08
  License Count: Non-Counted
  License Priority: Low
StoreIndex: 13 Feature: 1HX8G16G                         Version: 1.0
  License Type: EvalRightToUse
  License State: Active, In Use
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 5 weeks 3 days
    Period used: 3 weeks 0 day
    Transition date: Sep 04 2016 03:48:14
  License Count: Non-Counted
  License Priority: Low
StoreIndex: 14 Feature: interface_10g                    Version: 1.0
  License Type: EvalRightToUse
  License State: Active, In Use
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 5 weeks 3 days
    Period used: 3 weeks 0 day
    Transition date: Sep 04 2016 02:34:06
  License Count: 2/0 (In-use/Violation)
  License Priority: Low
StoreIndex: 15 Feature: interface_1g                     Version: 1.0
  License Type: EvalRightToUse
  License State: Active, In Use
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 5 weeks 3 days
    Period used: 3 weeks 0 day
    Transition date: Sep 04 2016 00:20:43
  License Count: 2/0 (In-use/Violation)
  License Priority: Low

```

Router#

The following example displays sample output from the **show license all** command for the Cisco ASR 1002-HX Router:

```

Router# show license all
License Store: Primary License Storage
License Store: Built-In License Storage
StoreIndex: 0 Feature: adventerprise Version: 1.0
License Type: EvalRightToUse
License State: Active, In Use
Evaluation total period: 8 weeks 4 days
Evaluation period left: 3 days 13 hours
Period used: 8 weeks 0 day
Transition date: Jan 25 2016 07:31:44
License Count: Non-Counted
License Priority: Low
StoreIndex: 1 Feature: advipservices Version: 1.0
License Type: EvalRightToUse
License State: Active, Not in Use, EULA not accepted
Evaluation total period: 8 weeks 4 days
Evaluation period left: 8 weeks 4 days
Period used: 0 minute 0 second
License Count: Non-Counted
License Priority: None
StoreIndex: 2 Feature: avc Version: 1.0
License Type: EvalRightToUse
License State: Active, Not in Use, EULA not accepted
Evaluation total period: 8 weeks 4 days
Evaluation period left: 8 weeks 4 days
Period used: 0 minute 0 second
License Count: Non-Counted
License Priority: None
StoreIndex: 3 Feature: fwnat_red Version: 1.0
License Type: EvalRightToUse
License State: Active, Not in Use, EULA not accepted
Evaluation total period: 8 weeks 4 days
Evaluation period left: 8 weeks 4 days
Period used: 0 minute 0 second
License Count: Non-Counted
License Priority: None
StoreIndex: 4 Feature: ipsec Version: 1.0
License Type: EvalRightToUse
License State: Active, Not in Use, EULA not accepted
Evaluation total period: 8 weeks 4 days
Evaluation period left: 8 weeks 4 days
Period used: 0 minute 0 second
License Count: Non-Counted
License Priority: None
StoreIndex: 5 Feature: lawful_intr Version: 1.0
License Type: EvalRightToUse
License State: Active, Not in Use, EULA not accepted
Evaluation total period: 8 weeks 4 days
Evaluation period left: 8 weeks 4 days
Period used: 0 minute 0 second
License Count: Non-Counted
License Priority: None
StoreIndex: 6 Feature: lisp Version: 1.0
License Type: EvalRightToUse
License State: Active, Not in Use, EULA not accepted
Evaluation total period: 8 weeks 4 days
Evaluation period left: 8 weeks 4 days
Period used: 0 minute 0 second
License Count: Non-Counted
License Priority: None
StoreIndex: 7 Feature: otv Version: 1.0
License Type: EvalRightToUse
License State: Active, Not in Use, EULA not accepted
Evaluation total period: 8 weeks 4 days
Evaluation period left: 8 weeks 4 days
Period used: 0 minute 0 second
License Count: Non-Counted
License Priority: None
StoreIndex: 8 Feature: sw_redundancy Version: 1.0

```

```

License Type: EvalRightToUse
License State: Active, Not in Use, EULA accepted
  Evaluation total period: 8 weeks 4 days
  Evaluation period left: 7 weeks 0 day
  Period used: 1 week 3 days
License Count: Non-Counted
License Priority: Low
StoreIndex: 9 Feature: vpls Version: 1.0
License Type: EvalRightToUse
License State: Active, Not in Use, EULA not accepted
  Evaluation total period: 8 weeks 4 days
  Evaluation period left: 8 weeks 4 days
  Period used: 0 minute 0 second
License Count: Non-Counted
License Priority: None
StoreIndex: 10 Feature: FoundationSuiteK9 Version: 1.0
License Type: EvalRightToUse
License State: Active, Not in Use, EULA not accepted
  Evaluation total period: 8 weeks 4 days
  Evaluation period left: 8 weeks 4 days
  Period used: 0 minute 0 second
License Count: Non-Counted
License Priority: None
StoreIndex: 11 Feature: AdvUCSuiteK9 Version: 1.0
License Type: EvalRightToUse
License State: Active, Not in Use, EULA not accepted
  Evaluation total period: 8 weeks 4 days
  Evaluation period left: 8 weeks 4 days
  Period used: 0 minute 0 second
License Count: Non-Counted
License Priority: None
StoreIndex: 12 Feature: 2HXIPS8G Version: 1.0
License Type: EvalRightToUse
License State: Active, In Use
  Evaluation total period: 8 weeks 4 days
  Evaluation period left: 6 weeks 5 days
  Period used: 1 week 5 days
  Transition date: Mar 09 2016 16:10:35
License Count: Non-Counted
License Priority: Low
StoreIndex: 13 Feature: 2HX8G16G Version: 1.0
License Type: EvalRightToUse
License State: Active, Not in Use, EULA not accepted
  Evaluation total period: 8 weeks 4 days
  Evaluation period left: 8 weeks 4 days
  Period used: 0 minute 0 second
License Count: Non-Counted
License Priority: None
StoreIndex: 14 Feature: 2HX8G25G Version: 1.0
License Type: EvalRightToUse
License State: Active, In Use
  Evaluation total period: 8 weeks 4 days
  Evaluation period left: 6 weeks 5 days
  Period used: 1 week 5 days
  Transition date: Mar 09 2016 16:10:35
License Count: Non-Counted
License Priority: Low
StoreIndex: 15 Feature: 2HX16G25G Version: 1.0
License Type: EvalRightToUse
License State: Active, Not in Use, EULA not accepted
  Evaluation total period: 8 weeks 4 days
  Evaluation period left: 8 weeks 4 days
  Period used: 0 minute 0 second
License Count: Non-Counted
License Priority: None
StoreIndex: 16 Feature: interface_10g Version: 1.0
License Type: EvalRightToUse
License State: Active, Not in Use, EULA accepted
  Evaluation total period: 8 weeks 4 days
  Evaluation period left: 7 weeks 1 day
  Period used: 1 week 2 days
License Count: 0/0 (In-use/Violation)
License Priority: Low

```

```

StoreIndex: 17  Feature: interface_1g  Version: 1.0
License Type: EvalRightToUse
License State: Active, In Use
  Evaluation total period: 8 weeks 4 days
  Evaluation period left: 8 weeks 2 days
  Period used: 1 day 2 hours
  Transition date: Apr 23 2016 22:33:22
License Count: 1/0 (In-use/Violation)
License Priority: Low

router#


```

Port Licensing

Port Licensing for the Cisco ASR 1001-HX Router

The Cisco ASR 1001-HX Router has eight 1GE SFP ports in Bay 0 and eight 1GE SFP or 10GE SFP+ ports in Bay 1. By default, four ports in Bay 0 and four ports in Bay 1 can be enabled without a license (ports 0 through 3). The remaining ports can be enabled in pairs (ports 4 and 5; and ports 6 and 7) through licenses.

Figure 34: Cisco ASR 1001-HX Router Ports



1	1GE SFP ports 0-3 can be enabled by default.	4	10GE SFP+ ports 0-3 can be enabled by default.
2	1GE ports 4 and 5 require a port license. Enabling either port will use one port license. Licensed ports use a 1GE port license when you install SFP in either 4 or 5 port; or in both 4 and 5 ports.	5	10GE ports 4 and 5 require a port license. Enabling either port will use one port license. <ul style="list-style-type: none"> Licensed ports use a 1GE port license when you install SFP in either 4 or 5 port; or in both 4 and 5 ports. Licensed ports use a 10GE port license when you install a combination of SFP and SFP+ or SFP+ in both 4 and 5 ports.

3	<p>1GE ports 6 and 7 require a port license. Enabling either port will use one port license.</p> <p>Licensed ports use a 1GE port license when you install SFP in either 6 or 7 port; or in both 6 and 7 ports.</p>	6	<p>10GE ports 6 and 7 require a port license. Enabling either port will use one port license.</p> <ul style="list-style-type: none"> Licensed ports use a 1GE port license when you install SFP in either 6 or 7 port; or in both 6 and 7 ports. Licensed ports use a 10GE port license when you install a combination of SFP and SFP+ or SFP+ in both 6 and 7 ports.
---	---	---	---

Enabling one of the ports in a port pair using the **no shut** command consumes one count of the license, and the In-use count increases by 1.

Disabling the ports in the port pair using the **shut** command releases one count of the license, and the In-use count decreases by 1.

An End-User License Agreement (EULA) is displayed for each port pair if there is no permanent license present to support these ports.

Cisco ASR 1001-HX Router Licensing

The Cisco ASR 1001-HX Router image carries four 1GE and two 10GE port EvalRTU (Evaluation) licenses. If the EvalRTU license expires, it becomes a Right-To-Use (RTU) license.

- Licensed ports in Bay 0 use a 1GE port license.
- Licensed ports in Bay 1 use a 1GE port license when you install SFP in either ports of a port pair; or in both ports of a port pair (ports 4 and 5, or ports 6 and 7).
- Licensed ports in Bay 1 use a 10GE port license when you install a combination of SFP and SFP+ or SFP+ in both ports of a port pair (ports 4 and 5, or ports 6 and 7).



Caution

Cross-combinations (breaking the port grouping) with respect to paired licenses on ports is invalid. For example, if you purchase a paired license that is applicable for ports 4 and 5, and then you try to bring up ports 4 and 7, it will not work because this cross-combination is invalid.



Note

If you have an SFP and an SFP+ in a port pair, and you disable the SFP+ port, the license reverts to a 1GE license.



Note

If you power on the Cisco ASR 1001-HX Router before you install an SFP or SFP+, the licensed ports in Bay 1 use a 10GE port license.

For all possible port licensing scenarios, see [Licensing Scenarios for Cisco ASR 1001-HX Router, on page 105](#).

Example

The following EvalRTU license example displays the EvalRTU licenses used on the 10GE and 1G ports. A Permanent license works similarly:

```

Index 33 Feature: interface_10g
  Period left: 7 weeks 5 days
  Period Used: 5 days 6 hours
  License Type: EvalRightToUse
  License State: Active, Not in Use, EULA accepted
  License Count: 0/0 (In-use/Violation)
  License Priority: Low

Index 34 Feature: interface_1g
  Period left: 7 weeks 5 days
  Period Used: 5 days 15 hours
  License Type: EvalRightToUse
  License State: Active, Not in Use, EULA accepted
  License Count: 0/0 (In-use/Violation)
  License Priority: Low

```

Table 16: show license all Command Output Description

Field Name	Description
License Count: 0/0 (In-use/Violation)	No ports in use for the evaluation license.
License Count: 2/0 (In-use/Violation)	Two port pairs in use for the evaluation license (an EULA was accepted for each prior to use).

Licensing Scenarios for Cisco ASR 1001-HX Router

The following table provides all possible licensing scenarios for the Cisco ASR 1001-HX Router.

**Note**

Cisco ASR 1001-HX Router router supports dual modes of speed. Depending on the SFP present in the router, Bay 1 can work as 10GE or 1GE speed.

Table 17: Cisco ASR 1001-HX Router—BAY 0 (1GE Port)

Port 4 or Port 6	Port 4 or Port 6	License Consumption
SHUT	SHUT	No License
SHUT	NO_SHUT	1GE License
NO_SHUT	SHUT	1GE License
NO_SHUT	NO_SHUT	1GE License

Table 18: Cisco ASR 1001-HX Router—BAY 1 (10GE Port)


Port 4 or Port 6	Port 4 or Port 6	License Consumption
SHUT	SHUT	No License
SHUT	NO_SHUT	10GE License
NO_SHUT	SHUT	10GE License
NO_SHUT	NO_SHUT	10GE License

Table 19: Cisco ASR 1001-HX Router—BAY 1 (1GE Port)

Port 4	Port 5	License Consumption
SHUT	SHUT	No License
SHUT	NO_SHUT	1GE License
NO_SHUT	SHUT	1GE License
NO_SHUT	NO_SHUT	1GE License

Port Licensing for the Cisco ASR 1002-HX Router

The Cisco ASR 1002-HX Router has eight 1GE ports in Bay 0 and eight 10GE ports in Bay 1. By default, four ports in Bay 0 and four ports in Bay 1 can be enabled without a license (ports 0 through 3). The remaining ports can be enabled in pairs (ports 4 and 5, and ports 6 and 7) through licenses.

Figure 35: Cisco ASR 1002-HX Router Ports

1	1GE ports 0–3 can be enabled by default.	4	10GE ports 0–3 can be enabled by default.
---	--	---	---

2	1GE ports 4 and 5 require a port license. Enabling either port will use one port license.	5	10GE ports 4 and 5 require a port license. Enabling either port will use one port license.
3	1GE ports 6 and 7 require a port license. Enabling either port will use one port license.	6	10GE ports 6 and 7 require a port license. Enabling either port will use one port license.

Enabling one of the ports in a port pair using the **no shut** command consumes one count of the license, and the In-use count increases by 1.

Disabling the ports in the port pair using the **shut** command releases one count of the license, and the In-use count decreases by 1.

An End-User License Agreement (EULA) is displayed for each port pair if there is no permanent license present to support these ports.

Cisco ASR 1002-HX Router Licensing

The Cisco ASR 1002-HX Router image carries two 1GE and two 10GE port EvalRTU (Evaluation) licenses. If the EvalRTU license expires, it becomes a Right-To-Use (RTU) license.

- Licensed ports in Bay 0 use a 1GE port license.
- Licensed ports in Bay 1 use a 10GE port license.

For all possible port licensing scenarios, see [Licensing Scenarios for Cisco ASR 1002-HX Router](#), on page 108.

Example

The following EvalRTU license example displays the EvalRTU licenses used on the 10GE ports. A Permanent license works similarly:

```
StoreIndex: 16 Feature: interface_10g Version: 1.0
License Type: EvalRightToUse
License State: Active, In Use
Evaluation total period: 8 weeks 4 days
Evaluation period left: 8 weeks 3 days
Period used: 3 hours 13 minutes
Transition date: Aug 16 2013 19:05:26
License Count: 0/0 (In-use/Violation)
License Priority: Low
```

...

```
StoreIndex: 16 Feature: interface_10g Version: 1.0
License Type: EvalRightToUse
License State: Active, In Use
Evaluation total period: 8 weeks 4 days
Evaluation period left: 8 weeks 3 days
Period used: 3 hours 13 minutes
Transition date: Aug 16 2013 19:05:26
License Count: 2/0 (In-use/Violation)
License Priority: Low
```

Table 20: show license all Command Output Description

Field Name	Description
License Count: 0/0 (In-use/Violation)	No ports in use for the evaluation license.
License Count: 2/0 (In-use/Violation)	Two port pairs in use for the evaluation license (an EULA was accepted for each prior to use).

Licensing Scenarios for Cisco ASR 1002-HX Router

The following table provides all possible licensing scenarios for the Cisco ASR 1002-HX Router.


Note

In the Cisco ASR 1002-HX Router, Bay 0 can only support 1GE SFP and Bay 1 can only support 10GE SFP+ speed.

Table 21: Cisco ASR 1002-HX Router—BAY 0 (1GE Port)

Port 4 or Port 6	Port 5 or Port 7	License Consumption
SHUT	SHUT	No License
SHUT	NO_SHUT	1GE License
NO_SHUT	SHUT	1GE License
NO_SHUT	NO_SHUT	1GE License

Table 22: Cisco ASR 1002-HX Router—BAY 1 (10GE Port)

Port 4 or Port 6	Port 5 or Port 7	License Consumption
SHUT	SHUT	No License
SHUT	NO_SHUT	10GE License
NO_SHUT	SHUT	10GE License
NO_SHUT	NO_SHUT	10GE License

Evaluation License Features

The following are the features of the 1GE and 10GE Interface Evaluation license:

- There is only one 60-Day Evaluation Period countdown timer for the 1GE port pairs and 10GE port pairs. The timer is initiated as soon as the first of the port pairs is enabled.
- A EULA will be presented, and must be accepted, the first time you enable any of the ports in order to utilize the requested port.
- When the 60-Day Evaluation Period expires, the license automatically changes to an RTU license. As with all other RTU licenses, there is no functionality disruption or accessibility concerns following this transition.
- There can be only one active interface_1g license and one active interface_10g license. Either the Permanent License or the EvalRTU License can be Active, but not both.
- As with past license implementations, the Permanent license is of higher precedence than the built-in EvalRTU license. However, when the Permanent license does not have enough port-count (that is, when the user requests both port pairs but the Permanent License only allows for one port pair), the license priority changes between the Permanent and Evaluation licenses. In this case, the Evaluation License becomes Active since it can accommodate both port pairs. The Permanent License will automatically become Active if and when its port-count meets the user's desired configuration.

Configuring the Crypto Throughput Level

The field-upgradable crypto module has no default throughput. You can upgrade the throughput by applying a crypto throughput upgrade license. The Cisco ASR 1001-HX Router supports throughput levels of 8 Gbps or 16 Gbps. The Cisco ASR 1002-HX Router supports throughput levels of 8 Gbps, 16 Gbps, or 25 Gbps.

The following two types of crypto throughput licenses are available on the Cisco ASR 1001-HX Router and the Cisco ASR 1002-HX Router:

- Right-to-Use (RTU) license, which is honor-based
- Permanent license

When you use a Permanent license for crypto-throughput and want to upgrade it, you must download the appropriate Permanent license to upgrade it .

When you have an RTU license, you do not need to download a separate license (for example, a Permanent license). The license is already provided with the Cisco IOS. Therefore, to upgrade the RTU license, all you need to do is configure the crypto to a higher-level license.



Note

To install permanent IPsec license, you do not have to use license install commands. License related for example **show license feature** and **show license** commands do not have any IPsec related references.

To determine the current throughput level of the crypto module, enter the **show platform hardware crypto-throughput level** command. The following example shows the output from this command before you apply a crypto throughput upgrade license:

```
Router# show platform hardware crypto-throughput level
*Jun 17 22:04:56.711: %SYS-5-CONFIG_I: Configured from console by console
The current crypto throughput level is 0000000 kbps
```

To configure the crypto throughput level on the Cisco ASR 1001-HX Router, enter the following command:

```
Router(config)# platform hardware crypto-throughput level ?
 8-16g    crypto throughput upgrade, bits per second
 8g       crypto throughput level, bits per second

Router(config)# platform hardware crypto-throughput level 8g
% Crypto Bandwidth set to 8G bps.

Router(config)# platform hardware crypto-throughput level 8-16g
% Crypto Bandwidth set to 16G bps.
```

To configure the crypto throughput level on the Cisco ASR 1002-HX Router, enter the following command:

```
Router(config)# platform hardware crypto-throughput level ?
16-25g    crypto throughput upgrade, bits per second
 8-16g    crypto throughput upgrade, bits per second
 8-25g    crypto throughput upgrade, bits per second
 8g       crypto throughput level, bits per second
```

The following example shows the output of the **show platform hardware crypto-throughput level** command after you apply an 8-Gbps crypto-throughput upgrade license:

```
Router# show platform hardware crypto-throughput level
*Jun 17 22:07:07.078: %SYS-5-CONFIG_I: Configured from console by console
The current crypto throughput level is 8000000 kbps
```

To remove the configuration, enter the following command:

```
Router(config)# no platform hardware crypto-throughput level 8g
% Crypto Bandwidth reset to default 0g bps.
```



Note

Configuring a higher-level license automatically enables the lower-level licenses as Right to Use (RTU) if the corresponding permanent licenses are not installed yet. For example, configuring 16-25g on the Cisco ASR 1002-HX Router automatically enables 8g and 8-16g as RTU.

For more information about the software-activated performance upgrade license, see the [Software Activation Guide](#).



Removing and Replacing FRUs

This chapter describes procedures for removing and replacing field-replaceable units (FRUs) from Cisco ASR 1001-HX and 1002-HX Routers.

- [Removing and Replacing the Crypto Modules, page 111](#)
- [Removing AC Power Supplies, page 115](#)
- [Installing AC Power Supplies, page 116](#)
- [Removing DC Input Power Supplies, page 116](#)
- [Installing DC Input Power Supplies, page 117](#)
- [Removing and Replacing USB Flash Memory Stick, page 120](#)
- [Removing and Replacing a DIMM, page 120](#)
- [Removing and Replacing an EPA, page 131](#)
- [Removing and Replacing a NIM, page 133](#)
- [Removing and Replacing Fans, page 135](#)
- [Repacking the Router, page 144](#)

Removing and Replacing the Crypto Modules

The following sections describe the procedures for removing and replacing the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router crypto modules.



Note

The crypto modules in Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router are optional and field-upgradeable components

Removing and Replacing the Crypto Module in a Cisco ASR 1001-HX Router

Before You Begin

Perform the following steps before you begin the process of installing the crypto module in a Cisco ASR 1001-HX Router:

- Shut down the router. Enter the **copy running-config startup-config** command to save the configuration to NVRAM.
- Use an ESD-preventive wrist strap.
- Remove the power supplies before you remove the chassis top cover.

**Caution**

The top cover cannot be removed until the power supplies are removed from the chassis. The chassis has a safety mechanism built in to prevent the removal of the top cover until the power supplies are removed.

Procedure

Step 1 With an ESD wrist strap on, remove the power supplies from the chassis.

Note The chassis cover cannot be removed until the power supplies are removed from the chassis.

For instructions about how to remove the AC and DC power supplies, see:

- [Removing AC Power Supplies](#)
- [Removing DC Input Power Supplies](#)


Step 2 Remove the router from the rack.

Step 3 Remove the chassis top cover by performing the following steps:

- a) Remove the fourteen top surface screws on the chassis cover.
- b) Remove the two screws from the left side of the chassis and the two screws from the right side of the chassis.

- c) Putting your thumbs in the thumb depression shown in the following figure, slide the cover slightly backward and lift it off of the chassis.


Figure 36: Cisco ASR 1001-HX Router Top Cover Screw Locations



1	Thumb depression location
---	---------------------------

- Step 4** Remove the crypto module from its ESD bag.
- Step 5** Carefully align the crypto module with its connector on the mother board and snap into place.
- Step 6** Install the four screws into the location shown below and torque it to 5 in-lbs.

Figure 37: Cisco ASR 1001-HX Router Crypto Module



1	Screws	2	Crypto module
---	--------	---	---------------

- Step 7** Install the cover.
- Step 8** Install the chassis in the rack.
- Step 9** Power up the router by plugging in the power supplies and placing the chassis power switch to the On position.
- Step 10** Use the **show platform hardware crypto-device 0 status** command to verify successful installation:

```
Router# show platform hardware crypto-device 0 status
```

```
Encryption processor is functional
```

Removing and Replacing the Crypto Module in a Cisco ASR 1002-HX Router


Before You Begin

To install the crypto module, you must shut down the router and remove it from the rack. Enter the **copy running-config startup-config** command to save the configuration to NVRAM.

Procedure


- Step 1** Power down the router by placing the chassis power switch in the Standby position and unplug the power supplies.
- Step 2** Remove the router from the rack.
- Step 3** Open the access panel on the right side of the chassis by removing the 5 screws, as shown in the following figure.

Figure 38: Access Panel Screws



- Step 4** Align the crypto module with the guide rails and carefully slide the crypto module into the slot until it is fully seated.

Figure 39: Installing the Crypto Module



- Step 5** Tighten the captive installation screws on the crypto module.
- Step 6** Replace the access panel and screws.
- Step 7** Install the chassis in the rack.
- Step 8** Power up the router by plugging in the power supplies and placing the chassis power switch to the On position.
- Step 9** Use the **show platform hardware crypto-device 0 status** command to verify successful installation:

```
Router# show platform hardware crypto-device 0 status
```

```
Encryption processor is functional
```

Removing AC Power Supplies

Procedure

- Step 1** Ensure that the chassis power switch is in the Standby position.
- Note** It is not required to place the chassis power switch in the Standby position if you want to hot-swap a single power supply.
- Step 2** Unplug the power cable from the power supply.
- Step 3** Press the retaining latch towards the pull handle, grasp the handle with one hand, and pull the power supply out of the slot while supporting the weight of the power supply with the other hand.
- Step 4** Repeat these steps if it is required to remove the other AC power supply.

Installing AC Power Supplies



Note Do not install the power supplies with the chassis cover off.

Procedure

- Step 1** Ensure that the chassis power switch on the chassis is in the Standby position.
- Note** It is not required to place the chassis power switch in the Standby position if you want to hot-swap a single power supply.
- Step 2** Insert the power supply module into the appropriate slot(s), making sure that the retention latch is firmly placed. You can verify that the power supply module is firmly latched by gently pulling the power supply handle.
- Step 3** Insert the power supply cables firmly into the power supplies.
- Note** Ensure that both power supplies are inserted firmly and the power cords are in place.
- Step 4** If you have changed the chassis power switch to the Standby position in Step 1, press the power switch to the On position.
The power supply LEDs are illuminated (green).
-

Removing DC Input Power Supplies

The DC power supply has a terminal block that is installed into the power supply terminal block header.

Procedure

- Step 1** Turn off the circuit breaker from the power source.
- Step 2** Ensure that the chassis power switch is in the Standby position.
- Note** It is not required to place the chassis power switch in the Standby position if you want to hot-swap a single power supply.
- Step 3** Remove the plastic cover from the terminal block.
- Step 4** Unscrew the two terminal block screws on the unit and remove the wires from the power supply.
- Step 5** Press the power supply retaining latch towards the pull handle, grasp the handle with one hand, and pull the power supply out of the slot while supporting the weight of the power supply with the other hand.
-

Installing DC Input Power Supplies

**Warning****Statement 1003**—DC Power Disconnection

Before performing any of the following procedures, ensure that power is removed from the DC circuit.

**Warning****Statement 1030**—Equipment Installation

Only trained and qualified personnel should be allowed to install, replace, or service this equipment.

**Note**

Do not install the power supplies with the chassis cover off.

This section describes how to install the DC power supply input power leads to the DC input power supply. Before you begin, read these important notices:


- The color coding of the DC input power supply leads depends on the color coding of the DC power source at your site. Ensure that the lead color coding you choose for the DC input power supply matches the lead color coding used at the DC power source and verify that the power source is connected to the negative (–) terminal and to the positive (+) terminal on the power supply.
- Ensure that the chassis ground is connected on the chassis before you begin installing the DC power supply. Follow the steps provided in the "[Chassis Ground Connection](#)" section.
- For DC input power cables, the wire gauge is based on the National Electrical Code (NEC) and local codes for 26 amp service at nominal DC input voltage (–40/–72 VDC). One pair of cable leads, source DC (–) and source DC return (+), are required for each power distribution unit (PDU). These cables are available from any commercial cable vendor. All DC input power cables for the chassis should be 10 gauge wire and cable lengths should match within 10 percent of deviation.

Each DC input power cable is terminated at the PDU by a cable lug, as shown in the following figure.

**Note**

DC input power cables must be connected to the PDU terminal studs in the proper positive (+) and negative (-) polarity. In some cases, the DC cable leads are labeled, which is a relatively safe indication of the polarity. However, you must verify the polarity by measuring the voltage between the DC cable leads. When making the measurement, the positive (+) lead and the negative (-) lead must always match the (+) and (-) labels on the power distribution unit.

Figure 40: DC Input Power Cable Lug

**Note**

To avoid hazardous conditions, all components in the area where DC input power is accessible must be properly insulated. Therefore, before installing the DC cable lugs, be sure to insulate the lugs according to the manufacturer's instructions.

Wiring the DC Input Power Source

**Warning**

Statement 1046—Installing or Replacing the Unit


When installing or replacing the unit, the ground connection must always be made first and disconnected last.

Procedure

-
- Step 1** Turn off the circuit breaker from the power source.
- Step 2** Ensure that the chassis power switch is in the Standby position.
- Note** It is not required to place the power switch in the Standby position if you want to hot-swap a single power supply.
- Step 3** Remove the plastic cover from the terminal block.
- Caution** Before you continue to install the terminal block ground wires, stop and perform Step 4.

- Step 4** To prevent any contact with metal lead on the ground wire and the plastic cover, you must wrap the positive and negative lead cables with sleeving. Insulate the lug with shrink sleeving for each lead wire if using non-insulated crimp terminals. Sleeving is not required for insulated terminals.

Figure 41: DC Power Supply Terminal Block Ground Cable Lugs



Note This illustration shows the DC power supply for the Cisco ASR 1002-HX Router. The airflow for the Cisco ASR 1001-HX Router is reverse of what is shown in this illustration.

- Step 5** For easier cable-management, insert the negative lead cable first. Replace the ground lug with cable in the following order:
- a) Wire terminal

b) Screw with captive washer

Step 6 Tighten the M5 Screw with captive washer to recommended torque of 5 in-lbs for the positive stud and wire.
Note Secure the wires coming in from the terminal block so that they cannot be disturbed by casual contact.

Step 7 Replace the terminal block plastic cover. The plastic cover is slotted and keyed to fit correctly over the terminal block.

Step 8 Turn on the circuit breaker at the power source.

Step 9 If you have changed the chassis power switch to the Standby position in step 2, turn the power switch to the On position.
 The power supply LEDs illuminate green.

Removing and Replacing USB Flash Memory Stick

The Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router contain USB ports for a flash memory stick to store configurations or Cisco IOS XE consolidated packages.



Caution

Do not remove a USB Flash memory stick when issuing a file access command or a read/write operation to the Flash memory stick when it is processing. The router might reload or the USB Flash memory stick may get damaged. Prior to the removal of the USB device, check to see if the USB activity LED on the front panel is flashing.

To remove and then replace a USB flash memory stick, follow these steps:

Procedure

Step 1 Pull the flash memory stick from the USB port.

Step 2 To replace a Cisco USB Flash memory stick, insert the module into USB port 0 or 1. The Flash memory stick can be inserted only in one way, and can be inserted or removed regardless of whether the router is powered up or not.

Removing and Replacing a DIMM

This section describes how to replace the DIMMs on the Cisco ASR 1001-HX Router and Cisco ASR 1002-HX Router.

You might have to upgrade a DIMM for the following reasons:

- You have upgraded to a new Cisco IOS feature set or release that requires more memory.
- You are using very large routing tables or many protocols.

The DIMM component is keyed and slotted for easier connection.

Cisco ASR 1001-HX Router

The Cisco ASR 1001-HX Router has two DIMM slots and supports 8-GB configuration by default (two 4-GB DIMMS), and can be upgraded to 16-GB (two 8-GB DIMMS) configuration.

The following table shows the slots that are supported for inserting the memory DIMMs in the Cisco ASR 1001-HX Router.

Table 23: Cisco ASR 1001-HX Router: Supported Slots for Inserting the DIMMs

Memory PID Option	Slot 0	Slot 1
M-ASR1001HX-8GB (default)	4 GB	4 GB
M-ASR1001HX-16GB (upgrade)	8 GB	8 GB

Cisco ASR 1002-HX Router

The Cisco ASR 1002-HX Router has four DIMM slots and supports 16-GB configuration by default (two 8-GB DIMMS), and can be upgraded to 32-GB (four 8-GB DIMMS) configuration.



Caution

To ensure that each memory channel uses DIMMs from the same vendor, you must move the 8 GB DIMM from Channel A, Slot 1, to Channel B, Slot 2. You can then install the upgrade DIMMs in Channel A, Slots 0 and 1.

The following table shows the slots that are supported for inserting the memory DIMMs in the Cisco ASR 1002-HX Router.

Table 24: Cisco ASR 1002-HX Router: Supported Slots for Inserting the DIMMs

Memory PID Option	Memory Channel A		Memory Channel B	
	Slot 0 (U1DA0)	Slot 1 (U1DA1)	Slot 2 (U1DB0)	Slot 3 (U1DB1)
M-ASR1002HX-16GB (default)	–	8 GB	–	8 GB
M-ASR1002HX-32GB (upgrade)	8 GB	8 GB	8 GB	8 GB

Removing a DIMM from a Cisco ASR 1001-HX Router

Before You Begin

Perform the following steps before you begin the process of removing and replacing a DIMM from a Cisco ASR 1001-HX Router:

- Use an ESD-preventive wrist strap.

- Back up the data that you want to save.
- Remove the power supplies before you remove the chassis top cover.

**Caution**

The top cover cannot be removed until the power supplies are removed from the chassis. The chassis has a safety mechanism built in to prevent the removal of the top cover until the power supplies are removed.

Procedure

Step 1 With an ESD wrist strap on, remove the power supplies from the chassis.

Note The chassis cover cannot be removed until the power supplies are removed from the chassis.


For instructions about how to remove the AC and DC power supplies, see:

- [Removing AC Power Supplies](#)
- [Removing DC Input Power Supplies](#)

Step 2 Remove the chassis top cover by performing the following steps:

- Remove the fourteen top surface screws on the chassis cover.
- Remove the two screws from the left side of the chassis and the two screws from the right side of the chassis.
- Putting your thumbs in the thumb depression shown in the following figure, slide the cover slightly backward and lift it off of the chassis.

Figure 42: Cisco ASR 1001-HX Router Top Cover Screw Locations




1	Thumb depression location
---	---------------------------

Step 3 Position the chassis so that you have the most comfortable access to the chassis to remove the DIMM.

Step 4 Locate the DIMMs on the router.

The following figure shows the location of the DIMM slots in the Cisco ASR 1001-HX Router.


Figure 43: Cisco ASR 1001-HX Router and DIMM Location



1	Cisco ASR 1001-HX Router and DIMM location (two slots)
---	--

Step 5 Pull down the DIMM module spring latches to release the corresponding DIMM from the socket.

Figure 44: DIMM Module Spring Latches to Remove the DIMMs



Step 6 When both ends of the DIMM are released from the socket, grasp each end of the DIMM with your thumb and forefinger and pull the DIMM completely out of the socket. Handle only the edges of the DIMM; avoid

touching the memory module, pins, and the metal traces (the metal fingers along the connector edge of the DIMM) along the socket edge.


- Step 7** If you are upgrading the DIMM configuration from 8 GB to 16 GB using M-ASR1001HX-16GB, proceed to the ["Replacing a DIMM in a Cisco ASR 1001-HX Router, on page 124"](#) section. Otherwise, place the DIMM in an antistatic bag to protect it from ESD damage.

Replacing a DIMM in a Cisco ASR 1001-HX Router

Procedure

- Step 1** Place the DIMM on an antistatic mat or pad while wearing an antistatic device, such as a wrist strap.
- Caution** DIMMs are sensitive components that can be shorted by mishandling; they are susceptible to ESD damage. Handle the DIMM by the edges only, and avoid touching the pins.
- Step 2** Remove the new DIMM from the antistatic bag.
- Step 3** Locate the polarization notch and align the DIMM with the socket before inserting it.


Figure 45: DIMM Polarization Notch



- Step 4** Gently insert the new DIMM, taking care not to damage the pins on the edge of the DIMM. Using two hands, hold both sides of DIMM's top edges with your index fingers and thumbs and gently slide the DIMM straight in to the socket. Press the top of the DIMM towards the socket, being careful to apply force only on the DIMM that is parallel with the plane of the DIMM.
- Caution** When inserting DIMMs, use firm but not excessive pressure. If you damage a socket, you will have to return the router to the factory for repair.

- Step 5** Use light insertion force and insert smoothly, but ensure that the DIMM is inserted straight. If necessary, rock the DIMM gently back and forth to seat it properly. The following figure shows how to install the DIMM in the DIMM socket.

Figure 46: Installing a DIMM in the Socket



- Step 6** After the DIMM is installed, check whether the release levers are flush against the sides of the DIMM socket. If they are not, the DIMM might not be seated properly. If the DIMM appears misaligned, carefully remove it according to the removal procedure and then reseat it in the socket. Push the DIMM firmly back into the socket until the release levers are flush against the sides of the DIMM socket.
- Step 7** Replace the chassis top cover:
- Slide the cover onto the chassis ensuring that the interlock hook feature fits on the chassis cover and base.
 - Install the top surface screws and the side screws and tighten them slightly.
- Step 8** Install the power supplies into the chassis and power up the router. See:
- [Installing AC Power Supplies](#)
 - [Installing DC Input Power Supplies](#)

What to Do Next

After you have correctly installed the DIMMs, the system should reboot properly.

If the system fails to reboot properly or if the console terminal displays a checksum or memory error after you have installed the new DIMMs, ensure that all DIMMs are installed correctly. If necessary, shut down the system and remove the chassis cover. Check the DIMMs by looking straight down on them to inspect them at eye level. The DIMMs should be aligned at the same angle and the same height when properly installed. If a DIMM appears to stick out or rest in the socket at a different angle from the other, remove the DIMM and reinsert it. Replace the top chassis cover, and reboot the system for another installation check.

**Note**

After several attempts, if the system fails to restart properly, contact a Cisco service representative for assistance. Before you call, make note of any error messages, unusual LED states, or other indications that might help solve the problem.

Removing a DIMM from a Cisco ASR 1002-HX Router

Before You Begin

Perform the following steps before you begin the process of removing and replacing a DIMM from a Cisco ASR 1002-HX Router:

- Use an ESD-preventive wrist strap.
- Back up the data that you want to save.
- Remove the power supplies before you remove the chassis top cover.

**Caution**

The top cover cannot be removed until the power supplies are removed from the chassis. The chassis has a safety mechanism built in to prevent the removal of the top cover until the power supplies are removed.

Procedure

Step 1 With an ESD wrist strap on, remove the power supplies from the chassis.

Note The chassis cover cannot be removed until the power supplies are removed from the chassis.

For instructions about how to remove the AC and DC power supplies, see:


- [Removing AC Power Supplies](#)
- [Removing DC Input Power Supplies](#)

Step 2 After the power supplies are removed, remove the chassis top cover by performing the following steps:

- a) Remove the seven top surface screws on the chassis cover.
- b) Remove the three screws from the rear of the chassis cover.

- c) Remove one screw from the left side of the chassis and one screw from the right side of the chassis.

Figure 47: Cisco ASR 1002-HX Router Top Cover Screw Locations




- d) Using both hands, gently slide the cover slightly backward and lift it off of the chassis.

- Step 3** Position the chassis so that you have the most comfortable access to the chassis to remove the DIMM.
Step 4 Locate the DIMMs on the router.

The following figure shows the location of the DIMM slots in the Cisco ASR 1002-HX Router.


Figure 48: Cisco ASR 1002-HX Router DIMM Location



1	Cisco ASR 1002-HX Router DIMM location (four slots)
---	---

Step 5 Note If you are upgrading the DIMM configuration from 16 GB to 32 GB using M-ASR1002HX-32GB, perform the next step on the DIMM in Channel A, Slot 1. Pull down the DIMM module spring latches to release the corresponding DIMM from the socket.

Figure 49: DIMM Module Spring Latches to Remove the DIMMs




- Step 6** When both ends of the DIMM are released from the socket, grasp each end of the DIMM with your thumb and forefinger and pull the DIMM completely out of the socket. Handle only the edges of the DIMM; avoid touching the memory module, pins, and the metal traces (the metal fingers along the connector edge of the DIMM) along the socket edge.
- Step 7** If you are upgrading the DIMM configuration from 16 GB to 32 GB using M-ASR1002HX-32GB, proceed to the "[Replacing a DIMM in a Cisco ASR 1002-HX Router, on page 129](#)" section. Otherwise, place the DIMM in an antistatic bag to protect it from ESD damage. If you are removing the DIMMs without upgrading the system memory, repeat Steps 5 and 6 on the remaining DIMM.

Replacing a DIMM in a Cisco ASR 1002-HX Router

Procedure

- Step 1** Place the DIMM on an antistatic mat or pad while wearing an antistatic device, such as a wrist strap.
- Caution** DIMMs are sensitive components that can be shorted by mishandling; they are susceptible to ESD damage. Handle the DIMM by the edges only, and avoid touching the pins.
- Step 2** **Note** If you are upgrading the DIMM configuration from 16 GB to 32 GB using M-ASR1002HX-32GB, you must move the DIMM from Channel A, Slot 1, to Channel B, Slot 2. See the "[Removing and Replacing the Crypto Module in a Cisco ASR 1001-HX Router](#)" or "[Removing and Replacing the Crypto Module in a Cisco ASR 1002-HX Router](#)" section for removal instructions, then proceed to Step 3.
- Remove the new DIMM from the antistatic bag.
- Step 3** Locate the polarization notch and align the DIMM with the socket before inserting it.


Figure 50: DIMM Polarization Notch



- Step 4** Gently insert the new DIMM, taking care not to damage the pins on the edge of the DIMM. Using two hands, hold both sides of DIMM's top edges with your index fingers and thumbs and gently slide the DIMM straight in to the socket. Press the top of the DIMM towards the socket, being careful to apply force only on the DIMM that is parallel with the plane of the DIMM.
- Caution** When inserting DIMMs, use firm but not excessive pressure. If you damage a socket, you will have to return the router to the factory for repair.

- Step 5** Use light insertion force and insert smoothly, but ensure that the DIMM is inserted straight. If necessary, rock the DIMM gently back and forth to seat it properly. The following figure shows how to install the DIMM in the socket for the Cisco ASR 1002-HX Router.

Figure 51: Installing a DIMM in the Socket



- Step 6** After the DIMM is installed, check whether the release levers are flush against the sides of the DIMM socket. If they are not, the DIMM might not be seated properly. If the DIMM appears misaligned, carefully remove it according to the removal procedure and then reseat it in the socket. Push the DIMM firmly back into the socket until the release levers are flush against the sides of the DIMM socket.
- Step 7** If you are upgrading the DIMM configuration from 16 GB to 32 GB using M-ASR1002HX-32GB, repeat Steps 2 through 6 to install the upgrade DIMMs in Channel A, Slots 0 and 1.
- Step 8** Replace the Cisco ASR 1002-HX Router top cover:
- Slide the cover onto the chassis ensuring that the interlock hook feature fits on the chassis cover and base.
 - Install the top surface screws, the rear screws, and the side screws and tighten them slightly.
- Step 9** Install the power supplies into the chassis and power up the router. See:
- [Installing AC Power Supplies](#)
 - [Installing DC Input Power Supplies](#)

What to Do Next

After you have correctly installed the Cisco ASR 1002-HX Router DIMMs, the system should reboot properly.

If the system fails to reboot properly or if the console terminal displays a checksum or memory error after you have installed the new DIMMs, ensure that all DIMMs are installed correctly. If necessary, shut down the system and remove the chassis cover. Check the DIMMs by looking straight down on them to inspect them at eye level. The DIMMs should be aligned at the same angle and the same height when properly installed.

If a DIMM appears to stick out or rest in the socket at a different angle from the other, remove the DIMM and reinsert it. Replace the top chassis cover, and reboot the system for another installation check.



Note After several attempts, if the system fails to restart properly, contact a Cisco service representative for assistance. Before you call, make note of any error messages, unusual LED states, or other indications that might help solve the problem.

Removing and Replacing an EPA

The online insertion and removal (OIR) feature allows you to install and replace an Ethernet port adapter (EPA) while the router is operating. You do not have to shut down the system's power, although you should not run traffic through the EPA while it is being removed. OIR is a method that is seamless to end users on the network, maintains all routing information, and preserves sessions.



Note As you disengage the EPA from the router, OIR shuts down all the active interfaces in the EPA.



Note For detailed information about EPA software commands, such as preparing for OIR of EPAs, and activating and deactivating configuration examples, see the [Cisco ASR 1000 Series Modular Interface Processor Installation Guide](#).

We suggest you have the following tools and parts readily available for installing an EPA:

- Number 2 Phillips or a 3/16-inch flat-blade screwdriver
- EPA or blank filler plate (EPA-BLANK=)
- Any SFP or CPAK modules that you have to install (and have not already installed)
- Cables
- Your own ESD-prevention equipment or the disposable grounding wrist strap included with all upgrade kits, field-replaceable units (FRUs), and spares
- Antistatic mat or surface, or static shielding bag

If you need additional equipment, contact a service representative for ordering information.


Electrostatic Discharge Prevention

Electrostatic discharge (ESD) damages equipment and impairs electrical circuitry. ESD occurs when printed circuit boards are improperly handled and results in complete or intermittent failures.

Each EPA circuit board is mounted to a metal carrier and is sensitive to ESD damage. An EPA consists of a printed circuit board that is fixed in a metal carrier. Electromagnetic interference (EMI) shielding, connectors, and a handle are integral components of the carrier.

When the subslot is not in use, an EPA blank filler plate must fill the empty subslot to allow the router to conform to EMI emission requirements and to allow proper airflow across the installed modules. If you plan to install the EPA in the subslot that is not in use, you must first remove the EPA blank filler plate.

Figure 52: Handling an EPA



Although the metal carrier helps to protect the EPA from ESD, wear a preventive antistatic strap whenever you handle the EPA. Ensure that the strap makes good skin contact and connect the strap's clip to an unpainted chassis surface to safely channel unwanted ESD voltages to ground.

If no wrist strap is available, ground yourself by touching the metal part of the chassis.

The following are the guidelines for preventing ESD damage:

- Always use an ESD wrist strap or ankle strap when installing or replacing an EPA. Ensure that the ESD strap makes contact with your skin.
- Handle the EPA by its metal carrier edges and handles; avoid touching the printed circuit board or any connector pins.
- When removing the EPA, place it on an antistatic surface with the printed circuit board components facing upward, or in a static shielding bag.

Removing an EPA

Procedure

-
- Step 1** Attach an ESD wrist strap between you and an unpainted chassis surface.
- Step 2** Stop the EPA so that there is no traffic running through the EPA when it is removed.
- Caution** Removing an EPA while traffic is flowing through the ports may cause system disruption.
- a) At the `router#` prompt, enter **hw-module subslot 0/2 stop** and press **Enter**.

- b) At the `router#` prompt, enter **end** and press **Enter**.
- Step 3** Disconnect all the cables from the EPA.
- Step 4** Loosen the captive screw in the center of the EPA by turning it counterclockwise.
- Step 5** Slide the EPA out of the EPA slot.

Replacing an EPA

Procedure

- Step 1** Locate the guide rails that hold the EPA in place.
- Step 2** Align the EPA with the guide rails and carefully slide the EPA all the way all the way into the slot until the EPA stops.
- Step 3** Use a number 2 Phillips screwdriver to fully seat the EPA by turning the captive screw clockwise. When fully seated, the EPA should be flush with the router faceplate.
- Note** Avoid overtightening the EPA captive screw when installing the EPA. Tighten the captive screw on the EPA to a torque of 11 +/-1 inch-pounds.
- Step 4** Restart the EPA using the following steps:
- a) At the `router#` prompt, enter **hw-module subslot 0/2 start** and press **Enter**.
- b) At the `router#` prompt, enter **end** and press **Enter**.
- Step 5** Use the **show platform** command to verify whether the status of subslot 0/2 is OK.

```
Router# show platform
```

```
Chassis type: ASR1002-HX
```

Slot	Type	State	Insert time (ago)
0	ASR1002-HX	ok	00:07:52
0/0	BUILT-IN-EPA-8x1G	ok	00:07:00
0/1	BUILT-IN-EPA-8x10G	ok	00:07:00
0/2	EPA-18X1GE	ok	00:07:01
.			
.			
.			

Removing and Replacing a NIM

The OIR feature allows you to install and replace a NIM while the router is operating. You do not have to shut down the system's power although you should not run traffic through the NIM while it is being removed.

OIR is a method that is seamless to end users on the network, and maintains all routing information and preserves sessions.



Note As you disengage the NIM from the router, OIR shuts down all the active interfaces in the NIM.

We recommend that you have the following tools and parts readily available for installing a NIM:

- Number 2 Phillips or a 3/16-inch flat-blade screwdriver
- NIM
- Cables
- Your own ESD-prevention equipment or the disposable grounding wrist strap included with all upgrade kits, FRUs, and spares
- Antistatic mat or surface, or static shielding bag

If you need additional equipment, contact a Cisco service representative for ordering information.


For information about electrostatic discharge prevention, see the “Electrostatic Discharge Prevention” section on page 7-15.

Removing a NIM

Procedure

- Step 1** Attach an ESD wrist strap between you and an unpainted chassis surface.
- Step 2** Stop the NIM so that there is no traffic running through the NIM when it is removed, using the following steps:
- Note** Removing a NIM while traffic is flowing through the ports may cause system disruption.
- a) At the `router#` prompt, enter **hw-module subslot 0/3 stop** and press **Enter**.
 - b) At the `router#` prompt, enter **end** and press **Enter**.
- Step 3** Disconnect all the cables from the NIM.
- Step 4** Unscrew the captive installation screws on either side of the NIM.

Figure 53: Captive Installation Screws Location



1	Captive screws on the NIM
---	---------------------------

Step 5 Pull out the NIM out of the chassis.

Step 6 Place the NIM in an antistatic bag to protect it from electrostatic discharge (ESD) damage.

Replacing a NIM

Procedure

Step 1 To insert a NIM, locate the guide rails that hold the NIM in place. They are at the top left and top right of the NIM slot and are recessed about an inch.

Step 2 Carefully slide the NIM all the way in using both hands until the NIM is firmly seated in the NIM interface connector. When fully seated, the NIM might be slightly behind the faceplate.

Step 3 After the NIM is properly seated, fasten the NIM in place with the captive installation screws on either side of the NIM.

Note Ensure that you screw down the captive installation screws to provide appropriate connectivity.

The NIM should power up after installation.

Step 4 Use the **show platform** command to verify whether the status of subslot 0/3 is OK.

Removing and Replacing Fans

Removing the Fans from a Cisco ASR 1001-HX Router

Before You Begin

Perform the following steps before you begin the process of removing the fans from a Cisco ASR 1001-HX Router:

- Use an ESD-preventive wrist strap.
- Back up the data that you want to save.
- Remove the power supplies before you remove the chassis top cover.



Caution

The top cover cannot be removed until the power supplies are removed from the chassis. The chassis has a safety mechanism built in to prevent the removal of the top cover until the power supplies are removed.

Procedure


- Step 1** With an ESD wrist strap on, remove the power supplies from the chassis.
Note The chassis cover cannot be removed until the power supplies are removed from the chassis.

For instructions about how to remove the AC and DC power supplies, see:

- [Removing AC Power Supplies](#)
- [Removing DC Input Power Supplies](#)


- Step 2** Remove the chassis top cover by performing the following steps:
- a) Remove the fourteen top surface screws on the chassis cover.
 - b) Remove the two screws from the left side of the chassis and the two screws from the right side of the chassis.
 - c) Putting your thumbs in the thumb depression shown in the following figure, slide the cover slightly backward and lift it off of the chassis.

Figure 54: Cisco ASR 1001-HX Router Top Cover Screw Locations




1	Thumb depression location
---	---------------------------


- Step 3** Position the chassis so that you have the most comfortable access to the chassis to remove the fans. The fans are located at the rear of the chassis.
- Step 4** Unplug the six fan connectors from the motherboard.



Step 5 Remove the three screws from the rear of the chassis as shown in the following figure.



Step 6 Rotate the fan tray slightly forward, and then lift it out of the chassis as shown in the following figure.




1	Fan tray
---	----------

Replacing the Fans in a Cisco ASR 1001-HX Router


Procedure

Step 1 Gently insert the fan tray into the rear of the chassis.



1	Fan tray
---	----------

Step 2 Use three screws to attach the fan trays to the chassis.



Step 3 Plug the six fan connectors into the motherboard.

Step 4 Replace the chassis top cover:

- a) Slide the cover onto the chassis ensuring that the interlock hook feature fits on the chassis cover and base.
- b) Install the top surface screws and the side screws and tighten them slightly.

Step 5 Install the power supplies into the chassis and power up the router. See:

- [Installing AC Power Supplies](#)
- [Installing DC Input Power Supplies](#)

Removing the Fans from a Cisco ASR 1002-HX Router

Before You Begin

Perform the following steps before you begin the process of removing the fans from a Cisco ASR 1002-HX Router:

- Use an ESD-preventive wrist strap.
- Back up the data that you want to save.
- Remove the power supplies before you remove the chassis top cover.

**Caution**

The top cover cannot be removed until the power supplies are removed from the chassis. The chassis has a safety mechanism built in to prevent the removal of the top cover until the power supplies are removed.

Procedure

Step 1 With an ESD wrist strap on, remove the power supplies from the chassis.

Note The chassis cover cannot be removed until the power supplies are removed from the chassis.

For instructions about how to remove the AC and DC power supplies, see:


- [Removing AC Power Supplies](#)
- [Removing DC Input Power Supplies](#)

Step 2 After the power supplies are removed, remove the chassis top cover by performing the following steps:

- a) Remove the seven top surface screws on the chassis cover.
- b) Remove the three screws from the rear of the chassis cover.


- c) Remove one screw from the left side of the chassis and one screw from the right side of the chassis.

Figure 55: Cisco ASR 1002-HX Router Top Cover Screw Locations




- d) Using both hands, gently slide the cover slightly backward and lift it off of the chassis.

- Step 3** Position the chassis so that you have the most comfortable access to the chassis to remove the fans. The fans are located at the rear of the chassis.
- Step 4** Unplug the four fan connectors from the motherboard.




280476

Step 5 Remove the two screws from the rear of the chassis as shown in the following figure.



363913

Step 6 Lift the fan tray up and out of the chassis as shown in the following figure.




1	Fan tray
---	----------

Replacing the Fans in a Cisco ASR 1002-HX Router


Procedure

Step 1 Gently insert the fan tray into the rear of the chassis.



1	Fan tray
---	----------

Step 2 Use two screws to attach the fan trays to the chassis.



Step 3 Plug the four fan connectors into the motherboard.

Step 4 Replace the Cisco ASR 1002-HX Router top cover:

- a) Slide the cover onto the chassis ensuring that the interlock hook feature fits on the chassis cover and base.
- b) Install the top surface screws, the rear screws, and the side screws and tighten them slightly.

Step 5 Install the power supplies into the chassis and power up the router. See:

- [Installing AC Power Supplies](#)
- [Installing DC Input Power Supplies](#)

Repacking the Router

If your system is damaged, you must repack it for return shipment.

Before you return the router or move the router to a different location, repack the system using the original packaging material.



APPENDIX **A**

Technical Specifications

This appendix provides technical specifications for the Cisco ASR 1001-HX and 1002-HX Router.

- [Cisco ASR 1001-HX Router Specifications, page 145](#)
- [Cisco ASR 1002-HX Router Specifications, page 146](#)

Cisco ASR 1001-HX Router Specifications

Description	Specification
Dimensions (H x W x D)	Height—1.72 in. (43.69 mm) Width—17.3 in. (439.42 mm) Depth—21.78 in. (553.2 mm) including card handles, cable-management brackets, and power supply handles
Weight	23 lb (10.43 kg) fully loaded
Nominal operating temperature	32° to 104° F (0° to 40° C)
Short-term operating temperature	32° to 122° F (0° to 50° C)
Nominal operating humidity	10 to 90% relative humidity
Short-term operating humidity	5 to 90%
Storage temperature	−4° to 158° F (−20° to +70° C)
Power consumption	<ul style="list-style-type: none">• Maximum (DC): 400 W• Maximum (AC): 400 W

Cisco ASR 1002-HX Router Specifications

Description	Specification
Dimensions (H x W x D)	Height—3.5 in. (88.9 mm) Width—17.3 in. (439.42 mm) Depth—22.0 in. (558.8 mm) including card handles, cable-management brackets, and power supply handles
Weight	34 lb (15.42 kg) fully loaded
Nominal operating temperature	32° to 104° F (0° to 40° C)
Short-term operating temperature	32° to 122° F (0° to 50° C)
Nominal operating humidity	10 to 90% relative humidity
Short-term operating humidity	5 to 90%
Storage temperature	−4° to 158° F (−20° to +70° C)
Power consumption	<ul style="list-style-type: none"> • Maximum (DC): 750 W • Maximum (AC): 750 W • Maximum (Out): 450 W



Port Signals and Pinouts

This appendix provides the port signals and pinout specifications.

- [Management Ethernet Port Signals and Pinouts, page 147](#)
- [Console Port Signals and Pinouts, page 147](#)
- [Auxiliary Port Signals and Pinouts, page 148](#)

Management Ethernet Port Signals and Pinouts

The following table lists the Management Ethernet 10/100 RJ-45 port pinouts.

Pin	Signal	Direction	Description
1	TX/RX AData +	I/O	T/R data +
2	TX/RX AData -	I/O	T/R data -
3	TX/RX BData +	I/O	T/R Data +
4	TX/RX CData +	I/O	T/R Data + (Unused for 10/100)
5	TX/RX CData -	I/O	T/R Data - (Unused for 10/100)
6	TX/RX BData -	I/O	T/R Data -
7	TX/RX DData +	I/O	T/R Data + (Unused for 10/100)
8	TX/RX DData -	I/O	T/R Data - (Unused for 10/100)

Console Port Signals and Pinouts

The following table lists the pinouts of the RJ-45 console port.

Pin	Signal	Direction	Description
1	RTS	Output	Request to Send (tied to pin 8, CTS)
2	DTR	Output	Data Terminal Ready (always On)
3	TXD	Output	Transmit Data
4	GND	—	Ring Indicator
5	GND	—	—
6	RXD	Input	Receive Data
7	DSR	Input	Unused
8	CTS	Input	Clear to Send (tied to pin 1, RTS)

Auxiliary Port Signals and Pinouts

The following table lists the pinouts of the RJ-45 auxiliary port.

Pin	Signal	Direction	Description
1	RTS	Output	Request to Send
2	DTR	Output	Data Terminal Ready (always On)
3	TXD	Output	Transmit Data
4	RI	Input	Ring Indicator
5	GND	—	—
6	RXD	Input	Receive Data
7	DSR/DCD	Input	Data Set Ready/Data Carrier Detect
8	CTS	Input	Clear to Send