

## Content

<b>CHAPTER 1 COMMANDS FOR SNTP .....</b>	<b>1-1</b>
1.1 CLOCK TIMEZONE .....	1-1
1.2 DEBUG SNTP .....	1-1
1.3 SNTP POLLTIME .....	1-1
1.4 SNTP SERVER .....	1-2
1.5 SHOW SNTP .....	1-3
<b>CHAPTER 2 COMMANDS FOR NTP .....</b>	<b>2-1</b>
2.1 CLOCK TIMEZONE .....	2-1
2.2 DEBUG NTP ADJUST .....	2-1
2.3 DEBUG NTP AUTHENTICATION .....	2-1
2.4 DEBUG NTP EVENTS .....	2-2
2.5 DEBUG NTP PACKET .....	2-2
2.6 DEBUG NTP SYNC .....	2-3
2.7 NTP ACCESS-GROUP .....	2-3
2.8 NTP AUTHENTICATE .....	2-3
2.9 NTP AUTHENTICATION-KEY .....	2-4
2.10 NTP BROADCAST CLIENT .....	2-4
2.11 NTP BROADCAST SERVER COUNT .....	2-4
2.12 NTP DISABLE .....	2-4
2.13 NTP ENABLE .....	2-5
2.14 NTP IPV6 MULTICAST CLIENT .....	2-5
2.15 NTP MULTICAST CLIENT .....	2-6
2.16 NTP SERVER .....	2-6
2.17 NTP TRUSTED-KEY .....	2-6
2.18 SHOW NTP STATUS .....	2-7
2.19 SHOW NTP SESSION .....	2-7
<b>CHAPTER 3 COMMANDS FOR SUMMER TIME .....</b>	<b>3-1</b>
3.1 CLOCK SUMMER-TIME ABSOLUTE .....	3-1
3.2 CLOCK SUMMER-TIME RECURRING .....	3-1

**3.3 CLOCK SUMMER-TIME RECURRING .....3-2**

# Chapter 1 Commands for SNTP

## 1.1 clock timezone

**Command:** `clock timezone WORD {add | subtract} <0-23> [<0-59>]`  
`no clock timezone WORD`

**Function:** This command configures timezone in global mode, the no command deletes the configured timezone.

**Parameters:** **WORD:** timezone name, the length should not exceed 16  
**add | subtract:** the action of timezone  
**<0-23>:** the hour value  
**<0-59>:** the minute value

**Command Mode:** Global mode

**Default:** None.

**Usage Guide:** The timezone name is invalid with the blank, the hour and minute value must be in the specific range.

**Example:** Configure the action as add for the eighth timezone globally.

```
Switch(config)#clock timezone aaa add 8
```

## 1.2 debug sntp

**Command:** `debug sntp {adjust | packet | select }`  
`no debug sntp {adjust | packet | select}`

**Function:** Displays or disables SNTP debug information.

**Parameters:** **adjust** stands for SNTP clock adjustment information; **packet** for SNTP packets, **select** for SNTP clock selection.

**Command mode:** Admin Mode

**Example:** Displaying debugging information for SNTP packet.

```
Switch#debug sntp packet
```

## 1.3 sntp polltime

**Command:** `sntp polltime <interval>`  
`no sntp polltime`

**Function:** Sets the interval for SNTP clients to send requests to NTP/SNTP; the “**no sntp polltime**” command cancels the polltime sets and restores the default setting.

**Parameters:** *<interval>* is the interval value from 16 to 16284.

**Default:** The default polltime is 64 seconds.

**Command Mode:** Global Mode

**Example:** Setting the client to send request to the server every 128 seconds.

```
Switch#config
```

```
Switch(config)#sntp polltime128
```

## 1.4 sntp server

**Command:** `sntp server {<ip-address> | <ipv6-address>} [source {vlan <vlan no> | loopback <loopback no>}] [version <version_no>]`

**no sntp server {<ip-address> | <ipv6-address>} [source {vlan <vlan no> | loopback <loopback no>}] [version <version\_no>]**

**Function:** Enable the specified time server as clock source, the no command deletes the specified time server.

**Parameters:** ip-address: IPv4 address of time server

ipv6-address: IPv6 address of time server

source: Specify the interface of the source address

vlan: Configure the virtual LAN

vlan no: Virtual LAN number, ranging from 1 to 4094

loopback: Configure loopback interface

loopback no: Loopback identifier, ranging from 1 to 1024

version: Configure the version for the server

version\_no: Version number, ranging from 1 to 4, the default is 4

**Default:** Do not configure the time server.

**Command Mode:** Global mode

**Usage Guide:** None.

**Example:**

Configure the time server address as 1.1.1.1, specify the interface of the source address as vlan1:

```
Switch(config)#sntp server 1.1.1.1 source vlan 1
```

Delete the time server that the address is 1.1.1.1, the interface of the specified source address is vlan1:

```
Switch(config)#no sntp server 1.1.1.1 source vlan 1
```

## 1.5 show sntp

**Command:** show sntp

**Function:** Displays current SNTP client configuration and server status.

**Parameters:** N/A.

**Command Mode:** Admin and Configuration Mode.

**Example:** Displaying current SNTP configuration.

```
Switch#show sntp
```

SNTP server	Version	Last Receive
2.1.0.2	1	6

## Chapter 2 Commands for NTP

### 2.1 clock timezone

**Command:** `clock timezone WORD {add | subtract} <0-23> [<0-59>]`  
`no clock timezone WORD`

**Function:** This command configures timezone in global mode, the no command deletes the configured timezone.

**Parameters:** **WORD:** timezone name, the length should not exceed 16  
**add | subtract:** the action of timezone  
**<0-23>:** the hour value  
**<0-59>:** the minute value

**Command Mode:** Global mode

**Default:** None.

**Usage Guide:** The timezone name is invalid with the blank, the hour and minute value must be in the specific range.

**Example:** Configure the action as add for the eighth timezone globally.  
Switch(config)#clock timezone aaa add 8

### 2.2 debug ntp adjust

**Command:** `debug ntp adjust`  
`no debug ntp adjust`

**Function:** To enable/disable the debug switch of displaying local time adjust information.

**Parameter:** None.

**Default:** Disabled.

**Command Mode:** Admin Mode.

**Usage Guide:** None.

**Example:** To enable the debug switch of displaying local time adjust information.  
Switch# debug ntp adjust

### 2.3 debug ntp authentication

**Command:** `debug ntp authentication`  
`no debug ntp authentication`

**Function:** To display NTP authentication information, the no form command disabled the switch of displaying NTP authentication information.

**Parameter:** None.

**Default:** Disabled.

**Command Mode:** Admin Mode.

**Usage Guide:** To display NTP authentication information, if the switch is enabled, and if the packets schlepped authentication information when the packet in sending or receiving process, then the key identifier will be printed out.

**Example:** To enable the switch of displaying NTP authentication information.

```
Switch# debug ntp authentication
```

## 2.4 debug ntp events

**Command:** debug ntp events

no debug ntp events

**Function:** To enable/disable debug switch of displaying NTP event.

**Parameter:** None.

**Default:** Disable the debug switch of displaying NTP event.

**Command Mode:** Admin Mode.

**Usage Guide:** To enable debug switch of displaying NTP event, after that, if some server changed from available to unavailable or from unavailable to available, the received illegal packet events will be printed.

**Example:** To enable debug switch of displaying NTP event information.

```
Switch# debug ntp events
```

## 2.5 debug ntp packet

**Command:** debug ntp packet [send | receive]

no debug ntp packet [send | receive]

**Function:** To enable/disable the debug switch of displaying NTP packet information.

**Parameter:** send: The debug switch of sending NTP packet.

receive: The debug switch of receiving NTP packet.

If there is no parameter, that means should enable the sending and receiving switch of NTP packet in the same time.

**Default:** Disabled.

**Command Mode:** Admin Mode.

**Usage Guide:** None.

**Example:** To enable the debug switch of displaying NTP packet information.

```
Switch# debug ntp packet
```

## 2.6 debug ntp sync

**Command:** debug ntp sync  
no debug ntp sync

**Function:** To enable/disable debug switch of displaying local time synchronization information.

**Parameter:** None.

**Default:** Disabled.

**Command Mode:** Admin Mode.

**Usage Guide:** None.

**Example:** To enable debug switch of displaying local time synchronization information.

```
Switch# debug ntp sync
```

## 2.7 ntp access-group

**Command:** ntp access-group server <acl>  
no ntp access-group server <acl>

**Function:** To configure/cancel the access control list of NTP Server.

**Parameter:** <acl>: ACL number, range is from 1 to 99.

**Default:** Not configure the access control of NTP Server.

**Command Mode:** Global Mode.

**Usage Guide:** None.

**Example:** To configure access control list 2 on the switch.

```
Switch(config)#ntp access-group server 2
```

## 2.8 ntp authenticate

**Command:** ntp authenticate  
no ntp authenticate

**Function:** To enable/cancel NTP authentication function.

**Parameter:** None.

**Default:** Disabled.

**Command Mode:** Global Mode.

**Usage Guide:** None.

**Example:** To enable NTP authentication function.



```
Switch(config)#ntp authenticate
```

## 2.9 ntp authentication-key

**Command:** `ntp authentication-key <key-id> md5 <value>`  
`no ntp authentication-key <key-id>`

**Function:** To enable/cancel NTP authentication function, and defined NTP authentication key.

**Parameter:** key-id: The id of key, range is from 1 to 4294967295.

value: The value of key, range between 1 to 16 of ascii code.

**Default:** The authentication key of NTP authentication is not configured by default.

**Command Mode:** Global Mode.

**Usage Guide:** None.

**Example:** To define the authentication key of NTP authentication, the key-id is 20, the md5 is abc.

```
Switch(config)# ntp authentication-key 20 md5 abc
```

## 2.10 ntp broadcast client

This command is not supported by the switch.

## 2.11 ntp broadcast server count

**Command:** `ntp broadcast server count <number>`  
`no ntp broadcast server count`

**Function:** Set the max number of broadcast or multicast servers supported by the NTP client. The no operation will cancel the configuration and restore the default value.

**Parameters:** number: 1-100, the max number of broadcast servers.

**Default:** The default max number of broadcast servers is 50.

**Command Mode:** Global Mode.

**Examples:** Configure the max number of broadcast servers is 70 on the switch.

```
Switch(config)#ntp broadcast server count 70
```

## 2.12 ntp disable

**Command:** `ntp disable`  
`no ntp disable`

**Function:** To disable/enable the NTP function on port.

**Parameter:** None.

**Default:** To enable NTP function on all ports.

**Command Mode:** vlan Configuration Mode.

**Usage Guide:** None.

**Example:** To disable the NTP function on vlan1 interface.

```
Switch(config)# interface vlan 1
Switch(Config-if-Vlan1)#ntp disable
```

## 2.13 ntp enable

**Command:** ntp enable

ntp disable

**Function:** To enable/disable NTP function globally.

**Parameter:** None.

**Default:** Disabled.

**Command Mode:** Global Mode.

**Usage Guide:** None.

**Example:** To enable NTP function.

```
Switch(config)#ntp enable
```

## 2.14 ntp ipv6 multicast client

**Command:** ntp ipv6 multicast client

no ntp ipv6 multicast client

**Function:** Configure the specified interface to receive IPv6 NTP multicast packets, the no command will cancel the specified interface to receive IPv6 NTP multicast packets.

**Parameter:** None.

**Command mode:** vlan mode

**Default:** Interface does not receive IPv6 NTP multicast packets.

**Usage guide:** None.

**Example:** Enable the function for receiving IPv6 NTP multicast packets on vlan1 interface.

```
Switch(Config)# interface vlan 1
Switch(Config-if-Vlan1)#ntp ipv6 multicast client
```

## 2.15 ntp multicast client

**Command:** ntp multicast client

**no ntp multicast client**

**Function:** Configure the specified interface to receive NTP multicast packets, the no command will cancel the specified interface to receive NTP multicast packets.

**Parameter:** None.

**Command mode:** vlan mode

**Default:** Interface does not receive NTP multicast packets.

**Usage guide:** None.

**Example:** Enable the function for receiving NTP multicast packets on vlan1 interface.

```
Switch(Config)# interface vlan 1
```

```
Switch(Config-if-Vlan1)#ntp multicast client
```

## 2.16 ntp server

**Command:** ntp server {<ip-address> | <ipv6-address>} [version <version\_no>] [key <key-id>]

**no ntp server {<ip-address>|<ipv6-address>}**

**Function:** To enable specified time server of time source, the no form of this command cancels the specified time server of time source.

**Parameter:** ip-address: IPv4 address of time server.

ipv6-address: IPv6 address of time server.

version: The version information configured for server.

version\_no: The version number of server, range is from 1 to 4, default is 4.

key: To configure key for server.

key-id: The key id.

**Default:** Disabled.

**Command Mode:** Global Mode.

**Usage Guide:** None.

**Example:** To configure time server address as 1.1.1.1 on switch.

```
Switch(config)#ntp server 1.1.1.1
```

## 2.17 ntp trusted-key

**Command:** ntp trusted-key <key-id>

**no ntp trusted-key <key-id>**

**Function:** To configure the trusted key. The no command cancels the trusted key.

**Parameter:** key-id: The id of key, range is from 1 to 4294967295.

**Default:** Trusted key is not configured by default.

**Command Mode:** Global Mode.

**Usage Guide:** None.

**Example:** To configure the specified key 20 to trusted key.

```
Switch(config)# ntp trusted-key 20
```

## 2.18 show ntp status

**Command:** show ntp status

**Function:** To display time synchronization status, include synchronized or not, layers, address of time source and so on.

**Parameter:** None.

**Default:** None.

**Command Mode:** Admin and Configuration Mode.

**Usage Guide:** None.

**Example:**

```
Switch# show ntp status
```

```
Clock status: synchronized
```

```
Clock stratum: 3
```

```
Reference clock server: 1.1.1.2
```

```
Clock offset: 0.010 s
```

```
Root delay: 0.012 ms
```

```
Root dispersion: 0.000 ms
```

```
Reference time: TUE JAN 03 01:27:24 2006
```

## 2.19 show ntp session

**Command:** show ntp session [*<ip-address>* / *<ipv6-address>*]

**Function:** To display the information of all NTP session or one specific session, include server ID, server layer, and the local offset according to server. (The symbol \* means this server is the selected local time source)

**Parameter:** ip-address: The IPv4 address of some specifics configured time server.

ipv6-address: The IPv6 address of some specifics configured time server.

If no parameter, the session relative information of all servers will be displayed (Include broadcast and multicast servers)

**Default:** None.

**Command Mode:** Admin and Configuration Mode.

**Usage Guide:** None.

**Example:**

(Switch)# show ntp session

	server	stream	type	rootdelay	rootdispersion	trustlevel
*	1.1.1.2	2	unicast	0.010s	0.002s	10
	2.2.2.2	3	unicast	0.005s	0.000s	10

## Chapter 3 Commands for Summer Time

### 3.1 clock summer-time absolute

**Command:** `clock summer-time <word> absolute <HH:MM> <YYYY.MM.DD>  
<HH:MM> <YYYY.MM.DD> [<offset>]`

`no clock summer-time`

**Function:** Configure summer time range, the time in this range is summer time. The no command deletes the configuration.

**Parameter:** `<word>` is the time zone name of summer time; `<HH:MM>` is the start time, the format is hour (from 0 to 23):minute (from 0 to 59); `<YYYY.MM.DD>` is the start date, the format is year (from 1970 to 2038).month (from 1 to 12).date (from 1 to 31); `<HH:MM>` is the end time, the format is hour (from 0 to 23):minute (from 0 to 59); `<YYYY.MM.DD>` is the end date, the format is year (from 1970 to 2038).month (from 1 to 12).date (from 1 to 31); `<offset>` is the time offset, the range from 1 to 1440, unit is minute, default value is 60 minutes.

**Default:** There is no summer time range.

**Command Mode:** Global Mode

**Usage Guide:** This command sets the absolute start and end time for summer time. When the system time reaches to the start time point of summer time, the clock is changed and increase `<offset>` value, the system enters summer time. When the system time reaches to the end time point of summer time, the clock is changed again, subtract `<offset>` value from system time, the system finishes summer time. Note: the end time should be bigger than the start time for configuring summer time.

**Example:** Configure the time range of summer time at 12:10 from april 6th to august 6th in 2010, offset value as 70 minutes, summer time is named as aaa.

```
Switch(config)#clock summer-time aaa absolute 12:10 2010.4.6 12:10 2010.8.6 70
```

### 3.2 clock summer-time recurring

**Command:** `clock summer-time <word> recurring <HH:MM> <MM.DD> <HH:MM>  
<MM.DD> [<offset>]`

`no clock summer-time`

**Function:** Configure the recurrent summer time range, the time in this range is summer time.

**Parameter:** **<word>** is the time zone name of summer time; **<HH:MM>** is the start time, the format is hour (from 0 to 23):minute (from 0 to 59); **<MM.DD>** is the start date, the format is month(from 1 to 12).date(from 1 to 31); **<HH:MM>** is the end time, the format is hour(from 0 to 23):minute(from 0 to 59); **<MM.DD>** is the end date, the format is month(from 1 to 12).date(from 1 to 31); **<offset>** is the time offset, the range from 1 to 1440, unit is minute, default value is 60 minutes.

**Default:** There is no summer time range.

**Command Mode:** Global Mode

**Usage Guide:** This command sets the start and the end time for the recurrent summer time. When the system time reaches to the start time point of summer time, the clock is changed and increase **<offset>** value, the system enters summer time. When the system time reaches to the end time point of summer time, the clock is changed again, subtract **<offset>** value from system time, the system finishes summer time. There is no relation between the recurrent summer time to the year, the system clock will be changed when it reaches to the start and the end time point of summer time year after year. This command supports the summer time of southern hemisphere.

**Example:** Configure the time range of summer time at 12:10 from april 6th to august 6th year after year, offset value as 70 minutes, summer time is named as aaa.

```
Switch(config)# clock summer-time aaa recurring 12:10 4.6 12:10 8.6 70
```

### 3.3 clock summer-time recurring

**Command:** **clock summer-time <word> recurring <HH:MM> <week> <day> <month>**  
**< HH:MM > <week> <day> <month> [<offset>]**

**no clock summer-time**

**Function:** Configure the recurrent summer time range, the time in this range is summer time.

**Parameter:** **<word>** is the time zone name of summer time; **<HH:MM>** is the start time, the format is hour(from 0 to 23):minute(from 0 to 59); **<week>** is the week from 1 to 4, first or last; **<day>** is the week value, the value as "Sun", "Mon", "Tue", "Wed", "Thu", "Fri", "Sat"; **<month>** is the month, the value as "Jan", "Feb", "Mar", "Apr", "May", "Jun", "Jul", "Aug", "Sep", "Oct", "Nov", "Dec"; **<HH:MM>** is the end time, the format is hour(from 0 to 23):minute(from 0 to 59); **<week>** is the week from 1 to 4, first or last; **<day>** is the week value, the value as "Sun", "Mon", "Tue", "Wed", "Thu", "Fri", "Sat"; **<month>** is the month, the value as "Jan", "Feb", "Mar", "Apr", "May", "Jun", "Jul", "Aug", "Sep", "Oct", "Nov", "Dec" **<offset>** is the time offset, the range from 1 to 1440, unit is minute, default value is 60 minutes.

**Default:** There is no summer time range.

**Command Mode:** Global Mode

**Usage Guide:** This command sets the start and end time for the recurrent summer time flexibly. When the system time reaches to the start time point of summer time, the clock is changed and increase <offset> value, the system enters summer time. When the system time reaches to the end time point of summer time, the clock is changed again, subtract <offset> value from system time, the system finishes summer time. There is no relation between the recurrent summer time to the year, the system clock will be changed when it reaches to the start and the end time point of summer time year after year. This command supports summer time of southern hemisphere.

**Example:** Configure summer time at 12:10 from the first Monday of april to the last Saturday of august year after year, offset value as 70 minutes, summer time is named as aaa.

```
Switch(config)#clock summer-time aaa recurring 12:10 1 mon apr 12:10 last sat aug 70
```