




Yeostar TA FXO Gateway Integration Guide

Yeostar P-Series Appliance Edition

Version: 1.0

Date: 2021-07-16

-  Support: +86-592-5503301
-  Support: support@yeostar.com
-  <https://www.yeostar.com>

Contents


Connect Yeastar P-Series PBX System and Yeastar TA FXO Gateway.....	1
Connect Yeastar P-Series PBX System and Yeastar TA1610 Gateway.....	1
Make Outbound Calls through the Extended FXO Trunks.....	4
Receive inbound calls through the extended FXO trunks.....	7

Connect Yeastar P-Series PBX System and Yeastar TA FXO Gateway

This guide provides a configuration example to describe how to extend analog FXO trunks for Yeastar P-Series PBX System.

Background

The instructions provided in this guide are based on the following test environment.



Equipment	Firmware Version	IP Address
Yeastar P560 PBX System	37.2.0.32	192.168.6.124
Yeastar TA1610 FXO Gateway	48.0.0.18	192.168.6.24

Objectives

This guide provides guidance based on the above scenario to help you achieve following objectives:

- [Connect Yeastar P-Series PBX System and Yeastar TA1610 Gateway](#)
- [Make Outbound Calls through the Extended FXO Trunks](#)
- [Receive inbound calls through the extended FXO trunks](#)


Connect Yeastar P-Series PBX System and Yeastar TA1610 Gateway




This topic introduces the steps to connect Yeastar P-Series PBX System and Yeastar TA1610 via SIP peer trunks. After the two devices are connected, 16 FXO trunks are extended on the Yeastar P-Series PBX System.

Step1. Create a SIP peer trunk on Yeastar IPPBX

1. Log in to the PBX management portal, go to **Extension and Trunk > Trunk**, click **Add**.
2. Configure the trunk basic settings.
 - **Name:** Enter a name to help you identify it. For example, *Connect-to-TA1610-Gateway*.
 - **Trunk Status:** Select **Enabled**.
 - **Select ITSP Template:** Select **General**.
 - **Trunk Type:** Select **Peer Trunk**.
 - **Transport:** Select **UDP**.
 - **Hostname/IP:** Enter the IP address of Yeastar TA1610 gateway. In this example, enter *192.168.6.24*.
 - **Port:** Enter the SIP port of Yeastar TA1610 gateway. In this example, enter the default port *5060*.
 - **Domain:** Enter the IP address of Yeastar TA1610 gateway. In this example, enter *192.168.6.24*.

3. Click **Save and Apply**.
4. Wait for seconds and check the trunk status on the **Trunk** page.

If the status shows , Yeastar IPPBX is connected to the Yeastar TA1610 gateway.

Status	Name	Type	Hostname/Port	Username	Outbound Caller ID	Operations
	Connect-to-TA1610...	Peer Trunk	192.168.6.24:5060			 

Step2. Create a SIP peer trunk on Yeastar TA1610 Gateway

1. Log in to the gateway web interface, go to **Gateway > VoIP Settings > VoIP Trunk#click Add New Trunk**.

2. In the pop-up window, configure the following settings:

- **Trunk Type:** Select **Service Provider**.
- **Type:** Select **SIP**.
- **Provider Name:** Enter a name to help you identify it.
- **Hostname/IP:** Enter the IP address of Yeastar IPPBX and the SIP port. In this example, enter *192.168.6.124* and the default SIP port *5060*.

The screenshot shows a dialog box titled "Add New VoipTrunk" with a close button (X) in the top right corner. It has two tabs: "General" (selected) and "Advanced". The "General" tab contains the following fields:

- Server ID: 5 (dropdown menu)
- Trunk Type: Service Provider (dropdown menu)
- Type: SIP (dropdown menu)
- Provider Name: P560 (text input)
- Hostname/IP: 192.168.6.124 : 5060 (text input)

At the bottom of the dialog, there are two buttons: "Save" (with a green checkmark icon) and "Cancel" (with a red X icon).

3. Click **Save** and **Apply Changes**.

4. Wait for seconds and check the trunk status on the **Status > Port/Trunk** page.

If the status shows "OK", Yeastar TA1610 gateway is connected to the Yeastar IPPBX.


Status	Trunk Name	Type	User Name	Hostname/IP	Reachability
OK (3 ms)	P560	SP-SIP	--	192.168.6.124	OK

Make Outbound Calls through the Extended FXO Trunks

After the connection, you can make outbound calls through the extended FXO trunks.

Scenario

The application scenario is shown as the following figure.



Procedure


1. Create an outbound route on Yeastar IPPBX to allow users reach the Yeastar TA1610 gateway.
 - a. Log in to the PBX management portal, go to **Call Control > Outbound Route**, click **Add**.
 - b. Configure the following settings for the outbound route and leave other settings as default.

- **Name:** Enter a name to help you identify it. For example, *TO-TA1610*.
- **Dial Pattern:** Set the dial patterns according to your needs. In this example, set **Pattern** to 9., set **Strip** to 1.


Users should dial prefix 9 before the target number. For example, to call number 123456, users should dial 9123456.

* Pattern	Strip	Prepend
9.	1	

- **Trunk:** Select the SIP peer trunk that is connected to the Yeastar TA1610. In this example, select the trunk *Connect-to-TA1610-Gateway*.



- **Extension/Extension Group:** Select the extensions that are allowed to make calls through this outbound route. In this example, select the all extensions.



- c. Click **Save** and **Apply**.
2. Create an **IP->Port** route on Yeastar TA1610 gateway.
 - a. Log in to the gateway web interface, go to **Gateway > Route Settings > IP->Port**, click **Add IP->Port Route**.
 - b. In the pop-up window, configure the route.
 - **Simple Mode:** Yes
 - **Route Name:** Enter a name to help you identify it.
 - **Call Source:** Select the SIP trunk that is connected to Yeastar IPPBX. In this example, select the trunk *SPS – P560*.
 - **Call Destination:** Select the FXO trunks that will be used to call out. In this example, select all FXO trunks.

Route ID: 2

Simple Mode: Yes

Route Name: From-P560

Match Incoming Calls:

Call Source: SPS -- P560

Incoming Calls Processing:

Call Destination: Port Group4 -- All

Hotline:

Save Cancel

- c. Click **Save** and **Apply Changes**.
3. Make a test call from a PBX extension.


For example, to call number 1588035242, you need to dial 91588035242.

Receive inbound calls through the extended FXO trunks

After the connection, you can receive inbound calls through the extended FXO trunks.

Scenario

The application scenario is shown as the following figure.




Procedure

1. Create an inbound route on Yeastar IPPBX to accept incoming calls from Yeastar TA1610.
 - a. Log in to the PBX management portal, go to **Call Control > Inbound Route**, click **Add**.
 - b. Configure the following settings for the inbound route and leave other settings as default.
 - **Name:** Enter a name to help you identify it. For example, *From-TA1610*.
 - **DID Pattern:**
 - # **DID Matching Mode:** Select **DID Pattern**.
 - # **Pattern:** Enter a DID number. This DID number will be used to match the incoming calls from TA1610 gateway.In this example, enter *123456*.


DID Pattern	
* DID Matching Mode	
DID Pattern <input type="text" value="DID Pattern"/>	
Pattern	Operations
<input type="text" value="123456"/>	<input type="button" value=""/>

- **Trunk:** Select the SIP peer trunk that is connected to the Yeastar TA1610. In this example, select the trunk *Connect-to-TA1610-Gateway*.



- **Default Destination:** Select a destination for the inbound route.

In this example, set the **Destination** to extension 2000. When incoming calls from TA1610 gateway reach the PBX, the calls will be routed to extension 2000.



- c. Click **Save** and **Apply**.
2. Create a **Port->IP** route on Yeastar TA1610 gateway to route incoming calls to Yeastar IPPBX.
 - a. Log in to the gateway web interface, go to **Gateway > Route Settings > Port->IP/Port**, click **Add Port->IP/Port Route**.
 - b. In the pop-up window, configure the route.
 - **Simple Mode:** Yes
 - **Route Name:** Enter a name to help you identify it.
 - **Call Source:** Select the FXO trunks that will be used to call out. In this example, select all FXO trunks.
 - **Call Destination:** Select the SIP trunk that is connected to Yeastar IPPBX. In this example, select the trunk *SPS – P560*.
 - **Hotline:** Enter the DID number that is set on the inbound route of Yeastar IPPBX. In this example, enter *123456*.

Route ID: 4

Simple Mode: Yes

Route Name: To-P560

Match Incoming Calls:

Call Source: Port Group4 -- All

Incoming Calls Processing:

Call Destination: SPS -- P560

Hotline: 123456

Save Cancel

3. Make a test call to one of the extended FXO trunks.

For example, the extended FXO trunk's number is 505525301, you call dial 505525301 on your mobile phone. The call will be routed to extension 2000.