

Part No. 215659-B  
July 2004

4655 Great America Parkway  
Santa Clara, CA 95054

# Reference for the BayStack 420/425 Command Line Interface, Software Release 3.1



**NORTEL**  
NETWORKS™

## Copyright © 2004 Nortel Networks

All rights reserved. July 2004.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks NA Inc.

The software described in this document is furnished under a license agreement and may be used only in accordance with the terms of that license. The software license agreement is included in this document.

## Trademarks

Autotopology, BayStack, BaySecure, Business Policy Switch 2000, Nortel Networks, the Nortel Networks logo, Optivity, Optivity Policy Services, Preside, and Quick2Config are trademarks of Nortel Networks.

Microsoft, MS, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

Java is a trademark of Sun Microsystems, Inc.

Acrobat and Adobe are trademarks of Adobe Systems, Inc.

All other trademarks and registered trademarks are the property of their respective owners.

## Restricted rights legend

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Notwithstanding any other license agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government regarding its use, reproduction, and disclosure are as set forth in the Commercial Computer Software-Restricted Rights clause at FAR 52.227-19.

## Statement of conditions

In the interest of improving internal design, operational function, and/or reliability, Nortel Networks Inc. reserves the right to make changes to the products described in this document without notice.

Nortel Networks Inc. does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Portions of the code in this software product may be Copyright © 1988, Regents of the University of California. All rights reserved. Redistribution and use in source and binary forms of such portions are permitted, provided that the above copyright notice and this paragraph are duplicated in all such forms and that any documentation, advertising materials, and other materials related to such distribution and use acknowledge that such portions of the software were developed by the University of California, Berkeley. The name of the University may not be used to endorse or promote products derived from such portions of the software without specific prior written permission.

**SUCH PORTIONS OF THE SOFTWARE ARE PROVIDED "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.**

In addition, the program and information contained herein are licensed only pursuant to a license agreement that contains restrictions on use and disclosure (that may incorporate by reference certain limitations and notices imposed by third parties).

---

## International regulatory statements of conformity

This is to certify that the Nortel Networks BayStack 425 switch was evaluated to the international regulatory standards for electromagnetic compliance (EMC) and safety and were found to have met the requirements for the following international standards:

- EMC - Electromagnetic Emissions – CISPR 22, Class A
- EMC - Electromagnetic Immunity – CISPR 24
- Electrical Safety – IEC 60950, with CB member national deviations

Further, the equipment has been certified as compliant with the national standards as detailed below.

## National electromagnetic compliance (EMC) statements of compliance

### FCC statement (USA only)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy. If it is not installed and used in accordance with the instruction manual, it may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to take whatever measures may be necessary to correct the interference at their own expense.

### ICES statement (Canada only)

#### Canadian Department of Communications Radio Interference Regulations

This digital apparatus (Nortel Networks BayStack 425 switch) does not exceed the Class A limits for radio-noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

#### Règlement sur le brouillage radioélectrique du ministère des Communications

Cet appareil numérique (Nortel Networks BayStack 425 switch) respecte les limites de bruits radioélectriques visant les appareils numériques de classe A prescrites dans le Règlement sur le brouillage radioélectrique du ministère des Communications du Canada.

### CE marking statement (Europe only)

#### EN 55 022 statements

This is to certify that the Nortel Networks BayStack 425 switch is shielded against the generation of radio interference in accordance with the application of Council Directive 89/336/EEC. Conformity is declared by the application of EN 55 022 Class A (CISPR 22).



**Caution:** This device is a Class A product. In a domestic environment, this device can cause radio interference, in which case the user may be required to take appropriate measures.

---

**EN 55 024 statement**

This is to certify that the Nortel Networks BayStack 425 switch is shielded against the susceptibility to radio interference in accordance with the application of Council Directive 89/336/EEC. Conformity is declared by the application of EN 55 024 (CISPR 24).

**EC Declaration of Conformity**

This product conforms to the provisions of the R&TTE Directive 1999/5/EC.

**VCCI statement (Japan/Nippon only)**

This is a Class A product based on the standard of the Voluntary Control Council for Interference (VCCI) for information technology equipment. If this equipment is used in a domestic environment, radio disturbance may arise. When such trouble occurs, the user may be required to take corrective actions.

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

**BSMI statement for BayStack 425 (Taiwan only)**

This is a Class A product based on the standard of the Bureau of Standards, Metrology and Inspection (BSMI) CNS 13438, Class A.

**警告使用者：**

這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

**MIC notice for BayStack 425 (Republic of Korea only)**

This device has been approved for use in Business applications only per the Class A requirements of the Republic of Korea Ministry of Information and Communications (MIC). This device may not be sold for use in a non-business application.

Observe the Regulatory Marking label on the bottom surface of the chassis for specific certification information pertaining to this model. Each model in the BayStack Series which is approved for shipment to/usage in Korea is labeled as such, with all appropriate text and the appropriate MIC reference number.

---

## National safety statements of compliance

### CE marking statement (Europe only)

#### EN 60 950 statement

This is to certify that the Nortel Networks BayStack 425 switch is in compliance with the requirements of EN 60 950 in accordance with the Low Voltage Directive. Additional national differences for all European Union countries have been evaluated for compliance.

#### NOM statement BayStack 425 (Mexico only)

The following information is provided on the devices described in this document in compliance with the safety requirements of the Norma Oficial Mexicana (NOM):

Exporter: Nortel Networks, Inc.  
4655 Great America Parkway  
Santa Clara CA 95054 USA

Importer: Nortel Networks de México, S.A. de C.V.  
Avenida Insurgentes Sur #1605  
Piso 30, Oficina  
Col. San Jose Insurgentes  
Deleg-Benito Juarez  
México D.F. 03900

Tel: 52 5 480 2100

Fax: 52 5 480 2199

Input: BayStack 425  
100 - 120 VAC 16A 50 to 60 Hz  
200 - 240 VAC 12 A 50 to 60 Hz

#### Información NOM (unicamente para México)

La información siguiente se proporciona en el dispositivo o en los dispositivos descritos en este documento, en cumplimiento con los requisitos de la Norma Oficial Mexicana (NOM):

Exportador: Nortel Networks, Inc.  
4655 Great America Parkway  
Santa Clara, CA 95054 USA

Importador: Nortel Networks de México, S.A. de C.V.  
Avenida Insurgentes Sur #1605  
Piso 30, Oficina  
Col. San Jose Insurgentes  
Deleg-Benito Juarez  
México D.F. 03900

Tel: 52 5 480 2100

Fax: 52 5 480 2199

Embarcar a: BayStack 425  
100 - 120 VAC 16A 50 to 60 Hz  
200 - 240 VAC 12 A 50 to 60 Hz

---

## Nortel Networks Inc. software license agreement

This Software License Agreement (“License Agreement”) is between you, the end-user (“Customer”) and Nortel Networks Corporation and its subsidiaries and affiliates (“Nortel Networks”). PLEASE READ THE FOLLOWING CAREFULLY. YOU MUST ACCEPT THESE LICENSE TERMS IN ORDER TO DOWNLOAD AND/OR USE THE SOFTWARE. USE OF THE SOFTWARE CONSTITUTES YOUR ACCEPTANCE OF THIS LICENSE AGREEMENT. If you do not accept these terms and conditions, return the Software, unused and in the original shipping container, within 30 days of purchase to obtain a credit for the full purchase price.

“Software” is owned or licensed by Nortel Networks, its parent or one of its subsidiaries or affiliates, and is copyrighted and licensed, not sold. Software consists of machine-readable instructions, its components, data, audio-visual content (such as images, text, recordings or pictures) and related licensed materials including all whole or partial copies. Nortel Networks grants you a license to use the Software only in the country where you acquired the Software. You obtain no rights other than those granted to you under this License Agreement. You are responsible for the selection of the Software and for the installation of, use of, and results obtained from the Software.

- 1. Licensed Use of Software.** Nortel Networks grants Customer a nonexclusive license to use a copy of the Software on only one machine at any one time or to the extent of the activation or authorized usage level, whichever is applicable. To the extent Software is furnished for use with designated hardware or Customer furnished equipment (“CFE”), Customer is granted a nonexclusive license to use Software only on such hardware or CFE, as applicable. Software contains trade secrets and Customer agrees to treat Software as confidential information using the same care and discretion Customer uses with its own similar information that it does not wish to disclose, publish or disseminate. Customer will ensure that anyone who uses the Software does so only in compliance with the terms of this Agreement. Customer shall not a) use, copy, modify, transfer or distribute the Software except as expressly authorized; b) reverse assemble, reverse compile, reverse engineer or otherwise translate the Software; c) create derivative works or modifications unless expressly authorized; or d) sublicense, rent or lease the Software. Licensors of intellectual property to Nortel Networks are beneficiaries of this provision. Upon termination or breach of the license by Customer or in the event designated hardware or CFE is no longer in use, Customer will promptly return the Software to Nortel Networks or certify its destruction. Nortel Networks may audit by remote polling or other reasonable means to determine Customer’s Software activation or usage levels. If suppliers of third party software included in Software require Nortel Networks to include additional or different terms, Customer agrees to abide by such terms provided by Nortel Networks with respect to such third party software.
- 2. Warranty.** Except as may be otherwise expressly agreed to in writing between Nortel Networks and Customer, Software is provided “AS IS” without any warranties (conditions) of any kind. NORTEL NETWORKS DISCLAIMS ALL WARRANTIES (CONDITIONS) FOR THE SOFTWARE, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ANY WARRANTY OF NON-INFRINGEMENT. Nortel Networks is not obligated to provide support of any kind for the Software. Some jurisdictions do not allow exclusion of implied warranties, and, in such event, the above exclusions may not apply.
- 3. Limitation of Remedies.** IN NO EVENT SHALL NORTEL NETWORKS OR ITS AGENTS OR SUPPLIERS BE LIABLE FOR ANY OF THE FOLLOWING: a) DAMAGES BASED ON ANY THIRD PARTY CLAIM; b) LOSS OF, OR DAMAGE TO, CUSTOMER’S RECORDS, FILES OR DATA; OR c) DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), WHETHER IN CONTRACT, TORT OR OTHERWISE (INCLUDING NEGLIGENCE) ARISING OUT OF YOUR USE OF THE SOFTWARE, EVEN IF NORTEL NETWORKS, ITS AGENTS OR SUPPLIERS HAVE BEEN ADVISED OF THEIR POSSIBILITY. The forgoing limitations of remedies also apply to any developer and/or supplier of the Software. Such developer and/or supplier is an intended beneficiary of this Section. Some jurisdictions do not allow these limitations or exclusions and, in such event, they may not apply.
- 4. General**

- 
- a)** If Customer is the United States Government, the following paragraph shall apply: All Nortel Networks Software available under this License Agreement is commercial computer software and commercial computer software documentation and, in the event Software is licensed for or on behalf of the United States Government, the respective rights to the software and software documentation are governed by Nortel Networks standard commercial license in accordance with U.S. Federal Regulations at 48 C.F.R. Sections 12.212 (for non-Odd entities) and 48 C.F.R. 227.7202 (for Odd entities).
  - b)** Customer may terminate the license at any time. Nortel Networks may terminate the license if Customer fails to comply with the terms and conditions of this license. In either event, upon termination, Customer must either return the Software to Nortel Networks or certify its destruction.
  - c)** Customer is responsible for payment of any taxes, including personal property taxes, resulting from Customer's use of the Software. Customer agrees to comply with all applicable laws including all applicable export and import laws and regulations.
  - d)** Neither party may bring an action, regardless of form, more than two years after the cause of the action arose.
  - e)** The terms and conditions of this License Agreement form the complete and exclusive agreement between Customer and Nortel Networks.
  - f)** This License Agreement is governed by the laws of the country in which Customer acquires the Software. If the Software is acquired in the United States, then this License Agreement is governed by the laws of the state of New York.

## Revision History

<b>Date Revised</b>	<b>Version</b>	<b>Reason for revision</b>
July 2004	1.0	Documenting new features for software 3.1 release.



---

# Contents

---

<b>Preface</b> .....	<b>21</b>
About this guide .....	21
Before you begin .....	21
Text conventions .....	22
Related publications .....	23
How to get help .....	24
<b>Chapter 1</b>	
<b>CLI Basics</b> .....	<b>25</b>
CLI command modes .....	26
Port numbering .....	29
Port numbering in standalone mode .....	29
Port numbering in stacked mode .....	30
IP notation .....	31
Accessing the CLI .....	31
Setting the CLI password .....	33
cli password command .....	33
Getting help .....	34
Basic navigation .....	34
General navigation commands .....	35
Keystroke navigation .....	36
help command .....	37
no command .....	37
default command .....	38
logout command .....	38
enable command .....	38
configure command .....	39
interface command .....	39

disable command .....	40
end command .....	40
exit command .....	40
Managing basic system information .....	41
show sys-info command .....	41
show stack-info command .....	42
renumber unit command .....	43
Managing MAC address forwarding database table .....	43
show mac-address-table command .....	44
mac-address-table aging-time command .....	45
default mac-address-table aging-time command .....	46
<b>Chapter 2</b>	
<b>General CLI commands .....</b>	<b>47</b>
Setting the terminal .....	48
show terminal command .....	48
default terminal command .....	49
terminal command .....	49
Pinging .....	50
ping command .....	50
Custom Autonegotiation Advertisements .....	51
Configuring CANA using the CLI .....	51
Configuring CANA .....	52
Viewing current autonegotiation advertisements .....	52
Viewing hardware capabilities .....	53
Setting default autonegotiation advertisements .....	55
Automatically loading Configuration file .....	56
configure network command .....	56
show config-network command .....	57
Assigning and clearing IP addresses .....	58
ip address command .....	58
no ip address command .....	59
ip default-gateway command .....	60
no ip default-gateway command .....	60
show ip command .....	61

---

Assigning and clearing IP addresses for specific units	62
ip address unit command	62
no ip address unit command	63
default ip address unit command	64
Setting Telnet access	65
show telnet-access command	65
telnet-access command	66
no telnet-access command	67
default telnet-access command	68
Setting server for Web-based management	68
web-server	69
no web-server	69
Setting boot parameters	69
boot command	70
ip bootp server command	70
no ip bootp server command	71
default ip bootp server command	71
Setting TFTP parameters	72
show tftp-server command	72
tftp-server command	73
no tftp-server command	73
copy config tftp command	73
copy tftp config command	74
ASCII Configuration Generator	75
show running-config command	75
copy running-config tftp command	76
Upgrading software	77
download command	77
Displaying interfaces	79
show interfaces command	79
Setting SNMP parameters	81
snmp-server command	82
no snmp-server command	83
snmp trap link-status command	84
no snmp trap link-status command	84

default snmp trap link-status command .....	85
Setting the system event log .....	86
show logging .....	86
logging .....	87
no logging .....	87
default logging .....	88
clear logging command .....	88
Displaying port statistics .....	88
show port-statistics command .....	89
clear-stats command .....	90
Enabling or disabling a port .....	91
shutdown command .....	91
no shutdown command .....	92
Naming ports .....	92
name command .....	93
no name command .....	93
default name command .....	94
Setting port speed .....	94
speed command .....	95
default speed command .....	95
duplex command .....	96
default duplex command .....	97
Enabling Autopology .....	97
autotopology command .....	98
no autotopology command .....	98
default autotopology command .....	98
Enabling flow control .....	99
flowcontrol command .....	99
no flowcontrol command .....	100
default flowcontrol command .....	100
Banner Display Function .....	101
Setting Banner Display .....	101
banner command for displaying banner .....	101
show banner command .....	102
no banner command .....	102

---

default banner command .....	103
Setting the default management interface .....	103
cmd-interface command .....	103
<b>Chapter 3</b>	
<b>Security .....</b>	<b>105</b>
Using MAC address security .....	105
show mac-security command .....	106
mac-security command .....	107
mac-security mac-address-table address command .....	108
mac-security security-list command .....	109
no mac-security command .....	109
no mac-security mac-address-table command .....	110
no mac-security security-list command .....	110
mac-security command for specific ports .....	111
mac-security mac-da-filter command .....	112
Using RADIUS authentication .....	112
show radius-server command .....	113
radius-server command .....	113
no radius-server command .....	114
<b>Chapter 4</b>	
<b>Spanning Tree, MLT, and Port-Mirroring .....</b>	<b>115</b>
Using spanning tree .....	115
show spanning-tree command .....	116
spanning-tree command by port .....	118
default spanning-tree command by port .....	119
no spanning-tree command by port .....	119
Using Multi-Link Trunking .....	120
show mlt command .....	120
mlt command .....	121
no mlt command .....	122
Using port-mirroring .....	123
show port-mirroring command .....	123
port-mirroring command .....	123

no port-mirroring command .....	124
<b>Chapter 5</b>	
<b>VLANs .....</b>	<b>125</b>
Configuring and displaying VLANs .....	125
show vlan interface info command .....	126
show vlan interface vids command .....	127
vlan mgmt command .....	128
default vlan mgmt command .....	129
vlan create command .....	129
vlan delete command .....	130
no vlan command .....	130
vlan name command .....	131
auto-pvid command .....	131
no auto-pvid command .....	131
vlan ports command .....	132
vlan members command .....	133
<b>Command List .....</b>	<b>135</b>
<b>Index .....</b>	<b>141</b>

---

# Figures

---

Figure 1	CLI command mode hierarchy .....	27
Figure 2	BayStack 425-48T Switch banner .....	32
Figure 3	Main Menu for BayStack 425-48T Switch console interface .....	32
Figure 4	help command output in privExec mode .....	37
Figure 5	show sys-info command output .....	42
Figure 6	show stack-info command output .....	43
Figure 7	show mac-address-table command output .....	45
Figure 8	show terminal command output .....	49
Figure 9	ping command responses .....	51
Figure 10	auto-negotiation-advertisements sample output .....	52
Figure 11	show auto-negotiation-advertisements command sample output. ....	53
Figure 12	show auto-negotiation-advertisements command sample output .....	53
Figure 13	show auto-negotiation-capabilities command sample output .....	54
Figure 14	show auto-negotiation-capabilities command sample output .....	54
Figure 15	default auto-negotiation-advertisements command sample output ....	55
Figure 16	no auto-negotiation-advertisements command sample output .....	56
Figure 17	show config-network command .....	58
Figure 18	show ip command output .....	62
Figure 19	Telnet icon on Device Manager toolbar .....	65
Figure 20	show telnet-access command output .....	66
Figure 21	show tftp-server command output .....	72
Figure 22	Output of the show running-config command .....	76
Figure 23	download message for BayStack 425-48T Switch .....	79
Figure 24	show interfaces names command output .....	80
Figure 25	show interfaces command output .....	81
Figure 26	show logging command output .....	87
Figure 27	show port-statistics command output .....	90
Figure 28	show mac-security command output .....	107
Figure 29	show radius-server command output .....	113

Figure 30	show spanning-tree command output by port .....	117
Figure 31	show spanning-tree command output .....	118
Figure 32	show mlt command output .....	121
Figure 33	show port-mirroring command output .....	123
Figure 34	show vlan interface info output .....	127
Figure 35	show vlan interface vids output .....	128



---

## Tables

---

Table 1	Command mode prompts and entrance/exit commands	28
Table 2	cli password command parameters and variables	34
Table 3	Keystroke navigation	36
Table 4	configure command parameters and variables	39
Table 5	interface command parameters and variables	40
Table 6	show mac-address-table command parameters and variables	44
Table 7	mac-address-table aging-time command parameters and variables	45
Table 8	default terminal command parameters and variables	49
Table 9	terminal command parameters and variables	50
Table 10	ping command parameters and variables	51
Table 11	configure network command parameters and variables	57
Table 12	ip address command parameters and variables	59
Table 13	no ip address command parameters and variables	59
Table 14	ip default-gateway command parameters and variables	60
Table 15	show ip command parameters and variables	61
Table 16	ip address unit command parameters and variables	63
Table 17	no ip address command parameters and variables	63
Table 18	default ip address unit command parameters and variables	64
Table 19	telnet-access command parameters and variables	67
Table 20	no telnet-access command parameters and variables	68
Table 21	web-server command parameters and variables	69
Table 22	boot command parameters and variables	70
Table 23	ip bootp server command parameters and variables	71
Table 24	tftp-server command parameters and variables	73
Table 25	copy config tftp command parameters and variables	74
Table 26	copy tftp config command parameters and variables	74
Table 27	copy running-config tftp command parameters and variables	77
Table 28	download command parameters and variables	78
Table 29	show interfaces command parameters and variables	79

Table 30	snmp-server command parameters and variables	82
Table 31	no snmp-server command parameters and variables	83
Table 32	snmp trap link-status command parameters and variables	84
Table 33	no snmp trap link-status command parameters and variables	85
Table 34	default snmp trap link-status command parameters and variables	85
Table 35	show logging command parameters and variables	86
Table 36	logging command parameters and values	87
Table 37	clear logging command parameters and values	88
Table 38	show port-statistics command parameters and variables	89
Table 39	clear-stats command parameters and variables	91
Table 40	shutdown command parameters and variables	92
Table 41	no shutdown command parameters and variables	92
Table 42	name command parameters and variables	93
Table 43	no name command parameters and variables	94
Table 44	default name command parameters and variables	94
Table 45	speed command parameters and variables	95
Table 46	default speed command parameters and variables	96
Table 47	duplex command parameters and variables	96
Table 48	default duplex command parameters and variables	97
Table 49	flowcontrol command parameters and variables	99
Table 50	no flowcontrol command parameters and variables	100
Table 51	default flowcontrol command parameters and variables	101
Table 52	banner command parameters	102
Table 53	show banner command parameters	102
Table 54	cmd-interface command parameters and variables	104
Table 55	show mac-security command parameters and variables	106
Table 56	mac-security command parameters and values	107
Table 57	mac-security mac-address-table address parameters and values	109
Table 58	mac-security security-list command parameters and values	109
Table 59	no mac-security mac-address-table command parameters and values	110
Table 60	no mac-security security-list command parameters and values	111
Table 61	mac-security command for a single port parameters and variables	111
Table 62	mac-security mac-da-filter command parameters and values	112
Table 63	radius-server command parameters and variables	114
Table 64	show spanning-tree command parameters and variables	116

---

Table 65	spanning-tree command by port variables . . . . .	118
Table 66	default spanning-tree command by port parameters and variables . . . . .	119
Table 67	no spanning-tree command by port parameters and variables . . . . .	120
Table 68	show mlt command parameters and variables . . . . .	121
Table 69	mlt command parameters and variables . . . . .	122
Table 70	no mlt command parameters and variables . . . . .	122
Table 71	port-mirroring command parameters and variables . . . . .	124
Table 72	show vlan command interface info parameters and variables . . . . .	126
Table 73	show vlan command interface vids parameters and variables . . . . .	128
Table 74	vlan mgmt command parameters and variables . . . . .	129
Table 75	vlan create command parameters and variables . . . . .	129
Table 76	vlan delete command parameters and variables . . . . .	130
Table 77	no vlan command parameters and variables . . . . .	130
Table 78	vlan name command parameters and variables . . . . .	131
Table 79	vlan ports command parameters and variables . . . . .	132
Table 80	vlan members command parameters and variables . . . . .	133
Table 81	CLI command list . . . . .	135



---

## Preface

---

The Nortel Networks\* BayStack 425-24T/48T Switch\* Command Line Interface (CLI) is one tool used to configure and manage a BayStack 425-24T and BayStack 425-48T Switches. The CLI allows you to set up, configure, and manage your BayStack 420/425.

You can also use the Java\* Device Manager Graphical User Interface (GUI), the Web-based management system GUI and the Console Interface (CI) menus to configure and manage the switch. For more information on these management systems, refer to *Reference for the BayStack 420/425 Switch Management Software, Software Release 3.1*, *Using Web-based Management for the BayStack 420/425, Software Release 3.1*, and *Using the BayStack 420/425 Switch, Software Release 3.1*.

For general information on using and configuring the BayStack 425, refer to *Using the BayStack 420/425 Switch, Software Release 3.1*.

## About this guide

This guide provides information about using the features and capabilities of the CLI to manage switching operations in the BayStack 425-24T/48T Switch, as well as a complete list of CLI commands.

## Before you begin

This guide is intended for network administrators with the following background:

- Basic knowledge of networks, bridging, and IP
- Familiarity with networking concepts and terminology
- Basic knowledge of network topologies

Before using this guide, you must complete the procedures discussed in the *BayStack 425 Switch Installation Instructions*.

## Text conventions

angle brackets (< >)	<p>Indicate that you choose the text to enter based on the description inside the brackets. Do not type the brackets when entering the command.</p> <p>Example: If the command syntax is <code>ip default-gateway &lt;XXX.XXX.XXX.XXX&gt;</code>, you enter <code>ip default-gateway 192.32.10.12</code></p>
braces ({} )	<p>Indicate required elements in syntax descriptions where there is more than one option. You must choose only one of the options. Do not type the braces when entering the command.</p> <p>Example: If the command syntax is: <code>http-server {enable disable}</code> the options for are <code>enable</code> or <code>disable</code>.</p>
brackets ([ ])	<p>Indicate optional elements in syntax descriptions. Do not type the brackets when entering the command.</p> <p>Example: If the command syntax is: <code>show ip [bootp]</code>, you can enter either: <code>show ip</code> or <code>show ip bootp</code>.</p>
plain Courier text	<p>Indicates command syntax and system output.</p> <p>Example: TFTP Server IP Address: 192.168.100.15</p>
vertical line	<p>Separates choices for command keywords and arguments. Enter only one of the choices. Do not type the vertical line when entering the command.</p> <p>Example: If the command syntax is: <code>cli password &lt;serial telnet&gt;</code>, you must enter either <code>cli password serial</code> or <code>cli password telnet</code>, but not both.</p>
H.H.H.	<p>Enter a MAC address in this format (XXXX.XXXX.XXXX).</p>

## Related publications

For more information about managing or using the BayStack 420/425 Switch, refer to the following publications:

- *Using the BayStack 420/425 Switch, Software Release 3.1* (part number 215661-B)  
Describes how to use the BayStack 425 Switch for network configuration.
- *Using Web-based Management for the BayStack 420/425, Software Release 3.1* (part number 215660-B)  
Describes how to use the Web-based management tool to configure switch features.
- *Installing the BayStack 425 Switch* (part number 215658-B)  
Describes how to install the BayStack 425 Switch.
- *Release Notes for the BayStack 420/425 Switch, Software Release 3.1* (part number 216078-B)  
Documents important changes about the software and hardware that are not covered in other related publications.
- *Getting Started with BayStack 420/425 Switch Management Software, Software Release 3.1* (part number 215663-B)  
Describes how to install the Java-based device level software management application.
- *Reference for the BayStack 420/425 Switch Management Software, Software Release 3.1* (part number 215662-C)  
Describes how to use the Java-based device level software management application.

You can print selected technical manuals and release notes free, directly from the Internet. Go to the [www.nortelnetworks.com/documentation](http://www.nortelnetworks.com/documentation) URL. (The product family for the BayStack 420/425 is Data and Internet.) Find the product for which you need documentation. Then locate the specific category and model or version for your hardware or software product. Use Adobe\* Acrobat Reader\* to open the manuals and release notes, search for the sections you need, and print them on most standard printers. Go to Adobe Systems at the [www.adobe.com](http://www.adobe.com) URL to download a free copy of the Adobe Acrobat Reader.

## How to get help

If you purchased a service contract for your Nortel Networks product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

If you purchased a Nortel Networks service program, contact one of the following Nortel Networks Technical Solutions Centers:

Technical Solutions Center	Telephone
Europe, Middle East, and Africa	(33) (4) 92-966-968
North America	(800) 4NORTEL or (800) 466-7835
Asia Pacific	(61) (2) 9927-8800
China	(800) 810-5000

Additional information about the Nortel Networks Technical Solutions Centers is available from the [www.nortelnetworks.com/help/contact/global](http://www.nortelnetworks.com/help/contact/global) URL.

An Express Routing Code (ERC) is available for many Nortel Networks products and services. When you use an ERC, your call is routed to a technical support person who specializes in supporting that product or service. To locate an ERC for your product or service, go to the <http://www130.nortelnetworks.com/cgi-bin/eserv/common/essContactUs.jsp> URL.



---

# Chapter 1

## CLI Basics

---

You can manage the BayStack 420/425 with a number of tools. You can use either Graphical User Interface (GUI) or the Web-based management system. You can use the Console Interface (CI menus), or you can use the Command Line Interface (CLI). (For more information on using the DM, refer to *Reference for the BayStack 420/425 Switch Management Software, Software Release 3.1*. For more information on using the Web-based management system, refer to *Using Web-based Management for the BayStack 420/425, Software Release 3.1*. For more information on using the CI menus, refer to *Using the BayStack 420/425 Switch, Software Release 3.1*.)

The BayStack 425 24T/48T Command Line Interface (CLI) is a management tool that provides methods for configuring, managing, and monitoring the operational functions of the switch. You can access the CLI through a direct connection to the switch console port, or remotely using Telnet. For a complete, alphabetical list of CLI commands, refer to Appendix A.

You can use the CLI interactively, or you can load and execute CLI “scripts.” CLI scripts are loaded in one of the following ways:

- By entering the `configure network` command.
- By manually loading the script in the console menu.
- By automatically loading the script at boot-up

This chapter discusses the following CLI topics:

- [“CLI command modes” on page 26](#)
- [“Port numbering” on page 29](#)
- [“IP notation” on page 31](#)
- [“Accessing the CLI” on page 31](#)
- [“Setting the CLI password” on page 33](#)

- [“Getting help” on page 34](#)
- [“Basic navigation” on page 34](#)
- [“Managing basic system information” on page 41](#)
- [“Managing MAC address forwarding database table” on page 43](#)

## CLI command modes

Most CLI commands are available only under a certain command mode. The BayStack 420/425 has the following four command modes:

- User EXEC
- Privileged EXEC
- Global Configuration
- Interface Configuration

The User EXEC mode is the default mode; it is also referred to as `exec`. This command mode is the initial mode of access upon first powering-up the BayStack 420/425. In this command mode, the user can access only a subset of the total CLI commands; however, the commands in this mode are available while the user is in any of the other four modes. The commands in this mode are those you would generally need, such as `ping` and `logout`.

Commands in the Privileged EXEC mode are available to all other modes but the User EXEC mode. The commands in this mode allow you to perform basic switch-level management tasks, such as downloading the software image, setting passwords, and booting the BayStack 420/425. The Privileged EXEC mode is also referred to as `privExec` mode.


The last two command modes allow you to change the configuration of the BayStack 420/425. Changes made in these command modes are immediately applied to the switch configuration and saved to NVRAM.

The Global Configuration commands allow you to set and display general configurations for the switch, such as the IP address, SNMP parameters, the Telnet access, and VLANs. The Global Configuration mode is also referred to as `config` mode.

The Interface Configuration commands allow you to configure parameters for each port, such as speed and duplex mode. The Interface Configuration mode is also referred to as config-if mode.

[Figure 1](#) provides an illustration of the hierarchy of BayStack 420/425 CLI command modes.

**Figure 1** CLI command mode hierarchy



10194EA

You see a specific value for each command mode at the prompt line, and you use specific commands to enter or exit each command mode (Table 1). Additionally, you can only enter command modes from specific modes and only exit to specific command modes.

Table 1 describes the command mode prompts and entrance/exit commands

**Table 1** Command mode prompts and entrance/exit commands

Command mode	Prompt	Enter/exit command
User EXEC (exec)	BS425_48>	Default mode, automatically enter logout or exit to quit CLI
Privileged EXEC (privExec)	BS425_48#	enable to enter from User EXEC mode logout or exit to quit CLI
Global Configuration (config)	BS425_48 (config) #	configure to enter from Privileged EXEC mode logout to quit CLI; end or exit to exit to Privileged EXEC mode
Interface Configuration (config-if)	BS425_48 (config-if) #	interface Fast Ethernet {<portnum> all} to enter from Global Configuration mode logout to quit CLI; end to exit to Privileged EXEC mode; exit to exit to Global Configuration mode

The prompt displays the switch name, BS425, and the current CLI command mode:

- User EXEC—BS425\_48>
- Privileged EXEC—BS425\_48#
- Global Configuration—BS425\_48 (config) #
- Interface Configuration—BS425\_48 (config-if) #

Refer to Appendix A, for a complete, alphabetical list of all CLI commands and where they are explained.

The initial command mode in CLI depends on your access level when you logged into the BayStack 420/425 CI menus:

- With no password protection, you enter the CLI in userExec mode, and use the enable command to move to the privExec command mode.
- If you logged into the CI menus with read-only access, you enter the CLI in userExec mode and cannot access any other CLI command modes.

- If you logged into the CLI menus with read-write access, you enter the CLI in `privExec` mode and use the commands to move to the other command modes.

## Port numbering

The BayStack 420/425 operates either in standalone mode or in stack mode. The BayStack 425-24T Switch has 24 10/100 Mb/s ports and BayStack 425 48T has 48 10/100 ports on the front, as well as 2 combo ports, which includes 2GBIC or 2 copper ports 10/100/1000Mbps.

The CLI uses the variable `<portlist>` when a command specifies one or more ports for the command. The format of the variable `<portlist>` is different if you are working with a standalone BS 425 or with a stack.

### Port numbering in standalone mode

In standalone mode, the number of port is a integer between 1-50 for BayStack 425-48T and 1-26 for BayStack 425-24T. You can use the `<portlist>` variable in the following formats:

- A single port number—an integer between 1 through 50
  - Example: `7` means port 7
- A range of port numbers—a pair of port numbers between 1 and 50 separated by a dash
  - Example: `1-3` means ports 1, 2, and 3
  - Example: `5-24` means all ports from port 5 through port 24
- A list of port numbers and/or port ranges, separated by commas
  - Example: `1, 3, 7` means ports 1, 3, and 7
  - Example: `1-3, 9-11` means ports 1, 2, 3, 9, 10, and 11
  - Example: `1, 3-5, 9-11, 15` means ports 1, 3, 4, 5, 9, 10, 11, and 15
- `none` means no ports.
- `all` means all the ports on the standalone BS 425, including any GBIC ports.

You can also use the unit/port convention discussed in [“Port numbering in stacked mode,”](#) next, with a standalone BayStack 420/425 as long as the unit number is always 1.

## Port numbering in stacked mode

In BS 425 Stack mode, use the `<portlist>` variable to represent the number of the unit within the stack, followed by a forward slash (/), followed by port number(s). The unit numbers will always be integers between 1 and 8, and the port numbers will always be integers between 1 and 50. You can also use `none` to indicate none of the ports in the stack or `all` to indicate all of the ports in the stack.

In stacked mode, use the `<portlist>` variable in the following formats:

- A single port number—an integer for the unit, followed by /, and an integer for the port number
  - Example: `1/7` means unit 1 port 7
  - Example: `3/24` means unit 3, port 24
- A range of port numbers—an integer for the unit, followed by /, and integers for the port number between 1 and 28 separated by a dash
  - Example: `1/1-3` means unit 1, ports 1, 2, and 3
  - Example: `3/5-24` means unit 3, port 5 through port 24
- A unit with no ports specified—an integer for the unit, followed by /, and the word `none`.
  - `3/none` means unit 3 with no ports
- A unit with all ports specified—an integer for the unit, followed by /, and the word `all`.
  - `3/all` means unit 3 with all ports
- A list of port numbers, port ranges, and/or units with all ports or no ports—using the unit/port format—separated by commas
  - Example: `1/1, 2/3, 3/7` means unit 1 port 1; unit 2, port 3; and unit 3, port 7
  - Example: `1/1-3, 3/9-11` means unit 1, ports 1, 2, 3; and unit 3, ports 9, 10, and 11
  - Example: `1/1, 4/3-5, 5/9-11, 7/15` means unit 1, port 1; unit 4, ports 3, 4, 5; unit 5, ports 9, 10, 11; and unit 7, port 15
  - Example: `1/3, 3/ALL, 4/NONE` means unit 1, port 3; unit 3, all ports; and unit 4, no ports
- `none` means no ports in the stack.
- `all` means all the ports in the stack, including all GBIC ports.

To view the unit numbers in the stack, issue the `show stack-info` command (“[show stack-info command](#)” on page 42). You must be in the Privileged EXEC (`privExec`) mode to issue this command.

Refer to *Using the BayStack 425 Switch Software Version 3.1* guide, for more information on numbering units within the stack.

## IP notation

You enter IP addresses and subnet masks in one of the following two ways in the CLI. You can always enter an IP address in dotted decimal notation (`XXX.XXX.XXX.XXX`), specifying both the IP address and the subnet mask in dotted-decimal notation.

Or, when you are specifying both an IP address and a netmask, you may alternatively enter `XXX.XXX.XXX.XXX/0-32`, where `XXX.XXX.XXX.XXX` is the IP address in dotted-decimal notation and the value `0-32` specifies the number of bits starting from the left in the mask (for example, a value of 8 is `255.0.0.0`).

## Accessing the CLI

You access the CLI menus using Telnet or a direct connection to the switch from a terminal or personal computer (PC). You can use any terminal or PC with a terminal emulator as the CLI command station. Be sure the terminal has the following features:

- 9600 bits per second (b/s), 8 data bits, 1 stop bit, no parity, no flow control
- Serial terminal-emulation program such as Terminal or Hyperterm for Windows\* 95, Windows 98, Windows 2000, Windows XP or Windows NT\*.
- Cable and connector to match the male DTE connector (DB-9) on the BayStack 420/425 console port, with the DCE/DTE switch on the switch management module set to DTE
- VT100 Arrows checked in the Terminal Preferences window under Terminal Options, and Block Cursor unchecked; VT-100/ANSI checked under Emulation

To access the CLI:

- 1 When you access the BayStack 420/425, the banner appears (Figure 2).

**Figure 2** BayStack 425-48T Switch banner

```
*****  
*** BayStack 425-48T ***  
*** Nortel Networks ***  
*** Copyright (c) 1996-2004, All Rights Reserved ***  
*** ***  
*** HW:0C FW:3.1.0.4 SW:v3.1.0.60 ***  
*****
```

- 2 Press [Ctrl]+Y, and the Main Menu appears on the console screen (Figure 3) with the top line highlighted.

**Figure 3** Main Menu for BayStack 425-48T Switch console interface

```
BayStack 425-48T Main Menu  
  
IP Configuration/Setup...  
SNMP Configuration...  
System Characteristics...  
Switch Configuration...  
Console/Comm Port Configuration...  
Display Hardware Units...  
Spanning Tree Configuration...  
TELNET/SNMP/Web Access Configuration...  
Software Download...  
Configuration File...  
Display System Log...  
Reset...  
Reset to Default Settings...  
Command Line Interface...  
Logout...
```

Use arrow keys to highlight option, press <Return> or <Enter> to select option.



- Using the Down Arrow key, scroll down to Command Line Interface, and press [Enter]. The CLI cursor appears:

```
BS425_48T>
```

The > sign at the end of the name of the switch indicates that the CLI opens in User EXEC mode. Refer to “[CLI command modes](#)” on page 26, to select the command mode you want to use (and are authorized to use).

## Setting the CLI password

You can set passwords using the `cli password` command for selected types of access using the CLI, Telnet, or RADIUS security.

For more information on Telnet access, refer to Chapter 3. For more information on using RADIUS security with the CLI, refer to Chapter 3.

### cli password command

The `cli password` is in two forms and performs the following functions for either the switch or the entire stack:

- Changes the password for access through the serial console port and Telnet
- Specifies changing the password for serial console port or Telnet access and whether to authenticate password locally or with the RADIUS server

The syntax for the `cli password` commands are:

```
cli password {switch|stack} {ro|rw} <NAME> <PASSWORD>
```

```
cli password {switch|stack} {serial|telnet}  
{none|local|radius}
```

The `cli password` command is in the config command mode.

[Table 2](#) describes the parameters and variables for the `cli password` command.

**Table 2** cli password command parameters and variables

Parameters and variables	Description
switch stack	Specifies you are modifying the settings on the switch or on the stack.  Note: If you omit this parameter, the system modifies the information for the current mode.
rolrw	Specifies you are modifying the read-only (ro) password or the read-write (rw) password.
<NAME> <PASSWORD>	Enter your username for the first variable, and your password for the second variable.
serial telnet	Specifies you are modifying the password for serial console access or for Telnet access.
nonelocal radius	Specifies the password you are modifying: none—disables the password local—use the locally defined password for serial console or Telnet access radius—use RADIUS authentication for serial console or Telnet access

## Getting help

When you navigate through the CLI, online help is available at all levels. Entering a portion of the command, space, and a question mark (?) at the prompt results in a list of all options for that command.

Refer to [“help command” on page 37](#) for more information about the specific types of online help.

## Basic navigation

This section discusses basic navigation around the CLI and between the command modes. As you see, the CLI incorporates various shortcut commands and keystrokes to simplify its use. The following topics are covered in this section:

- “General navigation commands,” next
- “Keystroke navigation” on page 36
- “help command” on page 37
- “no command” on page 37
- “default command” on page 38
- “logout command” on page 38
- “enable command” on page 38
- “configure command” on page 39
- “interface command” on page 39
- “disable command” on page 40
- “end command” on page 40
- “exit command” on page 40

## General navigation commands

When you enter “?” at any point in the CLI session, the system retrieves help information for whatever portion of the command you entered thus far. Refer to “help command” on page 37 for more information.

The system records the last command in a CLI session. However, the last command is not saved across reboots.

Add the word `no` to the beginning of most CLI configuration commands to clear or remove the parameters of the actual command. For example, when you enter the command `ip stack address 192.32.154.126`, you set the IP stack address. However, when you enter `no ip stack address`, the system returns the IP address to zero. Refer to Appendix A for an alphabetical list of `no` commands.

Add the word `default` to the beginning of most CLI configuration commands returns the parameters of the actual command to the factory default values. Refer to Appendix A for an alphabetical list of `default` commands.

When you enter a portion of the command and the [Tab] key, the system finds the first unambiguous match of a command and displays that command. For example, if you enter `down+[Tab]`, the system displays `download`.

## Keystroke navigation

You change the location of the cursor using the key combinations shown in [Table 3](#).

**Table 3** Keystroke navigation

Key combination	Function
[Ctrl]+A	Start of line
[Ctrl]+B	Back 1 character
[Ctrl]+C	Abort command
[Ctrl]+D	Delete the character indicated by the cursor
[Ctrl]+E	End of line
[Ctrl]+F	Forward 1 character
[Ctrl]+H	Delete character left of cursor (Backspace key)
[Ctrl]+I &	Command/parameter completion
[Ctrl]+K & [Ctrl]+R	Redisplay line
[Ctrl]+N or [Down arrow]	Next history command
[Ctrl]+P or [Up arrow]	Previous history command
[Ctrl]+T	Transpose characters
[Ctrl]+U	Delete entire line
[Ctrl]+W	Delete word left of cursor
[Ctrl]+X	Delete all characters to left of cursor
[Ctrl]+z	Exit Global Configuration mode (to Privileged EXEC mode)
?	Context-sensitive help
[Esc]+c & [Esc]+u	Capitalize character at cursor
[Esc]+l	Change character at cursor to lowercase
[Esc]+b	Move back 1 word
[Esc]+d	Delete 1 word to the right
[Esc]+f	Move 1 word forward

## help command

The `help` command is in all command modes and displays a brief message about using the CLI help system. The syntax for the `help` command is:

```
help
```

The `help` command has no parameters or variables.

Figure 4 shows the output from the `help` command.

**Figure 4** help command output in `privExec` mode

```
BS425_48#help
Help may be requested at any point in a command by entering
a question mark '?'. If nothing matches, the help list will
be empty and you must backup until entering a '?' shows the
available options.
Two styles of help are provided:
1. Full help is available when you are ready to enter a command argument
(e.g. 'show ?') and describes each possible argument.
2. Partial help is provided when an abbreviated argument is entered and you
want to know what arguments match the input (e.g. 'show pr?').
```

## no command

The `no` command is always used as a prefix to a configuration command, and it negates the action performed by that command. The effect of the `no` command is to remove or to clear the configuration controlled by the specified command. Various `no` commands are in the `config` and `config-if` command modes.

Refer to Appendix A for an alphabetical listing of all `no` commands.



**Note:** Not all configuration commands support the `no` prefix command.

## default command

The `default` command is always used as a prefix to a configuration command, and it restores the configuration parameters to default values. The default values are specified by each command.

Refer to Appendix A for an alphabetical listing of all `default` commands.



**Note:** Not all commands support the `default` prefix command.

---

## logout command

The `logout` command logs you out of the CLI session and returns you to the Main Menu of the console interface (CI) menus (Figure 3). The syntax for the `logout` command is:

```
logout
```

The `logout` command is in all command modes.

The `logout` command has no parameters or variables.

## enable command

The `enable` command changes the command mode from User EXEC to `privExec` mode. The syntax for the `enable` command is:

```
enable
```

The `enable` command is in the `exec` command mode.

The `enable` command has no parameters or variables.



**Note:** You must have read-write access to the BayStack 420/425 switch to be able to use the `enable` command.

---

## configure command

The `configure` command moves you to the Global Configuration (`config`) command mode and identifies the source for the configuration commands. The syntax for the `configure` command is:

```
configure {terminal|network}
```

The `configure` command is in the `privExec` command mode.

[Table 4](#) describes the parameters and variables for the `configure` command.

**Table 4** `configure` command parameters and variables

Parameters and variables	Description
terminal network	Specifies the source for the configuration commands for the BayStack 420/425: terminal—allows you to enter config mode to enter configuration commands network—allows you to set up parameters for auto-loading a script at boot-up or for loading and executing a script immediately

## interface command

The `interface` command moves you to the Interface Configuration (`config-if`) command mode. The syntax for the `interface` command is:

```
interface FastEthernet {<portlist>}
```

The `interface` command is in the `config` command mode.

[Table 5](#) describes the parameters and variables for the `interface` command.

**Table 5** interface command parameters and variables

Parameters and variables	Description
<portlist>	Specifies the portlist you want to be affected by all the commands issued in the config-if command mode.

## disable command

The `disable` command returns you to the User EXEC (`exec`) command mode. The syntax for the `disable` command is:

```
disable
```

The `disable` command is in the `privExec` command mode.

The `disable` command has no parameters or variables.

## end command

The `end` command moves you to the `priv Exec` mode from either the Global Configuration (`config`) mode or the Interface Configuration (`config-if`) mode.

The syntax for the `end` command is:

```
end
```

The `end` command has no parameters or variables.

## exit command

The `exit` command moves you around the command modes:

- In User EXEC (`exec`) and Privileged EXEC (`privExec`) command modes, `exit` allows you to quit the CLI session.
- In Global Configuration (`config`) mode, `exit` moves you back to the `privExec` command mode.



- In Interface Configuration (config-if) command mode, `exit` moves you back to the config mode.

The syntax for the `exit` command is:

```
exit
```

The `exit` command has no parameters or variables.

## Managing basic system information

This section shows you how to view basic system information, such as the current software version and the stack mode; you can renumber the units within a stack.

The following topics are covered:

- [“show sys-info command,”](#) next
- [“show stack-info command”](#) on page 42
- [“renumber unit command”](#) on page 43

Refer to *Using the BayStack 420/425 Switch, Software Release 3.1*, for more information on the operation of the stack mode, including unit numbering.

### show sys-info command

The `show sys-info` command displays the current system characteristics. The syntax for the `show sys-info` command is:

```
show sys-info
```

The `show sys-info` command is in the `privExec` command mode.

The `show sys-info` command has no parameters or variables.

[Figure 5](#) displays sample output from the `show sys-info` command.

**Figure 5** show sys-info command output

```
BS425_48#show sys-info
Operation Mode:      Switch
MAC Address:        00-0F-6A-7D-C0-A0
Reset Count:        6
Last Reset Type:    Management Reset
Power Status:       Primary Power
Autotopology:       Enabled
Local GBIC Type:    (port 49) GBIC is missing
Local GBIC Type:    (port 50) GBIC is missing
sysDescr:           BayStack 425-48T
                    HW:0C          FW:3.1.0.4    SW:v3.1.0.60
                    Mfg Date:02192004
Serial #:           SACC26008D
sysObjectID:        1.3.6.1.4.1.45.3.57.1
sysUpTime:          6 days, 14:55:27
sysServices:        3
sysContact:
sysName:
sysLocation:
```

To change the system contact, name, or location, refer to the `snmp-server` command in Chapter 2.

## show stack-info command

The `show stack-info` command displays the current stack information, which includes unit numbers, GBIC, and software version for all units. The syntax for the `show stack-info` command is:

```
show stack-info
```

The `show stack-info` command is in the `privExec` command mode.

The `show stack-info` command has no parameters or variables.

[Figure 6](#) displays sample output from the `show stack-info` command.

**Figure 6** show stack-info command output

```
BS425_48#show stack-info
Unit #   Switch Model   GBIC Port   GBIC Port   SW Version
-----
1        BayStack 425-48T (0/49) None   (0/50) None   v3.1.0.60
```

## renumber unit command

The `renumber unit` command changes the unit number of each switch in the stack. The syntax for the `renumber unit` command is:

```
renumber unit
```

The `renumber unit` command is in the config command mode.

The `renumber unit` command has no parameters or variables.



**Note:** This command does not take effect until you reset the stack.

## Managing MAC address forwarding database table

This section shows you how to view the contents of the MAC address forwarding database table, as well as setting the age-out time for the addresses. The following topics are covered:

- [“show mac-address-table command,”](#) next
- [“mac-address-table aging-time command”](#) on page 45
- [“default mac-address-table aging-time command”](#) on page 46

## show mac-address-table command

The `show mac-address-table` command displays the current contents of the MAC address forwarding database table. The syntax for the `show mac-address-table` command is:

```
show mac-address-table [vid <1-4094>] [aging-time] [address <H.H.H>]
```

The `show mac-address-table` command is in the `privExec` command mode.

[Table 6](#) describes the parameters and variables for the `show mac-address-table` command.

**Table 6** show mac-address-table command parameters and variables

Parameters and variables	Description
vid <1-4094>	Enter the number of the VLAN you want to display the forwarding database of. Default is to display the management VLAN's database.
aging-time	Displays the time in seconds after which an unused entry is removed from the forwarding database.
address <H.H.H>	Displays a specific MAC address if it exists in the database. Enter the MAC address you want displayed.

[Figure 7](#) displays sample output from the `show mac-address-table` command.

**Figure 7** show mac-address-table command output

```

BS425_48#show mac-address-table
Mac Address Table Aging Time: 300
Number of addresses: 7

    MAC Address      Source          MAC Address      Source
    -----
00-00-A2-8D-58-50  Port: 48       00-02-E3-05-3B-B5  Port: 48
00-04-DC-76-8A-03  Port: 48       00-0F-6A-7D-C0-A0
00-60-FD-F8-FB-3B  Port: 48       00-A0-CC-58-EA-BE  Port: 48
00-C0-4F-0C-4E-24  Port: 48       08-00-20-7C-86-AD  Port: 48
BS425_48#

```

## mac-address-table aging-time command

The `mac-address-table aging-time` command sets the time that the switch retains unseen MAC addresses. The syntax for the `mac-address-table aging-time` command is:

```
mac-address-table aging-time <time>
```

The `mac-address-table aging-time` command is in the config command mode.

[Table 7](#) describes the parameters and variables for the `mac-address-table aging-time` command.

**Table 7** mac-address-table aging-time command parameters and variables

Parameters and variables	Description
time	Enter the aging time in seconds that you want for MAC addresses before they are flushed.

## **default mac-address-table aging-time command**

The `default mac-address-table aging-time` command sets the time that the switch retains unseen MAC addresses to 300 seconds. The syntax for the `default mac-address-table aging-time` command is:

```
default mac-address aging-time
```

The `default mac-address-table aging-time` command is in the config command mode.

The `default mac-address-table aging-time` command has no parameters or variables.

---

## Chapter 2

# General CLI commands

---

In the BayStack 420/425, the Command Line Interface (CLI) commands allows you to display and modify the switch configuration while the switch is operating.

This chapter includes information about general switch maintenance, such as setting up access parameters, upgrading the software, and setting the speed. This chapter covers the following topics:

- [“Setting the terminal,” next](#)
- [“Pinging” on page 50](#)
- [“Custom Autonegotiation Advertisements” on page 51](#)
- [“Automatically loading Configuration file” on page 56](#)
- [“Assigning and clearing IP addresses” on page 58](#)
- [“Assigning and clearing IP addresses for specific units” on page 62](#)
- [“Setting Telnet access” on page 65](#)
- [“Setting server for Web-based management” on page 68](#)
- [“Setting boot parameters” on page 69](#)
- [“Setting TFTP parameters” on page 72](#)
- [“ASCII Configuration Generator” on page 75](#)
- [“Upgrading software” on page 77](#)
- [“Displaying interfaces” on page 79](#)
- [“Setting SNMP parameters” on page 81](#)
- [“Setting the system event log” on page 86](#)
- [“Displaying port statistics” on page 88](#)
- [“Enabling or disabling a port” on page 91](#)
- [“Naming ports” on page 92](#)
- [“Setting port speed” on page 94](#)
- [“Enabling Autopology” on page 97](#)

- [“Enabling flow control” on page 99](#)
- [“Banner Display Function” on page 101](#)
- [“Setting the default management interface” on page 103](#)

## Setting the terminal

You can view the terminal settings, set them to default settings, or customize the terminal settings. This section covers:

- [“show terminal command,” next](#)
- [“default terminal command” on page 49](#)
- [“terminal command” on page 49](#)

### show terminal command

The `show terminal` command displays the current serial port information, which includes connection speed, as well as the terminal width and length in number of characters. The syntax for the `show terminal` command is:

```
show terminal
```

The `show terminal` command is in the exec command mode.

The `show terminal` command has no parameters or variables.

[Figure 8](#) shows the output from the `show terminal` command.



**Figure 8** show terminal command output

```
BS425_48#show terminal
Terminal speed: 9600
Terminal width: 79
Terminal length: 23
BS425_48#
```

## default terminal command

The `default terminal` command configures default settings for the terminal. These settings are transmit and receive speeds, terminal length, and terminal width. The syntax for the `default terminal` command is:

```
default terminal {speed|width|length}
```

The `default terminal` command is in the exec mode.

[Table 8](#) describes the parameters and variables for the `default terminal` command.

**Table 8** default terminal command parameters and variables

Parameters and variables	Description
speed width length	Sets the defaults <ul style="list-style-type: none"> <li>• <code>speed</code>—transmit and receive baud rates for the terminal; default is 9600 baud</li> <li>• <code>width</code>—width of the terminal display; default is 79 characters</li> <li>• <code>length</code>—Length of the terminal display; default is 24 characters</li> </ul>

## terminal command

The `terminal` command configures the settings for the terminal. These settings are transmit and receive speeds, terminal length, and terminal width. The syntax of the `terminal` command is:

```
terminal speed {2400|4800|9600|19200|38400}|length  
<1-132>|width <1-132>
```

The `terminal` command is in the exec mode.

[Table 9](#) describes the parameters and variables for the `terminal` command.

**Table 9** terminal command parameters and variables

Parameters and variables	Description
speed {2400 4800 9600  19200 38400}	Sets the transmit and receive baud rates for the terminal. You can set the speed at one of the five options shown; default is 9600.
length	Sets the length of the terminal display in characters; default is 24.
width	Sets the width of the terminal displaying characters; default 79.

## Pinging

To ensure that the BayStack 420/425 has connectivity to the network, ping a device you know is connected to this network.

### ping command

The `ping` command tests the network connection to another network device. The command sends an Internet Control Message Protocol (ICMP) packet from the switch to the target device. The local IP address must be set before issuing the `ping` command. Refer to [“Assigning and clearing IP addresses” on page 58](#) for information on setting IP addresses.

The syntax for the `ping` command is:

```
ping <XXX.XXX.XXX.XXX>
```

The `ping` command is in the exec command mode.

[Table 10](#) describes the parameters and variables for the ping command.

**Table 10** ping command parameters and variables

Parameters and variables	Description
XXX.XXX.XXX.XXX	Specify the IP address of the target device in dotted-decimal notation.

If the device receives the packet, it sends a ping reply. When the switch receives the reply, it displays a message indicating that the specified IP address is alive. If no reply is received, a message indicates that the address is not responding.

[Figure 9](#) shows sample ping responses.

**Figure 9** ping command responses

```
BS425_48#ping 10.10.40.29
Host is reachable
BS425_48#ping 10.10.41.29
Host is not reachable
```

## Custom Autonegotiation Advertisements

Custom Autonegotiation Advertisement (CANA) allows you to customize the capabilities that you advertise. It also allows you to control the capabilities that are advertised by the BayStack switch as part of the auto-negotiation process.

### Configuring CANA using the CLI

This section describes configuring CANA using the CLI and includes the following topics:

- [“Configuring CANA”, next](#)
- [“Viewing current autonegotiation advertisements” on page 52](#)
- [“Viewing hardware capabilities” on page 53](#)

- [“Setting default autonegotiation advertisements” on page 55](#)

## Configuring CANA

Use the `auto-negotiation-advertisements` command to configure CANA.

To configure port 5 to advertise the operational mode of 10 Mbps and full duplex enter the following command line:

```
auto-negotiation-advertisements port 5 10-full
```

[Figure 10](#) shows sample output for this command.

**Figure 10** auto-negotiation-advertisements sample output

```
BS425_48(config-if)#auto-negotiation-advertisements port 5 10-full
BS425_48(config-if)#
```

## Viewing current autonegotiation advertisements

To view the autonegotiation advertisements for the device, enter the following command line:

```
show auto-negotiation-advertisements [port <portlist>]
```

[Figure 11](#) and [Figure 12](#) shows sample output for this command. Port 5 has been configured to only advertise an operational mode of 10 Mbps full duplex.

**Figure 11** show auto-negotiation-advertisements command sample output.

```

BS425_48(config-if)#show auto-negotiation-advertisements
Port Autonegotiation Advertised Capabilities
-----
 1   10Full 10Half 100Full 100Half
 2   10Full 10Half 100Full 100Half
 3   10Full 10Half 100Full 100Half
 4   10Full 10Half 100Full 100Half
 5   10Full
 6   10Full 10Half 100Full 100Half
 7   10Full 10Half 100Full 100Half
 8   10Full 10Half 100Full 100Half
 9   10Full 10Half 100Full 100Half
10   10Full 10Half 100Full 100Half
11   10Full 10Half 100Full 100Half
12   10Full 10Half 100Full 100Half
13   10Full 10Half 100Full 100Half
14   10Full 10Half 100Full 100Half
15   10Full 10Half 100Full 100Half
16   10Full 10Half 100Full 100Half
17   10Full 10Half 100Full 100Half
18   10Full 10Half 100Full 100Half
19   10Full 10Half 100Full 100Half
20   10Full 10Half 100Full 100Half
----More (q=Quit, space/return=Continue)----

```

**Figure 12** show auto-negotiation-advertisements command sample output

```

BS425_48(config-if)#show auto-negotiation-advertisements port 5
Port Autonegotiation Advertised Capabilities
-----
 5   10Full
BS425_48(config-if)#

```

## Viewing hardware capabilities

To view the available operational modes for the device, enter the following command line:

```
show auto-negotiation-capabilities [port <portlist>]
```

Figure 13 and Figure 14 shows sample output for this command.

**Figure 13** show auto-negotiation-capabilities command sample output

```
BS425_48(config-if)#show auto-negotiation-capabilities
Port Autonegotiation Capabilities
-----
 1   10Full 10Half 100Full 100Half
 2   10Full 10Half 100Full 100Half
 3   10Full 10Half 100Full 100Half
 4   10Full 10Half 100Full 100Half
 5   10Full 10Half 100Full 100Half
 6   10Full 10Half 100Full 100Half
 7   10Full 10Half 100Full 100Half
 8   10Full 10Half 100Full 100Half
 9   10Full 10Half 100Full 100Half
10   10Full 10Half 100Full 100Half
11   10Full 10Half 100Full 100Half
12   10Full 10Half 100Full 100Half
13   10Full 10Half 100Full 100Half
14   10Full 10Half 100Full 100Half
15   10Full 10Half 100Full 100Half
16   10Full 10Half 100Full 100Half
17   10Full 10Half 100Full 100Half
18   10Full 10Half 100Full 100Half
19   10Full 10Half 100Full 100Half
20   10Full 10Half 100Full 100Half
----More (q=Quit, space/return=Continue)----
```

**Figure 14** show auto-negotiation-capabilities fr p dqg#dp s0# xwxw

```
BS425_48(config-if)#show auto-negotiation-capabilities port 5
Port Autonegotiation Capabilities
-----
 5   10Full 10Half 100Full 100Half
BS425_48(config-if)#
```

## Setting default autonegotiation advertisements

To set default autonegotiation advertisements for the device, enter the following command line in the interface configuration mode:

```
default auto-negotiation-advertisements [port <portlist>]
```

or

```
no auto-negotiation-advertisements [port <portlist>]
```

To set default advertisements for port 5 of the device, enter the following command line:


```
default auto-negotiation-advertisements port 5
```

or

```
no auto-negotiation-advertisements port 5
```

[Figure 15](#) and [Figure 16](#) shows sample output from this command.

**Figure 15** default auto-negotiation-advertisements command sample output



```
BS425_48(config-if)#default auto-negotiation-advertisements
BS425_48(config-if)#
```

**Figure 16** no auto-negotiation-advertisements command sample output

```
BS425_48(config-if)#no auto-negotiation-advertisements
BS425_48(config-if)#
```

## Automatically loading Configuration file

This section discusses how to download a configuration file when the system boots. You use standard CLI commands to modify the configuration file you want to download. This section covers these commands:

- “[configure network command](#),” next
- “[show config-network command](#)” on page 57

### configure network command

The `configure network` command allows you to load and execute a script immediately and to configure parameters to automatically download a configuration file when you reboot the switch or stack. The syntax for the `configure network` command is:

```
configure network [load-on-boot
{disable|use-bootp|use-config}] [filename <FILENAME>]
[address <XXX.XXX.XXX.XXX>]
```

The `configure network` command is in the exec mode.



**Note:** When you enter `configure network` with no parameters, the system prompts you for the script file name and TFTP server address and then downloads the script.

---



Table 11 describes the parameters and variables for the `configure network` command.

**Table 11** configure network command parameters and variables

Parameters and variables	Description
load-on-boot {disable use-boot use-config}	<p>Specifies the settings for automatically loading a configuration file when the system boots:</p> <ul style="list-style-type: none"> <li>• <code>disable</code>—disables the automatic loading of config file</li> <li>• <code>use-boot</code>—specifies using the BootP file as the automatically loaded config file</li> <li>• <code>use-config</code>—specifies using the ASCII configuration file as the automatically loaded config file</li> </ul> <p>Note: If you omit this parameter, the system immediately downloads and runs the ASCII config file.</p>
filename <FILENAME>	<p>Specifies the file name.</p> <p>Note: If you omit this parameter and do not specify BootP, the system uses the configured file name.</p>
address <XXX.XXX.XXX.XXX>	<p>Specifies the TFTP server from which to load the file. Enter the IP address in dotted-decimal notation.</p> <p>Note: If you omit this parameter and do not specify BootP, the system uses the configured address.</p>



**Note:** When you specify the file name or address, these parameters will be changed at the next reboot, even if you do not specify `load-on-boot`.

## show config-network command

The `show config-network` command displays information regarding the automatic loading of the configuration file, including the current status of this feature, the file name, the TFTP server address, and the status of the previous automatic configuration command. The syntax for the `show config-network` command is:

```
show config-network
```

The `show config-network` command is in the `privExec` mode.

The `show config-network` command has no parameters or values.

[Figure 17](#) shows the output for the `show config-network` command.

**Figure 17** show config-network command

```
BS425_48(config)#show config-network
Auto-Load Configuration On Boot: Disabled
Configuration Filename:
TFTP Server IP Address: 134.177.152.102
Last Auto Configuration Status: Passed
Last Manual Configuration Status: Passed
```

## Assigning and clearing IP addresses

Using the CLI, you can assign IP addresses and gateway addresses, clear these addresses, and view configured IP addresses. This section covers these topics:

- [“ip address command,”](#) next
- [“no ip address command”](#) on page 59
- [“ip default-gateway command”](#) on page 60
- [“no ip default-gateway command”](#) on page 60
- [“show ip command”](#) on page 61

### ip address command

The `ip address` command sets the IP address and subnet mask for the switch or a stack. The syntax for the `ip address` command is:

```
ip address [stack|switch] <XXX.XXX.XXX.XXX> [netmask
<XXX.XXX.XXX.XXX>]
```

The `ip address` command is in the `config` command mode.

If you do not enter either the stack or switch parameter, the system automatically modifies the stack IP address when in stack mode and modifies the switch IP address when in standalone mode.

Table 12 describes the parameters and variables for the `ip address` command.

**Table 12** `ip address` command parameters and variables

Parameters and variables	Description
stack switch	Sets the stack the IP address and netmask or the switch IP address and netmask.
XXX.XXX.XXX.XXX	Enter IP address in dotted decimal notation; netmask is optional.
netmask	Set the IP subnet mask for the stack or switch.



**Note:** When you change the IP address or subnet mask, you may lose connection to Telnet and the Web.

## no ip address command

The `no ip address` command clears the IP address and subnet mask. This command sets the IP address and subnet mask for a switch or a stack to all zeros (0). The syntax for the `no ip address` command is:

```
no ip address {stack|switch}
```

The `no ip address` command is in the config command mode.

Table 13 describes the parameters and variables for the `no ip address` command.

**Table 13** `no ip address` command parameters and variables

Parameters and variables	Description
stack switch	Zeroes out the stack IP address and subnet mask for the switch IP address and subnet mask.



**Note:** When you change the IP address or subnet mask, you may lose connection to Telnet and the Web. You also disable any new Telnet connection, and you must connect to the serial console port to configure a new IP address.

---

## ip default-gateway command

The `ip default-gateway` command sets the IP default gateway address for a switch or a stack to use. The syntax for the `ip default-gateway` command is:

```
ip default-gateway <XXX.XXX.XXX.XXX>
```

The `ip default-gateway` command is in the config command mode.

Table 14 describes the parameters and variables for the `ip default-gateway` command.

**Table 14** ip default-gateway command parameters and variables

Parameters and variables	Description
XXX.XXX.XXX.XXX	Enter the dotted-decimal IP address of the default IP gateway.



**Note:** When you change the IP gateway, you may lose connection to Telnet and the Web.

---

## no ip default-gateway command

The `no ip default-gateway` command sets the IP default gateway address to zeros (0). The syntax for the `no ip default-gateway` command is:

```
no ip default-gateway
```

The `no ip default-gateway` command is in the config command mode.

The `no ip default-gateway` command has no parameters or variables.



**Note:** When you change the IP gateway address, you may lose connection to Telnet and the Web. You also may disable any new Telnet connection be required to connect to the serial console port to configure a new IP gateway address.

## show ip command

The `show ip` command displays the IP configurations, specifically BootP mode, stack address, switch address, subnet mask, and gateway address. This command displays the these parameters for what is configured, what is in use, and the last BootP. The syntax for the `show ip` command is:

```
show ip [bootp] [default-gateway] [address [stack|switch]]
```

The `show ip` command is in the exec command mode. If you do not enter any parameters, this command displays all the IP-related configuration information.

[Table 15](#) describes the parameters and variables for the `show ip` command.

**Table 15** show ip command parameters and variables

Parameters and variables	Description
bootp	Displays BootP-related IP information.
default-gateway	Displays the IP address of the default gateway.
address	Displays the current IP address.
stack switch	Specifies current IP address of the stack or the switch.

[Figure 18](#) displays a sample output of the `show ip` command.

**Figure 18** show ip command output

```
BS425_48>show ip
BootP Mode: BootP Disabled

           Configured           In Use           Last BootP
-----
Stack IP Address: 10.10.40.29     10.10.40.29     0.0.0.0
Switch IP Address: 0.0.0.0        0.0.0.0         0.0.0.0
Subnet Mask:       255.255.255.0   255.255.255.0   0.0.0.0
Default Gateway:   10.10.40.1     10.10.40.1     0.0.0.0
BS425_48>
```

## Assigning and clearing IP addresses for specific units

You can assign IP addresses for specific units within a stack. This section covers these topics:

- [“ip address unit command,”](#) next
- [“no ip address unit command”](#) on page 63
- [“default ip address unit command”](#) on page 64

### ip address unit command

The `ip address unit` command sets the IP address and subnet mask for a specific unit in the stack. The syntax for the `ip address unit` command is:

```
ip address unit <1-8> A.B.C.D
```

The `ip address unit` command is in the config command mode.

Table 16 describes the parameters and variables for the `ip address unit` command.

**Table 16** `ip address unit` command parameters and variables

Parameters and variables	Description
unit <1-8>	Sets the unit you are assigning an IP address.
A.B.C.D	Enter IP address in dotted decimal notation.



**Note:** When you change the IP address or subnet mask, you may lose connection to Telnet and the Web.

## no ip address unit command

The `no ip address unit` command sets the IP address for the specified unit in a stack to all zeros (0). The syntax for the `no ip address unit` command is:

```
no ip address unit <1-8>
```

The `no ip address unit` command is in the config command mode.

Table 17 describes the parameters and variables for the `no ip address unit` command.

**Table 17** `no ip address` command parameters and variables

Parameters and variables	Description
unit <1-8>	Zeroes out the IP address for the specified unit.



**Note:** When you change the IP address or subnet mask, you may lose connection to Telnet and the Web. You also disable any new Telnet connection, and you must connect to the serial console port to configure a new IP address.

---

## default ip address unit command

The `default ip address unit` command sets the IP address for the specified unit in a stack to all zeros (0). The syntax for the `default ip address unit` command is:

```
default ip address unit <1-8>
```

The `default ip address unit` command is in the config command mode.

[Table 18](#) describes the parameters and variables for the `default ip address unit` command.

**Table 18** default ip address unit command parameters and variables

Parameters and variables	Description
unit <1-8>	Zeroes out the IP address for the specified unit.



**Note:** When you change the IP gateway, you may lose connection to Telnet and the Web.

---



## Setting Telnet access

You can also access the CLI through a Telnet session. To access the CLI remotely, the management port must have an assigned IP address and remote access must be enabled. You can log on to the switch using Telnet from a terminal that has access to the BayStack 420/425.

To open a Telnet session from Device Manager, click on the Telnet icon on the tool bar (Figure 19) or click Action > Telnet on the Device Manager tool bar.

**Figure 19** Telnet icon on Device Manager toolbar



**Note:** Multiple users can access the CLI system simultaneously, through the serial port, Telnet, and modems. The maximum number of simultaneous users is four plus one each at the serial port for a total of 12 users on the stack. All users can configure simultaneously.

You can view the Telnet allowed IP addresses and settings, change the settings, or disable the Telnet connection. This section covers the following topics:

- “[show telnet-access command](#),” next
- “[telnet-access command](#)” on page 66
- “[no telnet-access command](#)” on page 67
- “[default telnet-access command](#)” on page 68

### show telnet-access command

The `show telnet-access` command displays the current settings for Telnet access. The syntax for the `show telnet-access` command is:

```
show telnet-access
```

The `show telnet-access` command is in the `privExec` command mode.

The `show telnet-access` command has no parameters or variables.

Figure 20 shows sample output from the `show telnet-access` command.

**Figure 20** show telnet-access command output

```
BS425_48(config)#show telnet-access
TELNET Access:      Enabled
Login Timeout:     1 minute(s)
Login Retries:     3
Inactivity Timeout: 15 minute(s)
Event Logging:     All
Allowed Source IP Address  Allowed Source Mask
-----
0.0.0.0            0.0.0.0
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
255.255.255.255   255.255.255.255
```

## telnet-access command

The `telnet-access` command allows you to configure the Telnet connection used to manage the switch. The syntax for the `telnet-access` command is:

```
telnet-access [enable|disable] [login-timeout <1-10>] [retry
<1-100>] [inactive-timeout <0-60>] [logging
{none|access|failures|all}] [source-ip <1-10>
<XXX.XXX.XXX.XXX> [mask <XXX.XXX.XXX.XXX>]]
```

The `telnet-access` command is in the `config` command mode.

[Table 19](#) describes the parameters and variables for the `telnet-access` command.

**Table 19** telnet-access command parameters and variables

Parameters and variables	Description
<code>enable/disable</code>	Enables or disables Telnet connections.
<code>login-timeout &lt;1-10&gt;</code>	Specifies the time in minutes you want to wait between initial Telnet connection and accepted password before closing the Telnet connection; enter an integer between 1 and 10.
<code>retry &lt;1-100&gt;</code>	Specifies the number of times the user can enter an incorrect password before closing the connection; enter an integer between 1 and 100.
<code>inactive timeout &lt;0-60&gt;</code>	Specifies in minutes how long to wait before closing an inactive session; enter an integer between 0 and 60.
<code>logging {none access failure all}</code>	Specifies what types of events you want to save in the event log: <ul style="list-style-type: none"> <li>• none—do not save access events in the log</li> <li>• access—save access events in the log</li> <li>• failure—save failed access events in the log</li> <li>• all—save all access events in the log</li> </ul>
<code>[source-ip &lt;1-10&gt; &lt;XXX.XXX.XXX.XXX&gt;[mask &lt;XXX.XXX.XXX.XXX&gt;]</code>	Specifies the source IP address from which connections are allowed. Enter the IP address either as an integer or in dotted-decimal notation. Specifies the subnet mask from which connections are allowed; enter IP mask in dotted-decimal notation.  Note: These are the same source IP addresses as in the IP Manager list. For more information on the IP Manager list, refer to Chapter 3.

## no telnet-access command

The `no telnet-access` command allows you to disable the Telnet connection. The syntax for the `no telnet-access` command is:

```
no telnet-access [source-ip [<1-10>]]
```

The `no telnet-access` command is in the config mode.

[Table 20](#) describes the parameters and variables for the `no telnet-access` command.

**Table 20** no telnet-access command parameters and variables

Parameters and variables	Description
source-ip [<1-10>]	<p>Disables the Telnet access.</p> <p>When you do <i>not</i> use the optional parameter, the source-ip list is cleared, meaning the 1st index is set to 0.0.0.0./0.0.0.0. and the 2nd to 10th indexes are set to 255.255.255.255/255.255.255.255. When you <i>do</i> specify a source-ip value, the specified pair is set to 255.255.255.255/255.255.255.255.</p> <p>Note: These are the same source IP addresses as in the IP Manager list. For more information on the IP Manager list, refer to Chapter 3.</p>

## default telnet-access command

The `default telnet-access` command sets the Telnet settings to the default values. The syntax for the `default telnet-access` command is:

```
default telnet-access
```

The `default telnet-access` command is in the config command mode.

The `default telnet-access` command has no parameters or values.

## Setting server for Web-based management

You can enable or disable the Web server to use for the Web-based management system. Refer to *Using Web-based Management for the BayStack 425 Switch Software Version 3.1* for information on the Web-based management system. This section discusses the following commands:

- [“web-server,” next](#)
- [“no web-server” on page 69](#)

## web-server

The `web-server` command enables or disables the Web server that you use for Web-based management. The syntax for the `web-server` command is:

```
web-server {enable|disable}
```

The `web-server` command is in the config mode

[Table 21](#) describes the parameters and variables for the `web-server` command.

**Table 21** web-server command parameters and variables

Parameters and variables	Description
enable disable	Enables or disables the Web server.

## no web-server

The `no web-server` command disables the Web server that you use for Web-based management. The syntax for the `no web-server` command is:

```
no web-server
```

The `no web-server` command is in the config mode.

The `no web-server` command has no parameters or values.

## Setting boot parameters

You can reboot the switch or stack and configure BootP. The topics covered in this section are:

- [“boot command,”](#) next
- [“ip bootp server command”](#) on page 70
- [“no ip bootp server command”](#) on page 71
- [“default ip bootp server command”](#) on page 71

## boot command

The `boot` command performs a soft-boot of the switch or stack. The syntax for the `boot` command is:

```
boot [default]
```

The `boot` command is in the `privExec` command mode.

[Table 22](#) describes the parameters and variables for the `boot` command.

**Table 22** boot command parameters and variables

Parameters and variables	Description
default	Restores switch or stack to factory-default settings after rebooting.



**Note:** When you reset to factory defaults, the switch or stack retains the stack operational mode, last reset count, and reason for last reset; these three parameters are not defaulted to factory defaults.

---

## ip bootp server command

The `ip bootp server` command configures BootP on the current instance of the switch or server. The syntax for the `ip bootp server` command is:

```
ip bootp server {last|needed|disable|always}
```

The `ip bootp server` command is in the `config` command mode.

Table 23 describes the parameters and variables for the `ip bootp server` command.

**Table 23** `ip bootp server` command parameters and variables

Parameters and variables	Description
<code>lastneededldisablelalways</code>	Specifies when to use BootP: <ul style="list-style-type: none"> <li>• <code>last</code>—use BootP or the last known address</li> <li>• <code>needed</code>—use BootP only when needed</li> <li>• <code>disable</code>—never use BootP</li> <li>• <code>always</code>—Always use BootP</li> </ul>

## no ip bootp server command

The `no ip bootp server` command disables the BootP server. The syntax for the `no ip bootp server` command is:

```
no ip bootp server
```

The `no ip bootp server` command is in the config command mode.

The `no ip bootp server` command has no parameters or values.

## default ip bootp server command

The `default ip bootp server` command disables the BootP server. The syntax for the `default ip bootp server` command is:

```
default ip bootp server
```

The `default ip bootp server` command is in the config command mode.

The `default ip bootp server` command has no parameters or values.

## Setting TFTP parameters

You can display the IP address of the TFTP server, assign an IP address you want to use for a TFTP server, copy a configuration file to the TFTP server, or copy a configuration file from the TFTP server to the switch to use to configure the switch. This section covers:

- [“show tftp-server command,”](#) next
- [“tftp-server command”](#) on page 73
- [“no tftp-server command”](#) on page 73
- [“copy config tftp command”](#) on page 73
- [“copy tftp config command”](#) on page 74

### show tftp-server command

The `show tftp-server` command displays the IP address of the server used for all TFTP-related transfers. The syntax for the `show tftp-server` command is:

```
show tftp-server
```

The `show tftp-server` command is in the `privExec` command mode.

The `show tftp-server` command has no parameters or variables.

[Figure 21](#) shows a sample output of the `show tftp-server` command.

**Figure 21** show tftp-server command output

```
BS425_48#show tftp-server
TFTP Server IP address : 192.168.100.15
BS425_48#
```



## tftp-server command

The `tftp-server` command assigns the address for the stack or switch to use for TFTP services. The syntax of the `tftp-server` command is:

```
tftp-server <XXX.XXX.XXX.XXX>
```

The `tftp-server` command is in the config command mode.

[Table 24](#) describes the parameters and variables for the `tftp-server` command.

**Table 24** tftp-server command parameters and variables

Parameters and variables	Description
XXX.XXX.XXX.XXX	Enter the dotted-decimal IP address of the server you want to use for TFTP services.

## no tftp-server command

The `no tftp-server` command clears the TFTP server IP address to 0.0.0.0. The syntax of the `no tftp-server` command is:

```
no tftp-server
```

The `no tftp-server` command is in the config command mode.

The `no tftp-server` command has no parameters or values.

## copy config tftp command

The `copy config tftp` command copies the current configuration file onto the TFTP server. The syntax for the `copy config tftp` command is:

```
copy config tftp [address <XXX.XXX.XXX.XXX>] filename <WORD>
```

The `copy config tftp` command is in the privExec command mode.

[Table 25](#) describes the parameters and variables for the `copy config tftp` command.

**Table 25** `copy config tftp` command parameters and variables

Parameters and variables	Description
address <XXX.XXX.XXX.XXX>	Specifies the TFTP server IP address; enter in dotted-decimal notation.
filename <WORD>	Specifies that you want to copy the configuration file onto the TFTP server. Enter the name you want the configuration file to have on the TFTP server.

## copy tftp config command

The `copy tftp config` command retrieves the system configuration file from the TFTP server and uses the retrieved information as the current configuration on the system. The syntax for the `copy tftp config` command is:

```
copy tftp config [address <XXX.XXX.XXX.XXX>] filename <WORD>
```

The `copy tftp config` command is in the `privExec` command mode.

[Table 26](#) describes the parameters and variables for the `copy tftp config` command.

**Table 26** `copy tftp config` command parameters and variables

Parameters and variables	Description
address <XXX.XXX.XXX.XXX>	Specifies the TFTP server IP address; enter in dotted-decimal notation.
filename <WORD>	Enter the name of the configuration file you want to copy from the TFTP server.

## ASCII Configuration Generator

The primary goal of ASCII Configuration Generator (ACG) is to provide the user of the BayStack 425 switch with a tool that allows them to easily modify configuration of a particular switch or a stack.

ACG generates an ASCII configuration file which reproduces the behavior of the current binary configuration file. The user can also rely on this function to maintain backup configurations, as well as use it as a reliable method for debugging the current configuration of a switch.

The BayStack 425 switch can download an editable ASCII configuration file from the TFTP server. You can load the ASCII configuration file automatically at boot time or on demand using console menus or CLI. Once downloaded, the configuration file automatically configures the switch or stack according to the Command Line Interface (CLI) commands in the file. The maximum size for an ASCII configuration file is 100 KBs; larger configuration files must be split into multiple files.

For more information on loading the ASCII configuration file automatically, see [“Automatically loading Configuration file” on page 56](#).

The commands that are associated with ACG are:

- [“show running-config command”](#), next
- [“copy running-config tftp command” on page 76](#)

### show running-config command

This command displays the current configuration of switch or a stack as a series of CLI commands.

This command must be executed in the configuration mode and has no parameters or variables.

The syntax of this command is:

```
show running-config
```

Figure 22 shows the output of the `show running-config` command

**Figure 22** Output of the `show running-config` command

```
BS425_48#show running-config
! Embedded ASCII Configuration Generator Script
! Model = BayStack 425-48T
! Software version = v3.1.0.60
enable
configure terminal
!
! *** CORE ***
!
mac-address-table aging-time 300
autotopology
no snmp-server host
snmp-server authentication-trap enable
snmp-server community "public" ro
snmp-server community "private" rw
no radius-server
radius-server host 0.0.0.0
radius-server secondary-host 0.0.0.0
radius-server port 1645
telnet-access login-timeout 1
telnet-access retry 3
telnet-access inactive-timeout 15
telnet-access logging all
---More (q=Quit, space/return=Continue)---
```

## copy running-config tftp command

This command copies contents of the current configuration file to another file on the TFTP server. The syntax of the command is

```
copy running-config tftp {<IP Address> <filename>}
```

This command can be executed in the config mode.

[Table 27](#) describes the parameters and variables of this command.

**Table 27** copy running-config tftp command parameters and variables

Parameter	Description
IP Address	Signifies the IP address of the TFTP server
Filename	Denotes the filename to store configuration commands on the TFTP server

## Upgrading software

You can download the BayStack 420/425 software image that is located in non-volatile flash memory. To download the BayStack 420/425 software image, a properly configured Trivial File Transfer Protocol (TFTP) server must be present in your network, and the policy switch must have an IP address. To learn how to configure the switch or stack IP address, refer to [“Assigning and clearing IP addresses” on page 58](#).



**Caution:** Do not interrupt power to the device during the software download process. A power interruption can corrupt the firmware image.

This section covers the following topics:

- [“download command,”](#) next

### download command

The `download` command upgrades the software for the BayStack 420/425. You can upgrade both the software image and the diagnostics image. If you upgrade to a stack configuration, the entire stack will be upgraded, and the new image is loaded onto every unit of the stack.



**Note:** The system resets after downloading a new image.

The syntax for the download command is:

```
download [address <ip>] {image <image-name>|image-if-newer
<image-name>|diag <filename>}
```

The download command is in the privExec command mode.



**Note:** You can use the `download` command without parameters. The system displays the most recently used TFTP server IP address and file name; if you still want to use these, press `[Enter]`. You can also change these.

[Table 28](#) describes the parameters and variables for the `download` command.

**Table 28** download command parameters and variables

Parameters and variables	Description
address <ip>	Specifies the TFTP server you want to use.  Note: If this parameter is omitted, the system goes to the server specified by the <code>tftp-server</code> command.
image <image-name>	Enter the name of the BayStack 425 software image you want to download.
image-if-newer <image-name>	Enter the name of the BayStack 425 software image of the newer version you want to download.
diag <filename>	Enter the name of the BayStack 425 diagnostics image you want to download.

The software download process automatically completes without user intervention. The process erases the contents of flash memory and replaces it with a new software image. Take care not to interrupt the download process until after it runs to completion (the process can take up to 10 minutes, depending on network conditions).

When the download process is complete, the switch automatically resets and the new software image initiates a self-test. The system returns a message after successfully downloading a new image.

[Figure 23](#) shows a sample output of the download command.

**Figure 23** download message for BayStack 425-48T Switch

```
Download Image [/]
Saving Image [-]
Finishing Upgrading Image
```

During the download process, the BayStack 425 Switch is not operational. You can monitor the progress of the download process by observing the LED indications.

## Displaying interfaces

You can view the status of all interfaces on the switch or stack, including MultiLink Trunk membership, link status, autonegotiation, and speed.

### show interfaces command

The `show interfaces` command displays the current configuration and status of all interfaces. The syntax for the `show interfaces` command is:

```
show interfaces [names] [<portlist>]
```

The `show interfaces` command is in the exec command mode.

[Table 29](#) describes the parameters and variables for the `show interfaces` command.

**Table 29** show interfaces command parameters and variables

Parameters and variables	Description
names <portlist>	Displays the interface names; enter specific ports if you want to see only those.

Figure 24 displays a sample output of the `show interfaces names` command.

**Figure 24** show interfaces names command output

```
BS425_48 SW 1.1 in SC2-02 LAB>show interfaces names 1-3
Port Name
-----
1      LabBldg4
2      Testing
3      Floor1Bldg2
```

Figure 25 Shows a sample output of the `show interfaces` command without the names variable.



**Figure 25** show interfaces command output

```

BS425_48(config)#show interfaces
                Status                Auto                Flow
Port Trunk Admin   Oper Link LinkTrap Negotiation Speed Duplex Control
-----
1          Enable Down Down Enabled Enabled
2          Enable Down Down Enabled Enabled
3          Enable Down Down Enabled Enabled
4          Enable Down Down Enabled Enabled
5          Enable Down Down Enabled Enabled
6          Enable Down Down Enabled Enabled
7          Enable Down Down Enabled Enabled
8          Enable Down Down Enabled Enabled
9          Enable Down Down Enabled Enabled
10         Enable Down Down Enabled Enabled
11         Enable Down Down Enabled Enabled
12         Enable Down Down Enabled Enabled
13         Enable Down Down Enabled Enabled
14         Enable Down Down Enabled Enabled
15         Enable Down Down Enabled Enabled
16         Enable Down Down Enabled Enabled
17         Enable Down Down Enabled Enabled
18         Enable Down Down Enabled Enabled
19         Enable Down Down Enabled Enabled
---More (q=Quit, space/return=Continue)---

```

## Setting SNMP parameters

You can set various SNMP parameters and traps, as well as disable SNMP traps. This section covers:

- [“snmp-server command,”](#) next
- [“no snmp-server command”](#) on page 83
- [“snmp trap link-status command”](#) on page 84
- [“no snmp trap link-status command”](#) on page 84
- [“default snmp trap link-status command”](#) on page 85

## snmp-server command

The `snmp-server` command configures various SNMP parameters. The syntax for the `snmp-server` command is:

```
snmp-server
{{enable|disable}|authentication-trap|bootstrap|community
<community-string> contact <text>|host <host-ip>
<community-string>|location <text>|name <text>|user
<text>|view <text>}
```

The `snmp-server` command is in the `config` command mode.

[Table 30](#) describes the parameters and variables for the `snmp-server` command.

**Table 30** snmp-server command parameters and variables

Parameters and variables	Description
authentication-trap	Enables generation of SNMP authentication failure traps.
bootstrap	Generates SNMP bootstrap parameters
community <community-string>	Changes the read-only (ro) or read-write (rw) community strings for SNMP v1 and SNMPv2c access. Enter a community string that works as a password and permits access to the SNMP protocol.
contact <text>	Specifies the SNMP sysContact value; enter an alphanumeric string.
disable	Disables SNMP access
enable	Enables SNMP access.
host <host-ip> <community-string>	Configures an SNMP trap destination: <ul style="list-style-type: none"> <li>host-ip—enter a dotted-decimal IP address of a host that will be the trap destination</li> <li>community-string—enter a community string that works as a password and permits access to the SNMP protocol</li> </ul>
location <text>	Specifies the SNMP sysLocation value; enter an alphanumeric string.
name <text>	Specifies the SNMP sysName value; enter an alphanumeric string.
user	Creates SNMPv3 user
view	Creates or modifies an SNMP access view

## no snmp-server command

The `no snmp-server` command disables SNMP or clears the configuration. If you omit the parameters, this command disables SNMP access. The syntax for the `no snmp-server` command is:

```
no snmp-server [authentication-trap|community [ro|rw]
contact|host [<host-ip> <community-string>] |location
|name|user|view]
```

The `no snmp-server` command is in the config command mode.

[Table 31](#) describes the parameters and variables for the `no snmp-server` command.

**Table 31** no snmp-server command parameters and variables

Parameters and variables	Description
enable/disable	With no parameters, disables SNMP access.
authentication-trap	Disables authentication failure traps.
community	Disables the community string.
ro/rw	Disables either read-only or read-write access.
contact <text>	Clears the SNMP sysContact value.
host <host-ip> <community-string>	Removes an SNMP trap destination or all destinations.
location	Clears the SNMP sysLocation value.
name	Clears the SNMP sysName value
user	Removes SNMPv3 user
view	Removes SNMPv3 view



**Note:** Disabling SNMP access will also lock you out of the DM management system.

## snmp trap link-status command

The `snmp trap link-status` command enables the linkUp/linkDown traps for the port. The syntax of the command is:

```
snmp trap link-status [port <portlist>]
```

The `snmp trap link-status` command is in the config-if command mode.

[Table 32](#) describes the parameters and variables for the `snmp trap link-status` command.

**Table 32** snmp trap link-status command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to enable the linkUp/linkDown traps on. Enter the port numbers or all.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## no snmp trap link-status command

The `no snmp trap link-status` command disables the linkUp/linkDown traps for the port. The syntax of the command is:

```
no snmp trap link-status [port <portlist>]
```

The `no snmp trap link-status` command is in the config-if command mode.

[Table 33](#) describes the parameters and variables for the `no snmp trap link-status` command.

**Table 33** no snmp trap link-status command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to disable the linkUp/linkDown traps on. Enter the port numbers or all.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## default snmp trap link-status command

The `default snmp trap link-status` command disables the linkUp/linkDown traps for the port. The syntax of the command is:

```
default snmp trap link-status [port <portlist>]
```

The `default snmp trap link-status` command is in the `config-if` command mode.

[Table 34](#) describes the parameters and variables for the `default snmp trap link-status` command.

**Table 34** default snmp trap link-status command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to disable the linkUp/linkDown traps on. Enter the port numbers or all.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## Setting the system event log

You can set the system event log to log different levels of events. This section covers:

- [“show logging,”](#) next
- [“logging”](#) on page 87
- [“no logging”](#) on page 87
- [“default logging”](#) on page 88
- [“clear logging command”](#) on page 88

### show logging

The `show logging` command displays the current contents of the system event log. The syntax for the `show logging` command is:

```
show logging [critical] [serious] [informational]
```

The `show logging` command is in the `privExec` command mode.

[Table 35](#) describes the parameters and variables for the `show logging` command.

**Table 35** show logging command parameters and variables

Parameters and variables	Description
critical	Displays critical log messages.
serious	Displays serious log messages.
informational	Displays informational log messages.

[Figure 26](#) shows the output of the `show logging informational` command.

**Figure 26** show logging command output

```
BS425_48#show logging informational
Type Unit Time      Index      Src Message
-----
I      1      00:00:01:52 1           Warm Start Trap
I      1      00:00:01:52 2           Enterprise Specific Trap
I      1      00:00:01:57 3           Link Up Trap
I      1      00:00:01:57 4           Link Up Trap
I      1      00:00:01:57 5           Link Up Trap
I      1      00:00:01:57 6           Link Up Trap
```

## logging

The logging command configures the system settings for the system event log. The syntax for the logging command is:

```
logging [enable|disable] [level
critical|serious|informational] [nv-level
critical|serious|informational|none]
```

The logging command is in the config command mode.

[Table 36](#) describes the parameters and variables for the logging command.

**Table 36** logging command parameters and values

Parameters and variables	Description
enable disable	Enables or disables the event log (default is enabled).
level critical serious informational	Specifies the level of logging stored in dynamic memory.
nv-level critical serious informational none	Specifies the level of logging stored in non-volatile memory.

## no logging

The no logging command disables the system event log. The syntax for the no logging command is:

```
no logging
```

The `no logging` command is in the config command mode.

The `no logging` command has no parameters or values.

## default logging

The `default logging` command configures the system settings as the factory default settings for the system event log. The syntax for the `default logging` command is:

```
default logging
```

The `default logging` command is in the config command mode.

The `default logging` command has no parameters or values.

## clear logging command

The `clear logging` command clears all log messages in DRAM. The syntax for the `clear logging` command is:

```
clear logging [nv]
```

The `clear logging` command is in the `privExec` command mode.

[Table 37](#) describes the parameters and values for the `clear logging` command.

**Table 37** clear logging command parameters and values

Parameters and values	Description
<code>nv</code>	Clears all log messages in both DRAM and NVRAM.

## Displaying port statistics

You can display the statistics for a port for both received and transmitted traffic. This section covers:

- “[show port-statistics command](#),” next



- [“clear-stats command” on page 90](#)

## show port-statistics command



**Note:** You must be in interface configuration mode to use the `show port-statistics` command.

The `show port-statistics` command displays the statistics for the port on both received and transmitted traffic. The syntax for the `show port-statistics` command is:

```
show port-statistics [port <portlist>]
```

The `show port-statistics` command is in the `config-if` command mode.

[Table 38](#) describes the parameters and variables for the `show port-statistics` command.

**Table 38** show port-statistics command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to configure to display statistics on; enter the port numbers.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

[Figure 27](#) shows sample output from the `show port-statistics` command.

**Figure 27** show port-statistics command output

```
BS425_48(config-if)#show port-statistics

Received
  Packets:                0
  Multicasts:             0
  Broadcasts:            0
  Total Octets:          0
  Lost Packets:          0
  FCS Errors:            0
  Undersized Packets:    0
  Oversized Packets:     0
  Filtered Packets:      0
  Flooded Packets:       0
  Frame Errors:          0
Transmitted
  Packets:                0
  Multicasts:             0
  Broadcasts:            0
  Total Octets:          0
  Collisions:            0
  Single Collisions:     0
  Multiple Collisions:   0
  Excessive Collisions:  0
  Deferred Packets:      0
  Late Collisions:       0
Received / Transmitted
  Packets 64 bytes:       0
    65-127 bytes:        0
    128-255 bytes:       0
    256-511 bytes:       0
    512-1023 bytes:      0
    1024-1518 bytes:     0
```

## clear-stats command

The `clear-stats` command clears all statistical information for the specified port. All counters are set to zero (0). The syntax for the `clear-stats` command is:

```
clear-stats [port <portlist>]
```

The `clear-stats` command is in the config-if command mode.

[Table 39](#) describes the parameters and variables for the `clear-stats` command.

**Table 39** clear-stats command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to clear of statistical information; enter the port numbers.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## Enabling or disabling a port

You can enable or disable a port using the CLI. This section covers the following commands:

- [“shutdown command,”](#) next
- [“no shutdown command”](#) on page 92

### shutdown command

The `shutdown` command disables the port. The syntax for the `shutdown` command is:

```
shutdown [port <portlist>]
```

The `shutdown` command is in the config-if command mode.

[Table 40](#) describes the parameters and variables for the `shutdown` command.

**Table 40** shutdown command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to shut down or disable. Enter the port numbers you want to disable.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## no shutdown command

The `no shutdown` command enables the port. The syntax for the `no shutdown` command is:

```
no shutdown [port <portlist>]
```

The `no shutdown` command is in the config-if command mode.

[Table 41](#) describes the parameters and variables for the `no shutdown` command.

**Table 41** no shutdown command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to enable. Enter the port numbers you want to disable.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## Naming ports

You can name a port using the CLI. This section covers the following commands:

- [“name command,”](#) next
- [“no name command”](#) on page 93

- [“default name command” on page 94](#)

## name command

The `name` command allows you to name ports or to change the name. The syntax for the `name` command is:

```
name [port <portlist>] <LINE>
```

The `name` command is in the `config-if` command mode.

[Table 42](#) describes the parameters and variables for the `name` command.

**Table 42** name command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to name.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.
<LINE>	Enter up to 26 alphanumeric characters.

## no name command

The `no name` command clears the port names; it resets the field to an empty string. The syntax for the `no name` command is:

```
no name [port <portlist>]
```

The `no name` command is in the `config-if` command mode.

[Table 43](#) describes the parameters and variables for the `no name` command.

**Table 43** no name command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to clear of names.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## default name command

The `default name` command clears the port names; it resets the field to an empty string. The syntax for the `default name` command is:

```
default name [port <portlist>]
```

The `default name` command is in the `config-if` command mode.

[Table 44](#) describes the parameters and variables for the `default name` command.

**Table 44** default name command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to clear of names.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## Setting port speed

You can set the speed and duplex mode for a port. This section covers:

- [“speed command,”](#) next
- [“default speed command”](#) on page 95
- [“duplex command”](#) on page 96

- [“default duplex command” on page 97](#)

## speed command

The `speed` command sets the speed of the port. The syntax for the `speed` command is:

```
speed [port <portlist>] {10|100|1000|auto}
```

The `speed` command is in the `config-if` command mode.

[Table 45](#) describes the parameters and variables for the `speed` command.

**Table 45** speed command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to configure the speed. Enter the port numbers you want to configure.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.
10 100 1000 auto	Sets speed to: <ul style="list-style-type: none"> <li>• 10—10 Mb/s</li> <li>• 100—100 Mb/s</li> <li>• 1000—1000 Mb/s or 1 GB/s</li> <li>• auto—autonegotiation</li> </ul>



**Note:** When you set the port speed for autonegotiation, ensure that the other side of the link is also set for autonegotiation.

## default speed command

The `default speed` command sets the speed of the port to the factory default speed. The syntax for the `default speed` command is:

```
default speed [port <portlist>]
```

The default `speed` command is in the `config-if` command mode.

[Table 46](#) describes the parameters and variables for the default `speed` command.

**Table 46** default speed command parameters and variables

Parameters and variables	Description
<code>port &lt;portlist&gt;</code>	Specifies the port numbers to set the speed to factory default. Enter the port numbers you want to set.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## duplex command

The `duplex` command specifies the duplex operation for a port. The syntax for the `duplex` command is:

```
duplex [port <portlist>] {full|half|auto}
```

The `duplex` command is in the `config-if` command mode.

[Table 47](#) describes the parameters and variables for the `duplex` command.

**Table 47** duplex command parameters and variables

Parameters and variables	Description
<code>port &lt;portlist&gt;</code>	Specifies the port number to configure the duplex mode. Enter the port number you want to configure, or all to configure all ports simultaneously.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.
<code>full half auto</code>	Sets duplex to: <ul style="list-style-type: none"><li>• full—full-duplex mode</li><li>• half—half-duplex mode</li><li>• auto—autonegotiation</li></ul>





**Note:** When you set the duplex mode for autonegotiation, ensure that the other side of the link is also set for autonegotiation.

## default duplex command

The `default duplex` command sets the duplex operation for a port to the factory default duplex value. The syntax for the `default duplex` command is:

```
default duplex [port <portlist>]
```

The `default duplex` command is in the config-if command mode.

[Table 48](#) describes the parameters and variables for the `default duplex` command.

**Table 48** default duplex command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to reset the duplex mode to factory default values. Enter the port numbers you want to configure, or all to configure all ports simultaneously. The default value is autonegotiation.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## Enabling Autopology

You can enable the Optivity\* Autopology\* protocol using the CLI. Refer to the [www.nortelnetworks.com/documentation](http://www.nortelnetworks.com/documentation) URL for information on Autopology. (The product family for Optivity and Autopology is Data and Internet.). This section covers the following commands:

- “[autotopology command](#),” next
- “[no autotopology command](#)” on page 98

- [“default autotopology command” on page 98](#)

## autotopology command

The `autotopology` command enables the Autotopology protocol. The syntax for the `autotopology` command is:

```
autotopology
```

The `autotopology` command is in the config command mode.

The `autotopology` command has no parameters or values.

## no autotopology command

The `no autotopology` command disables the Autotopology protocol. The syntax for the `no autotopology` command is:

```
no autotopology
```

The `no autotopology` command is in the config command mode.

The `no autotopology` command has no parameters or values.

## default autotopology command

The `default autotopology` command enables the Autotopology protocol. The syntax for the `default autotopology` command is:

```
default autotopology
```

The `default autotopology` command is in the config command mode.

The `default autotopology` command has no parameters or values.

## Enabling flow control

If you use a Gigabit Ethernet MDA with the BayStack 420/425, you control traffic on this port using the `flowcontrol` command. This section covers the following commands:

- “[flowcontrol command](#),” next
- “[no flowcontrol command](#)” on page 100
- “[default flowcontrol command](#)” on page 100

### flowcontrol command

The `flowcontrol` command is used only on Gigabit Ethernet ports and controls the traffic rates during congestion. The syntax for the `flowcontrol` command is:

```
flowcontrol [port <portlist>]
{asymmetric|symmetric|auto|disable}
```

The `flowcontrol` command is in the `config-if` mode.

[Table 49](#) describes the parameters and variables for the `flowcontrol` command.

**Table 49** flowcontrol command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to configure for flow control.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.
asymmetric symmetric auto disable	Sets the mode for flow control: <ul style="list-style-type: none"> <li>• asymmetric—enables the local port to perform flow control on the remote port</li> <li>• symmetric—enables the local port to perform flow control</li> <li>• auto—sets the port to automatically determine the flow control mode (default)</li> <li>• disable—disables flow control on the port</li> </ul>

## no flowcontrol command

The `no flowcontrol` command is used only on Gigabit Ethernet ports and disables flow control. The syntax for the `no flowcontrol` command is:

```
no flowcontrol [port <portlist>]
```

The `no flowcontrol` command is in the config-if mode.

[Table 50](#) describes the parameters and variables for the `no flowcontrol` command.

**Table 50** no flowcontrol command parameters and variables

Parameters and variables	Description
port <portlist>	Specifies the port numbers to disable flow control.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## default flowcontrol command

The `default flowcontrol` command is used only on Gigabit Ethernet ports and sets the flow control to auto, which automatically detects the flow control. The syntax for the `default flowcontrol` command is:

```
default flowcontrol [port <portlist>]
```

The `default flowcontrol` command is in the config-if mode.

[Table 51](#) describes the parameters and variables for the `default flowcontrol` command.

**Table 51** default flowcontrol command parameters and variables

Parameters and variables	Description
<code>port &lt;portlist&gt;</code>	Specifies the port numbers to default to auto flow control.  Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

## Banner Display Function

### Setting Banner Display

This release of BayStack 425 provides the banner control feature. The banner control feature provides you an option to specify banner display. This section covers the following commands:

- [“banner command for displaying banner”](#) next
- [“show banner command”](#) on page 102
- [“no banner command”](#) on page 102
- [“default banner command”](#) on page 103

#### **banner command for displaying banner**

The `banner` command for displaying banner specifies the banner displayed at startup; either static or custom. The syntax for the `banner` command to display banner is:

```
banner [ custom | static | disabled | <1-15> LINE | clear ]
```

The `banner` command for displaying banner is in the config mode.

[Table 52](#) describes the parameters for the banner command.

**Table 52** banner command parameters

Parameters	Description
static	Displays the default agent-banner.
custom	Displays the custom agent-banner.
disabled	Skips the agent-banner display.
<1-15> <i>LINE</i>	Fills the Nth line of the custom banner ( $1 \leq N \leq 15$ ) with the text specified in <i>LINE</i> .
clear	clears the custom agent-banner.

## show banner command

The `show banner` command displays the banner. The syntax for the `show banner` command is:

```
show banner [ custom | static ]
```

The `show banner` command is in the config mode.

[Table 53](#) describes the parameters for the banner command.

**Table 53** show banner command parameters

Parameters	Description
static	Displays default banner
custom	Displays custom banner
(if empty)	Displays static, custom or disabled status if parameter is not entered.

## no banner command

The `no-banner` command allows you to clear all lines of a previously stored custom banner. The syntax for the `no-banner` command is:

```
no-banner
```

The `no-banner` command is in the config mode.

### **default banner command**

The `default banner` command allows you to restore the default banner. The syntax for the `default banner` command is:

```
no banner
```

The `default banner` command is in the config mode.

## **Setting the default management interface**

You can set the default management interface when you connect to the BayStack 420/425 through console port or Telnet. This selection is stored in NVRAM and propagated to all units in a stack configuration.

On system startup, the banner displays and prompts the user to enter Ctrl+Y. After entering these characters, the system displays either a menu or the Nortel Networks Command Line Interface (NNCLI) prompt, depending on which is set using this command.

When using the console port, you must logout for the new mode to display. When using Telnet, all subsequent Telnet sessions display the selection.

### **cmd-interface command**

The `cmd-interface` command allows you to set the default management interface when you use the console port or Telnet.

The syntax for the `cmd-interface` command is:

```
cmd-interface {cli|menu}
```

The `cmd-interface` command is in the `privExec` command mode.

[Table 54](#) describes the parameters and variables for the `cmd-interface` command.

**Table 54** `cmd-interface` command parameters and variables

<b>Parameters and variables</b>	<b>Description</b>
cli/menu	Allows you to set the default management system when using console port or Telnet: <ul style="list-style-type: none"><li>• <code>cli</code>—the system automatically enters the NNCLI mode and displays the NNCLI prompt after you enter Ctrl+Y</li><li>• <code>menu</code>—the system automatically enters the CI menu mode and displays the menus after you enter Ctrl+Y.</li></ul>



---

## Chapter 3

# Security

---

This chapter describes the security commands available with the CLI. There are four types of security available on the BayStack 420/425:

- [“Using MAC address security” on page 105](#)
- [“Using RADIUS authentication” on page 112](#)
- [“Using RADIUS authentication” on page 112](#)

Refer to *Using the BayStack 425 Switch Software Version 3.1* for more information on these security features, as well as using the console interface (CI) menus. Refer to *Using Web-based Management for the BayStack 425 Switch Software Version 3.1* for information on configuring these features using the Web-based management system, and refer to *Reference for the BayStack 425 Switch Management Software Version 3.1* for information on configuring with the DM.

## Using MAC address security

You configure the BaySecure\* application using MAC addresses with the following commands:

- [“show mac-security command,” next](#)
- [“mac-security command” on page 107](#)
- [“mac-security mac-address-table address command” on page 108](#)
- [“mac-security security-list command” on page 109](#)
- [“no mac-security command” on page 109](#)
- [“no mac-security mac-address-table command” on page 110](#)
- [“no mac-security security-list command” on page 110](#)
- [“mac-security command for specific ports” on page 111](#)

- [“mac-security mac-da-filter command” on page 112](#)

## show mac-security command

The `show mac-security` command displays configuration information for the BaySecure application. The syntax for the `show mac-security` command is:

```
show mac-security {config|mac-address-table [address <macaddr>] |port |security-lists |mac-da-filter}
```

The `show mac-security` command is in the `privExec` command mode.

[Table 55](#) describes the parameters and variables for the `show mac-security` command.

**Table 55** show mac-security command parameters and variables

Parameters and variables	Description
config	Displays general BaySecure configuration.
mac-address-table [address <macaddr>]	Displays contents of BaySecure table of allowed MAC addresses: <ul style="list-style-type: none"><li>• address—specifies a single MAC address to display; enter the MAC address</li></ul>
port	Displays the BaySecure status of all ports.
security-lists	Displays port membership of all security lists.
mac-da-filter	Displays MAC DA filtering addresses.

[Figure 28](#) shows sample output from the `show mac-security` command.

**Figure 28** show mac-security command output

```

BS425_48#show mac-security config
MAC Address Security: Disabled
MAC Address Security SNMP-Locked: Disabled
Partition Port on Intrusion Detected: Disabled
DA Filtering on Intrusion Detected: Disabled
Generate SNMP Trap on Intrusion: Disabled
Current Learning Mode: Disabled
Learn by Ports: NONE

```

## mac-security command

The `mac-security` command modifies the BaySecure configuration. The syntax for the `mac-security` command is:

```

mac-security [disable|enable] [filtering {enable|disable}]
[intrusion-detect {enable|disable|forever}] [intrusion-timer
<1-65535>] [learning-ports <portlist>] [learning
{enable|disable}] |mac-address-table|mac-da-filter|security
list [snmp-lock {enable|disable}] [snmp-trap
{enable|disable}]

```

The `mac-security` command is in the config command mode.

[Table 56](#) describes the parameters and variables for the `mac-security` command.

**Table 56** mac-security command parameters and values

Parameters and variables	Description
disable enable	Disables or enables MAC address-based security.
filtering {enable disable}	Enables or disables destination address (DA) filtering on intrusion detected.
intrusion-detect {enable disable forever}	Specifies partitioning of a port when an intrusion is detected: <ul style="list-style-type: none"> <li>• enable—port is partitioned for a period of time</li> <li>• disabled—port is not partitioned on detection</li> <li>• forever—port is partitioned until manually changed</li> </ul>

**Table 56** mac-security command parameters and values

Parameters and variables	Description
intrusion-timer <1-65535>	Specifies, in seconds, length of time a port is partitioned when an intrusion is detected; enter the number of you want.
learning {enable disable}	Specifies MAC address learning: <ul style="list-style-type: none"> <li>• enable—enables learning by ports</li> <li>• disable—disables learning by ports</li> </ul>
learning-ports <portlist>	Specifies MAC address learning. Learned addresses are added to the table of allowed MAC addresses. Enter the ports you want to learn; it can be a single port, a range of ports, several ranges, all, or none.
mac-address-table	Adds addresses to MAC security address table.
mac-da-filter	Adds or deletes MAC DA filtering addresses.
security-list	Modifies security list port membership.
snmp-lock {enable disable}	Enables or disables a lock on SNMP write-access to the BaySecure MIBs.
snmp-trap {enable disable}	Enables or disables trap generation upon intrusion detection.

## mac-security mac-address-table address command

The `mac-security mac-address-table address` command assigns either a specific port or a security list to the MAC address. This removes any previous assignment to the specified MAC address and creates an entry in the BaySecure table of allowed MAC addresses. The syntax for the `mac-security mac-address-table address` command is:

```
mac-security mac-address-table address <H.H.H.> {port
<portlist>|security-list <1-32>}
```



**Note:** In this command, `portlist` must specify only a single port

The `mac-security mac-address-table address` command is in the config command mode.

[Table 57](#) describes the parameters and variables for the `mac-security mac-address-table address` command.

**Table 57** `mac-security mac-address-table address` parameters and values

Parameters and variables	Description
<H.H.H>	Enter the MAC address in the form of H.H.H.
port <portlist> security-list <1-32>	Enter the port number or the security list number.

## mac-security security-list command

The `mac-security security-list` command assigns a list of ports to a security list. The syntax for the `mac-security security-list` command is:

```
mac-security security-list <1-32> <portlist>
```

The `mac-security security-list` command is in the config command mode.

[Table 58](#) describes the parameters and variables for the `mac-security security-list` command.

**Table 58** `mac-security security-list` command parameters and values

Parameters and variables	Description
<1-32>	Enter the number of the security list you want to use.
<portlist>	Enter a list or range of port numbers.

## no mac-security command

The `no mac-security` command disables MAC source address-based security. The syntax for the `no mac-security` command is:

```
no mac-security
```

The `no mac-security` command is in the config command mode.

The `no mac-security` command has no parameters or values.

## no mac-security mac-address-table command

The `no mac-security mac-address-table` command clears entries from the MAC address security table. The syntax for the `no mac-security mac-address-table` command is:

```
no mac-security mac-address-table {address <H.H.H.> |port
<portlist>|security-list <1-32>}
```

The `no mac-security mac-address-table` command is in the config command mode.

[Table 59](#) describes the parameters and variables for the `no mac-security mac-address-table` command.

**Table 59** no mac-security mac-address-table command parameters and values

Parameters and variables	Description
address <H.H.H.>	Enter the MAC address in the form of H.H.H.
port <portlist>	Enter a list or range of port numbers.
security-list <1-32>	Enter the security list number.

## no mac-security security-list command

The `no mac-security security-list` command clears the port membership of a security list. The syntax for the `no mac-security security-list` command is:

```
no mac-security security-list <1-32>
```

The `no mac-security security-list` command is in the config command mode.

[Table 60](#) describes the parameters and variables for the `no mac-security security-list` command.

**Table 60** no mac-security security-list command parameters and values

Parameters and variables	Description
<1-32>	Enter the number of the security list you want to clear.

## mac-security command for specific ports

The `mac-security` command for specific ports configures the BaySecure status of specific ports. The syntax for the `mac-security` command for specific ports is:

```
mac-security [port <portlist>] {disable|enable|learning}
```

The `mac-security` command for specific ports is in the config-if command mode

[Table 61](#) describes the parameters and variables for the `mac-security` command for specific ports.

**Table 61** mac-security command for a single port parameters and variables

Parameters and variables	Description
port <portlist>	Enter the port numbers.
disable enable learning	Directs the specific port: <ul style="list-style-type: none"> <li>• <code>disable</code>—disables BaySecure on the specified port and removes the port from the list of ports for which MAC address learning is being performed</li> <li>• <code>enable</code>—enables BaySecure on the specified port and removes the port from the list of ports for which MAC address learning is being performed</li> <li>• <code>learning</code>—disables BaySecure on the specified port and adds these port to the list of ports for which MAC address learning is being performed</li> </ul>

## mac-security mac-da-filter command

The `mac-security mac-da-filter` command allows you to filter packets from up to 10 specified MAC DAs. You also use this command to delete such a filter and then receive packets from the specified MAC DA. The syntax for the `mac-security mac-da-filter` command is:

```
mac-security mac-da-filter {add|delete} <H.H.H.>
```

The `mac-security mac-da-filter` command is in the config command mode.

[Table 62](#) describes the parameters and variables for the `mac-security mac-da-filter` command.

**Table 62** mac-security mac-da-filter command parameters and values

Parameters and variables	Description
{add delete} <H.H.H.>	Add or delete the specified MAC address; enter the MAC address in the form of H.H.H.



**Note:** Ensure that you do not enter the MAC address of the management unit.

## Using RADIUS authentication

Using a the RADIUS protocol and a server, you can configure the BayStack 420/425 for authentication. With the CLI system, you use the following commands:

- “[show radius-server command](#),” next
- “[radius-server command](#)” on page 113
- “[no radius-server command](#)” on page 114



## show radius-server command

The `show radius-server` command displays the RADIUS server configuration. The syntax for the `show radius-server` command is:

```
show radius-server
```

The `show radius-server` command is in the `privExec` command mode.

The `show radius-server` command has no parameters or variables.

[Figure 29](#) shows sample output from the `show radius-server` command.

**Figure 29** show radius-server command output

```
BS425_48#show radius-server
Primary Host: 0.0.0.0
Secondary Host: 0.0.0.0
Port: 1645
Key:
BS425_48#
```

## radius-server command

The `radius-server` command changes the RADIUS server settings. The syntax for the `radius-server` command is:

```
radius-server host <address> [secondary-host <address>] port
<num> key <string>
```

The `radius-server` command is in the `config` command mode.

[Table 63](#) describes the parameters and variables for the `radius-server` command.

**Table 63** radius-server command parameters and variables

Parameters and variables	Description
<code>host &lt;address&gt;</code>	Specifies the primary RADIUS server. Enter the IP address of the RADIUS server.
<code>secondary-host &lt;address&gt;</code>	Specifies the secondary RADIUS server. Enter the IP address of the secondary RADIUS server.
<code>port &lt;num&gt;</code>	Enter the port number of the RADIUS server.
<code>key &lt;string&gt;</code>	Specifies a secret text string that is shared between the switch and the RADIUS server. Enter the secret string, which is an alphanumeric string up to 16 characters.

## no radius-server command

The `no radius-server` command clears the RADIUS server settings. The syntax for the `no radius-server` command is:

```
no radius-server
```

The `no radius-server` command is in the config command mode.

The `no radius-server` command has no parameters or values.

---

## Chapter 4

# Spanning Tree, MLT, and Port-Mirroring

---

This chapter describes how to configure the Spanning Tree Protocol, a spanning tree group, Multi-Link Trunking (MLT), and port-mirroring. This chapter covers the following topics:

- [“Using spanning tree,”](#) next
- [“Using Multi-Link Trunking”](#) on page 120
- [“Using port-mirroring”](#) on page 123

Refer to the *Using the BayStack 420/425 Switch, Software Release 3.1* for more information on multiple spanning tree groups, spanning tree, MLT, and port-mirroring, as well as configuration directions using the console interface (CLI) menus. Refer to *Using Web-based Management for the BayStack 420/425, Software Release 3.1* for information on configuring these features using the Web-based management system, and refer to *Reference for the BayStack 420/425 Switch Management Software, Software Release 3.1* for configuration information for the DM.

## Using spanning tree

The CLI allows you to configure a spanning tree, to add or remove VLANs to the spanning tree, and to configure the usual spanning tree parameters and FastLearn. This section covers the following topics:

- [“show spanning-tree command,”](#) next
- [“spanning-tree command by port”](#) on page 118
- [“default spanning-tree command by port”](#) on page 119
- [“no spanning-tree command by port”](#) on page 119

For detailed information on spanning tree parameters, spanning tree groups, and configuration guidelines, refer to *Using the BayStack 420/425 Switch, Software Release 3.1*.

## show spanning-tree command

The `show spanning-tree` command displays spanning tree configuration information that is specific to either the spanning tree group or to the port. The syntax for the `show spanning-tree` command is:

```
show spanning-tree {config|port}
```

The `show spanning-tree` command is in the `privExec` command mode,

[Table 64](#) describes the parameters and variables for the `show spanning-tree` command.

**Table 64** show spanning-tree command parameters and variables

Variables	Values
config	Displays Spanning Tree configuration.
port	Displays Spanning Tree status of each port.

[Figure 30](#) displays sample output from the `show spanning-tree` command for the default spanning tree (STP1).

[Figure 31](#) shows the spanning tree parameters by port.

**Figure 30** show spanning-tree command output by port

```

BS425_48#show spanning-tree port
Unit Port Trunk   Participation   Priority   Path Cost   State
-----
1     1           Normal Learning 128         10         Forwarding
1     2           Normal Learning 128         10         Forwarding
1     3           Normal Learning 128         10         Forwarding
1     4           Normal Learning 128         10         Forwarding
1     5           Normal Learning 128         10         Forwarding
1     6           Normal Learning 128         10         Forwarding
1     7           Normal Learning 128         10         Forwarding
1     8           Normal Learning 128         10         Forwarding
1     9           Normal Learning 128         10         Forwarding
1    10          Normal Learning 128         10         Forwarding
1    11          Normal Learning 128         10         Forwarding
1    12          Normal Learning 128         10         Forwarding
1    13          Normal Learning 128         10         Forwarding
1    14          Normal Learning 128         10         Forwarding
1    15          Normal Learning 128         10         Forwarding
1    16          Normal Learning 128         10         Forwarding
1    17          Normal Learning 128         10         Forwarding
1    18          Normal Learning 128         10         Forwarding
1    19          Normal Learning 128         10         Forwarding
1    20          Normal Learning 128         10         Forwarding
----More (q=Quit, space/return=Continue)----

```

**Figure 31** show spanning-tree command output

```

BS425_48#show spanning-tree config
Bridge Priority:          8000
Designated Root:        8000000342f6de21
Root Port:              2
Root Path Cost:         30
Hello Time:             2 seconds
Maximum Age Time:      20 seconds
Forward Delay:         15 seconds
Bridge Hello Time:     2 seconds
Bridge Maximum Age Time: 20 seconds
Bridge Forward Delay:  15 seconds

```

## spanning-tree command by port

The `spanning-tree` command by port sets each Spanning Tree Protocol (STP) for ports. The syntax for the `spanning-tree` command by port is:

```
spanning-tree [port <portlist>] [learning
{disable|normal|fast}] [cost <1-65535>] [priority <0-255>]
```

The `spanning-tree` command by port is in the `config-if` command mode.

[Table 65](#) describes the variables and values for the `spanning-tree` command by port.

**Table 65** spanning-tree command by port variables

Variables	Values
FORWARD-TIME	4 - 30 seconds
HELLO-TIME	1 - 10
MAX-AGE	6 - 40
PRIORITY	0 - 65535

For guidelines for configuring STGs, VLANs, and MLTs, refer to Chapter 1 of the *Using the BayStack 420/425 Switch, Software Release 3.1*.

## default spanning-tree command by port

The `default spanning-tree` command by port sets the spanning tree values for the ports within the specified spanning tree group to the factory default settings. The syntax for the `default spanning-tree` command by port is:

```
default spanning-tree [port <portlist>] [stp] [learning]
[cost] [priority]
```

The `default spanning-tree` command by port is in the config-if command mode.

[Table 66](#) describes the parameters and variables for the `default spanning-tree` command by port.

**Table 66** default spanning-tree command by port parameters and variables

Parameters and variables	Description
port <portlist>	Enables spanning tree for the specified port or ports; enter port or ports you want set to factory spanning tree default values.  Note: If you omit this parameter, the system uses the port number you specified when you issued the <code>interface</code> command.
learning	Sets the spanning tree learning mode to factory default value. Default value for learning is normal mode.
cost	Sets the path cost to factory default value. Default value for path cost depends on the type of port.
priority	Sets the priority to factory default value. Default value for the priority is 0x8000.

## no spanning-tree command by port

The `no spanning-tree` command by port disables spanning tree for a port in a specific spanning tree group. The syntax for the `no spanning-tree` command by port is:

```
no spanning-tree [port <portlist>]
```

The `no spanning-tree` command by port is in the config-if command mode.

[Table 67](#) describes the parameters and variables for the `no spanning-tree` command by port.

**Table 67** no spanning-tree command by port parameters and variables

Parameters and variables	Description
port <portlist>	Disables spanning tree for the specified port or ports; enter port or ports you want enabled for STP.  Note: If you omit this parameter, the system uses the port number you specified when you issued the <code>interface</code> command.

## Using Multi-Link Trunking

You configure Multi-Link Trunking (MLT) using the following commands:

- [“show mlt command,”](#) next
- [“mlt command”](#) on page 121
- [“no mlt command”](#) on page 122



**Note:** For guidelines for configuring STG, VLANs, and MLTs, refer to Chapter 1 of the *Using the BayStack 420/425 Switch, Software Release 3.1*.

---

### show mlt command

The `show mlt` command displays the Multi-Link Trunking (MLT) configuration and utilization. The syntax for the `show mlt` command is:

```
show mlt [utilization <1-6>]
```

The `show mlt` command is in the `privExec` command mode.



Table 68 describes the parameters and variables for the `show mlt` command.

**Table 68** show mlt command parameters and variables

Parameters and variables	Description
utilization <1-6>	Displays the utilization of the specified enabled MLT(s) in percentages.

Figure 32 shows sample output from the `show mlt` command.

**Figure 32** show mlt command output

```
BS425_48#show mlt
Trunk Name                Members                STP Learn Bpdu  Mode  Status
-----
1      Trunk #1              NONE                  Normal   All   Basic  Disabled
2      Trunk #2              NONE                  Normal   All   Basic  Disabled
3      Trunk #3              NONE                  Normal   All   Basic  Disabled
4      Trunk #4              NONE                  Normal   All   Basic  Disabled
5      Trunk #5              NONE                  Normal   All   Basic  Disabled
6      Trunk #6              NONE                  Normal   All   Basic  Disabled
```

## mlt command

The `mlt` command configures a Multi-Link Trunk (MLT). The syntax for the `mlt` command is:

```
mlt <id> [name <trunkname>] [enable|disable] [member
<portlist>] [learning {disable|fast|normal}]
```

The `mlt` command is in the `config` command mode.

Table 69 describes the parameters and variables for the `mlt` command.

**Table 69** mlt command parameters and variables

Parameters and variables	Description
id	Enter the trunk ID; range is 1 to 6.
name <trunkname>	Specifies a text name for the trunk; enter up to 16 alphanumeric characters.
enable/disable	Enables or disables the trunk.
member <portlist>	Enter the ports that you want as members of the trunk.
learning <disable/fast/normal>	Sets STP learning mode.



**Note:** You can modify an MLT when it is enabled or disabled.

---

## no mlt command

The `no mlt` command disables a Multi-Link Trunk (MLT), clearing all the port members. The syntax for the `no mlt` command is:

```
no mlt [<id>]
```

The `no mlt` command is in the config command mode.

Table 70 describes the parameters and variables for the `no mlt` command.

**Table 70** no mlt command parameters and variables

Parameters and variables	Description
<id>	Enter the trunk ID to disable the trunk and to clear the port members of the specified trunk.

## Using port-mirroring

You use port-mirroring to monitor traffic. Refer to *Using the BayStack 420/425 Switch, Software Release 3.1* for configuration guidelines for port-mirroring. This section covers the following commands:

- “show port-mirroring command,” next
- “port-mirroring command” on page 123
- “no port-mirroring command” on page 124

### show port-mirroring command

The `show port-mirroring` command displays the port-mirroring configuration. The syntax for the `show port-mirroring` command is:

```
show port-mirroring
```

The `show port-mirroring` command is in the `privExec` command mode.

The `show port-mirroring` command has no parameters or variables.

[Figure 33](#) displays sample output from the `show port-mirroring` command.

**Figure 33** show port-mirroring command output

```
BayStack 425_48(config)#show port-mirroring
Monitoring Mode: Xrx ( -> Port X )
Monitor Port:    1/3
Port X:          1/1
```

### port-mirroring command

The `port-mirroring` command sets the port-mirroring configuration. The syntax of the `port-mirroring` command is:

```
port-mirroring mode
{disable |
Xrx monitor-port <portlist> mirror-port-X <portlist>
```



**Note:** In this command, `portlist` must specify only a single port

---

The `port-mirroring` command is in the config command mode.

[Table 71](#) describes the parameters and variables for the `port-mirroring` command.

**Table 71** port-mirroring command parameters and variables

Parameters and variables	Description
disable	Disables port-mirroring.
Xrx	Mirror packets received on port X.

## no port-mirroring command

The `no port-mirroring` command disables port-mirroring. The syntax of the `no port-mirroring` command is:

```
no port-mirroring
```

The `no port-mirroring` command is in the config command mode.

The `no port-mirroring` command has no parameters or variables.

---

## Chapter 5

# VLANs

---

This chapter describes how to configure virtual LANs and IGMP snooping parameters. This chapter covers the following topic:

- [“Configuring and displaying VLANs” on page 125](#)

Refer to the *Using the BayStack 420/425 Switch, Software Release 3.1* for more information on VLANs, IGMP snooping, and multicast groups, as well as configuration directions using the console interface (CI) menus. Refer to *Using Web-based Management for the BayStack 420/425, Software Release 3.1* for information on configuring these features using the Web-based management system, and refer to *Reference for the BayStack 420/425 Switch Management Software, Software Release 3.1* for configuration information for the DM.

## Configuring and displaying VLANs

You configure and display VLANs using a variety of command modes, depending on whether you are working with ports, protocol-based VLANs, or MAC source address-based VLANs. You can also enable or disable the automatic PVID feature. This section covers the following topics:

- [“show vlan interface info command,”](#) next
- [“show vlan interface vids command” on page 127](#)
- [“vlan mgmt command” on page 128](#)
- [“default vlan mgmt command” on page 129](#)
- [“vlan create command” on page 129](#)
- [“vlan delete command” on page 130](#)
- [“no vlan command” on page 130v](#)
- [“vlan name command” on page 131](#)

- “auto-pvid command” on page 131
- “no auto-pvid command” on page 131
- “vlan ports command” on page 132
- “vlan members command” on page 133

Refer to Appendix A for an alphabetical list of the VLAN commands.

## show vlan interface info command

The `show vlan interface info` command displays VLAN settings associated with a port, including tagging information, PVID number, priority, and filtering information for tagged, untagged, and unregistered frames. The syntax for the `show vlan interface info` command is:

```
show vlan interface info [<portlist>]
```

The `show vlan interface info` command is in the `privExec` command mode.

[Table 72](#) describes the parameters and variables for the `show vlan interface info` command.

**Table 72** show vlan command interface info parameters and variables

Parameters and variables	Description
<portlist>	Enter the list of ports you want the VLAN information for, or enter all to display all ports.

[Figure 34](#) shows sample output from the `show vlan interface info` command.

**Figure 34** show vlan interface info output

```

BS425_48(config-if)#show vlan interface info
  Filter
  Untagged
Port  Frames  PVID Priority  Remarking  Tagging  Name
-----
 1   No       1     0         Disabled  Disabled Port 1
 2   No       1     0         Disabled  Disabled Port 2
 3   No       1     0         Disabled  Disabled Port 3
 4   No       1     0         Disabled  Disabled Port 4
 5   No       1     0         Disabled  Disabled Port 5
 6   No       1     0         Disabled  Disabled Port 6
 7   No       1     0         Disabled  Disabled Port 7
 8   No       1     0         Disabled  Disabled Port 8
 9   No       1     0         Disabled  Disabled Port 9
10   No       1     0         Disabled  Disabled Port 10
11   No       1     0         Disabled  Disabled Port 11
12   No       1     0         Disabled  Disabled Port 12
13   No       1     0         Disabled  Disabled Port 13
14   No       1     0         Disabled  Disabled Port 14
15   No       1     0         Disabled  Disabled Port 15
16   No       1     0         Disabled  Disabled Port 16
17   No       1     0         Disabled  Disabled Port 17
18   No       1     0         Disabled  Disabled Port 18
----More (q=Quit, space/return=Continue)----

```

## show vlan interface vids command

The `show vlan interface vids` command displays port memberships in VLANs. The syntax for the `show vlan interface vids` command is:

```
show vlan interface vids [<portlist>]
```

The `show vlan interface vids` command is in the `privExec` command mode.

Table 73 describes the parameters and variables for the `show vlan interface vids` command.

**Table 73** show vlan command interface vids parameters and variables

Parameters and variables	Description
<portlist>	Enter the list of ports you want the VLAN information for, or enter all to display all ports.

Figure 35 shows sample output from the `show vlan interface vids` command.

**Figure 35** show vlan interface vids output

```
BS425_48#show vlan interface vids
Unit/Port  VLAN  VLAN Name          VLAN  VLAN Name          VLAN  VLAN Name
-----
1/1        1     VLAN #1
-----
1/2        1     VLAN #1           2     VLAN #2
-----
1/3        1     VLAN #1
-----
1/4        1     VLAN #1
-----
1/5        1     VLAN #1
-----
1/6        1     VLAN #1
-----
```

## vlan mgmt command

The `vlan mgmt` command allows you to set a VLAN as the management VLAN. The syntax for the `vlan mgmt` command is:

```
vlan mgmt <1-4094>
```

The `vlan mgmt` command is in the config command mode.



[Table 74](#) describes the parameters and variables for the `vlan mgmt` command.

**Table 74** `vlan mgmt` command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the number of the VLAN you want to serve as the management VLAN.

## default vlan mgmt command

The `default vlan mgmt` command resets the management VLAN. The syntax for the `default vlan mgmt` command is:

```
default vlan mgmt
```

The `default vlan mgmt` command is in the config command mode.

The `default vlan mgmt` command has no variables or parameters.

## vlan create command

The `vlan create` command allows you to create a VLAN. You create a VLAN by setting the state of a previously non-existent VLAN.

The syntax for the `vlan create` command is:

```
vlan create <1-4094>]
```

The `vlan create` command is in the config command mode.

[Table 75](#) describes the parameters and variables for the `vlan create` command.

**Table 75** `vlan create` command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the number of the VLAN to create.



**Note:** This command fails if the VLAN already exists.

---

## vlan delete command

The `vlan delete` command allows you to delete a VLAN. The syntax for the `vlan delete` command is:

```
vlan delete <1-4094>
```

The `vlan delete` command is in the config command mode.

[Table 76](#) describes the parameters and variables for the `vlan delete` command.

**Table 76** vlan delete command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the number of the VLAN to delete.

## no vlan command

The `no vlan` command allows you to delete a VLAN. The syntax for the `no vlan` command is:

```
no vlan <1-4094>
```

The `no vlan` command is in the config command mode.

[Table 77](#) describes the parameters and variables for the `no vlan` command.

**Table 77** no vlan command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the number of the VLAN to delete.

## vlan name command

The `vlan name` command allows you to change the name of an existing VLAN. The syntax for the `vlan name` command is:

```
vlan name <1-4094> <line>
```

The `vlan name` command is in the config command mode.

[Table 78](#) describes the parameters and variables for the `vlan name` command.

**Table 78** vlan name command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the number of the VLAN you want to change the name of.
<line>	Enter the new name you want for the VLAN.

## auto-pvid command

The `auto-pvid` command allows you to enable the automatic PVID feature. The syntax for the `auto-pvid` command is:

```
auto-pvid
```

The `auto-pvid` command is in the config command mode.

The `auto-pvid` command has no parameters or variables.

For more information on the automatic PVID feature, refer to *Using the BayStack 425 Switch Software Version 3.1*.

## no auto-pvid command

The `no auto-pvid` command allows you to disable the automatic PVID feature. The syntax for the `no auto-pvid` command is:

```
no auto-pvid
```

The `no auto-pvid` command is in the config command mode.

The `no auto-pvid` command has no parameters or variables.

For more information on the automatic PVID feature, refer to *Using the BayStack 425 Switch Software Version 3.1*.

## vlan ports command

The `vlan ports` command configures the VLAN-related settings for a port. The syntax for the `vlan ports` command is:

```
vlan ports [<portlist>] [tagging {enable|disable}] [pvid <1-4094>]
[filter-untagged-frame {enable|disable}] [remarking
{enable|disable}] [priority <0-7>] [name <line>]
```

The `vlan ports` command is in the config command mode.

[Table 79](#) describes the parameters and variables for the `vlan ports` command.

**Table 79** vlan ports command parameters and variables

Parameters and variables	Description
<portlist>	Enter the port number(s) you want to configure for a VLAN.
tagging {enable disable}	Enables or disables the port as a tagged VLAN member for egressing packet.
pvid <1-4094>	Associates the port with a specific VLAN
filter-untagged-frame {enable disable}	Enables or disables the port to filter received untagged packets.
remarking {enable disable}	Enables or disables the tagged frames
priority <0-7>	Sets the port as a priority for the switch to consider as it forwards received packets.
name <line>	Enter the name you want for this port.  Note: This option can only be used if a single port is specified in the <portlist>.

## vlan members command

The `vlan members` command adds a port to or deletes a port from a VLAN. The syntax for the `vlan members` command is:

```
vlan members [add|remove] <1-4094> <portlist>
```

The `vlan members` command is in the config mode.

[Table 80](#) describes the parameters and variables for the `vlan members` command.

**Table 80** vlan members command parameters and variables

Parameters and variables	Description
add remove	Adds a port to or removes a port from a VLAN.  Note: If you omit this parameter, you are setting the exact port membership for the VLAN; the prior port membership of the VLAN is discarded and replaced by the new list of ports.
<1-4094>	Specifies the target VLAN.
portlist	Enter the list of port(s) you are adding, removing, or assigning to the VLAN.



# Appendix A

## Command List

This appendix provides the complete CLI command list in alphabetical order, with approximate page references for the beginning pages of further explanations.



**Note:** This information is presented for reference only and should not be considered to be an exact representation.

**Table 81** CLI command list

Command	Page No.
auto-negotiation-advertisements	<a href="#">page 52</a>
auto-pvid	<a href="#">page 131</a>
autotopology	<a href="#">page 98</a>
boot [default]	<a href="#">page 70</a>
clear logging [nv]	<a href="#">page 88</a>
clear-stats [port<portlist>]	<a href="#">page 90</a>
cli-password {switch stack} {rolrw} <WORD> <WORD>	<a href="#">page 33</a>
cli-password {switch stack} {serial telnet} {nonellocallradius}	
cmd-interface	<a href="#">page 103</a>
configure {terminallnetwork memory}	<a href="#">page 39</a>
configure network [load-on-boot {disable use-boot use-config}]	<a href="#">page 56</a>
configure network [filename <WORD>]	
configure network [address <XXX.XXX.XXX.XXX>]	
Configuring CANA	<a href="#">page 52</a>
Configuring CANA using the CLI	<a href="#">page 51</a>
copy config tftp [address <XXX.XXX.XXX.XXX>] filename <WORD>	<a href="#">page 73</a>
copy tftp config [address <XXX.XXX.XXX.XXX>] filename <WORD>	<a href="#">page 74</a>
default auto-negotiation-advertisements	<a href="#">page 55</a>

**Table 81** CLI command list (continued)

<b>Command</b>	<b>Page No.</b>
default autotopology	<a href="#">page 98</a>
default duplex [port <portlist>]	<a href="#">page 97</a>
default flowcontrol [port <portlist>]	<a href="#">page 100</a>
default ip address unit <1-8>	<a href="#">page 64</a>
default ip bootp server	<a href="#">page 71</a>
default logging	<a href="#">page 88</a>
default mac-address-table aging-time	<a href="#">page 46</a>
default name [port <port.ist>]	<a href="#">page 94</a>
default snmp trap link-status [port <portlist>]	<a href="#">page 85</a>
default spanning-tree [port <portlist>] [stp <1-8>] [learning] [cost] [priority]	<a href="#">page 119</a>
default speed [port <portlist>]	<a href="#">page 95</a>
default telnet-access	<a href="#">page 68</a>
default terminal {speed length width}	<a href="#">page 49</a>
default vlan mgmt <1-4094>	<a href="#">page 129</a>
disable	<a href="#">page 40</a>
download [address <ip>] {image <image-name> [bs425-image <image-name>] diag <filename>}	<a href="#">page 77</a>
duplex [port <portlist>] {full half auto}	<a href="#">page 96</a>
enable	<a href="#">page 38</a>
end	<a href="#">page 40</a>
exit	<a href="#">page 40</a>
flowcontrol [port <portlist>] {asymmetric symmetric auto disable}	<a href="#">page 99</a>
help	<a href="#">page 37</a>
interface FastEthernet {<portlist>}	<a href="#">page 39</a>
ip address unit <1-8> A.B.C.D	<a href="#">page 62</a>
ip address[stack switch] <XXX.XXX.XXX.XXX> [netmask <XXX.XXX.XXX.XXX>]	<a href="#">page 58</a>
ip bootp server {last needed disable always}	<a href="#">page 70</a>
ip default-gateway <XXX.XXX.XXX.XXX>	<a href="#">page 60</a>
logging [enable disable] [level critical serious informational] [nv-level critical serious informational none]	<a href="#">page 87</a>
logout	<a href="#">page 38</a>



**Table 81** CLI command list (continued)

Command	Page No.
mac-address-table aging-time <time>	<a href="#">page 45</a>
mac-security [disable enable] [filtering {enable disable}] [intrusion-detect{enable disable forever}] [intrusion-timer <1-65535>] [learning-ports <portlist>] [learning {enable disable}] [snmp-lock {enable disable}] [snmp-trap {enable disable}]	<a href="#">page 107</a>
mac-security [port <portlist>] {disable enable learning}	<a href="#">page 111</a>
mac-security mac-address-table address <H.H.H.> [port <portlist> security-list <1-32>]	<a href="#">page 108</a>
mac-security mac-da-filter	<a href="#">page 112</a>
mac-security security-list <1-32>	<a href="#">page 109</a>
mac-security security-list <portlist>	
mlt <id> [name <trunkname>] [enable disable] [member <portlist>]	<a href="#">page 121</a>
name [port <portlist>] <LINE>	<a href="#">page 93</a>
no auto-pvid	<a href="#">page 131</a>
no autotopology	<a href="#">page 98</a>
no flowcontrol [port <portlist>]	<a href="#">page 100</a>
no ip address {stack switch}	<a href="#">page 59</a>
no ip address unit <1-8>	<a href="#">page 63</a>
no ip bootp server	<a href="#">page 71</a>
no ip default-gateway	<a href="#">page 60</a>
no logging	<a href="#">page 87</a>
no mac-security	<a href="#">page 109</a>
no mac-security mac-address-table {address <H.H.H.> port <portlist> security-list <1-32>}	<a href="#">page 110</a>
no mac-security security-list <1-32>	<a href="#">page 110</a>
no mlt [<id>]	<a href="#">page 122</a>
no name [port <portlist>]	<a href="#">page 93</a>
no port-mirroring	<a href="#">page 124</a>
no radius-server	<a href="#">page 114</a>
no shutdown [port <portlist>]	<a href="#">page 92</a>
no snmp server [authentication-trap community [rol rw] contact host [<host-ip> <community-string>] [location name]	<a href="#">page 83</a>
no snmp trap link-status [port <portlist>]	<a href="#">page 84</a>
no spanning-tree [port <portlist>] [stp <1-8>]	<a href="#">page 119</a>
no telnet-access [source-ip [<1-10>]]	<a href="#">page 67</a>

**Table 81** CLI command list (continued)

<b>Command</b>	<b>Page No.</b>
no tftp-server	<a href="#">page 73</a>
no vlan <1-4094>	<a href="#">page 130</a>
no web-server	<a href="#">page 69</a>
ping <XXX.XXX.XXX.XXX>	<a href="#">page 50</a>
port-mirroring mode disable	<a href="#">page 123</a>
port-mirroring mode Xrx monitor-port <portlist> mirror-port X <portlist>	
radius-server host <address> [secondary-host <address>] port <num> key <string>	<a href="#">page 113</a>
renumber unit	<a href="#">page 43</a>
Setting Banner Display	<a href="#">page 101</a>
show config-network	<a href="#">page 57</a>
show interfaces [names] [<portlist>]	<a href="#">page 79</a>
show ip [bootp] [default-gateway] [address [stack switch]]	<a href="#">page 61</a>
show logging [critical]	<a href="#">page 86</a>
show logging [serious]	
show logging [informational]	
show mac-address-table [aging-time]	<a href="#">page 44</a>
show mac-address-table [vid <1-4094>] [address <H.H.H.>]	
show mac-security {config mac-address-table [addr <macaddr>] port security-lists}	<a href="#">page 106</a>
show mlt [utilization <1-6>]	<a href="#">page 120</a>
show port-mirroring	<a href="#">page 123</a>
show port-statistics [port <portlist>]	<a href="#">page 89</a>
show radius-server	<a href="#">page 113</a>
show spanning-tree {stp <1-8>} {config port}	<a href="#">page 116</a>
show sys-info	<a href="#">page 41</a>
show telnet-access	<a href="#">page 65</a>
show terminal	<a href="#">page 48</a>
show tftp-server	<a href="#">page 72</a>
show vlan interface info [<portlist>]	<a href="#">page 126</a>
show vlan interface vids [<portlist>]	<a href="#">page 127</a>
show-stack-info	<a href="#">page 42</a>
shutdown [port <portlist>]	<a href="#">page 91</a>

**Table 81** CLI command list (continued)

<b>Command</b>	<b>Page No.</b>
snmp trap link-status [port <portlist>]	<a href="#">page 84</a>
snmp-server {{enable disable} authentication-trap community <community-string> [ro rw] contact <text> host <host-ip> <community-string> location >text> name <text>}	<a href="#">page 82</a>
spanning-tree [port <portlist>] [stp <1-8>] [learning {disable normal fast}] [cost <1-65535>] [priority <0-255>]	<a href="#">page 118</a>
speed [port <portlist>] {10 100 1000 auto}	<a href="#">page 95</a>
telnet-access [enable disable] [login-timeout <1-10>] [retry <1-100>] [inactive-timeout <0-60>] [logging {none access failures all}] [source-ip <1-10> <XXX.XXX.XXX.XXX> [mask <XXX.XXX.XXX.XXX>]]	<a href="#">page 66</a>
terminal {2400 4800 9600 19200 38400} length <1-132> width <1-132>	<a href="#">page 49</a>
tftp-server <XXX.XXX.XXX.XXX>	<a href="#">page 73</a>
viewing hardware capabilities	<a href="#">page 53</a>
vlan create <1-4094>	<a href="#">page 129</a>
vlan delete <1-4094>	<a href="#">page 130</a>
vlan members <1-4094> <portlist> vlan members add <1-4094> <portlist> vlan members remove <1-4094> <portlist>	<a href="#">page 133</a>
vlan mgmt <1-4094>	<a href="#">page 128</a>
vlan name <1-4094> <line>	<a href="#">page 131</a>
vlan ports [<portlist>] [tagging {enable disable}] [pvid <1-4094>] [filter-tagged-frame {enable disable}] [filter-untagged-frame {enable disable}] [priority <0-7>] [name <line>]	<a href="#">page 132</a>
web-server{enable disable}	<a href="#">page 69</a>



---

# Index

---

## A

access 31, 66  
accessing the CLI 31  
age-out time 43  
alphabetical list of commands 135  
authentication 112  
automatic PVID feature 125  
autonegotiation 79, 94  
auto-pvid command 131  
autotopology command 98

## B

BaySecure 105  
boot command 70  
booting the switch 69  
BootP 61, 69  
    modes 70

## C

CI Main Menu 32  
CI menus 21  
clear logging command 88  
clear-stats command 90  
CLI 31  
CLI command list, alphabetical 135  
cli password command 33  
cmd\_interface command 103  
command modes 26, 39  
configuration

    default system 103  
configure command 39  
configure network command 56  
conversation steering 123  
copy config tftp command 73  
copy configuration file 72  
copy tftp config command 74  
customer support 24

## D

DA filtering 105  
default autotopology command 98  
default command 35, 38  
default duplex command 97  
default flowcontrol command 100  
default ip address unit command 64  
default ipbootp server command 71  
default mac-address-table aging-time  
    command 46  
default name command 94  
default set logging command 88  
default snmp trap link-status command 85  
default spanning-tree command 119  
default speed command 95  
default telnet-access command 68  
default terminal command 49  
default vlan mgmt command 129  
Device Manager 21  
diagnostics 77

disable command 40  
displaying logs 86  
download command 77  
duplex command 96  
duplex mode 79, 94

## E

enable command 38  
end command 40  
Ethernet statistics 88  
event logs 86  
exit command 40

## F

flow control 99  
flowcontrol command 99  
format 29, 31  
forwarding table 43

## G

gateway 58  
General CLI commands 47  
Gigabit Ethernet 99

## H

help 34, 35  
hybrid mode 29

## I

interface command 39  
interfaces 39  
IP 31  
IP address 58, 59, 62, 63  
    per unit 62  
ip address command 58

ip address unit command 62  
ip bootp server command 70  
ip default-gateway command 60

## L

link status 91  
logging 86  
logout command 38

## M

MAC address 41, 43  
MAC address forwarding database table 43  
MAC DA filtering 105  
MAC security  
    DA filtering 105  
    source-address based 105  
mac-address-table aging-time command 45  
mac-security command 107  
mac-security command for a single port 111  
mac-security mac-address-table address  
    command 108  
mac-security mac-da-filter command 112  
mac-security mad-address-table address  
    command 108, 109, 110  
mac-security security-list command 109  
management 21  
    default management system 103  
MDAs 99  
MLT 79, 120  
mlt command 121  
monitoring 123  
MultiLink Trunking 120

## N

name command 93  
naming ports 92

---

netmask 31, 58, 62  
no auto-pvid command 131  
no autotopology command 98  
no command 35  
no flowcontrol command 100  
no ip address command 59  
no ip address unit command 63  
no ip bootp server command 71  
no ip default-gateway 60  
no mac-security command 109  
no mac-security mac-address-table command 110  
no mac-security security-list command 110  
no mlt command 122  
no name command 93  
no port-mirroring command 124  
no radius-server command 114  
no set logging command 87  
no shutdown command 92  
no snmp-server command 83  
no snmp trap link-status command 84  
no spanning-tree command 119  
no telnet-access command 67  
no tftp-server command 73  
no vlan command 130  
no web-server command 69

## P

passwords 33  
ping command 50  
port number and port list 29  
port statistics 88  
port, enabling or disabling 91  
portlist 29  
port-mirroring 123  
port-mirroring command 123

portnum 29  
ports 94  
    naming 79, 92  
product support 24  
protocol VLANs 125  
publications 23  
PVID 125

## Q

quit 38

## R

RADIUS access 33  
RADIUS authentication 112  
radius-server command 113  
remote access requirements 65  
renumber unit command 43  
requirements 31  
    accessing the CLI 31  
    remote access 65  
    terminal 31

## S

scripts 25, 39  
security 33, 66, 105, 112  
security lists 105  
serial port 31  
set logging command 87  
show config-network command 57  
show interfaces command 79  
show ip command 61  
show logging command 86  
show mac-address-table command 44  
show mac-security command 106  
show mlt command 120  
show port-mirroring command 123

show port-statistics command 89  
show radius-server command 113  
show spanning-tree command 116  
show stack-info command 42  
show sys-info command 41  
show telnet-access command 65  
show terminal command 48  
show tftp-server command 72  
show vlan interface info command 126, 127  
show vlan interface vids command 127  
shutdown command 91  
SNMP 81  
snmp trap link-status command 84  
snmp-server command 82  
software download  
    process 78  
software versions 41  
software, downloading 77  
spanning-tree command 118  
speed 79, 94  
speed command 95  
stack 79  
stack information 42  
standalone mode 29  
statistics 88  
subnet mask 31, 58, 62  
support, Nortel Networks 24  
system contact 81  
system information 41  
system location 81  
system name 81

## T

Tab key navigation 35  
tagged frames 125

technical publications 23  
technical support 24  
Telnet 31, 33, 65, 66  
telnet-access command 66  
terminal command 49  
terminal 39  
    requirements 31  
    settings 48  
TFTP 72  
tftp-server command 73  
traffic  
    Gigabit Ethernet 99  
traps 81, 84  
troubleshooting 31, 108, 124  
    access 38, 59, 63, 65, 105, 112  
    ping 50  
    port numbers 29  
    port-mirroring 123  
    ports 39  
    stack 43  
    VLANs 130  
trunks 120

## U

unregistered frames 125  
untagged frames 125  
upgrading diagnostics 77  
upgrading software 77  
utilizing trunks 120

## V

vlan create command 129  
vlan delete command 130  
vlan members command 133  
vlan mgmt command 128  
vlan name command 131  
vlan ports command 132



VLANs 125  
  creating 129  
  learning 129  
  management VLAN 125  
  ports 125  
  protocol-based 129  
  type 129

## **W**

Web-based management system 21  
web-server command 69