
Service Manual For RM150/25C and RM200/25C



INVT Power System

Power Solution Specialist



INVT POWER SYSTEM (SHENZHEN) CO.,LTD

Safety Instruction

Safety Message

Danger: Serious human injury or even death may be caused, if this requirement is ignored.




Warning: Human injury or equipment damage may be caused, if this requirement is ignored.

Attention: Equipment damage, loss of data or poor performance may be caused, if this requirement is ignored.





Commissioning Engineer: The engineer who installs or operates the equipment should be well trained in electricity and safety and familiar with the operation, debug, and maintenance of the equipment.

Warning Label




The warning label indicates the possibility of human injury or equipment damage, and advises the proper step to avoid the danger. In this manual, there are three types of warning labels as below.

Labels	Description
 Danger	Serious human injury or even death may be caused, if this requirement is ignored.
 Warning	Human injury or equipment damage may be caused, if this requirement is ignored.
 Attention	Equipment damage, loss of data or poor performance may be caused, if this requirement is ignored.



Safety Instruction

 Danger	<ul style="list-style-type: none"> ✧ Performed only by commissioning engineers. ✧ This UPS is designed for commercial and industrial applications only, and is not intended for any use in life-support devices or system.
 Warning	<ul style="list-style-type: none"> ✧ Read all the warning labels carefully before operation, and follow the instructions.
	<ul style="list-style-type: none"> ✧ When the system is running, do not touch the surface with this label, to avoid any hurt of scald.
	<ul style="list-style-type: none"> ✧ ESD sensitive components inside the UPS, anti-ESD measure should be taken before handling.


Move & Install

 Danger	<ul style="list-style-type: none"> ✧ Keep the equipment away from heat source or air outlets. ✧ In case of fire, use dry powder extinguisher only, any liquid extinguisher can result in electric shock.
 Warning	<ul style="list-style-type: none"> ✧ Do not start the system if any damage or abnormal parts founded. ✧ Contacting the UPS with wet material or hands may be subject to electric shock.
 Attention	<ul style="list-style-type: none"> ✧ Use proper facilities to handle and install the UPS. Shielding shoes, protective clothes and other protective facilities are necessary to avoid injury. ✧ During positioning, keep the UPS way from shock or vibration. ✧ Install the UPS in proper environment, more detail in section 3.3.


Debug & Operate

 Danger	<ul style="list-style-type: none"> ✧ Make sure the grounding cable is well connected before connecting the power cables, the grounding cable and neutral cable must be in accordance with the local and national codes practice. ✧ Before moving or re-connecting the cables, make sure to cut off all the input power sources, and wait for at least 10 minutes for internal discharge. Use a multi-meter to measure the voltage on terminals and ensure the voltage is lower than 36V before operation.
 Attention	<ul style="list-style-type: none"> ✧ The earth leakage current of load will be carried by RCCB or RCD. ✧ Initial check and inspection should be performed after long time storing of UPS.

Maintenance & Replacement


 Danger	<ul style="list-style-type: none"> ✧ All the equipment maintenance and servicing procedures involving internal access need special tools and should be carried out only by trained personnel. The components that can only be accessed by opening the protective cover with tools cannot be maintained by user. ✧ This UPS full complies with "IEC62040-1-1-General and safety requirements for use in operator access area UPS". Dangerous voltages are present within the battery box. However, the risk of contact with these high voltages is minimized for non-service personnel. Since the component with dangerous voltage can only be touched by opening the protective cover with a tool, the possibility of touching high voltage component is minimized. No risk exists to any personnel when operating the equipment in the normal manner, following the recommended operating procedures in this manual.
---	---

Battery Safety

 <p>Danger</p>	<ul style="list-style-type: none"> ✧ All the battery maintenance and servicing procedures involving internal access need special tools or keys and should be carried out only by trained personnel. ✧ WHEN CONNECTED TOGETHER, THE BATTERY TERMINAL VOLTAGE WILL EXCEED 400Vdc AND IS POTENTIALLY LEATHAL. ✧ Battery manufacturers supply details of the necessary precautions to be observed when working on, or in the vicinity of, a large bank of battery cells. These precautions should be followed implicitly at all times. Particular attention should be paid to the recommendations concerning local environmental conditions and the provision of protective clothing, first aid and fire-fighting facilities. ✧ Ambient temperature is a major factor in determining the battery capacity and life. The nominal operating temperature of battery is 20°C. Operating above this temperature will reduce the battery life. Periodically change the battery according to the battery user manuals to ensure the back-up time of UPS. ✧ Replace the batteries only with the same type and the same number, or it may cause explosion or poor performance. ✧ When connecting the battery, follow the precautions for high-voltage operation before accepting and using the battery, check the appearance the battery. If the package is damaged, or the battery terminal is dirty, corroded or rusted or the shell is broken, deformed or has leakage, replace it with new product. Otherwise, battery capacity reduction, electric leakage or fire may be caused. <ul style="list-style-type: none"> ● Before operating the battery, remove the finger ring, watch, necklace, bracelet and any other metal jewelry ● Wear rubber gloves. ● Eye protection should be worn to prevent injury from accidental electrical arcs. ● Only use tools (e.g. wrench) with insulated handles. ● The batteries are very heavy. Please handle and lift the battery with proper Possible reason to prevent any human injury or damage to the battery terminal. ● Do not decompose, modify or damage the battery. Otherwise, battery short circuit, leakage or even human injury may be caused. ● The battery contains sulfuric acid. In normal operation, all the sulfuric acid is attached to the separation board and plate in the battery. However, when the battery case is broken, the acid will leak from the battery. Therefore, be
--	--

	<p>sure to wear a pair of protective glasses, rubber gloves and skirt when operating the battery. Otherwise, you may become blind if acid enters your eyes and your skin may be damaged by the acid.</p> <ul style="list-style-type: none"> ● At the end of battery life, the battery may have internal short circuit, drain of electrolytic and erosion of positive/negative plates. If this condition continues, the battery may have temperature out of control, swell or leak. Be sure to replace the battery before these phenomena happen. ● If a battery leaks electrolyte, or is otherwise physically damaged, it must be replaced, stored in a container resistant to sulfuric acid and disposed of in accordance with local regulations. ● If electrolyte comes into contact with the skin, the affected area should be washed immediately with water.
--	---

Disposal

 <p>Warning</p>	<p>◇ Dispose of used battery according to the local instructions</p>
--	--

Contents

SAFETY INSTRUCTION	I
SAFETY MESSAGE	II
WARNING LABEL	II
SAFETY INSTRUCTION	II
MOVE & INSTALL	III
DEBUG & OPERATE	III
MAINTENANCE & REPLACEMENT.....	III
BATTERY SAFETY.....	IV
DISPOSAL.....	V
1 INTRODUCTION TO UPS STRUCTURE AND KEY COMPONENTS	1
1.1 STRUCTURE	1
1.2 TOPOLOGICAL DIAGRAM	1
2 STRUCTURE OF THE CABINET	3
2.1 FRONT OF THE CABINET.....	3
2.2 BACK OF THE CABINET	3
2.3 COMMUNICATION INTERFACE.....	4
3 STRUCTURE OF MODULE.....	5
3.1 BYPASS AND MONITOR MODULE.....	5
3.2 POWER MODULE.....	5
3.3 WIRING DIAGRAM OF THE POWER MODULE.....	6
4 POWER MODULE INSPECTION.....	7
4.1 TESTING OF RECTIFIER SCR AND DRIVE.....	7
4.2 RECTIFIER IGBT.....	8
4.3 INVERTER IGBT	9
4.4 FUSE	9
4.5 RELAY	10
5 TROUBLE SHOOTING	11
5.1 STATUS BITS DESCRIPTION	11
5.2 ALARM BITS DESCRIPTION	12
5.3 ALARMS CHECK AND SOLUTION TIPS	15
5.4 CABINET TROUBLE SHOOTING	19
APPENDIX: LED INDICATION	21

1 Introduction to UPS Structure and Key components

1.1 Structure

The modular UPS consists of power unit, STS, Bypass Maintenance Switch and external battery, as is shown in Figure 1-1.

Power unit:

It consists of parallel power modules. Each power module includes Rectifier and Inverter.

STS: It consists of two paralleled SCR. The load can be powered directly by the utility through the STS.

Bypass Maintenance Switch: The Bypass Maintenance Switch is used when Maintenance work needs to be done while keep the load on.

External Battery: When the utility is off or being abnormal, the UPS power the load by obtaining energy from the External Battery.




Figure 1-1 UPS Structure

1.2 Topological Diagram

The Topological diagram of the system is shown as Figure 1.2:




Figure 1.2 Topological diagram of the system

2 Structure of the Cabinet

2.1 Front of the Cabinet

The front view is shown in Figure 2.1.




Figure 2.1 Front view

2.2 Back of the Cabinet

The back view is shown in Figure 2.2






Figure 2.2 Back view

2.3 Communication Interface

The more details of interface is shown in Figure 2.3



(a) Communication interface of RM150/25C



(b) Communication interface of RM200/25C

Figure 2.3 Communication interface

3 Structure of Module

3.1 Bypass and monitor module

The details of bypass and monitor module is shown in Figure 3.1




Figure 3.1 bypass and monitor module

3.2 Power module

The power module mainly contains input board, rectifier board, inverter board, output board, REC control board, INV control board, etc. More details is shown in Figure 3.2





Figure 3.2 power module

3.3 Wiring diagram of module

The wiring diagram of bypass and monitoring module is shown in Figure 3.3.



Fig

3.3 Wiring diagram of bypass and monitoring module

The wiring diagram of power module is shown in Figure 3.4.




Fig 3.4 Wiring diagram of power module

4 Power module inspection

Firstly, please follow the below steps to check the components in the power module.

- ① Exam the connectors terminals at the back of power module if they are out of shape, burnt or drawn in.
- ② Open the cover to check visually whether the circuit paths are burnt, broken or have bumps on copper foils. To exams whether the components are burnt or have bumps (such as input or output capacitors)
- ③ Exam the fuses of input and output
- ④ Detect rectifier SCR, IGBT of rectifier and inverter, as is shown in chapter 7
- ⑤ Exam the relay of output
- ⑥ Record the fault information on the cabinet

4.1 Testing of Rectifier SCR and drive

Turn the multi-meter to the resistive channel, measure the resistance of pin A-K (pin1 to pin3), **the normal value should be around 10Ω-40Ω**.The pins of the SCR are defined in Figure 4.1.



Figure 4.1 Pins definition the SCR module

The normal drive signal of the pin A-K SCR is shown in Figure 4.2




Figure 4.2 Drive signal of the SCR pin A-K

4.2 Rectifier IGBT

Turn the multi-meter to the diode channel, measure the status of diode (anode to cathode), **the normal value should be around 0.4V**. The procedures of testing rectifier IGBT are shown in Figure 4.3.



Figure 4.3 Rectifier IGBT pin test

Test the G-K pin of IGBT modules with multi-meter, the normal wave should be as follows, as is shown in Figure 4.4.




Figure 4.4 Normal drive signal wave for IGBT

4.3 Inverter IGBT

Turn the multi-meter to Diode Channel and test the voltage drop of the inverter IGBT, the normal value should be around 0.4V. The procedures of testing inverter IGBT are shown in Figure 4.5.



Figure 4.5 Definition of the pin

The drive signal wave is as following, as shown in Figure 4.6.




Figure 4.6 Drive signal wave

4.4 Fuse

Detect the resistance of the fuses. If the resistance is less than 1ohm, it means the fuses work well. If the resistance is infinite or no value, the fuses have be damaged. The fuses to be detected and their definitions are shown in Figure 4.7 to 4.9.




Figure 4.7 BUS fuses




Figure 4.8 Input fuses and battery fuses




Figure 4.9 Output fuses

4.5 Relay

Check the resistance of the relay between the input terminal and the fuse, as shown in Figure 4.10. If the resistance is infinite or no value, the relays should be OK. If the values are under several ohms the relays maybe get shorted.




Figure 4.10 output relays

5 Trouble shooting

5.1 Status Bits Description

Seq.			Items	0	1	2	4	8	
1	S0	1	Load on status	None	UPS	BYP	Other Module		
2			REC status	OFF	Soft-start	Normal work			
3			INV status	OFF	Soft-start	Normal work			
4			BYP status	Out range	Ok for supply				
5		2	5	Battery status	Not connected	Boost	float	Discharging	not work
6			6	Reserved					
7			7	Reserved					
8			8	Reserved					
9		3	9	Maintenance CB status	Open	Closed			
10			10	Reserved					
11			11	Reserved					
12			12	Positive Battery connect status	Not connect	Connected			
13		4	13	negative Battery connect status	Not connect	Connected			
14	14		INV allow on status	Inhibited On	Allow On				

15	S1	1	5	INV supply status	Not allow to supply	Ready for supply	Supplying		
16			6	Generator in	Not Generator	Generator In			
17		1	1	1	Reserved				
18				2	Reserved				
19				3	Reserved				
20				4	Exterior BCB trip	Trip signal inactive	Trip signal active		
21		2	2	5	Exterior BCB connect status	Not connected	Connected		
22				6	Exterior BCB status	Open	Closed		
23				7	EPO status	Not EPO	EPO		
24				8	Module pulled Out	Pushed (Connected OK)	Pulled (Connected Fail)		
25		3	9	9	Inv available	Inv not available	Available		
26				10	System power up end	During power up step	Power up step ended.		
27			11	11	Reserved				
28				12	Reserved				
29			4	13	13	Reserved			
30		14			Reserved				
31		15			Reserved				
32		16			Reserved				

5.2 Alarm Bits Description

Seq.				Items	0	1	2	4	8
1	A0	1	1	Synchronous Fault	Sync.	Not sync.			
2			2	Main Input Fault	OK	Fault			

3		3	REC Fault	OK	Fault			
4		4	INV Fault	OK	Fault			
5		5	Reserved					
6		6	Reserved					
7		7	Reserved					
8		8	Reserved					
9		9	Reserved					
10		10	Reserved					
11		11	Reserved					
12		12	Reserved					
13		13	Input phase A over current	OK	Fault			
14		14	Input phase B over current	OK	Fault			
15		15	Input phase C over current	OK	Fault			
16		16	Output phase A voltage Fault	OK	Fault			
17	A1	1	Output phase B voltage Fault	OK	Fault			
18		2	Output phase C voltage Fault	OK	Fault			
19		3	Reserved					
20		4	Reserved					
21		5	Reserved					
22		6	Positive bus voltage Fault	OK	Low voltage	Over voltage		
23		7	Negative bus voltage Fault	OK	Low voltage	Over voltage		
24		8	Input current unbalance Fault	OK	Fault			
25		9	Input voltage Fault	OK	Fault			
26		10	Input Frequency Fault	OK	Fault			
27		11	Input Sequence Fault	OK	Fault			
28		12	REC soft-start Fault	OK	Fault			
29		13	REC IGBT over current	OK	Fault			
30		14	Reserved					
31		15	REC over temperature	OK	Fault			
32		16	Positive bus over voltage Fault	OK	Fault			
33	A2	1	1	Negative bus over	OK	Fault		

			voltage Fault					
34		2	Fan Fault	OK	Fault			
35		3	Reserved					
36		4	Reserved					
37		2	5 Positive bus under voltage	OK	Fault			
38	6 Negative bus under voltage		OK	Fault				
39	7 Positive battery reversed		OK	Fault				
40	8 Negative battery reversed		OK	Fault				
41		3	9 Reserved					
42	10 Reserved							
43	11 Positive charger voltage Fault		OK	under voltage	over voltage			
44	12 Negative charger voltage Fault		OK	under voltage	over voltage			
45		4	13 Reserved					
46	14 Reserved							
47	15 Positive charger Fault		OK	Fault				
48	16 Negative charger Fault		OK	Fault				
49	A3	1	1 Positive battery voltage low	OK	Fault			
50			2 Negative battery voltage low	OK	Fault			
51			3 Positive battery EOD	OK	Fault			
52			4 Negative battery EOD	OK	Fault			
53		2	5 Input neutral lost	OK	Fault			
54			6 BYP sequence Fault	OK	Fault			
55			7 BYP voltage Fault	OK	Fault			
56			8 Reserved					
57		3	9 Reserved					
58			10 Reserved					
59			11 BYP frequency over track range	OK	Fault			
60			12 Reserved					
61		4	13 Reserved					
62			14 Over load time out	OK	Fault			
63			15 Reserved					
64			16 Reserved					

65	A4	1	1	Manual shutdown	normal	shutdown				
66			2	INV protect	OK	Fault				
67			3	Transfer times limit in one hour	OK	Fault				
68			4	INV power back feed	OK	Fault				
69		2	5	Reserved						
70			6	Reserved						
71			7	Reserved						
72			8	INV over temperature Fault	OK	Fault				
73		3	9	INV IGBT over current	OK	Fault				
74			10	Reserved						
75			11	Over load	normal	over load				
76			12	INV relay or fuse Fault	OK	Fault				
77		4	13	Reserved						
78			14	Reserved						
79			15	Reserved						
80			16	Reserved						
81	A5	1	1	Reserved						
82			2	Output shorted	OK	Fault				
83			3	Battery test	None	OK	Fault			
84			4	Battery maintenance	None	OK	Fault			
85		2	5	Reserved						
86			6	Reserved						
87			7	Reserved						
88			8	Reserved						
89		3	9	Reserved						
90			10	Reserved						
91			11	Reserved						
92			12	Reserved						
93		4	13	Reserved						
94			14	Reserved						
95			15	Reserved						
96			16	Reserved						

5.3 alarms Check and Solution tips

- 1) Synchronous Fault
 - A) BYP frequency out of synchronize range.
 - B) SYNC signal in the parallel Fault.

- 2) Main Input Fault
 - A) Main input voltage out of range.
 - B) Main input frequency out of range.
 - C) Main input sequence is reversed

- 3) REC Fault
 - A) REC over temperature.
 - B) Dc bus over voltage latched.
 - C) REC soft-start Fault.
 - D) Input current unbalance.

- 4) INV Fault
 - A) INV IGBT over current.
 - B) INV over temperature.
 - C) INV voltage abnormal

- 5) Input phase A/B/C over current
 - A) Input current over limited.
 - Tip 1: IGBT Fault.
 - Tip 2: DC bus shorted.
 - Tip 3: IGBT driver Fault.

- 6) Output Phase A/B/C Voltage Fault
 - A) INV voltage out of range.
 - Tip 1: IGBT open.
 - Tip 2: IGBT driver lost.
 - Tip 3: Voltage detects and sample fail.

- 7) Positive/Negative Bus Voltage Fault
 - A) DC bus voltage out of range.

- 8) Input current unbalance fault
 - A) The difference of max current and min current of the input three phases is out of the limited range.
 - Tip 1: One of the input current detecting CT/HALL fail..
 - Tip 2: Some REC IGBT open.
 - Tip 3: input current detecting and sample circuit fail.

- 9) Input Voltage Fault
 - A) Input voltage out of range.

- 10) Input Frequency fault
A) Input frequency out of range
- 11) Input Sequence Fault
A) Input sequence is reversed
- 12) REC soft-start fault
A) After the REC soft-start step, the bus voltage can not reach the default value.
Tip 1: REC SCR fail.
Tip 2: REC SCR driver fail.
Tip 3: Bus voltage detects and sample fail.
- 13) REC IGBT over current
A) Big current flow through REC IGBT.
Tip 1: REC IGBT fail.
Tip 2: DC Bus shorted.
Tip 3: REC IGBT driver fail.
- 14) REC over temperature
A) REC temperature out of the limited range.
- 15) Positive/Negative bus over voltage fault
A) Bus voltage over the up limited.
- 16) Fan fault
A) At least one of the fan fail.
- 17) Positive/Negative bus under voltage
A) Bus voltage out of the down limited.
- 18) Positive/Negative battery reversed
A) Battery connection reversed.
- 19) Positive/Negative charger voltage fault
A) Charger voltage out of the range limited.
Tip 1: Charger IGBT fail.
Tip 2: Charger IGBT driver fail.
Tip 3: Charger voltage detecting and sampling circuit fail.
- 20) Positive/Negative charger fault
A) During charging step (boost or float), the charger voltage out of the range limited.
Tip 1: Charger IGBT fail.
Tip 2: Charger IGBT driver fail.

Tip 3: Charger voltage detecting and sampling circuit fail.

21) Positive/Negative battery voltage low
A) Battery voltage is low (a little bigger than the EOD point).

22) Positive/Negative battery EOD
A) Battery voltage reaches the end of discharge point.

23) BYP sequence fault
A) BYP sequence reversed.

24) BYP voltage fault
A) BYP voltage out of the range limited.

25) BYP frequency over track range
A) BYP frequency out of the sync window.

26) Over load time out
A) INV over load time out.

27) Manual shutdown
A) Manual Off button is pressed to shutdown the PM.

28) INV protect.
A) INV detects power back feed to dc bus.
B) INV voltage out of range.
C) INV detects the bus voltage over the limited.

NOTES: INV protect fault is auto cleared.

29) Transfer times limit in one hour
A) Transfer to BYP times in one hour exceeds the limited.

30) INV power back feed
A) INV detects power back feed to dc bus.

31) INV over temperature fault
A) INV temperature out of the limited range.

INV IGBT over current

A) Big current flow through INV IGBT.

- Tip 1: INV IGBT fail.
- Tip 2: INV IGBT driver fail.

- 32) Over load
- A) PM over load.

- 33) INV relay or fuse fault.
- A) INV relay Fail
 - Tip 1: relay can not be closed.
 - Tip 2: relay can not be opened.
- B) INV fuse fail.

- 34) Output shorted
- A) Output shorted is detected.
 - Notes: This fault could be cleared only by "Fault Clear" button.

- 35) Battery test Fail.
- A) Battery test condition is not allowed.
 - Tip 1: Battery voltage (cell) smaller than (float voltage (cell) – 0.1V).
 - Tip 2: BYP is not qualified.
 - Tip 3: At least one Alarm exists in the system.
- B) Battery discharging time is less than 20 Sec.

- 36) Battery maintenance Fail.
- A) Battery test condition is not allowed.
 - Tip 1: Battery voltage (cell) smaller than (float voltage (cell) – 0.1V).
 - Tip 2: BYP is not qualified.
 - Tip 3: At least one Alarm exists in the system.
- B) The time lasted before battery voltage low is less than 20 Sec.

5.4 Cabinet trouble shooting

- 1) Maintenance CB Operation.

- Step 1: Transfer system to BYP manually.
- Step 2: Close Maintenance CB.
- Step 3: Open Output and Input CB.
- Step 4: Doing maintenance.
- Step 5: After system is fixed, Close Output and Input CB.
- Step 6: After BYP SCR is fired, Open Maintenance CB.
- Step 7: System will works automatically.

- 2) Cabinet Failures Description.
 - i. On UPS Inhibited
 - A) System transfer to UPS is inhibited.
 - Tip 1: BYP SCR shorted.
 - Tip 2: System is in EPO.
 - Tip 3: Maintenance CB is Closed.
 - Tip 4: Manual transfer to BYP latched.
 - Tip 5: Transfer times per hours Limited.
 - Tip 6: Output load is more than the total capacitor of the ready INV.
 - ii. BYP Fault
 - A) BYP SCR shorted.
 - Tip 1: SCR fail.
 - Tip 2: SCR driver fail.
 - B) BYP SCR opened.
 - Tip 1: SCR fail.
 - Tip 2: SCR driver lost.

Appendix: LED INDICATION

		OFF	FLASHING GREEN	CONSTANT GREEN	FLASHING RED	CONSTANT RED
Power Module	REC	REC not work	REC soft-start.	REC works normally.	Input is abnormal.	REC failure.
	INV	INV not work	INV soft-start or started but not supply.	INV is supplying.	INV is not allowed to start.	INV failure.
	BATT	BATT not work	BATT is discharging.	BATT is charging.	BATT voltage is low.	EOD, not connected or connected reversely.
Cabinet Monitor	STATUS	---	---	System is normal.		Alarm or failure exists.
	REC	REC of all PMs do not work.	At least one PM's REC soft-starts.	REC of all PMs work normally.	At least one PM detected input failure.	At least one PM's REC failure.
	BYP	BYP is OK, but not supply output.	---	BYP is normal and is supplying output.	BYP is abnormal or frequency is out of the trace range.	BYP Failure (SCR shorted or Open)
	INV	INV of all PMs do not work.	At least one PM's INV soft-start or started but not supply.	At least one PM's INV is supplying output and all INV are not failure.	At least one PM's INV is supplying output and some INV is failure.	None INV supplies output and at least one INV is failure.
	OUTPUT	Output None.	---	Output is normal	Output is in over load	Over load time out or output shorted and output lost.
	BATTERY	Battery not work	Battery is discharging.	Battery is charging.	BATT voltage is low.	EOD, not connected or connected reversely.