

Interface Range Configuration

Table of Contents

1.1 Interface Range Configuration Task.....	1
1.1.1 Understanding Interface Range.....	1
1.1.2 Entering Interface Range Mode.....	1
1.1.3 Configuration Example.....	1

Chapter 1 Interface Range Configuration

1.1 Interface Range Configuration Task

1.1.1 Understanding Interface Range

In the process of configuring interface tasks, there are cases when you have to configure the same attribute on ports of the same type. In order to avoid repeated configuration on each port, we provide the interface range configuration mode. You can configure ports of the same type and slot number with the same configuration parameters. This reduces the workload. Note: when entering the interface range mode, all interfaces included in this mode must have been established.

1.1.2 Entering Interface Range Mode

Run the following command to enter the interface range mode.

Procedure	Command	Purpose
1	interface range type slot/{port1-port2 port3}[,{port1-port2 port3}]	Enters the range mode. All ports included in this mode accord to the following conditions: <ol style="list-style-type: none"> 1) The slot number is set to slot. 2) The port numbers before/after the hyphen (-) must range between port1 and port2, or equal to port3. 3) Port 2 must be no less than port1; 4) There must be space before/after the hyphen (-) or the comma(,).
2	Interface range gpon slot/port:{ channel1-chann el channel3}[, {channel1-channel2 chan nel3}]	Enters the range mode of LLID port. All ports included in this mode accord to the following conditions: <ol style="list-style-type: none"> 1) PON port is slot/port; 2) The port numbers before/after the hyphen (-) must range between channel 1 and channel 2, or equal to channel 3; 3) channel 2 must less than channel 1; 4) There must be no space before/after the hyphen (-) or the comma(,).

1.1.3 Configuration Example

The following example shows how to enter the port configuration mode of gigabit Ethernet port 1, 2, 3 or 4 on slot 0.

```
switch_config# interface range g0/1-2,3-4
switch_config_if_range#
```

Run the following command to enter ONU port configuration mode, which includes three ONU ports 1, 2 and 5 under gp0/1:

```
switch_config# interface range gp0/1:1-2,5  
switch_config_if_range#
```