

Content

Chapter 1 Commands for Portal Authentication in NAT 1-1

1.1 virtual-ip-map enable..... 1-1

Chapter 1 Commands for Portal Authentication in NAT

1.1 virtual-ip-map enable

Command: virtual-ip-map enable

no virtual-ip-map enable

Function: Enable the virtual IP map function. The no command disables this function.

Parameters: None.

Command Mode: Captive Portal Global Configuration Mode.

Default: Disable.

Usage Guide: In the portal authentication, after enabled the virtual IP map function, AC can deal with the IP of the client with map and ensure the portal function can work normally in the NAT environment. In the NAT environment, this function must be enabled.

Example: Enable the virtual IP map function.

```
AC(config-cp)#virtual-ip-map enable
```