

IPv6 Protocol Configuration

Table of Contents

Chapter 1 IPv6 Protocol Configuration.....	1
1.1 IPv6 Protocol Configuration.....	1
1.2 Enabling IPv6.....	1
1.2.1 Setting the IPv6 Address.....	1
Chapter 2 Setting the IPv6 Services.....	1
2.1 Setting the IPv6 Services.....	1
2.2 Managing the IPv6 Link.....	1

Chapter 1 IPv6 Protocol Configuration

1.1 IPv6 Protocol Configuration

The configuration of the IPv6 address of the OLT only takes effect on the VLAN interface, not on the physical interface.

The IPv6 protocol is disabled in default state. If the IPv6 protocol need be used on a VLAN interface, this protocol should be first enabled in VLAN interface configuration mode. To enable the IPv6 protocol, users have to set the IPv6 address. If on a VLAN interface at least one IPv6 address is set, the VLAN interface can handle the IPv6 packets and communicates with other IPv6 devices. Otherwise, there will be no IPv6 address and the protocol will not be enabled.

To enable the IPv6 protocol, users should finish the following task:

- Setting at least one IPv6 address in VLAN interface configuration mode

1.2 Enabling IPv6

1.2.1 Setting the IPv6 Address

The IPv6 address is used to determine the destination address to which the IPv6 packets can be sent. There are three kinds of IPv6 addresses.

Type	Referred Format	Purpose
Unicast address	2001:0:0:0:0DB8:800:200C:417A/64	2001:0:0:0:0DB8:800:200C:417A is address. Meanwhile the prefix length of the address must be specified (such as 64 in the reference format)
Multicast address	FF01:0:0:0:0:0:101	All multicast addresses begin with FF.
Any address	2002:0:0:0:0DB8:800:200C:417A/64	The format of this address is the same as that of the unicast address. Different VLAN interfaces can be set to have the same address, no matter it is a unicast/broadcast/multicast address. Packets forwarding to any broadcast address will "route" to the VLAN port with one configured broadcast address nearest to the sender.

For the further details of the IPv6 address, see RFC 4291.

In order to enable IPv6, users must set a unicast address in VLAN interface configuration mode. The set unicast address must be one or multiple addresses of the following type:

- IPv6 link-local address
- Global IPv6 address

To set an IPv6 link-local address in VLAN interface configuration mode, run the following commands.

Command	Purpose
ipv6 enable	Sets a link-local address automatically.
ipv6 address fe80::x link-local	Sets a link-local address manually.

Note:

- The link-local address must begin with fe80. The default length of the prefix is 64 bit. At manual settings only the values at the last 64 bits can be designated.
- On a VLAN interface can only one link-local address be set.
- After IPv6 is enabled through the configuration of the link-local address, IPv6 only takes effect on the local link.

To set a global IPv6 address in VLAN interface configuration mode, run the following commands.

Command	Purpose
ipv6 address autoconfig	Sets a global address automatically.
ipv6 address [ipv6-address/prefix-length general-prefix prefix-name sub-bits/prefix-length] [eui-64]	Sets a global address.
ipv6 address X:X:X::X/<0-128> anycast	Sets an address of unicast/broadcast/multicast.

Note:

- When IPv6 is enabled through the configuration of a global address, all interconnected IPv6 device can be handled by IPv6.
- If a link-local address has not been set before the configuration of the global address, the system will set a link-local address automatically.

Chapter 2 Setting the IPv6 Services

2.1 Setting the IPv6 Services

After IPv6 is enabled, all services provided by IPv6 can be set. The configurable IPv6 service is shown below:

- (1) Managing the IPv6 Link

2.2 Managing the IPv6 Link

IPv6 provides a series of services to control and manage the IPv6 link. This series of services includes:

- (1) Setting the transmission frequency of the ICMPv6 packet
- (2) Setting the source IPv6 route
- (3) Setting the MTU of IPv6
- (4) Setting IPv6 redirection
- (5) Setting IPv6 destination unreachability
- (6) Setting IPv6 ACL
- (7) Setting IPv6 Hop-Limit

1. Setting the transmission frequency of the ICMPv6 packet

If you want to limit the transmission frequency of the ICMPv6 packet, run the command in the following table. If the ICMPv6 transmission frequency is larger than the set value, the transmission frequency will be limited.

The default transmission frequency is 1000us. Modify the command in the global configuration mode:

Command	Purpose
<code>ipv6 icmp error-interval ratelimit</code>	Setting the transmission frequency of the ICMPv6 packet.

2. Setting the source IPv6 route

IPv6 allows a host to designate the route of an IPv6 network, that is, the source route. The host can realize the source route through using the routing header in the IPv6 packets.

The OLT can forward packets through the routing header, or desert this kind of packets considering security.

The router supports the source OLT by default. If the source route is closed, users can run the following command in global configuration mode to open the source route.

Command	Purpose
ipv6 source-route	Allows the source IPv6 route.

3. Setting the MTU of IPv6

All interfaces have a default IPv6 MTU. If the IPv6 message length exceeds MTU, the routing OLT segments the message.

To set IPv6 MTU on a specific interface, run the following command in interface configuration mode:

Command	Purpose
ipv6 mtu bytes	Sets IPv6 MTU on an interface.

4. Setting IPv6 redirection

Sometimes the host selects an unfavorable route. After a routing OLT on the route receives a message from the host, it is to check the routing table and then forward the message through the message-receiving interface to another OLT that is in the same network segment as the host. In this case, the OLT notifies the source host of directly sending the message with the destination to another OLT without winding itself. The redirection message requires the source host to discard the original route and take more direct route suggested in the message. Many host's operating system adds a host route to its routing table. However, the routing OLT is more willing to trust information obtained through the routing protocol. Therefore, the OLT will not add the host route according to the information.

The function is enabled by default. However, if a hot standby router protocol is configured on an interface, IPv6 redirection is automatically closed. If the hot standby router protocol is canceled, this function will not automatically opened.

To enable IPv6 redirection, run the following command:

Command	Purpose
---------	---------

ipv6 redirects	Allows IPv6 to transmit the redirection packets.
-----------------------	--

5. Setting IPv6 destination unreachability

In many cases, the system will automatically transmit the destination-unreachable packets.

Users can close this function. If this function is closed, the system will not transmit the ICMP unreachable packets.

To enable this function, run the following command:

Command	Purpose
ipv6 unreachable	Allowing IPv6 to transmit the destination unreachable packets.

6. Setting IPv6 ACL

Users can use ACL to control the reception and transmission of packets on a VLAN interface. If you introduce ACL on a VLAN interface in global configuration mode and designate the filtration's direction, the IPv6 packets will be filtered on this VLAN interface.

To filter the IPv6 packets, run the following command in interface configuration mode.

Command	Purpose
ipv6 access-group <i>WORD</i> { in out }	Filters the IPv6 packets in the reception or transmission direction (in: receive; out: transmit) on a VLAN interface.

7. Setting IPv6 Hop-Limit

Users can designate an OLT to transmit the value of the hop-limit field in the packets (except those forwarded packets). All those packets that this OLT transmits out, if the upper-level application does not apparently designate a hop-limit value, use the set value of hop-limit. At the same time, the value of the hop-limit field is added to the RA packets that this OLT transmits.

The default hop-limit value is 64. If you want to change this value, you can run the following command in interface configuration mode.

Command	Purpose
ipv6 enable	Enables ipv6 function
ipv6 cur-hoplimit <i>value</i>	Designates an OLT to transmit the hop-limit field of the packets.

