

IP Address & Application Commands

1. IP Address/Service Commands
2. ARP Commands
3. IPv6 Commands
4. DHCP Commands
5. DHCPv6 Commands
6. DNS Commands
7. FTP Server Commands
8. FTP Client Commands
9. Tunnel Commands
10. Network Connectivity Test Tool Commands
11. TCP Commands
12. IPv4/IPv6 REF Commands

1 IP Address/Service Commands

1.1 gateway

Use this command to set the gateway address for the management port. Use the **no** form of this command to remove the setting.

gateway *address*
no gateway

Parameter	Parameter	Description
Description	<i>address</i>	Sets the gateway address for the management port

Defaults N/A

Command Mode Interface configuration mode

Usage Guide N/A

Configuration Examples The following example sets the gateway address for the management port to 1.1.1.1.

```
Orion_B54Q(config)# interface mgmt 0
Orion_B54Q(config-if-Mgmt 0)# gateway 1.1.1.1
Orion_B54Q(config-if-Mgmt 0)#
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

1.2 ip-address

Use this command to configure the IP address of an interface. Use the **no** form of this command to restore the default setting.

ip address *ip-address network-mask* [**secondary**] | [**slave**] | [**gateway** *ip-address*]
no ip address [*ip-address network-mask* [**secondary**] | [**slave**] | [**gateway**]]

Parameter	Parameter	Description
Description	<i>ip-address</i>	32-bit IP address, with 8 bits in one group in decimal format. Groups

	are separated by dots.
<i>network-mask</i>	32-bit network mask. 1 stands for the mask bit, 0 stands for the host bit, with 8 bits in one group in decimal format. Groups are separated by dots.
<i>slave</i>	Slave IP address.
<i>secondary</i>	Secondary IP address
<i>gateway ip-address</i>	Configures the gateway address for the layer-2 switch, which is only supported on the layer-2 switches. No address is followed by the gateway when using the no form of this command.

Defaults No IP address is configured for the interface by default.

Command N/A

Mode

Usage Guide Interface configuration mode.

The equipment cannot receive and send IP packets before it is configured with an IP address. After an IP address is configured for the interface, the interface is allowed to run the Internet Protocol (IP).

The network mask is also a 32-bit value that identifies which bits among the IP address is the network portion. Among the network mask, the IP address bits that correspond to value “1” are the network address. The IP address bits that correspond to value “0” are the host address. For example, the network mask of Class A IP address is “255.0.0.0”. You can divide a network into different subnets using the network mask. Subnet division means to use the bits in the host address part as the network address part, so as to reduce the capacity of a host and increase the number of networks. In this case, the network mask is called subnet mask.

The NOS software supports multiple IP address for an interface, in which one is the primary IP address and others are the secondary/slave IP addresses. Theoretically, there is no limit for the number of secondary IP addresses. The primary IP address must be configured before the secondary IP addresses. The secondary IP address and the primary IP address must belong to the same network or different networks. Secondary IP addresses are often used in network construction. Typically, you can try to use secondary IP addresses in the following situations:

A network hasn’t enough host addresses. At present, the LAN should be a class C network where 254 hosts can be configured. However, when there are more than 254 hosts in the LAN, another class C network address is necessary since one class C network is not enough. Therefore, the device should be connected to two networks and multiple IP addresses should be configured.

Many older networks are layer 2-based bridge networks that have not been divided into different subnets. Use of secondary IP addresses will make it very easy to upgrade this network to an IP layer-based routing network. The equipment configures an IP address for each subnet.

Two subnets of a network are separated by another network. You can create a subnet for the separated network, and connect the separated subnet by configuring a secondary IP address. One subnet cannot appear on two or more interfaces of a device.

Slave IP address is applied to the gateway cluster scenario. Only after the primary IP address is configured can the slave IP address be configured. Both slave and primary addresses are configured on an Layer 3 interface, backing up each other. In general, the master device adopts the primary IP address and the slave device uses the slave IP address. When the slave device becomes the master, its IP address becomes the primary IP address. When the master device turns into a slave, its IP address becomes the slave IP address.

In general, the layer-2 switch is configured a default gateway with the **ip default-gateway** command. Sometimes the layer-2 switch may be managed through the telnet, and the management IP and default gateway of the layer-2 switch needed to be modified. In this case, after configuring any one of the **ip address** and **ip default-gateway** command, the other cannot be configured any more due to the configuration change which causes failing to access this device through the network. So you need to use the keyword **gateway** in the **ip address** command to modify both the management IP and default gateway. The keyword **gateway** is not in the output of **show running config**, but in the output of **ip default-gate** command.

Configuration Examples The following example configures the primary IP address and the network mask as 10.10.10.1 and 255.255.255.0 respectively .

```
Orion_B54Q(config-if)# ip address 10.10.10.1 255.255.255.0
```

The following example configures the default gateway address as 10.10.10.254.

```
Orion_B54Q(config-if)# ip address 10.10.10.1 255.255.255.0 gateway
10.10.10.254
```

The following example configures the master and slave IP addresses as 10.10.10.1/24 and 10.10.20.1/24 respectively.

```
Orion_B54Q(config)# interface gigabitEthernet 0/1
Orion_B54Q(config-if-GigabitEthernet 0/1)# ip address 10.10.10.1
255.255.255.0
Orion_B54Q(config-if-GigabitEthernet 0/1)# ip address 10.10.20.1
255.255.255.0 slave
```

Related Commands	Command	Description
	show interface	Displays detailed information of the interface.

Platform N/A
Description

1.3 ip address negotiate

Use this command to configure an IP address for the interface through PPP negotiation. Use the **no** form of this command to restore the setting.

ip address negotiate
no ip address negotiate

Parameter	Parameter	Description
Description	N/A	N/A

Defaults This function is disabled by default.

Command Mode Interface configuration mode

Usage Guide Only the PPP interface of the router supports IP address configuration through PPP negotiation. After the interface is configured with the **ip address negotiate** command, the peer end should be configured with the **peer default ip address** command.

Configuration Examples The following example obtains an IP address for the interface through PPP negotiation.

```
Orion_B54Q(config)# interface dialer 1
Orion_B54Q(onfig-if-dialer 1)# ip address negotiate
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

1.4 ip broadcast-addresss

Use this command to define a broadcast address for an interface in the interface configuration mode. Use the **no** form of this command to restore the default setting.

ip broadcast-addresss *ip-address*
no ip broadcast-addresss

Parameter	Parameter	Description
Description	<i>ip-address</i>	Broadcast address of IP network

Defaults The default IP broadcast address is 255.255.255.255.

Command Mode Interface configuration mode.

Usage Guide At present, the destination address of IP broadcast packet is all "1", represented as 255.255.255.255. The NOS software can generate broadcast packets with other IP addresses through definition, and can receive both all "1" and the broadcast packets defined by itself.

Configuration The following example sets the destination address of IP broadcast packets generated by this

Examples

```
interface to 0.0.0.0.
Orion_B54Q(config-if)# ip broadcast-address 0.0.0.0
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A
Description

1.5 ip icmp error-interval

Use this command to set the rate to send the ICMP destination unreachable packets triggered by DF in the IP header. Use the **no** form of this command to restore the default setting.

```
ip icmp error-interval DF milliseconds [ bucket-size ]
no ip icmp error-interval DF milliseconds [ bucket-size ]
```

Use this command to set the rate to send other ICMP error packets. Use the **no** form of this command to restore the default setting.

```
ip icmp error-interval milliseconds [bucket-size]
no ip icmp error-interval milliseconds [ bucket-siz ]
```

Parameter	Parameter	Description
Description	<i>milliseconds</i>	The refresh period of the token bucket, in the range from 0 to 2147483647 in the unit of milliseconds. 0 indicates no limit on the rate to send ICMP error packets. The default is 100.
	<i>bucket-size</i>	The number of tokens in the bucket, in the range is from 1 to 200. The default is 10.

Defaults The default rate is 10 packets per 100 millisecond.

Command Mode Global configuration mode.

Usage Guide To prevent DoS attack, the token bucket algorithm is adopted to limit the rate to send ICMP error packets.

If IP packets need to be fragmented while the DF is set to 1, the device sends ICMP destination unreachable packets numbered 4 to the source IP address for path MTU discovery. Rate limits on ICMP destination unreachable packets and other error packets are needed to prevent path MTU discovery failure.

It is recommended to set the refresh period to an integral multiple of 10 milliseconds. If the refresh period is not an integral multiple of 10 milliseconds, it is adjusted automatically. For example, 1 per 5 milliseconds is adjusted to 2 per 10 milliseconds; 3 per 15 milliseconds is adjusted to 2 per 10 milliseconds.

Configuration Examples The following example sets the rate to send the ICMP destination unreachable packets triggered by DF in the IP header to 100 per second.

```
Orion_B54Q(config)# ip icmp error-interval DF 1000 100
```

The following example sets the rate to send other ICMP error packets to 10 per second.

```
Orion_B54Q(config)# ip icmp error-interval 1000 10
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

1.6 ip directed-broadcast

Use this command to enable the conversion from IP directed broadcast to physical broadcast in the interface configuration mode. Use the **no** form of this command to restore the default setting.

```
ip directed-broadcast [ access-list-number ]
no ip directed-broadcast
```

Parameter Description	Parameter	Description
	<i>access-list-number</i>	(Optional) Access list number, in the range from 1 to 199 and from 1300 to 2699. After an access list number has been defined, only the IP directed broadcast packets that match this access list are converted.

Defaults This function is disabled by default.

Command Mode Interface configuration mode.

Usage Guide IP directed broadcast packet is an IP packet whose destination address is an IP subnet broadcast address. For example, the packet with the destination address 172.16.16.255 is called a directed broadcast packet. However, the node that generates this packet is not a member of the destination subnet.

The device that is not directly connected to the destination subnet receives an IP directed broadcast packet and handles this packet in the same way as forwarding a unicast packet. After the directed broadcast packet reaches a device that is directly connected to this subnet, the device converts the directed broadcast packet into a flooding broadcast packet (typically the broadcast packet whose destination IP address is all "1"), and then sends the packet to all the hosts in the destination subnet in the manner of link layer broadcast.

You can enable conversion from directed broadcast into physical broadcast on a specified interface, so that this interface can forward a direct broadcast packet to a directly connected

network. This command affects only the final transmission of directed broadcast packets that have reached the destination subnet instead of normal forwarding of other directed broadcast packets.

You can also define an access list on an interface to control which directed broadcast packets to forward. After an access list is defined, only the packets that conform to the conditions defined in the access list undergo conversion from directed broadcast into physical broadcast. If the **no ip directed-broadcast** command is configured on an interface, NOS will discard the directed broadcast packets received from the directly connected network.

Configuration

The following example enables forwarding of directed broadcast packet on the fastEthernet 0/1 port of a device.

Examples

```
Orion_B54Q(config)# interface fastEthernet 0/1
Orion_B54Q(config-if)# ip directed-broadcast
```

Related Commands

Command	Description
N/A	N/A

Platform

N/A

Description

1.7 ip mask-reply

Use this command to configure the NOS software to respond the ICMP mask request and send an ICMP response message in the interface configuration mode. Use the **no** form of this command to restore the default setting.

ip mask-reply
no ip mask-reply

Parameter

Parameter	Description
N/A	N/A

Description

Defaults

This function is disabled by default.

Command mode

Interface configuration mode.

Usage Guide

Sometimes, a network device needs the subnet mask of a subnet on the Internet. To obtain such information, the network device can send an ICMP mask request message, and the network device that receives this message will send a mask response message.

Configuration

The following example sets the FastEthernet 0/1 interface of a device to respond the ICMP mask request message.

Examples

```
Orion_B54Q(config)# interface fastEthernet 0/1
Orion_B54Q(config-if)# ip mask-reply
```


Related Commands

Command	Description
N/A	N/A

Platform Description

N/A

1.8 ip mtu

Use this command to set the Maximum Transmission Unit (MTU) for an IP packet in the interface configuration mode. Use the **no** form of this command is restore the default setting.

ip mtu bytes
no ip mtu

Parameter Description

Parameter	Description
<i>bytes</i>	Maximum transmission unit of IP packet , in the range from 68 to 1500 bytes

Defaults

It is the same as the value configured in the interface command **mtu** by default.

Command Mode

Interface configuration mode.

Usage Guide

If an IP packet is larger than the IP MTU, the NOS software will split this packet. All the devices in the same physical network segment must have the same IP MTU for the interconnected interface.

If the interface configuration command **mtu** is used to set the maximum transmission unit value of the interface, IP MTU will automatically match with the MTU value of the interface. However, if the IP MTU value is changed, the MTU value of the interface will remain unchanged.

Configuration Examples

The following iexample sets the IP MTU value of the fastEthernet 0/1 interface to 512 bytes.

```
Orion_B54Q(config)# interface fastEthernet 0/1
Orion_B54Q(config-if)# ip mtu 512
```

Related Commands

Command	Description
mtu	Sets the MTU value of an interface.

Platform Description

N/A

1.9 ip redirects

Use this command to allow the NOS software to send an ICMP redirection message in the interface

configuration mode. Use the **no** form of this command to disable this function.

- ip redirects**
- no ip redirects**

Parameter	Parameter	Description
Description	N/A	N/A

Defaults This function is enabled by default.

Command Mode Interface configuration mode.

Usage Guide When the route is not optimum, it may make the device to receive packets through one interface and send it though the same interface. If the device sends the packet through the interface through which this packet is received, the device will send an ICMP redirection message to the data source, telling the data source that the gateway for the destination address is another device in the subnet. In this way the data source will send subsequent packets along the optimum path.

Configuration Examples The following example disables ICMP redirection for the fastEthernet 0/1 interface.

```
Orion_B54Q(config)# interface fastEthernet 0/1
Orion_B54Q(config-if)# no ip redirects
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

1.10 ip routing

Use this command to enable IPv4 unicast forwarding. Use the **no** form of this command to disable this function.

- ip routing**
- no ip routing**

Parameter	Parameter	Description
Description	N/A	N/A

Defaults This function is enabled by default.

Command Mode Global configuration mode.

Usage Guide N/A

Configuration The following example disables IPv4 unicast forwarding.

Examples `Orion_B54Q(config)# no ip routing`

Related Commands	Command	Description
	N/A	N/A

Platform N/A

Description

1.11 ip source-route

Use this command to allow the NOS software to process an IP packet with source route information in global configuration mode. Use the **no** form of this command to disable this function.

ip source-route

no ip source-route

Parameter Description	Parameter	Description
	N/A	N/A

Defaults This function is enabled by default.

Command Mode Global configuration mode.

Usage Guide NOS supports IP source route. When the device receives an IP packet, it will check the options of the IP packet, such as strict source route, loose source route and record route. Details about these options can be found in RFC 791. If an option is found to be enabled in this packet, a response will be made. If an invalid option is detected, an ICMP parameter problem message will be sent to the data source, and then this packet is discarded.

Configuration The following example disables the IP source route.

Examples `Orion_B54Q(config)# no ip source-route`

Related Commands	Command	Description
	N/A	N/A

Platform N/A

Description

1.12 ip ttl

Use this command to set the TTL value of the unicast packet. Use the **no** form of this command to restore the default setting.

ip ttl *value*

no ip ttl

Parameter	Parameter	Description
Description	<i>value</i>	Sets the TTL value of the unicast packet, in the range from 0 to 255.

Defaults The default is 64.

Command Mode Global configuration mode

Usage Guide N/A

Configuration Examples The following example sets the TTL value of the unicast packet to 100.

```
Orion_B54Q(config)# ip ttl 100
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

1.13 ip unnumbered

This command is used to configure unnumbered interfaces. After an interface is set to an unnumbered interface, IP can be run on the interface and packets can be sent or received on the interface. Use the **no** form of this command to restore the default setting.

ip unnumbered *interface-type interface-number*

no ip unnumbered

Parameter	Parameter	Description
Description	<i>interface-type</i>	Type of the associated interface
	<i>interface-number</i>	No. of the associated interface

Defaults No unnumbered interface is configured by default.

Command mode Interface configuration mode

Usage Guide An unnumbered interface indicates that IP is enabled on the interface but no IP address is allocated for the interface. An unnumbered interface must associate with an interface with an IP address. The source IP address of the IP packets generated on an unnumbered interface is the IP address of the associated interface. In addition, the routing protocol process determines whether to send route update packets to the unnumbered interface according to the IP address of the associated interface. Pay attention to the following when using an unnumbered interface:
 An Ethernet interface cannot be set to an unnumbered interface.
 When SLIP, HDLC, PPP, LAPB, and Frame-relay are encapsulated on a serial port, the port can be set to an unnumbered interface. When a frame relay is encapsulated, only a point-to-point subinterface can be set to an unnumbered interface. In the case of X.25 encapsulation, unnumbered interface is not allowed.
 The **ping** command cannot be used to check whether an unnumbered interface is working properly because the interface does not have an IP address. The status of an unnumbered interface can be remotely monitored over SNMP.
 The network cannot be enabled using an unnumbered interface.

Configuration Examples to the following example configures the local interface as an unnumbered interface and sets the associated interface to FastEthernet 0/1 (an IP address is configured for the interface).

```
Orion_B54Q(config-if)# ip unnumbered fastEthernet 0/1
```

Related Commands	Command	Description
	show interface	Displays the detailed information about the interface.

Platform Description N/A

1.14 ip unreachable

Use this command to allow the NOS software to generate ICMP destination unreachable messages. Use the **no** form of this command to disable this function.

ip unreachable
no ip unreachable

Parameter Description	Parameter	Description
	N/A	N/A

Defaults This function is enabled by default.

Command Mode Interface configuration mode.

Usage Guide NOS software will send a ICMP destination unreachable message if it receives unicast message

with self-destination-address and can not process the upper protocol of this message. NOS software will send ICMP host unreachable message to source data if it can not forward a message due to no routing.

This command influences all ICMP destination unreachable messages.

Configuration Examples The following example disables sending ICMP destination unreachable message on FastEthernet 0/1.

```
Orion_B54Q(config)# interface fastEthernet 0/1
Orion_B54Q(config-if)# no ip unreachable
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A

Description

1.15 show ip interface

Use this command to display the IP status information of an interface.

show ip interface [*interface-type interface-number* | **brief**]

Parameter Description	Parameter	Description
	<i>interface-type</i>	Specifies interface type.
	<i>interface-number</i>	Specifies interface number.
	<i>brief</i>	Displays the brief configurations about the IP of the layer-3 interface (including the interface primary ip, secondary ip and interface status)

Defaults N/A.

Command Mode Privileged EXEC mode.

Usage Guide When an interface is available, NOS will create a direct route in the routing table. The interface is available in that the NOS software can receive and send packets through this interface. If the interface changes from available status to unavailable status, the NOS software removes the appropriate direct route from the routing table.

If the interface is unavailable, for example, two-way communication is allowed, the line protocol status will be shown as "UP". If only the physical line is available, the interface status will be shown as "UP".

The results shown may vary with the interface type, because some contents are the interface-specific options

Configuration The following example displays the output of the **show ip interface brief** command.

Examples

```
Orion_B54Q#show ip interface brief
Interface IP-Address(Pri) IP-Address(Sec) Status Protocol
GigabitEthernet 0/10 2.2.2.2/24 3.3.3.3/24 down down
GigabitEthernet 0/11 no address no address down down
VLAN 1 1.1.1.1/24 no address down down
```

Description of fields:

Field	Description
Status	Link status of an interface. The value can be up , down , or administratively down .
Protocol	IPv4 protocol status of an interface.

The following example displays the output of the **show ip interface vlan** command.

```
SwitchA#show ip interface vlan 1
VLAN 1
  IP interface state is: DOWN
  IP interface type is: BROADCAST
  IP interface MTU is: 1500
  IP address is:
  1.1.1.1/24 (primary)
  IP address negotiate is: OFF
  Forward direct-broadcast is: OFF
  ICMP mask reply is: ON
  Send ICMP redirect is: ON
  Send ICMP unreachable is: ON
  DHCP relay is: OFF
  Fast switch is: ON
  Help address is:
  Proxy ARP is: OFF
ARP packet input number: 0
  Request packet: 0
  Reply packet: 0
  Unknown packet: 0
TTL invalid packet number: 0
ICMP packet input number: 0
  Echo request: 0
Echo reply: 0
  Unreachable: 0
  Source quench: 0
  Routing redirect: 0
```

Description of fields in the results:

Field	Description
IP interface state is:	The network interface is available, and both its interface

	hardware status and line protocol status are "UP".
IP interface type is:	Show the interface type, such as broadcast, point-to-point, etc.
IP interface MTU is:	Show the MTU value of the interface.
IP address is:	Show the IP address and mask of the interface.
IP address negotiate is:	Show whether the IP address is obtained through negotiation.
Forward direct-broadcast is:	Show whether the directed broadcast is forwarded.
ICMP mask reply is:	Show whether an ICMP mask response message is sent.
Send ICMP redirect is:	Show whether an ICMP redirection message is sent.
Send ICMP unreachable is:	Show whether an ICMP unreachable message is sent.
DHCP relay is:	Show whether the DHCP relay is enabled.
Fast switch is:	Show whether the IP fast switching function is enabled.
Route horizontal-split is:	Show whether horizontal split is enabled, which will affect the route update behavior of the distance vector protocol.
Help address is:	Show the helper IP address.
Proxy ARP is:	Show whether the agent ARP is enabled.
ARP packet input number: Request packet: Reply packet: Unknown packet:	Show the total number of ARP packets received on the interface, including: ARP request packet ARP reply packet Unknown packet
TTL invalid packet number:	Show the TTL invalid packet number
ICMP packet input number: Echo request: Echo reply: Unreachable: Source quench: Routing redirect:	Show the total number of ICMP packets received on the interface, including: Echo request packet Echo reply packet Unreachable packet Source quench packet Routing redirection packet
Outgoing access list is	Show whether an outgoing access list has been configured for an interface.
Inbound access list is	Show whether an incoming access list has been configured for an interface.

**Related
Commands**

Command	Description
N/A.	N/A.

Platform N/A.
Description

1.16 show ip packet statistics

Use this command to display the statistics of IP packets.

show ip packet statistics [total | interface-name]

Parameter	Parameter	Description
Description	<i>interface-name</i>	Interface name
	<i>total</i>	Displays the total statistics of all interfaces.

Defaults N/A.

Command Mode Privileged EXEC mode.

Usage Guide N/A.

Configuration The following example displays the output of this command.

```
Examples
Orion_B54Q# show ip packet statistics
Total
Received 1000 packets, 1000000 bytes
Unicast:1000,Multicast:0,Broadcast:0
Discards:0
HdrErrors:0 (BadChecksum:0, TTLExceeded:0, Others:0)
NoRoutes:0
Others:0
Sent 100 packets, 6000 bytes
Unicast:50,Multicast:50,Broadcast:0

VLAN 1
Received 1000 packets, 1000000 bytes
Unicast:1000,Multicast:0,Broadcast:0
Discards:0
HdrErrors:0 (BadChecksum:0, TTLExceeded:0, Others:0)
NoRoutes:0
Others:0
Sent 100 packets, 6000 bytes
Unicast:50,Multicast:50,Broadcast:0
```

Related	Command	Description
Commands	ip default-gateway	Configures the default gateway, which is only supported on the Layer 2 switch.

Platform N/A
Description

1.17 show ip raw-socket

Use this command to display IPv4 raw sockets.

show ip raw-socket [*num*]

Parameter	Parameter	Description
Description	<i>num</i>	Protocol.

Defaults N/A.

Command Mode Privileged EXEC mode.

Usage Guide N/A.

Configuration The following example displays all IPv4 raw sockets.

Examples

```
Orion_B54Q# show ip raw-socket
Number Protocol Process name
1 ICMP dhcp.elf
2 ICMP vrrp.elf
3 IGMP igmp.elf
4 VRRP vrrp.elf
Total: 4
```

Field Description

Field	Description
Number	Number
Protocol	Protocol
Process name	Process name
Total	Total number

Related	Command	Description
Commands	N/A	N/A

Platform N/A
Description

1.18 show ip sockets

Use this command to display all IPv4 sockets.

show ip sockets

Parameter	Parameter	Description
Description	N/A.	N/A.

Defaults N/A.

Command Mode Privileged EXEC mode.

Usage Guide N/A.

Configuration The following displays all IPv4 sockets.

```

Examples Orion_B54Q# show ip sockets
Number Process name      Type      Protocol LocalIP:Port  ForeignIP:Port
State
1      dhcp.elf              RAW       ICMP        0.0.0.0:1     0.0.0.0:0
*
2      vrrp.elf              RAW       ICMP        0.0.0.0:1     0.0.0.0:0
*
3      igmp.elf              RAW       IGMP        0.0.0.0:2     0.0.0.0:0
*
4      vrrp.elf              RAW       VRRP        0.0.0.0:112   0.0.0.0:0
*
5      dhcpc.elf            DGRAM    UDP         0.0.0.0:68    0.0.0.0:0
*
6      orion-snmpd          DGRAM    UDP         0.0.0.0:161   0.0.0.0:0
*
7      wbav2                DGRAM    UDP         0.0.0.0:2000  0.0.0.0:0
*
8      vrrp_plus.elf        DGRAM    UDP         0.0.0.0:3333  0.0.0.0:0
*
9      mpls.elf             DGRAM    UDP         0.0.0.0:3503  0.0.0.0:0
*
10     rds_other_th         DGRAM    UDP         0.0.0.0:3799  0.0.0.0:0
*
11     orion-snmpd          DGRAM    UDP         0.0.0.0:14800 0.0.0.0:0
*
12     orion-sshd           STREAM   TCP         0.0.0.0:22    0.0.0.0:0
LISTEN
13     orion-telnetd        STREAM   TCP         0.0.0.0:23    0.0.0.0:0
    
```

```

LISTEN
14      wbard          STREAM  TCP      0.0.0.0:4389  0.0.0.0:0
LISTEN
15      wbard          STREAM  TCP      0.0.0.0:7165  0.0.0.0:0
LISTEN
Total: 15

```

Field Description

Field	Description
Number	Serial number.
Process name	Process name.
Type	Socket type, including the following types: RAW: raw sockets DGRAM: datagram type STREAM: stream type.
Protocol	Protocol.
LocalIP:Port	Local IP address and port.
ForeignIP:Port	Peer IP address and port.
State	State. This field is for only TCP sockets.
Total	The total number of sockets.

Related
Commands

Command	Description
N/A	N/A

Platform
Description

N/A

1.19 show ip udp

Use this command to display IPv4 UDP sockets.

show ip udp [*local-port num*]

Use this command to display IPv4 UDP socket statistics.

show ip udp statistics

Parameter
Description

Parameter	Description
<i>local-port num</i>	Local port number

Defaults

N/A.

Command Mode

Privileged EXEC mode.

Usage Guide N/A.

Configuration The following example displays all IPv4 UDP sockets.

Examples

```
Orion_B54Q# show ip udp
Number Local Address      Peer Address      Process name
1      0.0.0.0:68             0.0.0.0:0        dhcpc.elf
2      0.0.0.0:161           0.0.0.0:0        orion-snmpd
3      0.0.0.0:2000          0.0.0.0:0        wbav2
4      0.0.0.0:3333          0.0.0.0:0        vrrp_plus.elf
5      0.0.0.0:3503          0.0.0.0:0        mpls.elf
6      0.0.0.0:3799          0.0.0.0:0        rds_other_th
7      0.0.0.0:14800         0.0.0.0:0        orion-snmpd
```

Field Description

Field	Description
Number	Number.
Local Address	Local IP address and port.
Peer Address	Peer IP address and port.
Process name	Process name.

Related Commands

Command	Description
N/A	N/A

Platform Description N/A

2 ARP Commands

2.1 arp

Use this command to add a permanent IP address and MAC address mapping to the ARP cache table. Use the **no** form of this command to restore the default setting.

arp *ip-address* *MAC-address* *type* [**alias**]

no arp *ip-address* *MAC-address* *type* [**alias**]

Parameter	Parameter	Description
Description	<i>ip-address</i>	The IP address that corresponds to the MAC address. It includes four parts of numeric values in decimal format separated by dots.
	<i>MAC-address</i>	48-bit data link layer address
	<i>type</i>	ARP encapsulation type. The keyword is arpa for the Ethernet interface.
	<i>alias</i>	(Optional) NOS will respond to the ARP request from this IP address after this parameter is defined.

Defaults There is no static mapping record in the ARP cache table by default.

Command Mode Global configuration mode.

Usage Guide NOS finds the 48-bit MAC address according to the 32-bit IP address using the ARP cache table. Since most hosts support dynamic ARP resolution, usually static ARP mapping is not necessary. The **clear arp-cache** command can be used to delete the ARP mapping that is learned dynamically.

Configuration Examples The following example sets an ARP static mapping record for a host in the Ethernet.

```
Orion_B54Q(config)# arp 1.1.1.1 4e54.3800.0002 arpa
```

Related Commands	Command	Description
	clear arp-cache	Clears the ARP cache table

Platform Description N/A

2.2 arp anti-ip-attack

For the messages corresponds to the directly-connected route, if the switch does not learn the ARP that corresponds to the destination IP address, it is not able to forward the message in

hardware, and it needs to send the message to the CPU to resolve the address(that is the ARP learning). Sending large number of this message to the CPU will influence the other tasks of the switch. To prevent the IP messages from attacking the CPU, a discarded entry is set to the hardware during the address resolution, so that all sequential messages with that destination IP address are not sent to the CPU. After the address resolution, the entry is updated to the forwarding status, so that the switch could forward the message with that destination IP address in hardware.

In general, during the ARP request ,if the switch CPU receives three destination IP address messages corresponding to the ARP entry, it is considered to be possible to attack the CPU and the switch sets the discarded entry to prevent the unknown unicast message from attacking the CPU. User could set the *num* parameter of this command to decide whether it attacks the CPU in specific network environment or disable this function. Use the **arp anti-ip-attack** command to set the parameter or disable this function. Use the **no** form of this command to restore the default setting.

arp anti-ip-attack num
no arp anti-ip-attack

Parameter Description	Parameter	Description
	<i>num</i>	The number of the IP message to trigger the ARP to set the discarded entry in the range from 0 to 100. 0 stands for disabling the arp anti-ip-attack function.

Defaults By default, set the discarded entry after 3 unknown unicast messages are sent to the CPU.

Command Mode Global configuration mode.

Usage Guide The arp anti-ip-attack function needs to occupy the switch hardware routing resources when attacked by the unknown unicast message. If there are enough resources, the **arp anti-ip-attack num** could be smaller. If not, in order to preferential ensure the use of the normal routing, the *num* could be larger or disable this function.

Configuration Examples The following example sets the IP message number that triggers to set the discarding entry as 5.

```
Orion_B54Q(config)# arp anti-ip-attack 5
```

The following example disables the ARP anti-ip-attack function.

```
Orion_B54Q(config)# arp anti-ip-attack 0
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

2.3 arp gratuitous-send interval

Use this command to set the interval of sending the free ARP request message on the interface. Use the **no** form of this command to restore the default setting.

arp gratuitous-send interval *seconds*

no arp gratuitous-send

Parameter	Parameter	Description
Description	<i>seconds</i>	The time interval to send the free ARP request message in the range from 1 to 3600 in the unit of seconds.

Defaults This function is disabled by default.

Command Mode Interface configuration mode.

Usage Guide If an interface of the switch is used as the gateway of its downlink devices and counterfeit gateway behavior occurs in the downlink devices, you can configure to send the free ARP request message regularly on this interface to notify that the switch is the real gateway.

Configuration Examples The following example sets to send one free ARP request to SVI 1 per second.

```
Orion_B54Q(config)# interface vlan 1
Orion_B54Q(config-if)# arp gratuitous-send interval 1
```

The following example stops sending the free ARP request to SVI 1.

```
Orion_B54Q(config)# interface vlan 1
Orion_B54Q(config-if)# no arp gratuitous-send
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A

Description

2.4 arp oob

Use this command to configure the static ARP on the management interface. Use the **no** form of this command to restore the default setting.

arp oob [*mgmt.-name*] *ip-address mac-address type*

no arp oob [*mgmt.-name*] *ip-address*

Parameter	Parameter	Description
Description	<i>ip-address</i>	The IP address corresponding to the MAC address, written as four

	groups of dotted decimal values.
<i>mac-address</i>	The data link layer address, composed of 48 bits.
<i>type</i>	The ARP encapsulation type. The key word for the Ethernet interface is arpa .
<i>mgmt.-name</i>	Specifies the ARP-mapping management interface when there are multiple management interfaces.

Defaults No static ARP is configured by default.

Command Mode Global configuration mode

Usage Guide NOS uses the ARP cache table to search for the 48-bit MAC address according to the 32-bit IP address.
 Most hosts support dynamic ARP analysis, so static ARP mapping does not need to be configured. The clear arp-cache oob command is used to clear the ARP mapping learned by the management port dynamically.
 If no management interface is specified, the static ARP is configured on the first management interface by default. If you specify the first management interface, the *mgmt-name* parameter is not displayed by running the **show run** command.

Configuration Examples The following example configures a static ARP mapping record for the Ethernet host

```
Orion_B54Q(config)# arp oob 1.1.1.1 4e54.3800.0002 arpa
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

2.5 arp retry interval

Use this command to set the frequency for sending the arp request message locally, namely, the time interval between two continuous ARP requests sent for resolving one IP address. Use the **no** form of this command to restore the default setting.

arp retry interval seconds
no arp retry interval

Parameter Description	Parameter	Description
	<i>seconds</i>	Time for retransmitting the ARP request message in the range from 1 to 3600 in the unit of seconds.

Defaults The default is 1.

Command Mode Global configuration mode.

Usage Guide The switch sends the ARP request message frequently, and thus causing problems like network busy. In this case, you can set the retry interval of the ARP request message longer. In general, it should not exceed the aging time of the dynamic ARP entry.

Configuration Examples The following example sets the retry interval of the ARP request as 30 seconds.

```
Orion_B54Q(config)# arp retry interval 30
```

Related Commands	Command	Description
	arp retry times	Number of times for retransmitting an ARP request message.

Platform Description N/A

2.6 arp retry times

Use this command to set the local retry times of the ARP request message, namely, the times of sending the ARP request message to resolve one IP address. Use the **no** form of this command to restore the default setting.

arp retry times *number*
no arp retry times

Parameter Description	Parameter	Description
	<i>number</i>	The times of sending the same ARP request in the range from 1 to100.When it is set as 1, it indicates that the ARP request is not retransmitted, only 1 ARP request message is sent.

Defaults The default is 5.

Command Mode Global configuration mode.

Usage Guide The switch sends the ARP request message frequently, and thus causing problems like network busy. In this case, you can set the retry times of the ARP request smaller. In general, the retry times should not be set too large.

Configuration Examples The following example sets the local ARP request not to be retried.

```
Orion_B54Q(config)# arp retry times 1
```

The following example sets the local ARP request to be retried for one time.

```
Orion_B54Q(config)# arp retry times 2
```

Related Commands	Command	Description
	arp retry interval	Interval for retransmitting an ARP request message

Platform N/A

Description

2.7 arp-suppress-auth-vlan-req

Use this command to disable the SVI interface from sending the ARP request to the authentication VLAN. Use the **no** form of this command to disable this function.

arp suppress-auth-vlan-req

no arp suppress-auth-vlan-req

Parameter Description	Parameter	Description
	N/A	N/A

Defaults This function is enabled by default.

Command Mode Interface configuration mode

Usage Guide In gateway authentication mode, all sub-VLANs of SuperVLAN are authentication VLANs by default. Users on authentication VLANs should pass the authentication before accessing the network. Static ARP table entries are generated on the device after users pass authentication. The device does not need to send ARP requests to the authentication VLAN when accessing these users. If the device accesses users on the authentication-exemption VLAN, it only needs to send ARP requests to the authentication-exemption VLAN.

In gateway authentication mode, the device enables suppression of ARP request sent to the authentication VLAN by default. If the device needs to access authentication-exemption users on the authentication VLAN, this function should be disabled.

Configuration Examples The following example disables VLAN 2 from sending the ARP request to the authentication VLAN.

```
Orion_B54Q(config)# interface vlan 2
Orion_B54Q(config-if-VLAN 2)# arp suppress-auth-vlan-req
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A

Description

2.8 arp timeout

Use this command to configure the timeout for the ARP static mapping record in the ARP cache.

Use the **no** form of this command to restore the default setting.

arp timeout *seconds*

no arp timeout

Parameter	Parameter	Description
Description	<i>seconds</i>	The timeout is in the range from 0 to 2147483 in the unit of seconds.

Defaults The default is 3600.

Command Mode Interface configuration mode/Global configuration mode

Usage Guide The ARP timeout setting is only applicable to the IP address and the MAC address mapping that are learned dynamically. The shorter the timeout, the truer the mapping table saved in the ARP cache, but the more network bandwidth occupied by the ARP. Hence the advantages and disadvantages should be weighted. Generally it is not necessary to configure the ARP timeout unless there is a special requirement.

The ARP timeout configuration is supported in both global and interface configuration modes and interface configuration mode has a higher priority over the global configuration mode. If interface 1 is configured with 3000s ARP timeout in global configuration mode and 1800s ARP timeout in interface configuration mode, the 1800s configuration takes effect. ARP timeout for the other interfaces is determined by global configuration, namely, 3000s.

Configuration Examples The following example sets the timeout for the dynamic ARP mapping record that is learned dynamically from FastEthernet port 0/1 to 120s.

```
Orion_B54Q(config)# interface fastEthernet 0/1
Orion_B54Q(config-if)# arp timeout 120
```

The following example sets the ARP timeout to 3000s.

```
Orion_B54Q(config)# arp timeout 3
```

Related Commands	Command	Description
	clear arp-cache	Clears the ARP cache list.
	show interface	Displays the interface information.

Platform Description N/A

2.9 arp trusted

Use this command to set the maximum number of trusted ARP entries. Use the **no** form of this command to restore the default setting.

arp trusted *number*

no arp trusted

Parameter	Parameter	Description
Description	<i>number</i>	Maximum number of trusted ARP entries.

Defaults N/A

Command Mode Global configuration mode.

Usage Guide To make this command valid, enable the trusted ARP function firstly. The trusted ARP entries and other entries share the memory. Too much trusted ARP entries may lead to insufficient ARP entry space. In general, you should set the maximum number of trusted ARP entries according to your real requirements.

Configuration Examples The following example sets 1000 trusted ARPs.

```
Orion_B54Q(config)# arp trusted 1000
```

Related Commands	Command	Description
	service trustedarp	Enables the trusted ARP function.

Platform N/A

Description

2.10 arp trust-monitor enable

Use this command to enable egress gateway trusted ARP. Use the **no** form of this command to restore the default setting.

arp trust-monitor enable

no arp trust-monitor enable

Parameter	Parameter	Description
Description	N/A	N/A

Defaults This function is disabled by default.

Command Interface configuration mode

Mode

Usage Guide The egress gateway trusted ARP is different from GSN trusted ARP. With this function enabled, the device sends a unicast request for confirmation when learning an ARP table entry. The device learns the ARP table entry after receiving the response. When the device receives the ARP packet, only if the ARP table entry is aged or incomplete and the ARP packet is a response packet will the packet be handled. After egress gateway trusted ARP is enabled, the aging time of the ARP table entry turns to 60 seconds. After this function is disabled, the aging time restores to 3600 seconds.

Configuration The following example enables egress gateway trusted ARP.

```
Orion_B54Q(config)# interface gi 0/0
Orion_B54Q(config-if-GigabitEthernet 0/0)# arp trust-monitor enable
```

The following example disables engress gateway trusted ARP.

```
Orion_B54Q(config)# interface gi 0/0
Orion_B54Q(config-if-GigabitEthernet 0/0)# no arp trust-monitor enable
```

Related	Command	Description
Commands	N/A	N/A

Platform N/A
Description

2.11 arp trusted aging

Use this command to set trusted ARP aging. Use the **no** form of this command to restore the default setting.

- arp trusted aging**
- no arp trusted aging**

Parameter	Parameter	Description
Description	N/A	N/A

Defaults This function is disabled by default.

Command Global configuration mode.
Mode

Usage Guide Use this command to set trusted ARP aging. Aging time is the same as dynamic ARP aging time. Use the **arp timeout** command to set aging time in interface mode.

Configuration N/A
Examples

Related	Command	Description
Commands	service trustedarp	Enables trusted ARP function.

Platform N/A
Description

2.12 arp trusted user-vlan

Use this command to execute the VLAN transformation while setting the trusted ARP entries. Use the **no** form of this command to restore the default setting.

arp trusted user-vlan *vid1* **translated-vlan** *vid2*

no arp trusted user-vlan *vid1*

Parameter	Parameter	Description
Description	<i>vid1</i>	VID set by the server.
	<i>vid2</i>	VID after the transformation.

Defaults This function is disabled by default.

Command Mode Global configuration mode.

Usage Guide In order to validate this command, enable the trusted ARP function first. This command is needed only when the VLAN sent by the server is different from the VLAN which takes effect in the trusted ARP entry.

Configuration Examples The following example sets the VLAN sent by the server to 3, but the VLAN which takes effect in the trusted ARP entry to 5.

```
Orion_B54Q(config)# arp trusted user-vlan 3 translated-vlan 5
```

Related	Command	Description
Commands	service trustedarp	Enables the trusted ARP function.

Platform N/A
Description

2.13 arp unresolve

Use this command to set the maximum number of the unresolved ARP entries. Use **no** form of this command to restore the default setting.

arp unresolve *number*

no arp unresolve

Parameter	Parameter	Description
Description	<i>number</i>	The maximum number of the unresolved ARP entries in the range from 1 to the ARP table size supported by the device.

Defaults The default is the ARP table size supported by the device.

Command Mode Global configuration mode.

Usage Guide If there are a large number of unresolved entries in the ARP cache table and they do not disappear after a period of time, this command can be used to limit the quantity of the unresolved entries.

Configuration Examples The following example sets the maximum number of the unresolved items to 500.

```
Orion_B54Q(config)# arp unresolve 500
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

2.14 clear arp-cache

Use this command to remove a dynamic ARP mapping record from the ARP cache table and clear an IP route cache table.

clear arp-cache [*vrf vrf_name* | **trusted**] [*ip [mask]*] | **interface** *interface-name*]

Parameter	Parameter	Description
Description	<i>trusted</i>	Deletes trusted ARP entries. Dynamic ARP entries are deleted by default.
	vrf <i>vrf_name</i>	Deletes dynamic ARP entries of the specified VRF instance. The default is the public instance.
	<i>ip</i>	Deletes ARP entries of the specified IP address. If <i>trusted</i> value is specified, trusted ARP entries are deleted; otherwise, all dynamic ARP entries are deleted which is the default.
	<i>mask</i>	Deletes ARP entries in a subnet mask. If <i>trusted</i> value is specified, trusted ARP entries in the subnet mask are deleted; otherwise, all dynamic ARP entries are deleted. The dynamic ARP entry specified by the IP address is deleted by default.
	interface <i>interface-name</i>	Deletes dynamic ARP entries on the specified interface. Dynamic

	ARP entries are deleted on all interfaces by default.
--	---

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide This command can be used to refresh an ARP cache table.

On a NFPP-based (Network Foundation Protection Policy) device, it receives one ARP packet for every mac/ip address per second by default. If the interval of two **clear arp** times is within 1s, the second response packet will be filtered and the ARP packet will not be resolved for a short time.

Configuration The following example deletes all dynamic ARP mapping records.

Examples Orion_B54Q# clear arp-cache

The following deletes the dynamic ARP entry 1.1.1.1.

Orion_B54Q# clear arp-cache 1.1.1.1

The following example deletes the dynamic ARP entry on interface SVI1.

Orion_B54Q# clear arp-cache interface Vlan 1

Related Commands	Command	Description
	arp	Adds a static mapping record to the ARP cache table.

Platform Description N/A

2.15 clear arp-cache oob

Use this command to clear dynamic ARP mapping records.

clear arp-cache oob [ip [mask]]

Parameter Description	Parameter	Description
	ip	Clears the ARP table entry of the specified IP address. All dynamic ARP table entries are cleared by default.
	mask	Clears the ARP table entry within the specified subnet. The dynamic ARP table entry of the specified IP address (the previous parameter) is cleared by default.

Defaults N/A

Command Privileged EXEC mode
Mode

Usage Guide On a device supporting Network Foundation Protection Policy (NFPP), every MAC / IP address receives an ARP packet per second by default. If the **clear arp oob** command is run twice within one second, the second response packet may be filtered, causing ARP uanalysis for a short time.

Configuration The following example clears the cache table of dynamic ARP mapping records.

Examples

```
Orion_B54Q# clear arp-cache oob
```

The following example clears dynamic ARP table entry 1.1.1.1.

```
Orion_B54Q# clear arp-cache oob 1.1.1.1
```

The following example clears the dynamic ARP table entry within the specified subnet.

```
Orion_B54Q# clear arp-cache oob 1.0.0.0 255.0.0.0
```

Related	Command	Description
Commands	N/A	N/A

Platform N/A
Description

2.16 ip proxy-arp

Use this command to enable ARP proxy function on the interface. Use the **no** form of this command to restore the default setting.

ip proxy-arp
no ip proxy-arp

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Mode Interface configuration mode.

Usage Guide Proxy ARP helps those hosts without routing message obtain MAC address of other networks or subnet IP address. For example, a device receives an ARP request. The IP addresses of request sender and receiver are in different networks. However, the device that knows the routing of IP address of request receiver sends ARP response, which is Ethernet MAC address of the device itself.

Configuration The following example enables ARP on FastEthernet port 0/1.

Examples

```
Orion_B54Q(config)# interface fastEthernet 0/1
Orion_B54Q(config-if)# ip proxy-arp
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A
Description

2.17 local-proxy-arp

Use this command to enable local proxy ARP on the SVI interface. Use the **no** form of this command to restore the default setting.

local-proxy-arp
no local-proxy-arp

Parameter Description	Parameter	Description
	N/A	N/A

Defaults N/A

Command Mode Interface configuration mode

Usage Guide With local proxy ARP enabled, the device helps a host to obtain MAC addresses of other hosts on the subnet. If the device enables switchport protected, users on different ports are segregated on layer 2. After local proxy ARP is enabled, the device serves as a proxy to send a response after receiving an ARP request. The ARP response contains a MAC address which is the device's Ethernet MAC address, realizing communication between different hosts through L3 routes.

Configuration Examples The following example enables local proxy ARP on VLAN1.

```
Orion_B54Q(config)# interface vlan 1
Orion_B54Q(config-if-VLAN 1)# local-proxy-arp
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A
Description

2.18 service trustedarp

Use this command to enable the trusted ARP function. Use the **no** form of this command to restore the default setting.

service trustedarp
no service trustedarp

Parameter	Parameter	Description
Description	N/A	N/A

Defaults This function is disabled by default.

Command Mode Global configuration mode

Usage Guide The trusted ARP function of the device is to prevent the ARP fraud function. As a part of the GSN scheme, it should be used together with the GSN scheme.

In the following three cases, the STP protocol clears not only the dynamic MAC address of a port but also the trusted entries, including trusted MAC and trusted ARP:

STP is enabled.

The port is set to neither root port nor designed port. This may be caused when the port is up or down or the port priority is modified.

TC packet is received on the port, and the addresses of the ports not receiving PC packet are cleared.

Configuration Examples The following example enables the trusted ARP function in global configuration mode.

```
config
service trustedarp
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

2.19 show arp

Use this command to display the Address Resolution Protocol (ARP) cache table

show arp [[**vrf** *vrf-name*] [**trusted**] *ip* [*mask*] | **static** | **complete** | **incomplete** | *mac-address*]

Parameter Description	Parameter	Description
	<i>ip</i>	Displays the ARP entry of the specified IP address.
	<i>vrf vrf-name</i>	VRF instance, which Displays the ARP entry with specified VRF.
	<i>ip mask</i>	Displays the ARP entries of the network segment included within the mask.
	<i>trusted</i>	Displays the trusted ARP entries. Currently, only the global VRF

	supports the trusted ARP.
<i>static</i>	Displays all the static ARP entries.
<i>complete</i>	Displays all the resolved dynamic ARP entries.
<i>incomplete</i>	Displays all the unresolved dynamic ARP entries.
<i>mac-address</i>	Displays the ARP entry with the specified mac address.

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example displays the output result of the **show arp** command:

```
Orion_B54Q# show arp
Total Numbers of Arp: 7
Protocol Address Age(min) Hardware Type Interface
Internet 192.168.195.68 0 0013.20a5.7a5f arpa VLAN 1
Internet 192.168.195.67 0 001a.a0b5.378d arpa VLAN 1
Internet 192.168.195.65 0 0018.8b7b.713e arpa VLAN 1
Internet 192.168.195.64 0 0018.8b7b.9106 arpa VLAN 1
Internet 192.168.195.63 0 001a.a0b5.3990 arpa VLAN 1
Internet 192.168.195.62 0 001a.a0b5.0b25 arpa VLAN 1
Internet 192.168.195.5 -- 00d0.f822.33b1 arpa VLAN 1
```

The meaning of each field in the ARP cache table is described as below:

Table 1 Fields in the ARP cache table

Field	Description
Protocol	Protocol of the network address, always to be Internet
Address	IP address corresponding to the hardware address
Age (min)	Age of the ARP cache record, in minutes; If it is not locally or statically configured, the value of the field is represented with “-”.
Hardware	Hardware address corresponding to the IP address
Type	Hardware address type, ARPA for all Ethernet addresses
Interface	Interface associated with the IP addresses

The following example displays the output result of **show arp 192.168.195.68**

```
Orion_B54Q# show arp 192.168.195.68
Protocol Address Age(min) Hardware Type Interface
Internet 192.168.195.68 1 0013.20a5.7a5f arpa VLAN 1
```

The following example displays the output result of **show arp 192.168.195.0 255.255.255.0**

```
Orion_B54Q# show arp 192.168.195.0 255.255.255.0
Protocol Address Age(min) Hardware Type Interface
Internet 192.168.195.64 0 0018.8b7b.9106 arpa VLAN 1
Internet 192.168.195.2 1 00d0.f8ff.f00e arpa VLAN 1
Internet 192.168.195.5 -- 00d0.f822.33b1 arpa VLAN 1
Internet 192.168.195.1 0 00d0.f8a6.5af7 arpa VLAN 1
Internet 192.168.195.51 1 0018.8b82.8691 arpa VLAN 1
```

The following example displays the output result of **show arp 001a.a0b5.378d**

```
Orion_B54Q# show arp 001a.a0b5.378d
Protocol Address Age(min) Hardware Type Interface
Internet 192.168.195.67 4 001a.a0b5.378d arpa VLAN 1
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A
Description

2.20 show arp oob

Use this command to display the ARP cache table.

show arp oob [*ip* [*mask*] | **static** | **complete** | **incomplete** | *mac-address*]

Parameter Description	Parameter	Description
	<i>ip</i>	Displays ARP table entries of the specified IP address.
	<i>mask</i>	Displays ARP table entries within the IP subnet.
	static	Displays all static ARP table entries.
	complete	Displays all analyzed ARP table entries.
	incomplete	Displays all unanalyzed ARP table entries.
	<i>mac-address</i>	Displays ARP table entries of the specified MAC address.

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide This command is used to display the ARP cache table. The **complete** / **incomplete** key word represents analyzed / unanalyzed ARP table entries.

Configuration Examples The following example displays the outcome of the running the show arp oob command.

```
Orion_B54Q# show arp oob
```

```
Total Numbers of Arp: 7
Protocol  Address          Age (min)  Hardware      Type  Interface
Internet  192.168.195.68   0          0013.20a5.7a5f arpa  mgmt 0
Internet  192.168.195.67   0          001a.a0b5.378d arpa  mgmt 0
Internet  192.168.195.65   0          0018.8b7b.713e arpa  mgmt 0
Internet  192.168.195.64   0          0018.8b7b.9106 arpa  mgmt 0
Internet  192.168.195.63   0          001a.a0b5.3990 arpa  mgmt 0
Internet  192.168.195.62   0          001a.a0b5.0b25 arpa  mgmt 0
Internet  192.168.195.5    --         00d0.f822.33b1 arpa  mgmt 0
```

The following example displays the outcome of running the **show arp oob 192.168.195.68** command.

```
Orion_B54Q# show arp oob 192.168.195.68
Protocol  Address          Age (min)  Hardware      Type  Interface
Internet  192.168.195.68   1          0013.20a5.7a5f arpa  mgmt 0
```

The following example displays the outcome of running the **show arp oob 192.168.195.0 255.255.255.0**.

```
Orion_B54Q# show arp 192.168.195.0 255.255.255.0
Protocol  Address          Age (min)  Hardware      Type  Interface
Internet  192.168.195.64   0          0018.8b7b.9106 arpa  mgmt 0
Internet  192.168.195.2    1          00d0.f8ff.f00e arpa  mgmt 0
Internet  192.168.195.5    --         00d0.f822.33b1 arpa  mgmt 0
Internet  192.168.195.1    0          00d0.f8a6.5af7 arpa  mgmt 0
Internet  192.168.195.51   1          0018.8b82.8691 arpa  mgmt 0
```

The following example displays the outcome of running the **show arp oob 001a.a0b5.378d** command.

```
Orion_B54Q# show arp 001a.a0b5.378d
Protocol  Address          Age (min)  Hardware      Type  Interface
Internet  192.168.195.67   4          001a.a0b5.378d arpa  mgmt 0
```

Field	Description
Protocol	Only "Internet" is available at present, which indicates the IP protocol.
Address	The IPv4 address.
Age(min)	The age of the table entry. For the local IP address, the field is displayed as '-'. For the static table entry, the field is displayed as <static>. For the dynamic table entry, the field indicates the time for which the table entry has been learned, in the unit of minutes.
Hardware	48-bit MAC address, written as a dotted triple of four-digit hexadecimal numbers.
Type	Only "arpa" is available at present.

Interface	The L3 interface corresponding to the ARP table entry. The field is NULL for static ARP table entries for the IP address of the static ARP is not within any network segment directly connected with the device.
-----------	---

Related	Command	Description
Commands	N/A	N/A

Platform N/A
Description

2.21 show arp counter

Use this command to display the number of ARP entries in the ARP cache table.

show arp counter

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example displays the output result of the **show arp counter** command:

```
Orion_B54Q# show arp counter
The Arp Entry counter:0
The Unresolve Arp Entry:0
```

The meaning of each field in the ARP cache table is described in Table 1.

Related	Command	Description
Commands	N/A	N/A

Platform N/A
Description

2.22 show arp detail

Use this command to display the details of the Address Resolution Protocol (ARP) cache table.

show arp detail [*interface-type interface-number* | **trusted** [*ip* [*mask*]] | [**vrf** *vrf-name*] [*ip* [*mask*] | *mac-address* | **static** | **complete** | **incomplete**] | **subvlan** { *subvlan-number* | **min-max** *min_value max_value*]

Parameter Description	Parameter	Description
	<i>interface-type interface-number</i>	Displays the ARP of the layer 2 port or the layer 3 interface.
	<i>ip</i>	Displays the ARP entry of the specified IP address.
	<i>ip mask</i>	Displays the ARP entries of the network segment included within the mask.
	<i>mac-address</i>	Displays the ARP entry of the specified MAC address.
	<i>static</i>	Displays all the static ARP entries.
	<i>complete</i>	Displays all the resolved dynamic ARP entries.
	<i>incomplete</i>	Displays all the unresolved dynamic ARP entries.
	subvlan	Displays the ARP entries of the specified subvlan
	<i>subvlan-number</i>	Subvlan ID
	min-max	Displays the minimum and maximum subvlan ID
	<i>min_value</i>	Minimum subvlan ID
	<i>max_value</i>]	Maximum subvlan ID.

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide Use this command to display the ARP details, such as the ARP type (Dynamic, Static, Local, Trust), the information on the layer2 port.
If you enter a *min_value* greater than *max_value*, no error message is prompted. Instead, ARP entries corresponding to the subvlan are displayed.

Configuration Examples The following example displays the output result of the **show arp detail** command:

```
Orion_B54Q# show arp detail
IP Address MAC Address Type Age(min) Interface Port
20.1.1.1 000f.e200.0001 Static -- -- --
20.1.1.1 000f.e200.0001 Static -- V13 --
20.1.1.1 000f.e200.0001 Static -- V13 Gi2/0/1
193.1.1.70 00e0.fe50.6503 Dynamic 1 V13 Gi2/0/1
192.168.0.1 0012.a990.2241 Dynamic 10 Gi2/0/3 Gi2/0/3
192.168.0.1 0012.a990.2241 Dynamic 20 Ag1 Ag1
192.168.0.1 0012.a990.2241 Dynamic 30 V12 Ag2
192.168.0.39 0012.a990.2241 Local -- V13 --
192.168.0.39 0012.a990.2241 Local -- Gi2/0/3 --
192.168.0.1 0012.a990.2241 Local -- V13 --
```

```
192.168.0.1 0012.a990.2241 Local -- Gi2/3/2 --
```

The meaning of each field in the ARP cache table is described as below:

Table 1 Fields in the ARP cache table

Field	Description
IP Address	IP address corresponding to the hardware address
MAC Address	hardware address corresponding to the IP address
Age (min)	Age of the ARP learning, in minutes
Port	Layer2 port associated with the ARP
Type	ARP type, includes the Static, Dynamic, Trust,Local
Interface	Layer 3 interface associated with the IP addresses
Subvlan	Subvlan corresponding to the ARP entries

Related Commands	Command	Description
	N/A	N/A

Platform N/A

Description

2.23 show arp packet statistics

Use this command to display the statistics of ARP packets.

show arp packet statistics [*interface-name*]

Parameter	Parameter	Description
Description	<i>interface-name</i>	Displays the statistics of ARP packets on the specified interface.

Defaults N/A.

Command Mode Privileged EXEC mode.

Usage Guide N/A.

Configuration The following example displays the output information of the command.

Examples

```
Orion_B54Q# show arp packet statistics
Interface Received Received Received Sent Sent
Name Requests Replies Others Requests Replies
-----
```

```
VLAN 1 10 20 1 50 10
VLAN 2 5 8 0 10 10
VLAN 3 20 5 0 15 12
VLAN 4 5 8 0 10 10
VLAN 5 20 5 0 15 12
VLAN 6 20 5 0 15 12
VLAN 7 20 5 0 15 12
VLAN 8 5 8 0 10 10
VLAN 9 20 5 0 15 12
VLAN 10 20 5 0 15 12
VLAN 11 20 5 0 15 12
VLAN 12 20 5 0 15 12
```

Description of fields:

Field	description
Received Requests	Number of received ARP requests
Received Replies	Number of received ARP response messages
Received Others	Number of other received ARP packets
Sent Requests	Number of sent ARP requests
Sent Replies	Number of sent ARP requests

**Related
Commands**

Command	Description
N/A.	N/A.

**Platform
Description**

N/A

2.24 show arp timeout

Use this command to display the aging time of a dynamic ARP entry on the interface.

show arp timeout

**Parameter
Description**

Parameter	Description
N/A.	N/A.

Defaults

N/A.

**Command
Mode**

Privileged EXEC mode

Usage Guide

N/A.

Configuration The following example displays the output of the **show arp timeout** command:

Examples

```
Orion_B54Q# show arp timeout
Interface arp timeout(sec)
-----
VLAN 1 3600
```

The meaning of each field in the ARP cache table is described in Table 1.

Related Commands

Command	Description
N/A.	N/A.

Platform Description

N/A

2.25 show ip arp

Use this command to display the Address Resolution Protocol (ARP) cache table.

show ip arp

Parameter Description

Parameter	Description
N/A.	N/A.

Defaults

N/A.

Command Mode

Privileged EXEC mode.

Usage Guide

N/A.

Configuration Examples The following example displays the output of **show ip arp**:

Examples

```
Orion_B54Q# show ip arp
Protocol Address Age(min) Hardware Type Interface
Internet 192.168.7.233 23 0007.e9d9.0488 ARPA FastEthernet 0/0
Internet 192.168.7.112 10 0050.eb08.6617 ARPA FastEthernet 0/0
Internet 192.168.7.79 12 00d0.f808.3d5c ARPA FastEthernet 0/0
Internet 192.168.7.1 50 00d0.f84e.1c7f ARPA FastEthernet 0/0
Internet 192.168.7.215 36 00d0.f80d.1090 ARPA FastEthernet 0/0
Internet 192.168.7.127 0 0060.97bd.ebee ARPA FastEthernet 0/0
Internet 192.168.7.195 57 0060.97bd.ef2d ARPA FastEthernet 0/0
Internet 192.168.7.183 -- 00d0.f8fb.108b ARPA FastEthernet 0/0
```

Each field in the ARP cache table has the following meanings:

Field	Description
Protocol	Network address protocol, always Internet.

Address	The IP address corresponding to the hardware address.
Age (min)	Age of the ARP cache record, in minutes; If it is not locally or statically configured, the value of the field is represented with "-".
Hardware	Hardware address corresponding to the IP address
Type	The type of hardware address. The value is ARPA for all Ethernet addresses.
Interface	Interface associated with the IP address.

Related Commands	Command	Description
	N/A.	N/A.

Platform N/A
Description

3 IPv6 Commands

3.1 clear ipv6 neighbors

Use this command to clear the dynamic IPv6 neighbors.

clear ipv6 neighbors [*vrf vrf-name*] [*oob*] [*interface-id*]

Parameter	Parameter	Description
Description	<i>vrf-name</i>	VRF name. All global IPv6 neighbors are cleared without specified VRF name by default.
	oob	Clears the dynamic IPv6 neighbors discovered by neighbors on MGMT interface.
	<i>interface-id</i>	Interface name. Clear the dynamically learned IPv6 neighbors on the specified interface.
Defaults	N/A	
Command Mode	Privileged EXEC mode.	
Usage Guide	This command does not clear all the dynamic neighbors on authentication VLAN. Note that the static neighbors will not be cleared.	
Configuration Examples	The following example clears the dynamic IPv6 neighbors. <pre>Orion_B54Q# clear ipv6 neighbors</pre>	
Related Commands	Command	Description
	ipv6 neighbor	Configures the neighbor.
	show ipv6 neighbors	Displays the neighbor information.
Platform Description	N/A	

3.2 ipv6 address

Use this command to configure an IPv6 address for a network interface. Use the **no** form of this command to restore the default setting.

ipv6 address ipv6-address/prefix-length

ipv6 address *ipv6-prefix/prefix-length eui-64*

ipv6 address *prefix-name sub-bits/prefix-length* [**eui-64**]

no ipv6 address
no ipv6 address *ipv6-address/prefix-length*
no ipv6 address *ipv6-prefix/prefix-length eui-64*
no ipv6 address *prefix-name sub-bits/prefix-length [eui-64]*

Parameter	Parameter	Description
Description	<i>iipv6-prefix</i>	IPv6 address prefix in the format defined in RFC4291. The address shall be in hex; the fields in the address shall be separated by comma, and each field shall contain 16 bits.
	<i>ipv6-address</i>	IPv6 address in the format defined in RFC4291. The address shall be in hex; the fields in the address shall be separated by comma, and each field shall contain 16 bits.
	<i>prefix-length</i>	Length of the IPv6 prefix, the network address of the IPv6 address. Note: The prefix length range of the IPv6 address of the interface of S86 is 0 to 64 or 128 to 128.
	<i>prefix-name</i>	The general prefix name. Use the specified general prefix to generate the interface address.
	<i>sub-bits</i>	The value of the sub-prefix bit and the host bit generates the interface address combining with the general prefix. The value shall be in the format defined in the RFC4291.
	eui-64	The generated IPV6 address consists of the address prefix and the 64 bit interface ID

Defaults N/A

Command Mode Interface configuration mode

Usage Guide When an IPv6 interface is created and the link status is UP, the system will automatically generate a local IP address for the interface.

The IPv6 address could also be generated using the general prefix. That is, the IPv6 address consists of the general prefix and the sub-prefix and the host bit. The general prefix could be configured using the **ipv6 general-prefix** command or may be learned through the DHCPv6 agent PD (Prefix Discovery) function (please refer to the *DHCPv6 Configuration*). Use the *sub-bits/prefix-length* parameter of this command to configure the sub-prefix and the host bit.

If no deleted address is specified when using **no ipv6 address**, all the manually configured addresses will be deleted.

no ipv6 address *ipv6-prefix/prefix-length eui-64* can be used to delete the addresses configured with **ipv6 address** *ipv6-prefix/prefix-length eui-64*.

1.

```

Configuratio Orion_B54Q(config-if)# ipv6 address 2001:1::1/64
n Examples Orion_B54Q(config-if)# no ipv6 address 2001:1::1/64
Orion_B54Q(config-if)# ipv6 address 2002:1::1/64 eui-64
Orion_B54Q(config-if)# no ipv6 address 2002:1::1/64 eui-64
    
```

Related	Command	Description
Commands	N/A	N/A

Platform N/A
Description

3.3 ipv6 address autoconfig

Use this command to automatically configure an IPv6 stateless address for a network interface. Use the **no** form of this command to restore the default setting.

ipv6 address autoconfig [default]
no ipv6 address autoconfig

Parameter	Parameter	Description
Description	default	(Optional) If this keyword is configured, a default routing is generated. Note that only one layer3 interface on the entire device is allowed to use the default keyword

Defaults N/A

Command Mode Interface configuration mode

Usage Guide The stateless automatic address configuration is that when receiving the RA (Route Advertisement) message, the device could use the prefix information of the RA message to automatically generate the EUI-64 interface address.

If the RA message contains the flag of the “other configurations”, the interface will obtain these “other configurations” through the DHCPv6. The “other configurations” usually means the IPv6 address of the DNS server, the IPv6 address of the NTP server, etc.

Use the **no ipv6 address autoconfig** command to delete the IPv6 address.

```

Configuratio Orion_B54Q(config-if)# ipv6 address autoconfig default
n Examples Orion_B54Q(config-if)# no ipv6 address autoconfig
    
```

Related	Command	Description
Commands	ipv6 address ipv6-prefix/prefix-length [eui-64]	Configures the IPv6 address for the interface manually.

Platform N/A
Description

3.4 IPv6 icmp error-interval

Use this command to set the frequency with which ICMPv6-oversize error packets are sent. Use the **no** form of this command to restore the default setting.

ipv6 icmp error-interval too-big *milliseconds* [*bucket-size*]

no ipv6 icmp error-interval too-big *milliseconds* [*bucket-size*]

Use this command to set the frequency with which other ICMPv6 error packets are sent. Use the **no** form of this command to restore the default setting.

ipv6 icmp error-interval *milliseconds* [*bucket-size*]

no ipv6 icmp error-interval *milliseconds* [*bucket-size*]

Parameter	Parameter	Description
Description	<i>milliseconds</i>	Sets the refresh interval of the token bucket, in the range from 0 to 2147483647 in the unit of seconds. Setting the value to 0 indicates that the frequency with which ICMPv6 error packets are sent is not fixed.
	<i>bucket-size</i>	Sets the number of tokens in the token bucket, in the range from 1 to 200.

Defaults The default *milliseconds* is 100 and *bucket-size* is 10.

Command Mode Global configuration mode

Usage Guide The token bucket algorithm is adopted to set the frequency with which ICMPv6 error packets are sent so as to prevent Denial of Service (DoS) attack, If the forwarded IPv6 packet is greater than the egress IPv6 MTU in size, the router discards the IPv6 packet and sends the ICMPv6-oversize error packet to the source IPv6 address. This kind of ICMPv6 error packet is used for IPv6 path MTU discovery. If there are too many ICMPv6 error packets, the ICMPv6-oversize error packet may not be sent, causing IPv6 path MTU discovery failure. Therefore, it is recommended to set the frequency of ICMPv6-oversize error packet and other ICMPv6 error packet respectively. Note that ICMPv6 redirect packet is not an ICMPv6 error packet and Orion_B54Q sets the frequency of the ICMPv6 redirect packet the same as that of other ICMPv6 error packet.

For the timer is accurate to 10 milliseconds, it is recommended to set the refresh interval of the token bucket to an integer multiple of 10 milliseconds. If the refresh interval is not an integer multiple of 10 milliseconds, it is converted automatically. For example, the frequency of 1 per five milliseconds turns out to be 2 per 10 milliseconds; the frequency of 3 per 15 milliseconds is converted to 2 per 10 milliseconds.

Configuration Examples The following example sets the frequency with which ICMPv6-oversize error packets are sent to 100 per second.

```
Orion_B54Q(config)# ipv6 icmp error-interval too-big 1000 100
```

The following example sets the frequency with which other ICMPv6 error packets are sent to 10 per second.

```
Orion_B54Q(config)# ipv6 icmp error-interval 1000 10
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

3.5 ipv6 enable

Use this command to enable the IPv6 function on an interface. Use the **no** form of this command to restore the default setting.

ipv6 enable
no ipv6 enable

Parameter Description	Parameter	Description
	N/A	N/A

Defaults This function is disabled by default.

Command Mode Interface configuration mode

Usage Guide The IPv6 function of an interface can be enabled by configuring **ipv6 enable** or by configuring IPv6 address for the interface.

- ✔ If an IPv6 address is configured for the interface, the IPv6 function will be enabled automatically on the interface and cannot be disabled with **no ipv6 enable**.

Configuration Examples Orion_B54Q(config-if)# **ipv6 enable**

Related Commands	Command	Description
	show ipv6 interface	Displays the related information of an interface.

Platform Description N/A

3.6 Ipv6 gateway

Use this command to configure the default gateway IPv6 address on the management port.

ipv6 gateway *ipv6-address*

Parameter	Parameter	Description
Description	<i>ipv6-address</i>	Configures the default gateway IPv6 address.
Defaults	N/A	
Command Mode	Interface configuration mode	
Usage Guide	The management port is MGMT in type and 0 in ID.	
Configuration Examples	<p>The following example configures the default gateway IPv6 address on the management port.</p> <pre>Orion_B54Q(config)# interface mgmt 0 Orion_B54Q(config-int)# ipv6 gateway 2001:1::1 Orion_B54Q(config-int)# exit Orion_B54Q(config)#</pre>	
Related Commands	Command	Description
	N/A	N/A

Platform N/A
Description

3.7 ipv6 general-prefix

Use this command to configure the IPv6 general prefix in the global configuration mode.

ipv6 general-prefix *prefix-name ipv6-prefix/prefix-length*

no ipv6 general-prefix *prefix-name ipv6-prefix/prefix-length*

Parameter	Parameter	Description
Description	<i>prefix-name</i>	The general prefix name.
	<i>pv6-prefix</i>	The network prefix value of the general-prefix following the format defined in RFC4291.
	<i>prefix-length</i>	The length of the general prefix.

Defaults N/A

Command Global configuration mode.

Mode

Usage Guide It is convenient to number the network by using the general prefix, which defines a prefix so that many longer specified prefixes could refer to it. These specified prefixes are updated whenever the general prefix changes. If the network number changes, just modify the general prefix. A general prefix could contain multiple prefixes. These longer specified prefixes are usually used for the Ipv6 address configuration on the interface.

Configuration Examples The following example configures manually a general prefix as my-prefix.

```
Orion_B54Q(config)# ipv6 general-prefix my-prefix 2001:1111:2222::/48
```

Related Commands	Command	Description
	ipv6 address prefix-name sub-bits/prefix-length	Configures the interface address using the general prefix.
	show ipv6 general-prefix	Displays the general prefix.

Platform N/A
Description

3.8 ipv6 hop-limit

Use this command to configure the default hopcount to send unicast messages in the global configuration mode.

ipv6 hop-limit value
no ipv6 hop-limit

Parameter Description	Parameter	Description
	N/A	N/A

Defaults The default is 64.

Command Mode Global configuration mode.

Usage Guide This command takes effect for the unicast messages only, not for multicast messages.

Configuration Examples

```
Orion_B54Q(config)# ipv6 hop-limit 100
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A

Description

3.9 ipv6 mtu

Use this command to configure the MTU of IPv6 packets. Use the **no** form of this command to restore the default setting.

ipv6 mtu *bytes*
no ipv6 mtu

Parameter	Parameter	Description
Description	<i>bytes</i>	MTU of IPv6 packets, in bytes. The value ranges from 1280 to 1500.

Defaults The default configuration is the same as the configuration of the **mtu** command.

Command Mode Interface configuration mode

Usage Guide If the size of an IPv6 packet exceeds the IPv6 MTU, the NOS software segments the packet. For all devices in the same physical network segment, the IPv6 MTU of the interconnected interface must be the same.

Configuration Examples The following example sets the IPv6 MTU of the FastEthernet 0/1 interface to 1400 bytes.

```
Orion_B54Q(config)# interface fastEthernet 0/1
Orion_B54Q(config-if)# ipv6 mtu 1400
```

Related Commands	Command	Description
	mtu	Sets the MTU of an interface.

Platform Description This command cannot be used on Layer 2 devices.

3.10 ipv6 nd cache interface-limit

Use this command to set the maximum number of neighbors learned on the interface. Use the **no** form of this command to restore the default setting.

ipv6 nd cache interface-limit *value*
no ipv6 nd cache interface-limit

Parameter	Parameter	Description
Description	<i>value</i>	Sets the maximum number of neighbors learned on the interface, including the static and dynamic neighbors, in the range from 0 to the number

	supported by the device. 0 indicates the number is not limited.
--	---

Defaults The default is 0.

Command Mode Interface configuration mode

Usage Guide This function can prevent neighbor entries generated by malicious neighbor attacks from consuming memory. *limit* must be no smaller than the number of neighbors learned on the interface. Otherwise, the configuration does not take effect.

Configuration Examples The following example sets the number of neighbors learned on the interface to 100.

```
Orion_B54Q(config)# interface GigabitEthernet 0/1
Orion_B54Q(config-if-GigabitEthernet 0/1)# ipv6 nd cache interface-limit
100
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

3.11 ipv6 nd dad attempts

Use this command to set the number of the NS packets to be continuously sent for IPv6 address collision check on the interface. Use the **no** form of this command to restore it to the default setting.

ipv6 nd dad attempts *value*
no ipv6 nd dad attempts *value*

Parameter Description	Parameter	Description
	<i>value</i>	Number of the NS packets. If it is set to 0, it indicates that the IPv6 address collision check is disabled on the interface. The range is 0 to 600.

Defaults The default is 1.

Command Mode Interface configuration mode.

Usage Guide When the interface is configured with a new IPv6 address, the address collision shall be checked before the address is assigned to the interface, and the address shall be in the "tentative" status. After the address collision check is completed, if no collision is detected, the address can be used

normally; if collision is detected and the interface ID of the address is an EUI-64 ID, it indicates that the link-layer address is repeated, and the system will automatically shut down the interface (that is, to prohibit IPv6 operations on the interface). In this case, you shall modify and configure a new address manually, and restart address collision check for the **down/up** interface. Whenever the state of an interface changes from **down** to **up**, the address collision check function of the interface will be enabled.

Configuration Examples

```
Orion_B54Q(config-if)# ipv6 nd dad attempts 3
```

Related Commands

Command	Description
show ipv6 interface	Displays the interface information.

Platform Description

N/A

3.12 ipv6 nd dad retry

Use this command to set the interval for address conflict detection. Use the **no** form of this command to restore the default setting.

ipv6 nd dad retry *value*
no ipv6 nd dad retry

Parameter Description

Parameter	Description
<i>value</i>	Sets the interval for address conflict detection, 60 seconds by default. Setting <i>value</i> to 0 indicates that the function is disabled.

Defaults

N/A

Command Mode

Global configuration mode

Usage Guide

Before configuring a new IPv6 address for an interface, enable address conflict detection on the interface. If a conflict address is detected, the device does not receive the IPv6 packet destined to the conflict address. This command is used to perform conflict detection again when the interval expires. If there is no conflict, the address can be used.

Configuration Examples

The following example sets the interval for address conflict detection to 10s.

```
Orion_B54Q(config)# ipv6 nd dad retry 10
```

Related Commands

Command	Description
N/A	N/A

Platform N/A
Description

3.13 ipv6 nd managed-config-flag

Use this command to set the “managed address configuration” flag bit of the RA message. Use the **no** form of this command to restore the default setting.

ipv6 nd managed-config-flag
no ipv6 nd managed-config-flag

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command

Mode Interface configuration mode.

Usage Guide This flag determines whether the host that receives the RA message obtains an IP address through stateful auto configuration. If the flag is set, the host obtains an IP address through stateful auto configuration, otherwise it does not be used.

Configuration Examples

```
Orion_B54Q(config-if)# ipv6 nd managed-config-flag
```

Related Commands	Command	Description
	show ipv6 interface	Displays the interface information.
	ipv6 nd other-config-flag	Sets the flag for obtaining all information except IP address through stateful auto configuration.

Platform N/A
Description

3.14 ipv6 nd ns-interval

Use this command to set the interval for the interface to retransmitting NS (Neighbor Solicitation). Use the **no** form of this command to restore the default setting.

ipv6 nd ns-interval milliseconds
no ipv6 nd ns-interval

Parameter	Parameter	Description
-----------	-----------	-------------

Description	<i>milliseconds</i>	Interval for retransmitting NS in the range of 1000 to 429467295 milliseconds				
Defaults	The default value in RA is 0 (unspecified); the interval for retransmitting NS is 1000 milliseconds (1 second).					
Command mode	Interface configuration mode.					
Usage Guide	The configured value will be advertised through RA and will be used by the device itself. It is not recommended to set a too short interval.					
Configuration Examples	<pre>Orion_B54Q(conifig-if)# ipv6 nd ns-interval 2000</pre>					
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>show ipv6 interface</td> <td>Displays the interface information.</td> </tr> </tbody> </table>	Command	Description	show ipv6 interface	Displays the interface information.	
Command	Description					
show ipv6 interface	Displays the interface information.					
Platform Description	N/A					

3.15 ipv6 nd other-config-flag

Use this command to set “other stateful configuration” flag bit of the RA message. Use the **no** form of this command to delete the flag bit.

ipv6 nd other-config-flag
no ipv6 nd other-config-flag

Parameter Description	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>N/A</td> <td>N/A</td> </tr> </tbody> </table>	Parameter	Description	N/A	N/A
Parameter	Description				
N/A	N/A				
Defaults	The flag bit is not set by default.				
Command mode	Interface configuration mode.				
Usage Guide	With this flag bit set, the flag bit of the RA message sent by the device is set. After receiving this flag bit, the host uses the dhcpv6 to acquire the information excluding the IPv6 address for the purpose of automatic configuration. When the managed address configuration is set, the default other stateful configuration is also set				
Configuration Examples	<pre>Orion_B54Q(config-if)# ipv6 nd other-config-flag</pre>				

Related	Command	Description
Commands	show ipv6 interface	Displays the interface information.

Platform N/A
Description

3.16 ipv6 nd prefix

Use this command to configure the address prefix included in the RA. Use the **no** form of this command to delete the set prefix or restore the default setting.

ipv6 nd prefix { *ipv6-prefix/prefix-length* | **default** } [[*valid-lifetime preferred-lifetime*]] [**at valid-date preferred-date**] | [**infinite** | *preferred-lifetime*]] [**no-advertise**] [[**off-link**] [**no-autoconfig**]]
no ipv6 nd prefix { *ipv6-prefix/prefix-length* | **default** } [[**off-link**] [**no-autoconfig**]] [**no-advertise**]]

Parameter	Parameter	Description
Description	<i>ipv6-prefix</i>	IPv6 network ID following the format defined in RFC4291
	<i>prefix-length</i>	Length of the IPv6 prefix. "/" shall be added in front of the prefix
	<i>valid-lifetime</i>	Valid lifetime of the RA prefix received by the host
	<i>preferred-lifetime</i>	Preferred lifetime of the RA prefix received by the host
	<i>at valid-date preferred-date</i>	Sets the dead line for the valid lifetime and that of the preferred lifetime, in day, month, year, hour, minute.
	infinite	Indicates that the prefix is always valid.
	default	Sets the default prefix.
	no-advertise	The prefix will not be advertised by the device.
	off-link	When the host sends an IPv6 packet, if the prefix of the destination address matches the set prefix, it is considered that the destination is on-link and is directly reachable. If this option is set, it indicates that the prefix is not used for on-link judgment.
no-autoconfig	Indicates that the RA prefix received by the host cannot be used for auto address configuration.	

Defaults By default, the advertised prefix is the one set with **ipv6 address** on the interface. The default parameters of the prefix configured in the RA are as follows:

valid-lifetime: 2592000s (30 days)

preferred-lifetime: 604800s (7 days),

The prefix is advertised and is used for on-link judgment and auto address configuration.

Command Interface configuration mode.
Mode

Usage Guide This command can be used to configure the parameters of each prefix, including whether to advertise the prefix. By default, the prefix advertised in RA is the one set with **ipv6 address** on the

interface. To add other prefixes, use this command.

ipv6 nd prefix default

Set the default parameters to be used by the interface. If no parameter is specified for an added prefix, the parameters set with **ipv6 nd prefix default** will be used. Note that after a parameter is specified for the prefix, the default configuration will not be used. That is to say, the configuration of the prefix cannot be modified with **ipv6 nd prefix default**; only the prefix that uses all the default configurations can be modified with this command.

at valid-date preferred-date

The valid lifetime of a prefix can be specified in two ways. One way is to specify a fixed time for each prefix in the RA; the other way is to specify the end time (in this mode, the valid lifetime of the prefix sent in RA will be gradually reduced until the end time is 0).

Configuration The following example adds a prefix for SVI 1.

```
Orion_B54Q(config)# interface vlan 1
Orion_B54Q(config-if)# ipv6 nd prefix 2001::/64 infinite 2592000
```

The following example sets the default prefix parameters for SVI 1 (they cannot be used for auto address configuration):

```
Orion_B54Q(config)# interface vlan 1
Orion_B54Q(config-if)# ipv6 prefix default no-autoconfig
```

If no parameter is specified, the default parameters will be used, and the prefix cannot be used for auto address configuration.

Related	Command	Description
Commands	show ipv6 interface	Displays the RA information of an interface.

Platform N/A
Description

3.17 ipv6 nd ra-hoplimit

Use this command to set the hopcount of the RA message. Use the **no** form of this command to restore the default setting.

ipv6 nd ra-hoplimit value
no ipv6 nd ra-hoplimit

Parameter	Parameter	Description
Description	<i>value</i>	Hopcount

Defaults The default is 64.

Command Mode Interface configuration mode.

Usage Guide This command is used to set the hopcount of the RA message.

Configuration Examples

```
Orion_B54Q(config -if)# ipv6 nd ra-hoplimit 110
```

Related Commands	Command	Description
	show ipv6 interface	Displays the interface information.
	ipv6 nd ra-lifetime	Sets the lifetime of the device.
	ipv6 nd ra-interval	Sets the interval of sending the RA message.
	ipv6 nd ra-mtu	Sets the MTU of the RA message.

Platform Description N/A

3.18 ipv6 nd ra-interval

Use this command to set the interval of sending the RA. Use the **no** form of this command to restore the default setting.

ipv6 nd ra-interval { *seconds* | **min-max** *min_value* *max_value* }

no ipv6 nd ra-interval

Parameter Description	Parameter	Description
	<i>seconds</i>	Interval of sending the RA message in seconds, 3-1800s.
	min-max	Maximum and minimum interval sending the RA message in seconds
	<i>min_value</i>	Minimum interval sending the RA message in seconds
	<i>max_value</i>	Maximum interval sending the RA message in seconds

Defaults 200s. The actual interval of sending the RA message will be fluctuated 20% based on 200s.

Command Mode Interface configuration mode.

Usage Guide If the device serves as the default device, the set interval shall not be longer than the lifetime of the device. Besides, to ensure other devices along the link occupies network bandwidth while sending the RA message, the actual interval for sending the RA message will be fluctuated 20% based on the set value.

If the key word **min-max** is specified, the actual interval for sending the packet will be chosen between the range of minimum value and maximum value.

Configuration Examples

```
Orion_B54Q(config-if)# ipv6 nd ra-interval 110
Orion_B54Q(config-if)# ipv6 nd ra-interval min-max 110 120
```

Related Commands	Command	Description
	show ipv6 interface	Displays the interface information.
	ipv6 nd ra-lifetime	Sets the lifetime of the device.
	ipv6 nd ra-hoplimit	Sets the hopcount of the RA message.
	ipv6 nd ra-mtu	Sets the MTU of the RA message.

Platform N/A
Description

3.19 ipv6 nd ra-lifetime

Use this command to set the device lifetime of the RA sent on the interface. Use the **no** form of this command to restore the default setting.

ipv6 nd ra-lifetime *seconds*
no ipv6 nd ra-lifetime

Parameter Description	Parameter	Description
	<i>seconds</i>	Default life time of the device on the interface, in the range from 0 to 9000 in the unit of seconds.

Defaults The default is 1800.

Command Mode Interface configuration mode.

Usage Guide The router lifetime field is available in each RA. It specifies the time during which the hosts along the link of the interface can select the device as the default device. If the value is set to 0, the device will not serve as the default device any longer. If it is not set to 0, it shall be larger than or equal to the interval of sending the RA (ra-interval)

Configuration Examples

```
Orion_B54Q(config-if)# ipv6 nd ra-lifetime 2000
```

Related Commands	Command	Description
	show ipv6 interface	Displays the interface information.
	ipv6 nd ra-interval	Sets the interval of sending the RA.
	ipv6 nd ra-hoplimit	Sets the hopcount of the RA.
	ipv6 nd ra-mtu	Sets the MTU of the RA.

Platform N/A
Description

3.20 ipv6 nd ra-mtu

Use this command to set the MTU of the RA message. Use the **no** form of this command to restore the default setting.

ipv6 nd ra-mtu *value*
no ipv6 nd ra-mtu

Parameter	Parameter	Description
Description	<i>value</i>	MTU value, in the range from 0 to 4294967295.

Defaults IPv6 MTU value of the network interface.

Command Mode Interface configuration mode.

Usage Guide If it is specified as 0, the RA will not have the MTU option

Configuration Examples

```
Orion_B54Q(config-if)# ipv6 nd ra-mtu 1400
```

Related Commands	Command	Description
	show ipv6 interface	Displays the interface information.
	ipv6 nd ra-lifetime	Sets the lifetime of the device.
	ipv6 nd ra-interval	Sets the interval of sending the RA message.
	ipv6 nd ra-hoplimit	Sets the hopcount of the RA message.

Platform N/A
Description

3.21 ipv6 nd reachable-time

Use this command to set the reachable time after the interface checks the reachability of the neighbor dynamically learned through NDP. Use the **no** form of this command to restore the default setting.

ipv6 nd reachable-time *milliseconds*
no ipv6 nd reachable-time

Parameter	Parameter	Description
Description	<i>milliseconds</i>	Reachable time for the neighbor in the range from 0 to 3600000 in the unit of

	milliseconds.
--	---------------

Defaults The default value in RA is 0 (unspecified); the reachable time for the neighbor is 30000 milliseconds (30 seconds) when the device discovers the neighbor.

Command Mode Interface configuration mode.

Usage Guide The device checks the unreachable neighbor through the set time. A shorter time means that the device can check the neighbor failure more quickly, but more network bandwidth and device resource will be occupied. Therefore, it is not recommended to set a too short reachable time. The configured value will be advertised through RA and will be used by the device itself. If the value is set to 0, it indicates that the time is not specified, that is, the default value is used. According to RFC4861, the actual time to reach neighbor is not consistent with the configured value, ranging from 0.5*configured value to 1.5*configured value.

Configuration Examples

```
Orion_B54Q(config-if)# ipv6 nd reachable-time 1000000
```

Related Commands	Command	Description
	show ipv6 interface	Displays the interface information.

Platform Description N/A

3.22 ipv6 nd state-time

Use this command to set the period for the neighbor to maintain the state. Use the **no** form of this command to restore the default setting.

ipv6 nd stale-time seconds
no ipv6 nd stale-time

Parameter Description	Parameter	Description
	<i>Seconds</i>	Sets the period for the neighbor to maintain the state, in the range from 0 to 86400 in the unit of seconds.

Defaults The default is 3600.

Command Mode Global configuration mode

Usage Guide This command is used to set the period for the neighbor to maintain the state. After the period expires, neighbor unreachability detection is performed. The shorter the period, the faster the

neighbor is found unreachable. On the other hand, more network bandwidth and device resources are consumed. Therefore, it is recommended to set a value not too small.

Configuration Examples The following example sets the period to 600 seconds for the neighbor to maintain the state.

```
Orion_B54Q(config)# ipv6 nd stale-time 600
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

3.23 ipv6 nd suppress-auth-vlan-ns

Use this command to disable the SVI interface from sending the NS packet to the authentication VLAN. Use the **no** form of this command to disable this function.

ipv6 nd suppress-auth-vlan-ns

no ipv6 nd suppress-auth-vlan-ns

Parameter Description	Parameter	Description
	N/A	N/A

Defaults This function is enabled by default.

Command Mode Interface configuration mode

Usage Guide This command is supported on the SVI interface in gateway authentication mode.

Configuration Examples The following example enables VLAN 2 to send the NS packet to the authentication VLAN.

```
Orion_B54Q(config-if-VLAN 2)# no ipv6 nd suppress-auth-vlan-ns
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

3.24 ipv6 nd suppress-ra

Use this command to disable the interface from sending the RA message. Use the **no** form of this command to enable the function.

ipv6 nd suppress-ra
no ipv6 nd suppress-ra

Parameter	Parameter	Description
Description	N/A	N/A

Defaults The **ipv6 nd suppress-ra** command is enabled by default.

Command Mode Interface configuration mode.

Usage Guide This command suppresses the sending of the RA message on an interface.

Configuration Examples

```
Orion_B54Q(config-if)# ipv6 nd suppress-ra
```

Related Commands	Command	Description
	show ipv6 interface	Displays the interface information.

Platform Description N/A

3.25 ipv6 nd unresolved

Use this command to set the maximum number of the unresolved neighbor table entries. Use the **no** form of this command to restore the default setting.

ipv6 nd unresolved *number*
no ipv6 nd unresolved

Parameter	Parameter	Description
Description	<i>number</i>	Sets the maximum number of the unresolved neighbor table entries, in the range from 1 to the neighbor table size supported by the device.

Defaults The default is 0. (The maximum number is the neighbor table size supported by the device)

Command Mode Global configuration mode

Usage Guide This command is used to prevent unresolved ND table entries generated by malicious scan attacks from consuming table entry resources,

Configuration The following example sets the maximum number of the unresolved neighbor table entries to 200.

n Examples `Orion_B54Q(config)# ipv6 nd unresolved 200`

Related Commands	Command	Description
	N/A	N/A

Platform N/A
Description

3.26 ipv6 neighbor

Use this command to configure a static neighbor. Use the **no** form of this command to delete a static neighbor.

ipv6 neighbor *ipv6-address interface-id hardware-address*

no ipv6 neighbor *ipv6-address interface-id*

Parameter Description	Parameter	Description
	<i>ipv6-address</i>	The neighbor IPv6 address, in the form as defined in RFC4291.
	<i>interface-id</i>	Specifies the network interface where the neighbor is (including Router Port, L3 AP port and SVI interface).
	<i>hardware-address</i>	The 48-bit MAC address, a dotted triple of four-digit hexadecimal numbers.

Defaults No static neighbor is configured by default.

Command Mode Global configuration mode

Usage Guide This command can only be configured on the interface enabled with IPv6 protocol, similar to the ARP command.

If the neighbor to be configured has been learned through Neighbor Discovery Protocol (NDP) and stored in the NDP neighbor table, the dynamic neighbor turns to be static. If the static neighbor is valid, it is always reachable. An invalid static neighbor refers to the neighbor whose IPv6 address is not valid (not in the IPv6 network segment configured for the interface or interface address conflict). The packet is not forwarded to the MAC address as specified by the invalid static neighbor. The invalid static neighbor is in inactive state. Use the `show ipv6 neighbor static` command to display the state of the static neighbor.

Use the **clear ipv6 neighbors** command to clear all neighbors learned dynamically through NDP.

Configuration Examples The following example configures a static neighbor on SVI 1.

n Examples `Orion_B54Q(config)# ipv6 neighbor 2001::1 vlan 1 00d0.f811.1111`

Related	Command	Description
---------	---------	-------------

Commands	N/A	N/A
-----------------	-----	-----

Platform N/A

Description

3.27 ipv6 ns-linklocal-src

Use this command to set the local address of the link as the source IP address to send neighbor requests. Use the **no** form of this command to use the global IP address as the source address to send neighbor requests.

ipv6 ns-linklocal-src

no ipv6 ns-linklocal-src

Parameter	Parameter	Description
Description	N/A	N/A

Defaults The local address of the link is always used as the source address to send neighbor requests.

Command Mode Global configuration mode.

Usage Guide N/A

Configuration Examples

```
Orion_B54Q(config)# no ipv6 ns-linklocal-src
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A

Description

3.28 ipv6 redirects

Use this command to control whether to send ICMPv6 redirect message when the switch receives and forwards an IPv6 packet through an interface. Use the **no** form of this command to restore the default setting.

ipv6 redirects

no ipv6 redirects

Parameter	Parameter	Description
Description	N/A	N/A

Defaults This function is enabled by default.

Command Mode Interface configuration mode.

Usage Guide The transmission rate of any ICMPv6 error message is limited. By default, it is 10pps.

Configuration Examples The following example enables ICMPv6 redirection on interface GigabitEthernet 0/1.

```
Orion_B54Q(config-if-GigabitEthernet 0/1)# ipv6 redirects
```

Related Commands	Command	Description
	show ipv6 interface	Displays the interface information.

Platform Description N/A

3.29 ipv6 source-route

Use this command to forward the IPv6 packet with route header. Use the **no** form of this command to restore the default setting.

ipv6 source-route
no ipv6 source-route

Parameter Description	Parameter	Description
	N/A	N/A

Defaults The **ipv6 source-route** command is disabled by default.

Command Mode Global configuration mode.

Usage Guide Because of the potential security of the header of type 0 route, it's easy for the device to suffer from the denial service attack. Therefore, forwarding the IPv6 packet with route header is disabled by default. However, the IPv6 packet of route header with type 0 that destined to the local machine is processed.

Configuration Examples

```
Orion_B54Q(config)# no ipv6 source-route
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A
Description

3.30 show ipv6 address

Use this command to display the IPv6 addresses.

show ipv6 address [*interface-name*]

Parameter	Parameter	Description
Description	<i>interface-name</i>	Interface name

Defaults N/A

Command Mode Privileged EXEC mode.

Usage Guide N/A

Configuration Examples The following example displays all IPv6 address configured on the device.

```
Ruijie#show ipv6 address
Global unicast address limit: 1024, Global unicast address count: 3
Tentative address count: 2,Duplicate address count: 1
Preferred address count: 3,Deprecated address count: 0
Gi 0/5
  FE80::1/64 Preferred
    Preferred lifetime: INFINITE, Valid lifetime: INFINITE
  1000::1/64 Duplicate
    Preferred lifetime: INFINITE, Valid lifetime: INFINITE
Gi 0/6
  FE80::1/64 Tentative
    Preferred lifetime: INFINITE, Valid lifetime: INFINITE
  1111:1111:1111:1111:1111:1111:1111:1111/64 Tentative
    Preferred lifetime: INFINITE, Valid lifetime: INFINITE
Gi 0/7
  FE80::1/64 Preferred
    Preferred lifetime: INFINITE, Valid lifetime: INFINITE
  2000:1111:1111:1111:1111:1111:1111:1111/64 Preferred
    Preferred lifetime: INFINITE, Valid lifetime: INFINITE
```

The following example displays the IPv6 address configured on the GigabitEthernet 0/1.

```
Ruijie#show ipv6 address Gi 0/5
Global unicast address count: 3
Tentative address count: 0,Duplicate address count: 1
Preferred address count: 1,Deprecated address count: 0
FE80::1/64 Preferred
Preferred lifetime: INFINITE, Valid lifetime: INFINITE
1000::1/64 Duplicate
Preferred lifetime: INFINITE, Valid lifetime: INFINITE
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A
Description

3.31 show ipv6 general-prefix

Use this command to display the information of the general prefix.

show ipv6 general-prefix

Parameter Description	Parameter	Description
	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode.

Usage Guide Use this command to display the information of the general prefix including the manually configured and learned from the DHCPv6 agent.

Configuration Examples

```
The following example displays the information of the general prefix.
Orion_B54Q# show ipv6 general-prefix
There is 1 general prefix.
IPv6 general prefix my-prefix, acquired via Manual configuration
2001:1111:2222::/48
2001:1111:3333::/48
```

Related Commands	Command	Description
	ipv6 general-prefix	Configures the general prefix.

Platform N/A
Description

3.32 show ipv6 interface

Use this command to display the IPv6 interface information.

show ipv6 interface [*interface-id*] [**ra-info**] [*brief* [*interface-id*]]

Parameter	Parameter	Description
Description	<i>interface-id</i>	Interface (including Ethernet interface, aggregate port, or SVI)
	ra-info	Displays the RA information of the interface.
	<i>brief</i>	Displays the brief information of the interface (interface status and address information).

Defaults N/A

Command Mode Privileged EXEC mode.

Usage Guide Use this command to display the address configuration, ND configuration and other information of an IPv6 interface.

Configuration Examples The following example displays the information of the IPv6 interface.

```
Orion_B54Q# show ipv6 interface vlan 1
Interface vlan 1 is Up, ifindex: 2001
address(es):
Mac Address: 00:00:00:00:00:01
INET6: fe80::200:ff:fe00:1 , subnet is fe80::/64
Joined group address(es):
ff01:1::1
ff02:1::1
ff02:1::2
ff02:1::1:ff00:1
INET6: 2001::1 , subnet is 2001::/64 [TENTATIVE]
Joined group address(es):
ff01:1::1
ff02:1::1
ff02:1::2
ff02:1::1:ff00:1
MTU is 1500 bytes
ICMP error messages limited to one every 10 milliseconds
ICMP redirects are enabled
ND DAD is enabled, number of DAD attempts: 1
ND reachable time is 30000 milliseconds
ND advertised reachable time is 0 milliseconds
ND retransmit interval is 1000 milliseconds
```

```
ND advertised retransmit interval is 0 milliseconds
ND router advertisements are sent every 200 seconds<240--160>
ND device advertisements live for 1800 seconds
```

The following line is included in the above information: 2001::1, subnet is 2001::/64 [TENTATIVE].
The flag bit in the [] following the INET6 address is explained as follows:

Flag	Meaning
ANYCAST	Indicate that the address is an anycast address.
TENTATIVE	Indicate that the DAD is underway. The address is a tentative before the DAD is completed.
DUPLICATED	Indicate that a duplicate address exists.
DEPRECATED	Indicate that the preferred lifetime of the address expires.
NODAD	Indicate that no DAD is implemented for the address.
AUTOIFID	Indicate that the interface ID of the address is automatically generated by the system, which is usually an EUI-64 ID.

```
The following example displays the RA information of the IPv6
interface.Orion_B54Q# show ipv6 interface vlan 1 ra-info
vlan 1: DOWN
RA timer is stopped
waits: 0, initcount: 3
statistics: RA(out/in/inconsistent): 4/0/0, RS(input): 0
Link-layer address: 00:00:00:00:00:01
Physical MTU: 1500
ND device advertisements live for 1800 seconds
ND device advertisements are sent every 200 seconds<240--160>
Flags: !M!O, Adv MTU: 1500
ND advertised reachable time is 0 milliseconds
ND advertised retransmit time is 0 milliseconds
ND advertised CurHopLimit is 64
Prefixes: (total: 1)
fec0:1:1:1::/64(Def,Auto,vltime: 2592000, pltime: 604800, flags: LA)
```

Description of the fields in **ra-info**:

Field	Meaning
RA timer is stopped (on)	Indicate whether the RA timer is started.
waits	Indicate that the RS is received but the number of the responses is not available.
initcount	Indicate the number of the RAs when the RA timer is restarted.

RA(out/in/ inconsistent)	<p>out: Indicate the number of the RAs that are sent.</p> <p>In: Indicate the number of the RAs that are received.</p> <p>inconsistent: Indicate the number of the received RAs in which the parameters are different from those contained in the RAs advertised by the device.</p>
RS(input)	Indicate the number of the RSs that are received.
Link-layer address	Link-layer address of the interface.
Physical MTU	Link MTU of the interface.
!M M	!M indicates the managed-config-flag bit in the RA is not set. M: Conversely
!O O	!O indicates the other-config-flag bit in the RA is not set. O: Conversely

Description of the fields of the prefix list in **ra-info**:

Field	Meaning
total	The number of the prefixes of the interface.
fec0:1:1:1::/64	A specific prefix.
Def	Indicate that the interfaces use the default prefix.
Auto CFG	Auto: Indicate the prefix is automatically generated after the interface is configured with the corresponding IPv6 address. CFG: Indicate that the prefix is manually configured.
!Adv	Indicate that the prefix will not be advertised.
vlttime	Valid lifetime of the prefix, measured in seconds.
pltime	Preferred lifetime of the prefix, measured in seconds.
L !L	L: Indicate that the on-link in the prefix is set. !L: Indicate that the on-link in the prefix is not set.
A !A	A: Indicate that the auto-configure in the prefix is set. !A: It indicates that the auto-configure in the prefix is not set.

The following example displays the brief information of the IPv6 interface.

```
Orion_B54Q#show ipv6 interface brief

GigabitEthernet 0/1          [down/down]
    2222::2
    FE80::1614:4BFF:FE5C:ED3A
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A

Description

3.33 show ipv6 neighbors

Use this command to display the IPv6 neighbors.

show ipv6 neighbors [*vrf vrf-name*] [**verbose**] [*interface-id*] [*ipv6-address*]

show ipv6 neighbors static

Parameter	Parameter	Description
Description	verbose	Displays the neighbor details.
	static	Displays the validity status of static neighbors.
	<i>vrf-name</i>	VRF name
	<i>interface-id</i>	Displays the neighbors of the specified interface.
	<i>ipv6-address</i>	Displays the neighbors of the specified IPv6 address.

Defaults N/A

Command Mode Privileged EXEC mode.

Usage Guide

Configuration Examples

```
The following example displays the neighbors on the SVI 1
interface:Orion_B54Q# show ipv6 neighbors vlan 1
IPv6 Address Linklayer Addr Interface
fa::1 00d0.0000.0002 vlan 1
fe80::200:ff:fe00:2 00d0.0000.0002 vlan 1
Show the neighbor details:
Orion_B54Q# show ipv6 neighbors verbose
IPv6 Address Linklayer Addr Interface
2001::1 00d0.f800.0001 vlan 1
State: Reach/H Age: - asked: 0
fe80::200:ff:fe00:1 00d0.f800.0001 vlan 1
State: Reach/H Age: - asked: 0
```

Field	Meaning
IPv6 Address	IPv6 address of the Neighbor
Linklayer Addr	Link address, namely, MAC address. If it is not available, incomplete is displayed.
Interface	Interface the neighbor locates.

State	<p>State of the neighbor: state/H(R)</p> <p>The values of STATE are as below:</p> <p>INCMP (Incomplete): The address resolution of the neighbor is underway, the NS is sent, but the NA is not received.</p> <p>REACH (Reachable): The switch is connected with the neighbor. In this state, the switch takes no additional action when sending packets to the neighbor.</p> <p>STALE: The reachable time of the neighbor expires. In this state, the switch takes no additional action; it only starts NUD (Neighbor Unreachability Detection) after a packet is sent to the neighbor.</p> <p>DELAY: A packet is sent to the neighbor in STALE state. If the STALE state changes to DELAY, DELAY will be changed to PROBE if no neighbor reachability notification is received within DELAY_FIRST_PROBE_TIME seconds (5s), the NS will be sent to the neighbor to start NUD.</p> <p>PROBE: The NUD is started to check the reachability of the neighbor. The NS packets are sent to the neighbor at the interval of RetransTimer milliseconds until the response from the neighbor is received or the number of the sent NSs hits MAX_UNICAST_SOLICIT(3).</p> <p>?: Unknown state.</p> <p>/R—indicate the neighbor is considered as a device</p> <p>/H: The neighbor is a host.</p>
Age	<p>The reachable time of the neighbor. '-' indicates that the neighbor is always reachable. Note that the reachability of a static neighbor depends on the actual situation. 'expired' indicates that the lifetime of the neighbor expires, and the neighbor is waits for the triggering of NUD.</p>
Asked	<p>The number of the NSs that are sent to the neighbor for the resolution of the link address of the neighbor.</p>

Related	Command	Description
Commands	ipv6 neighbor	Configures a neighbor.

Platform N/A
Description

3.34 show ipv6 neighbors statistics

Use the following commands to display the statistics of one IPv6 neighbors.

show ipv6 neighbors [vrf vrf-name] statistics

Use the following command to show the statistics of all IPv6 neighbors.

show ipv6 neighbors statistics all

Parameter	Parameter	Description
-----------	-----------	-------------

Description	<i>vrf-name</i>	VRF name
Defaults	N/A	
Command Mode	Privileged EXEC mode.	
Usage Guide	N/A	

Configuration Examples The following example displays the statistics of the global neighbors.

Configuration Examples

```
Ruijie#show ipv6 neighbors statistics
Memory: 1000 bytes
Entries: 10
  Static: 1,Dynamic: 9,Local: 0
  Incomplete:1, Reachable:5, Stale:1, Delay:1, Probe:1

Ruijie#show ipv6 neighbors statistics all
IPv6 neighbor table count: 2
Static neighbor count: 4(2 active, 2 inactive)
Total
  Memory: 2000 bytes
  Entries: 20
    Static: 2,Dynamic: 18,Local: 0
    Incomplete:2, Reachable:10, Stale:2, Delay:2, Probe:2

Global
  Memory: 1000 bytes
  Entries: 10
    Static: 1,Dynamic: 9,Local: 0
    Incomplete:1, Reachable:5, Stale:1, Delay:1, Probe:1

VRF1
  Memory: 1000 bytes
  Entries: 10
    Static: 1,Dynamic: 9,Local: 0
    Incomplete:1, Reachable:5, Stale:1, Delay:1, Probe:1
```

Related Commands	Command	Description
	N/A	N/A

Platform Description Supported on all platforms.

3.35 show ipv6 packet statistics

Use this command to display the statistics of IPv6 packets.

show ipv6 packet statistics [*total* | *interface-name*]

Parameter	Parameter	Description
Description	total	Displays total statistics of all interfaces.
	<i>interface-name</i>	Interface name

Defaults N/A

Command Mode Privileged EXEC mode.

Usage Guide N/A

Configuration Examples The following example displays the total statistics of the Ipv6 packets and the statistics of each interface.

```
Ruijie#show ipv6 packet statistics
Total
  Received 1000 packets, 1000000 bytes
    Unicast:1000,Multicast:0
  Discards:0
    HdrErrors:0 (HoplimitExceeded:0,Others:0)
  NoRoutes:0
  Others:0
  Sent 100 packets, 6000 bytes
    Unicast:50,Multicast:50

VLAN 1
  Received 1000 packets, 1000000 bytes
    Unicast:1000,Multicast:0
  Discards:0
    HdrErrors:0 (HoplimitExceeded:0,Others:0)
  NoRoutes:0
  Others:0
  Sent 100 packets, 6000 bytes
    Unicast:50,Multicast:50
```

The following example displays the total statistics of the Ipv6 packets.

```
Ruijie#show ipv6 packet statistics total
Received 1000 packets, 1000000 bytes
  Unicast:1000,Multicast:0
  Discards:0
    HdrErrors:0 (HoplimitExceeded:0,Others:0)
  NoRoutes:0
  Others:0
  Sent 100 packets, 6000 bytes
    Unicast:50,Multicast:50
```

Related Commands	Command	Description
	N/A	N/A

Platform Supported on all platforms.

Description

3.36 show ipv6 raw-socket

Use this command to display all IPv6 raw sockets.

show ipv6 raw-socket [*num*]

Parameter	Parameter	Description										
Description	<i>num</i>	Protocol.										
Defaults	N/A											
Command Mode	Privileged EXEC mode.											
Usage Guide	N/A											
Configuration Examples	<p>The following example displays all IPv6 raw sockets.</p> <pre> Orion_B54Q# show ipv6 raw-socket Number Protocol Process name 1 ICMPv6 vrrp.elf 2 ICMPv6 tcpip.elf 3 VRRP vrrp.elf Total: 3 </pre> <table border="1"> <thead> <tr> <th>Field</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Number</td> <td>Number.</td> </tr> <tr> <td>Protocol</td> <td>Protocol.</td> </tr> <tr> <td>Process name</td> <td>Process number.</td> </tr> <tr> <td>Total</td> <td>Total number of IPv6 raw sockets.</td> </tr> </tbody> </table>		Field	Description	Number	Number.	Protocol	Protocol.	Process name	Process number.	Total	Total number of IPv6 raw sockets.
Field	Description											
Number	Number.											
Protocol	Protocol.											
Process name	Process number.											
Total	Total number of IPv6 raw sockets.											
Related Commands	Command	Description										
	N/A	N/A										

Platform N/A
Description

3.37 show ipv6 routers

In the IPv6 network, some neighbor routers send out the advertisement messages. Use this command to display the neighbor routers and the advertisement.

show ipv6 routers [*interface-type interface-number*]

Parameter	Parameter	Description
Description	<i>interface-type interface-number</i>	(Optional) Displays the routing advertisement of the specified interface.

Defaults N/A

Command Mode Privileged EXEC mode.

Usage Guide Use this command to display the neighbor routers and the routing advertisement. If no interface is specified, all the routing advertisement of this device will be displayed.

Configuration Examples The following example displays the IPv6 router

```
Orion_B54Q# show ipv6 routers
Router FE80::2D0:F8FF:FEC1:C6E1 on VLAN 2, last update 62 sec
  Hops 64, Lifetime 1800 sec, ManagedFlag=0, OtherFlag=0, MTU=1500
  Preference=MEDIUM
  Reachable time 0 msec, Retransmit time 0 msec
  Prefix 6001:3::/64 onlink autoconfig
  Valid lifetime 2592000 sec, preferred lifetime 604800 sec
  Prefix 6001:2::/64 onlink autoconfig
```

Valid lifetime 2592000 seconds, preferred lifetime 604800 seconds

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

3.38 show ipv6 sockets

Use this command to display all IPv6 sockets.

show ipv6 sockets

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Privileged EXEC mode.

Mode

Usage Guide N/A

Configuration Examples The following example displays all IPv6 sockets.

```

Orion_B54Q# show ipv6 sockets
Number Process name      Type  Protocol  LocalIP:Port  ForeignIP:Port  State
1      vrrp.elf              RAW   ICMPv6    :::58         :::0             *
2      tcpip.elf             RAW   ICMPv6    :::58         :::0             *
3      vrrp.elf              RAW   VRRP      :::112        :::0             *
4      orion-snmpd           DGRAM UDP       :::161        :::0
*
5      orion-snmpd           DGRAM UDP       :::162        :::0
*
6      dhcp6.elf             DGRAM UDP       :::547        :::0             *
7      orion-sshd            STREAM TCP     :::22         :::0
LISTEN
8      orion-telnetd         STREAM TCP     :::23         :::0
LISTEN
Total: 8
    
```

Field	Description
Number	Number.
Process name	Process name.
Type	Socket type. RAW indicates the raw socket. DGRAM indicates data packet type. STREAM indicates traffic type.
Protocol	Protocol number
LocalIP:Port	Local IPv6 address and port.
ForeignIP:Port	Peer IPv6 address and port.
State	State (for IPv6 TCP sockets).
Total	Total number of sockets.

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

3.39 show ipv6 udp

Use this command to display all IPv6 UDP sockets.

show ipv6 udp [local-port num] [peer-port num]

Use this command to display IPv6 UDP socket statistics.

show ipv6 udp statistics

Parameter	Parameter	Description
Description	local-port num	Local port number.
	peer-port num	Peer port number.
Defaults	N/A	
Command Mode	Privileged EXEC mode	
Usage Guide	N/A	
Configuration Examples	The following example displays all IPv6 UDP sockets.	
	<pre> Orion_B54Q# show ipv6 udp Number Local Address Peer Address Process name 1 :::161 :::0 orion-snmpd 2 :::162 :::0 orion-snmpd 3 :::547 :::0 dhcp6.elf </pre>	
	Filed	Description
	Number	Number.
	Local Address	Local IPv6 address and port.
	Peer Address	Peer IPv6 address and port.
	Process name	Process name.
Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

4 DHCP Commands

4.1 address range

Use this command to specify the network segment range of the addresses that can be allocated by CLASS associated with DHCP address pool. Use the **no** form of this command to restore the default setting.

address range *low-ip-address high-ip-address*

no address range

Parameter	Parameter	Description
Description	<i>low-ip-address</i>	Start address in the network segment range.
	<i>high-ip-address</i>	End address in the network segment range.

Defaults By default, the associated CLASS is not configured with the network segment range. The default is the address pool range.

Command Mode Address pool CLASS configuration mode.

Usage Guide Each CLASS corresponds to one network range which must be from low address to high address, so as to allow the duplication of network segment range between multiple CLASSes. If the CLASS associated with the address pool is specified without configuring the corresponding network segment range, the default network segment range of this CLASS is same as the range of the address pool where this CLASS is.

Configuration Examples The following example configures the network segment of class1 associated with address pool mypool0 ranging from 172.16.1.1 to 172.16.1.8.

```
Orion_B54Q(config)# ip dhcp pool mypool0
Orion_B54Q(dhcp-config)# class class1
Orion_B54Q (config-dhcp-pool-class)# address range 172.16.1.1 172.16.1.8
```

Related Commands	Command	Description
	ip dhcp pool	Defines the name of the DHCP address pool and enters the DHCP address pool configuration mode.
	class	Configures the CLASS associated with the DHCP address pool and enters the address pool CLASS configuration mode.

Platform Description N/A

4.2 address-manage

Use this command to enter the address manage configuration mode.

address-manage

Parameter Description	Parameter	Description
	-	-

Defaults -

Command Mode Global configuration mode

Usage Guide It is server configuration, so supervlan should be applied.该

Configuration Example Enter the address manage configuration mode.

```
Orion_B54Q(config)#address-manage
```

Verification Run the **show run** command to check whether the configuration is successful.

4.3 bootfile

Use this command to define the startup mapping file name of the DHCP client. Use the **no** or **default** form of this command to restore the default setting.

bootfile file-name

no bootfile

default bootfile

Parameter Description	Parameter	Description
	<i>file-name</i>	Startup file name.

Defaults No startup file name is defined by default.

Command Mode DHCP address pool configuration mode

Usage Guide Some DHCP clients need to download the operating system and configure the file during the startup. The DHCP server should provide the mapping file name required for the startup, so that DHCP

clients can download the file from the corresponding server (such as TFTP). Other servers are defined by the **next-server** command.

Configuration Examples The following example defines the device.conf as the startup file name.

```
bootfile device.conf
```

Related Commands	Command	Description
	ip dhcp pool	Defines the name of the DHCP address pool and enter the DHCP address pool configuration mode.
	next-server	Configures the next server IP address of the DHCP client startup process.

Platform N/A
Description

4.4 class

Use this command to configure the associated CLASS in the DHCP address pool. Use the **no** form of this command to restore the default setting.

class *class-name*
no class

Parameter Description	Parameter	Description
	<i>class-name</i>	Class name, which can be the character string or numeric such as myclass or 1.

Defaults By default, no CLASS is associated with the address pool.

Command Mode DHCP address pool configuration mode

Usage Guide Each DHCP address pool performs the address assignment according to the Option82 matching information. We can divide this Option82 information into classes and specify the available network segment range for these classes in the DHCP address pool. These classes are called CLASS. One DHCP address pool can map to multiple CLASSes, and each CLASS can specify different network segment range.

During the address assignment, firstly, ensure the assignable address pool through the network segment where the client is, then according to the Option82 information further ensure the CLASS and assign the IP address from the network segment range corresponding to the CLASS. If one request packet matches multiple CLASSes in the address pool, perform the address assignment according to the sequencing of configuring the CLASS in the address pool. If this CLASS's assigned addresses have been to the upper limit, then continue to assign the address from the next CLASS, and so on. Each CLASS corresponds to one network segment range that must be from low addresses to high addresses and the duplicated network ranges between multiple CLASSes are

allowed. If the CLASS corresponding to the address pool is specified and the network segment corresponding to the CLASS is not configured, this CLASS's default network segment range is same as the range of address pool where the CLASS is.

Configuration Examples The following example configures the address *mypool0* to associate with class1.

```
Orion_B54Q(config)# ip dhcp pool mypool0
Orion_B54Q(dhcp-config)# class class1
```

Related Commands	Command	Description
	ip dhcp pool	Defines the name of the DHCP address pool and enters the DHCP address pool configuration mode.

Platform N/A

Description

4.5 clear ip dhcp binding

Use this command to clear the DHCP binding table in the privileged user mode.

```
clear ip dhcp binding { * | ip-address }
```

Parameter	Parameter	Description
Description	*	Deletes all DHCP bindings.
	<i>ip-address</i>	Deletes the binding of the specified IP addresses.

Defaults N/A.

Command Mode Privileged EXEC mode.

Usage Guide This command can only clear the automatic DHCP binding, but the manual DHCP binding can be deleted by the **no ip dhcp pool** command.

Configuration Examples The following example clears the DHCP binding with the IP address 192.168.12.100.

```
clear ip dhcp binding 192.168.12.100
```

Related Commands	Command	Description
	show ip dhcp binding	Displays the address binding of the DHCP server.

Platform N/A

Description

4.6 clear ip dhcp conflict

Use this command to clear the DHCP address conflict record.

clear ip dhcp conflict { * | *ip-address* }

Parameter	Parameter	Description
Description	*	Deletes all DHCP address conflict records.
	<i>ip-address</i>	Deletes the conflict record of the specified IP addresses.

Defaults N/A.

Command Mode Privileged EXEC mode.

Usage Guide The DHCP server uses the ping session to detect the address conflict, while the DHCP client uses the address resolution protocol (ARP) to detect the address conflict. The **clear ip dhcp conflict** command can be used to delete the history conflict record.

Configuration Examples The following example clears all address conflict records.

```
clear ip dhcp conflict *
```

Related Commands	Command	Description
	ip dhcp ping packets	Defines the number of the data packets sent by the ping operation for the detection of the address conflict when the DHCP server assigns an IP address.
	show ip dhcp conflict	Displays the address conflict that the DHCP server detects when it assigns an IP address.

Platform Description N/A

4.7 clear ip dhcp history

Use this command to clear the address assigned by the DHCP server.

clear ip dhcp history{ * | *mac-address* }

Parameter	Parameter	Description
Description	*	Clears all addresses assigned by the DHCP server.
	<i>mac-address</i>	Clears the address assigned by the DHCP server corresponding to the specified MAC address.

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide This command is configured on the DHCP server.

Configuration Examples The following example clears all addresses assigned by the DHCP server.

```
Orion_B54Q# clear ip dhcp history *
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

4.8 clear ip dhcp server rate

Use this command to clear statistics about the packet processing rate of every module.

clear ip dhcp server rate

Parameter Description	Parameter	Description
	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide This command is used to clear statistics about the packet processing rate of every module, including arp, hot backup, lsm, and socket.

Configuration Examples The following example clears statistics about the packet processing rate of every module.

```
Orion_B54Q# clear ip dhcp server rate
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

4.9 clear ip dhcp server statistics

Use this command to reset the counter of the DHCP server in the privileged user mode.

clear ip dhcp server statistics

Parameter	Parameter	Description
Description	N/A	N/A
Defaults	N/A	
Command Mode	Privileged EXEC mode.	
Usage Guide	The DHCP server carries out the statistics counter, records the DHCP address pool, automatic binding, manual binding and expired binding. Furthermore, it also carries out the statistics to the number of sent and received DHCP messages. The clear ip dhcp server statistics command can be used to delete the history counter record and carry out the statistics starting from scratch.	
Configuration Examples	The following example clears the statistics record of the DHCP server.	
	<pre>clear ip dhcp server statistics</pre>	
Related Commands	Command	Description
	show ip dhcp server statistics	Displays the statistics record of the DHCP server.
Platform Description	N/A	

4.10 clear ip dhcp relay statistics

Use this command to clear the DHCP relay statistics.

clear ip dhcp relay statistics

Parameter	Parameter	Description
Description	N/A	N/A
Defaults	N/A	
Command Mode	Privileged EXEC mode	
Usage Guide	The DHCP relay is configured with the counter to count various packets received or transmitted by the relay. This command is used to clear the counters.	

Configuration Examples The following example clears the DHCP relay statistics.

```
Orion_B54Q# clear ip dhcp relay statistics
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A

Description

4.11 client-identifier

Use this command to define the unique ID of the DHCP client (indicated in hex, separated by dot) in the DHCP address pool configuration mode. Use the **no** form of this command to restore the default setting.

client-identifier *unique-identifier*

no client-identifier

Parameter Description	Parameter	Description
	<i>unique-identifier</i>	The DHCP client ID is indicated in hex and separated by dot, for instance, 0100.d0f8.2233.b467.6967.6162.6974.4574.6865.726e.6574.302f.31.

Defaults N/A.

Command Mode DHCP address pool configuration mode.

Usage Guide When some DHCP clients request the DHCP server to assign IP addresses, they use their client IDs rather than their hardware addresses. The client ID consists of media type, MAC addresses and interface name. For instance, the MAC address is 00d0.f822.33b4, the interface name is GigabitEthernet 0/1, and the corresponding client ID is 0100.d0f8.2233.b467.6967.6162.6974.4574.6865.726e.6574.302f.31, where, 01 denotes the type of the Ethernet media.
The 67.6967.6162.6974.4574.6865.726e.6574.302f.31 is the hex code of GigabitEthernet0/1. For the definition of the media code, refer to the Address Resolution Protocol Parameters section in RFC1700. This command is used only when the DHCP is defined by manual binding.

Configuration Examples The following example defines the client ID of the Ethernet DHCP client whose MAC address is 00d0.f822.33b4.

```
client-identifier
0100.d0f8.2233.b467.6967.6162.6974.4574.6865.726e.6574.302f.31
```

Related Commands	Command	Description
	hardware-address	Defines the hardware address of DHCP client.
	host	Defines the IP address and network mask, which is used to configure the DHCP manual binding.
	ip dhcp pool	Defines the name of the DHCP address pool and enters the DHCP address pool configuration mode.

Platform N/A

Description

4.12 client-name

Use this command to define the name of the DHCP client in the DHCP address pool configuration mode. Use the **no** form of this command to restore the default setting.

client-name *client-name*

no client-name

Parameter Description	Parameter	Description
	client-name	Name of DHCP client, a set of standards-based ASCII characters. The name should not include the suffix domain name. For instance, you can define the name of the DHCP client as river, not river.i-net.com.

Defaults No client name is defined by default.

Command Mode DHCP address pool configuration mode.

Usage Guide This command can be used to define the name of the DHCP client only when the DHCP is defined by manual binding. This name should not include the suffix domain name.

Configuration Examples The following example defines a string river as the name of the client.

```
client-name river
```

Related Commands	Command	Description
	host	Defines the IP address and network mask, which is used to configure the DHCP manual binding.
	ip dhcp pool	Defines the name of the DHCP address pool and enters the DHCP address pool configuration mode.

Platform N/A

Description

4.13 default-router

Use this command to define the default gateway of the DHCP client in the DHCP address pool configuration mode. Use the **no** form of this command to restore the default setting.

default-router *ip-address* [*ip-address2...ip-address8*]
no default-router

Parameter	Parameter	Description
Description	<i>ip-address</i>	Defines the IP address of the equipment. It is required to configure one IP address at least.
	<i>ip-address2...ip-address8</i>	(Optional) Up to 8 gateways can be configured.

Defaults No gateway is defined by default.

Command Mode DHCP address pool configuration mode.

Usage Guide In general, the DHCP client should get the information of the default gateway from the DHCP server. The DHCP server should specify one gateway address for the client at least, and this address should be of the same network segment as the address assigned to the client.

Configuration Examples The following example defines 192.168.12.1 as the default gateway.

```
default-router 192.168.12.1
```

Related Commands	Command	Description
	ip dhcp pool	Defines the name of the DHCP address pool and enters the DHCP address pool configuration mode.

Platform Description N/A

4.14 dns-server

Use this command to define the DNS server of the DHCP client in the DHCP address pool configuration mode. Use the **no** form of this command to restore the default setting.

dns-server { *ip-address* [*ip-address2...ip-address8*] | **use-dhcp-client** *interface-type interface-number* }
no dns-server

Parameter	Parameter	Description
Description	<i>ip-address</i>	Defines the IP address of the DNS server. At least one IP address should be configured.

<i>ip-address2...ip-address8</i>	(Optional) Up to 8 DNS servers can be configured.
use-dhcp-client interface-type interface-number	Uses the DNS server learned by the DHCP client of the NOS software as the DNS server of the DHCP client.

Defaults No DNS server is defined by default.

Command Mode DHCP address pool configuration mode.

Usage Guide When more than one DNS server is defined, the former will possess higher priority, so the DHCP client will select the next DNS server only when its communication with the former DNS server fails. If the NOS software also acts as the DHCP client, the DNS server information obtained by the client can be transmitted to the DHCP client.

Configuration Examples The following example specifies the DNS server 192.168.12.3 for the DHCP client.

```
dns-server 192.168.12.3
```

Related Commands	Command	Description
	domain-name	Defines the suffix domain name of the DHCP client.
	ip address dhcp	Enables the DHCP client on the interface to obtain the IP address information.
	ip dhcp pool	Defines the name of the DHCP address pool and enters the DHCP address pool configuration mode.

Platform Description N/A

4.15 domain-name

Use this command to define the suffix domain name of the DHCP client in the DHCP address pool configuration mode. Use the **no** form of this command to restore the default setting.

domain-name *domain-name*
no domain-name

Parameter Description	Parameter	Description
	<i>domain-name</i>	Defines the suffix domain name string of the DHCP client.

Defaults No suffix domain name by default.

Command Mode DHCP address pool configuration mode.

Usage Guide After the DHCP client obtains specified suffix domain name, it can access a host with the same suffix

domain name by the host name directly.

Configuration Examples The following example defines the suffix domain name i-net.com for the DHCP client.

```
Orion_B54Q(dhcp-config)#domain-name Orion_B54Q.com
```

Related Commands	Command	Description
	dns-server	Defines the DNS server of the DHCP client.
	ip dhcp pool	Defines the name of the DHCP address pool and enter the DHCP address pool configuration mode.

Platform N/A

Description

4.16 hardware-address

Use this command to define the hardware address of the DHCP client in the DHCP address pool configuration mode. Use the **no** form of this command to restore the default setting.

hardware-address *hardware-address* [*type*]

no hardware-address

Parameter Description	Parameter	Description
	<i>hardware-address</i>	Define the MAC address of the DHCP client.
	<i>type</i>	To indicate the hardware platform protocol of the DHCP client, use the string definition or digits definition. String option: Ethernet ieee802 Digits option: 1 (10M Ethernet) 6 (IEEE 802)

Defaults No hardware address is defined by default.
If there is no option when the hardware address is defined, it is the Ethernet by default.

Command Mode DHCP address pool configuration mode.

Usage Guide This command can be used only when the DHCP is defined by manual binding.

Configuration Examples The following example defines the MAC address 00d0.f838.bf3d with the type ethernet.

```
hardware-address 00d0.f838.bf3d
```

Related	Command	Description
---------	---------	-------------

Commands	client-identifier	Defines the unique ID of the DHCP client (Indicated by the hexadecimal numeral, separated by dot).
	host	Defines the IP address and network mask, which is used to configure the DHCP manual binding.
	ip dhcp pool	Defines the name of the DHCP address pool and enter the DHCP address pool configuration mode.
	default-router	Defines the default route of the DHCP client.

Platform N/A
Description

4.17 host

Use this command to define the IP address and network mask of the DHCP client host in the DHCP address pool configuration mode. Use the **no** form of this command to restore the default setting.

host *ip-address* [*netmask*]
no host

Parameter	Parameter	Description
Description	<i>ip-address</i>	Defines the IP address of DHCP client.
	<i>netmask</i>	Defines the network mask of DHCP client.

Defaults No IP address or network mask of the host is defined.

Command Mode DHCP address pool configuration mode.

Usage Guide If the network mask is not defined definitely, the DHCP server will use the natural network mask of this IP address: 255.0.0.0 for class A IP address, 255.255.0 for class B IP address, and 255.255.255.0 for class C IP address.
This command can be used only when the DHCP is defined by manual binding.

Configuration Examples The following example sets the client IP address as 192.168.12.91, and the network mask as 255.255.255.240.

```
host 192.168.12.91 255.255.255.240
```

Related Commands	Command	Description
default-router	client-identifier	Defines the unique ID of the DHCP client (Indicated in hex and separated by dot).
	hardware-address	Defines the hardware address of DHCP client.
	ip dhcp pool	Defines the name of the DHCP address pool and enters the DHCP address pool configuration mode.
	Define the default route of the	default-router

DHCP client.	
--------------	--

Platform N/A

Description

4.18 ip address dhcp

Use this command to make the Ethernet interface or the PPP, HDLC and FR encapsulated interface obtain the IP address information by the DHCP in the interface configuration mode. Use the **no** form of this command to restore the default setting.

ip address dhcp

no ip address dhcp

Parameter	Parameter	Description
Description	N/A	N/A

Defaults The interface cannot obtain the IP address by the DHCP by default.

Command Interface configuration mode.

Mode

Usage Guide When requesting the IP address, the DHCP client of the NOS software also requires the DHCP server provide 5 configuration parameter information: 1) DHCP option 1, client subnet mask, 2) DHCP option 3, it is the same as the gateway information of the same subnet, 3) DHCP option 6, the DNS server information, 4) DHCP option 15, the host suffix domain name, and 5) DHCP option 44, the WINS server information (optional).

The client of the NOS software is allowed to obtain the address on the PPP, FR or HDL link by the DHCP, which should be supported by the server. At present, our server can support this function.

Configuration Examples The following example makes the FastEthernet 0 port obtain the IP address automatically.

```
Orion_B54Q(config)# interface GigabitEthernet 0/1
Orion_B54Q(config-if-GigabitEthernet 0/1) ip address dhcp
```

Related Commands	Command	Description
	dns-server	Defines the DNS server of DHCP client.
	ip dhcp pool	Defines the name of the DHCP address pool and enters the DHCP address pool configuration mode.

Platform N/A

Description

4.19 ip dhcp class

Use this command to define a CLASS and enter the global CLASS configuration mode. Use the **no** form of this command to restore the default setting.

ip dhcp class *class-name*
no ip dhcp class *class-name*

Parameter	Parameter	Description
Description	<i>class-name</i>	Class name, which can be character string or numeric such as myclass or 1.

Defaults By default, the class is not configured.

Command Mode Global configuration mode.

Usage Guide After executing this command, it enters the global CLASS configuration mode which is shown as "Orion_B54Q (config-dhcp-class)#". In this configuration mode, user can configure the Option82 information that matches the CLASS and the CLASS identification information.

Configuration Examples The following example configures a global CLASS.

```
Orion_B54Q(config)# ip dhcp class myclass
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

4.20 ip dhcp excluded-address

Use this command to define some IP addresses and make the DHCP server not assign them to the DHCP client in the global configuration mode. Use the **no** form of this command to restore the default setting.

ip dhcp excluded-address *low-ip-address* [*high-ip-address*]
no ip dhcp excluded-address *low-ip-address* [*high-ip-address*]

Parameter	Parameter	Description
Description	<i>low-ip-address</i>	Excludes the IP address, or excludes the start IP address within the range of the IP address.
	<i>high-ip-address</i>	Excludes the end IP address within the range of the IP address.

Defaults The DHCP server assigns the IP addresses of the whole address pool by default.

Command Mode Global configuration mode.

Usage Guide If the excluded IP address is not configured, the DHCP server attempts to assign all IP addresses in the DHCP address pool. This command can reserve some IP addresses for specific hosts to prevent these addresses are assigned to the DHCP client, and define the excluded IP address accurately to reduce the conflict detecting time when the DHCP server assigns the address.

Configuration Examples In the following example, the DHCP server will not attempt to assign the IP addresses within 192.168.12.100~150.

```
ip dhcp excluded-address 192.168.12.100 192.168.12.150
```

Related Commands	Command	Description
	ip dhcp pool	Defines the name of the DHCP address pool and enters the DHCP address pool configuration mode.
	network (DHCP)	Defines the network number and network mask of the DHCP address pool.

Platform Description N/A

4.21 ip dhcp force-send-nak

Use this command to configure the forcible NAK packet sending function. Use the **no** or **default** form of this command to restore the default setting.

- ip dhcp force-send-nak**
- no ip dhcp force-send-nak**
- default ip dhcp force-send-nak**

Parameter Description	Parameter	Description
	N/A	N/A

Defaults This function is disabled by default.

Command Mode Global configuration mode.

Usage Guide The DHCP client checks the previously used IP address every time it is started and sends a DHCPREQUEST packet to continue leasing this IP address. If the address is not available, the DHCP server sends an NAK packet to let the client resend a DHCPDISCOVER packet to apply for a new IP address. If no corresponding lease record can be found on the server, the client keeps

sending DHCPDISCOVER packets. The forcible NAK packet sending function is added to shorten the interval at which the client sends DHCPDISCOVER packets.

Configuration Examples The following example enables the forcible NAK packet sending function in global configuration mode.

```
Orion_B54Q(config)# ip dhcp force-send-nak
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

4.22 ip dhcp monitor-vrrp-state

Use this command in layer-3 configuration mode to enable the DHCP Server to monitor the status of VRRP interfaces so that the DHCP Server processes only those packets sent from a VRRP interface in the Master state. Use the **no** form of this command to restore the default setting. If it is canceled, the DHCP Server processes packets from VRRP interfaces in the Master or Backup state.

```
ip dhcp monitor-vrrp-state  
no ip dhcp monitor-vrrp-state
```

Parameter Description	Parameter	Description
	N/A	N/A

Defaults The **ip dhcp monitor-vrrp-state** command is disabled by default. .

Command Mode Layer-3 interface configuration mode.

Usage Guide If a VRRP address is configured for an interface, the DHCP Server processes packets sent from the master interface and discards packets sent from the backup interface. If no VRRP address is configured, the DHCP Server does not monitor the status of VRRP interfaces. All DHCP packets will be processed.

Configuration Examples The following example enables the DHCP Server to monitor the status of VRRP interfaces.

```
Orion_B54Q(config-if)# ip dhcp monitor-vrrp-state
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

4.23 ip dhcp ping packet

Use this command to configure the times of pinging the IP address when the DHCP server detects address conflict in the global configuration mode. Use the **no** form of this command to restore the default setting.

ip dhcp ping packet [*number*]

no ip dhcp ping packet

Parameter	Parameter	Description
Description	<i>number</i>	(Optional) Number of packets in the range of 0 to 10, where 0 indicates disabling the ping operation. The Ping operation sends two packets by default.

Defaults The Ping operation sends two packets by default.

Command Mode Global configuration mode.

Usage Guide When the DHCP server attempts to assign the IP address from the DHCP address pool, use the ping operation to check whether this address is occupied by other hosts. Record it if the address is occupied, otherwise, assign it to the DHCP client. The Ping operation will send up to 10 packets, two packets by default.

Configuration Examples The following example sets the number of the packets sent by the ping operation as 3.

```
ip dhcp ping packets 3
```

Related Commands	Command	Description
	clear ip dhcp conflict	Clears the DHCP history conflict record.
	ip dhcp ping packet	Configures the timeout time that the DHCP server waits for the Ping response. If all the ping packets are not responded within the specified time, it indicates that this IP address can be assigned. Otherwise, it will record the address conflict.
	show ip dhcp conflict	Displays the DHCP server detects address conflict when it assigns an IP address.

Platform N/A

Description

4.24 ip dhcp ping timeout

Use this command to configure the timeout that the DHCP server waits for response when it uses the ping operation to detect the address conflict in the global configuration mode. Use the **no** form of this command to restore the default setting.

ip dhcp ping timeout *milli-seconds*
no ip dhcp ping timeout

Parameter	Parameter	Description
Description	<i>milli-seconds</i>	Time that the DHCP server waits for ping response in the range 100 to 10000 milliseconds.

Defaults The default is 500 seconds.

Command Mode Global configuration mode.

Usage Guide This command defines the time that the DHCP server waits for a ping response packet.

Configuration Examples The following example configures the waiting time of the ping response packet to 600ms.

```
ip dhcp ping timeout 600
```

Related Commands	Command	Description
	clear ip dhcp conflict	Clears the DHCP history conflict record.
	ip dhcp ping packets	Defines the number of the data packets sent by the ping operation for the detection of the address conflict when the DHCP server assigns an IP address.
	show ip dhcp conflict	Displays the address conflict the DHCP server detects when it assigns an IP address.

Platform N/A
Description

4.25 ip dhcp pool

Use this command to define a name of the DHCP address pool and enter the DHCP address pool configuration mode in the global configuration mode. Use the **no** form of this command to restore the default setting.

ip dhcp pool *pool-name*
no ip dhcp pool *pool-name*

Parameter	Parameter	Description
Description	<i>pool-name</i>	A string of characters and positive integers, for instance, mypool or 1.

Defaults No DHCP address pool is defined by default.

Command Mode Global configuration mode.

Usage Guide Execute the command to enter the DHCP address pool configuration mode:

```
Orion_B54Q(dhcp-config)#
```

 In this configuration mode, configure the IP address range, the DNS server and the default gateway.

Configuration Examples The following example defines a DHCP address pool named mypool0.

```
ip dhcp pool mypool0
```

Command	Description
host	Defines the IP address and network mask, which is used to configure the DHCP manual binding.
ip dhcp excluded-address	Defines the IP addresses that the DHCP server cannot assign to the clients.
network (DHCP)	Defines the network number and network mask of the DHCP address pool.

Platform N/A
Description

4.26 ip dhcp relay check server-id

Use this command to enable the **ip dhcp relay check server-id** function. Use the **no** form of this command to restore the default setting.

ip dhcp relay check server-id
no ip dhcp relay check server-id

Parameter	Parameter	Description
Description	N/A	N/A

Defaults The **ip dhcp relay check server-id** command is disabled.

Command Mode Global configuration mode.

Usage Guide Switch will select the server to be sent according to server-id option when forwarding DHCP REQUEST via this command. Without this command configured, the switch forwards the DHCP REQUEST to all configured DHCP servers.

Configuration Examples The following example enables the ip dhcp relay check server-id function.

```
Orion_B54Q# configure terminal
Orion_B54Q(config)# ip dhcp relay check server-id
```

Related	Command	Description
Commands	<code>service dhcp</code>	Enables the DHCP Relay.

Platform N/A
Description

4.27 ip dhcp relay multiple-giaddr

Use this command to enable multiple gateway IP addresses on DHCP Relay. Use the **no** form of this command to restore the default setting.

ip dhcp relay multiple-giaddr
no ip dhcp relay multiple-giaddr

Parameter	Parameter	Description
Description	N/A	N/A

Defaults This function is disabled by default.

Command Mode Global configuration mode

Usage Guide This command is configured on the server. When this function is configured, DHCP Relay requires IP addresses from the DHCP server by application of several interface IP addresses. When multiple gateway IP addresses are configured on interfaces, the master gateway IP address serves as the gateway IP address of the DHCP Relay, and the DHCP server allocates IP segments according to the gateway IP address of the DHCP Relay. After this function is enabled, if a client fails to apply for an IP address from the gateway with the master IP address, it can apply for one from a gateway with a slave IP address.

Configuration Examples The following example enables multiple gateway IP addresses.

```
Orion_B54Q(config)# ip dhcp relay multiple-giaddr
```

The following example disables this function.

```
Orion_B54Q(config)# no ip dhcp relay multiple-giaddr
```

Related	Command	Description
Commands	N/A	N/A

Platform N/A
Description

4.28 ip dhcp relay information option82

Use this command to configure to enable the **ip dhcp relay information option82** function. Use the **no** form of this command to restore the default setting.

ip dhcp relay information option82
no ip dhcp relay information option82

Parameter	Parameter	Description
Description	N/A	N/A

Defaults The **ip dhcp relay information option82** command is disabled.

Command Mode Global configuration mode.

Usage Guide This command is exclusive with the **option dot1x** command.

Configuration Examples The following example enables the option82 function on the DHCP relay.

```
Orion_B54Q# configure terminal
Orion_B54Q(config)# Ip dhcp relay information option82
```

Related Commands	Command	Description
	service dhcp	Enables the DHCP Relay.

Platform Description N/A

4.29 ip dhcp relay suppression

Use this command to enable the DHCP binding globally. Use the **no** form of this command to disable the DHCP binding globally and enable the **DHCP relay** suppression on the port.

ip dhcp relay suppression
no ip dhcp relay suppression

Parameter	Parameter	Description
Description	N/A	N/A

Defaults The **ip dhcp relay suppression** command is disabled.

Command Mode Interface configuration mode.

Usage Guide After executing this command, the system will not relay the DHCP request message on the interface.

Configuration Examples The following example enables the relay suppression function on the interface 1.

```
Orion_B54Q# configure terminal
Orion_B54Q(config)# interface fastEthernet 0/1
Orion_B54Q(config-if)# ip dhcp relay suppression
Orion_B54Q(config-if)# exit
Orion_B54Q(config)#
```

Related Commands	Command	Description
	service dhcp	Enables the DHCP Relay.

Platform N/A
Description

4.30 ip dhcp use class

Use this command to enable the CLASS to allocate addresses in the global configuration mode. Use the **no** form of this command can be used to disable the CLASS.

ip dhcp use class
no ip dhcp use class

Parameter Description	Parameter	Description
	N/A	N/A

Defaults Enabled

Command Mode This function is enabled by default.

Usage Guide N/A

Configuration Examples The following example enables the CLASS to allocate addresses.

```
Orion_B54Q(config)# ip dhcp use class
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A
Description

4.31 ip helper-address

Use this command to add an IP address of the DHCP server. Use the **no** form of this command to delete an IP address of the DHCP server.

The server address can be configured globally or on a specific interface. Therefore, this command can run in the global configuration mode or the interface configuration mode to add the DHCP server information.

ip helper-address [vrf *vrf-name*] *A.B.C.D*
no ip helper-address [vrf *vrf-name*] *A.B.C.D*

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Mode Global configuration mode, interface configuration mode.

Usage Guide Up to 20 DHCP server IP addresses can be configured globally or on a layer-3 interface. One DHCP request of this interface will be sent to these servers. You can select one for confirmation.
 The global configuration and port-based configuration of the vrf are slightly different. In the global configuration mode, if the vrf is not specified, the default address of the current server does not belong to any vrf. In the port-based configuration, if the vrf is not specified, the current default server and port configurations belong to the same vrf.

Configuration Examples The following example configures the addresses for two servers.

1. Set the IP address for the global server to 192.168.1.1
2. Set the IP address for the vrf instance-based server delp1 to 192.168.2.1

```
Orion_B54Q# configure terminal
Orion_B54Q(config)# ip helper-address 192.168.1.1
Orion_B54Q(config)# ip helper-address vrf dep1 192.168.2.1
```

Related Commands	Command	Description
	service dhcp	Enables the DHCP relay.

Platform Description N/A

4.32 lease

Use this command to define the lease time of the IP address that the DHCP server assigns to the client in the DHCP address pool configuration mode. Use the **no** form of this command to restore the default setting. A limited lease time ranges from 1 minute to 23 hours and 59 minutes.

lease { *days* [*hours*] [*minutes*] | **infinite** }

no lease

Parameter	Parameter	Description
Description	<i>days</i>	Lease time in days
	<i>hours</i>	(Optional) Lease time in hours. It is necessary to define the days before defining the hours.
	<i>minutes</i>	(Optional) Lease time in minutes. It is necessary to define the days and hours before defining the minutes.
	<i>infinite</i>	Infinite lease time.

Defaults The lease time for a static address pool is infinite. The lease time for other address pools is 1 day.

Command Mode DHCP address pool configuration mode.

Usage Guide When the lease is getting near to expire, the DHCP client will send the request of renewal of lease. In general, the DHCP server will allow the renewal of lease of the original IP address.

Configuration Examples The following example sets the DHCP lease to 1 hour.

```
lease 0 1
```

The following example sets the DHCP lease to 1 minute.

```
lease 0 0 1
```

Related Commands	Command	Description
	ip dhcp pool	Defines the name of the DHCP address pool and enters the DHCP address pool configuration mode.

Platform Description N/A

4.33 lease-threshold

Use this command in DHCP address pool configuration mode to define the DHCP alarm threshold. Use the **default** or **no** form of this command to restore the default setting.

lease-threshold *percentage*

default lease-threshold
no lease-threshold

Parameter	Parameter	Description
Description	<i>percentage</i>	Usage of the address pool, ranging from 60 to 100 in percentage.

Defaults 90

Command Mode DHCP address pool configuration mode.

Usage Guide If the maximum IP usage of the address pool reaches the threshold, the DHCP Server generates a SYSLOG alarm. The IP usage indicates the ratio of the number of assigned address pools to the total number of assignable address pools. If the number of assigned pools stays above the alarm threshold, an alarm is generated every 5 minutes.

Configuration Examples The following example sets the alarm threshold to 80%.

```
lease-threshold 80
```

The following example restores the default alarm threshold.

```
default lease-threshold
```

The following example disables the address pool alarm function.

```
no lease-threshold
```

Related Commands	Command	Description
	ip dhcp pool	Defines the name of the DHCP address pool and enters the DHCP address pool configuration mode.

Platform N/A
Description

4.34 match ip

Use this command to define address manage matching rules. **match ip:**
match ip *ip-address netmask [interface] [add/remove] vlan vlan-list*

Use the **no** form of this command to delete the definition.
no match ip *ip-address netmask [interface] [add/remove] vlan vlan-list*

Use the **clear** form of this command to delete all definitions.
clear match ip *[interface]*

Parameter	Parameter	Description
Description	<i>ip-address</i>	IP address

<i>netmask</i>	Netmask
<i>interface</i>	Interface name
<i>add/remove</i>	Add or remove a vlan
<i>vlan-list</i>	VLAN index

Defaults N/A

Command Mode Address manage configuration mode

Usage Guide

- 1: After this command is configured, all DHCP clients from a specified vlan + port obtain addresses of the configured range.
- 2: In the supervlan scenario, if a client is qualified for configuration of the DHCP static address pool, whichever subvlan the client is in, a same static address is assigned. And address manage does not need to configure the address based on all subvlans/ports but to configure the address to be in the corresponding vlan range. This rule only applies to assigning static addresses.

Configuration Example 1: Define vlan index 10 as the source of matching rule. For the DHCP client whose interface name is GigabitEthernet 0/10, set the network ID to 192.168.11.0 and mask 255.255.255.0.

```
Orion_B54Q(config-address-manage)#match ip 192.168.11.0 255.255.255.0 GigabitEthernet 0/10
vlan 10
```

Verification Run the **show run** command to check whether the configuration is successful.

4.35 match ip default

Use this command to define default address manage matching rules. **match ip default;**

match ip default *ip-address netmask*

Use the **no** form of the command to delete the definition.

no match ip default *ip-address netmask*

Parameter Description	Parameter	Description
	<i>ip-address</i>	IP address
	<i>netmask</i>	Netmask

Defaults N/A

Command Address manage configuration mode

Mode

Usage Guide After configuring this command, all DHCP clients for which `vlan + port/vlan` have not been configured obtain addresses of the default range. If this command is not configured and there is not `vlan + port` configuration as well, addresses are assigned in the normal process.

Configuration Example 1: Define the default matching rule: network ID: 192.168.12.0, mask: 255.255.255.0

```
Orion_B54Q(config-address-manage)#match ip default 192.168.12.0 255.255.255.0
```

Verification Run the **show run** command to check whether the configuration is successful.

4.36 netbios-name-server

Use this command to configure the WINS name server of the Microsoft DHCP client NETBIOS in the DHCP address pool configuration mode. The **no** form of this command can be used to restore the default setting.

netbios-name-server *ip-address* [*ip-address2...ip-address8*]
netbios-name-server

Parameter	Parameter	Description
Description	<i>ip-address</i>	IP address of the WINS server. It is required to configure one IP address at least.
	<i>ip-address2...ip-address8</i>	(Optional) IP addresses of WINS servers. Up to 8 WINS servers can be configured.

Defaults No WINS server is defined by default.

Command Mode DHCP address pool configuration mode.

Usage Guide When more than one WINS server is defined, the former has higher priority. The DHCP client will select the next WINS server only when its communication with the former WINS server fails.

Configuration Examples The following example specifies the WINS server 192.168.12.3 for the DHCP client.

```
netbios-name-server 192.168.12.3
```

Related Commands	Command	Description
	ip address dhcp	Enables the DHCP client on the interface to obtain the IP address.
	ip dhcp pool	Defines the name of the DHCP address pool and enter the DHCP address pool configuration mode.
	netbios-node-type	Defines the netbios node type of the client host.

Platform N/A

Description

4.37 netbios-node-type

Use this command to define the node type of the master NetBIOS of the Microsoft DHCP client in the DHCP address configuration mode. Use the **no** form of this command to restore the default setting.

netbios-node-type *type*
no netbios-node-type

Parameter	Parameter	Description
Description	<i>type</i>	Type of node in two modes: Digit in hexadecimal form in the range of 0 to FF. Only the following numerals are available: 1: b-node. 2: p-node. 4: m-node. 8: h-node. String: b-node: broadcast node p-node: peer-to-peer node m-node: mixed node h-node: hybrid node

Defaults No type of the NetBIOS node is defined by default.

Command Mode DHCP address pool configuration mode.

Usage Guide There are 4 types of the NetBIOS nodes of the Microsoft DHCP client: 1) Broadcast, which carries out the NetBIOS name resolution by the broadcast method, 2) Peer-to-peer, which directly requests the WINS server to carry out the NetBIOS name resolution, 3) Mixed, which requests the name resolution by the broadcast method firstly, and then carry out the name resolution by the WINS server connection, 4) Hybrid, which requests the WINS server to carry out the NetBIOS name resolution firstly, and it will carry out the NetBIOS name resolution by the broadcast method if the response is not received.

By default, the node type for Microsoft operating system is broadcast or hybrid. If the WINS server is not configured, broadcast node is used. Otherwise, hybrid node is used. It is recommended to set the type of the NetBIOS node as Hybrid.

Configuration Examples The following example sets the NetBIOS node of Microsoft DHCP client as Hybrid.

```
netbios-node-type h-node
```

Related Commands	Command	Description
	ip dhcp pool	Defines the name of DHCP address pool and enters the DHCP address pool configuration mode.
	netbios-name-server	Configures the WINS name server of the Microsoft DHCP client NETBIOS.

Platform N/A
Description

4.38 network (DHCP)

Use this command to define the network number and network mask of the DHCP address pool in the DHCP address pool configuration mode. Use the **no** form of this command to restore the default setting.

network *net-number net-mask*
no network

Parameter Description	Parameter	Description
	<i>net-number</i>	Network number of the DHCP address pool
	<i>net-mask</i>	Network mask of the DHCP address pool. If the network mask is not defined, the natural network mask will be used by default.

Defaults No network number or network mask is defined by default.

Command Mode DHCP address pool configuration mode.

Usage Guide This command defines the subnet and subnet mask of a DHCP address pool, and provides the DHCP server with an address space which can be assigned to the clients. Unless excluded addresses are configured, all the addresses of the DHCP address pool can be assigned to the clients. The DHCP server assigns the addresses in the address pool orderly. If the DHCP server found an IP address is in the DHCP binding table or in the network segment, it checks the next until it assigns an effective IP address.

The **show ip dhcp binding** command can be used to view the address assignment, and the **show ip dhcp conflict** command can be used to view the address conflict detection configuration.

Configuration Examples The following example defines the network number of the DHCP address pool as 192.168.12.0, and the network mask as 255.255.255.240.

```
network 192.168.12.0 255.255.255.240
```

Related Commands	Command	Description
	ip dhcp excluded-address	Defines the IP addresses that the DHCP server cannot assign to the clients.

ip dhcp pool	Defines the name of the DHCP address pool and enters the DHCP address pool configuration mode.
---------------------	--

Platform N/A
Description

4.39 next-server

Use this command to define the startup sever list that the DHCP client accesses during startup in the DHCP address configuration mode. Use the **no** form of this command to restore the default setting.

next-server *ip-address* [*ip-address2*...*ip-address8*]
no next-server

Parameter	Parameter	Description
Description	<i>ip-address</i>	Defines the IP address of the startup server, which is usually the TFTP server. It is required to configure one IP address at least.
	<i>ip-address2</i> ... <i>ip-address8</i>	(Optional) Up to 8 startup servers can be configured.

Defaults N/A

Command Mode DHCP address pool configuration mode.

Usage Guide When more than one startup server is defined, the former will possess higher priory. The DHCP client will select the next startup server only when its communication with the former startup server fails.

Configuration Examples The following example specifies the startup server 192.168.12.4 for the DHCP client.

```
next-server 192.168.12.4
```

Related Commands	Command	Description
	bootfile	Defines the default startup mapping file name of the DHCP client.
	ip dhcp pool	Defines the name of the DHCP address pool and enter the DHCP address pool configuration mode.
	ip help-address	Defines the Helper address on the interface.
	option	Configures the option of the NOS software DHCP server.

Platform N/A
Description

4.40 option

Use this command to configure the option of the DHCP server in the DHCP address pool configuration mode. Use the **no** form of this command to restore the default setting.

option code { **ascii string** | **hex string** | **ip ip-address** }

no option

Parameter Description	Parameter	Description
	<i>code</i>	Defines the DHCP option codes.
	<i>ascii string</i>	Defines an ASCII string.
	<i>hex string</i>	Defines a hex string.
	ip ip-address	Defines an IP address list.

Defaults N/A

Command Mode Global configuration mode

Usage Guide The DHCP provides a mechanism to transmit the configuration information to the host in the TCP/IP network. The DHCP message has a variable option field that can be defined according to the actual requirement. The DHCP client needs to carry the DHCP message with 32 bytes of option information at least. Furthermore, the fixed data field in the DHCP message is also referred to as an option. For the definition of current DHCP option, refer to RFC 2131.

Configuration Examples The following example defines the option code 19, which determines whether the DHCP client can enable the IP packet forwarding. 0 indicates to disable the IP packet forwarding, and 1 indicates to enable the IP packet forwarding. The configuration below enable the IP packet forwarding on the DHCP client.

```
Orion_B54Q(dhcp-config)# option 19 hex 1
```

The following example defines the option code 33, which provides the DHCP client with the static route information. The DHCP client will install two static routes: 1) the destination network 172.16.12.0 and the gateway 192.168.12.12, 2) the destination network 172.16.16.0 and the gateway 192.168.12.16.

```
option 33 ip 172.16.12.0 192.168.12.12 172.16.16.0 192.168.12.16
```

Related Commands	Command	Description
	ip dhcp pool	Defines the name of the DHCP address pool and enters the DHCP address pool configuration mode.

Platform Description N/A

4.41 pool-status

Use this command to enable or disable the DHCP address pool.

pool-status { enable | disable }

Parameter	Parameter	Description
Description	enable	Enables the address pool.
	disable	Disables the address pool.

Defaults By default, the address pool is enabled after it is configured.

Command Mode DHCP address pool configuration mode

Usage Guide This command is configured on the DHCP server.

Configuration Examples The following example disables the address pool.

```
Orion_B54Q(dhcp-config)# pool-status disable
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

4.42 relay agent information

Use this command to enter the Option82 matching information configuration mode in the global CLASS configuration mode. Use the **no** form of this command to delete the Option82 matching information of the CLASS.

relay agent information

no relay agent information

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Mode Global CLASS configuration mode

Usage Guide After executing this command, it enters the Option82 matching information configuration mode which

is shown as “Orion_B54Q (config-dhcp-class-relayinfo)#”.

In this configuration mode, user can configure the class matching multiple Option82 information.

Configuration Examples The following example configures a global CLASS and enters the Option82 matching information configuration mode.

```
Orion_B54Q(config)# ip dhcp class myclass
Orion_B54Q(config-dhcp-class)# relay agent information
Orion_B54Q(config-dhcp-class-relayinfo)#
```

Related Commands	Command	Description
	ip dhcp class	Defines a CLASS and enters the global CLASS configuration mode.

Platform N/A

Description

4.43 relay-information hex

Use this command to enter the Option82 matching information configuration mode. Use the **no** form of this command to delete a piece of matching information.

relay-information hex aabb.ccdd.eeff... [*]

no relay-information hex aabb.ccdd.eeff... [*]

Parameter Description	Parameter	Description
	<i>aabb.ccdd.eeff...[*]</i>	Hexadecimal Option82 matching information. The ‘*’ symbol means partial matching which needs the front part matching only. Without the ‘*’ means needing full matching.

Defaults N/A

Command Mode Global CLASS configuration mode

Usage Guide N/A

Configuration Examples The following example configures a global CLASS which can match multiple Option82 information.

```
Orion_B54Q(config)# ip dhcp class myclass
Orion_B54Q(config-dhcp-class)# relay agent information
Orion_B54Q(config-dhcp-class-relayinfo)# relay-information
hex 0102256535
Orion_B54Q(config-dhcp-class-relayinfo)# relay-information
hex 010225654565
Orion_B54Q(config-dhcp-class-relayinfo)# relay-information
hex 060225654565
```

```
Orion_B54Q(config-dhcp-class-relayinfo)# relay-information
hex 060223*
```

Related Commands	Command	Description
	ip dhcp class	Defines a CLASS and enter the global CLASS configuration mode.
	relay agent information	Enters the Option82 matching information configuration mode.

Platform N/A

Description

4.44 remark

Use this command to configure the identification which is used to describe the CLASS in this global CLASS configuration mode. Use the **no** form of this command to delete the identification.

remark *class-remark*

no remark

Parameter Description	Parameter	Description
	class-remark	Information used to identify the CLASS, which can be the character strings with space in them.

Defaults N/A.

Command Mode Global CLASS configuration mode.

Usage Guide N/A

Configuration Examples The following example configures the identification information for a global CLASS.

```
Orion_B54Q(config)# ip dhcp class myclass
Orion_B54Q(config-dhcp-class)# remark used in #1 build
```

Related Commands	Command	Description
	ip dhcp class	Defines a CLASS and enter the global CLASS configuration mode.

Platform N/A

Description

4.45 service dhcp

Use this command to enable the DHCP server and the DHCP relay on the device in global configuration mode. Use the **no** form of this command to restore the default setting.

service dhcp
no service dhcp

Parameter	Parameter	Description
Description	N/A	N/A

Defaults The **service dhcp** command is disabled.

Command Mode Global configuration mode

Usage Guide The DHCP server can assign the IP addresses to the clients automatically, and provide them with the network configuration information such as DNS server and default gateway. The DHCP relay can forward the DHCP requests to other servers, and the returned DHCP responses to the DHCP client, serving as the relay for DHCP packets.

Configuration Examples The following example enables the DHCP server and the DHCP relay feature.

```
service dhcp
```

Related Commands	Command	Description
	show ip dhcp server statistics	Displays various statistics information of the DHCP server.
	ip helper-address [vrf] A.B.C.D	Adds an IP address of the DHCP server.

Platform Description N/A

4.46 show dhcp lease

Use this command to display the lease information of the IP address obtained by the DHCP client.

show dhcp lease

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode.

Usage Guide If the IP address is not defined, display the binding condition of all addresses. If the IP address is defined, display the binding condition of this IP address.

Configuration The following example displays the result of the show dhcp lease.

n Examples

```
Orion_B54Q# show dhcp lease
Temp IP addr: 192.168.5.71 for peer on Interface: FastEthernet0/0
Temp sub net mask: 255.255.255.0
  DHCP Lease server: 192.168.5.70, state: 3 Bound
  DHCP transaction id: 168F
  Lease: 600 secs, Renewal: 300 secs, Rebind: 525 secs
Temp default-gateway addr: 192.168.5.1
  Next timer fires after: 00:04:29
  Retry count: 0 Client-ID: redgaint-00d0.f8fb.5740-Fa0/0
```

Related Commands

Command	Description
N/A	N/A

Platform Description N/A

4.47 show ip dhcp binding

Use this command to display the binding condition of the DHCP address.

show ip dhcp binding [*ip-address*]

Parameter Description

Parameter	Description
<i>ip-address</i>	(Optional) Only displays the binding condition of the specified IP addresses.

Defaults N/A

Command Mode Privileged EXEC mode.

Usage Guide If the IP address is not defined, show the binding condition of all addresses. If the IP address is defined, show the binding condition of this IP address

Configuratio The following is the result of the show ip dhcp binding.

n Examples

```
Orion_B54Q# show ip dhcp binding
Total number of clients      : 4
Expired clients              : 3
Running clients              : 1

IP address      Hardware address      Lease expiration      Type
20.1.1.1        2000.0000.2011      000 days 23 hours 59 mins
Automatic
```

The meaning of various fields in the show result is described as follows.

Field	Description
IP address	The IP address to be assigned to the DHCP client.
Client-Identifier /Hardware address	The client identifier or hardware address of the DHCP client.
Lease expiration	The expiration date of the lease. The Infinite indicates it is not limited by the time. The IDLE indicates the address is in the free status currently for it is not renewed or the DHCP client releases it actively.
Type	The type of the address binding. The Automatic indicates an IP address is assigned automatically, and the Manual indicates an IP address is assigned by manual.

Related Commands	Command	Description
	clear ip dhcp binding	Clears the DHCP address binding table.

Platform N/A
Description

4.48 show ip dhcp conflict

Use this command to show the conflict history record of the DHCP sever.

show ip dhcp conflict

Parameter Description	Parameter	Description
	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode.

Usage Guide This command can display the conflict address list detected by the DHCP server.

Configuration Examples The following example displays the output result of the **show ip dhcp conflict** command.

```
Orion_B54Q# show ip dhcp conflict
IP address  Detection Method
192.168.12.1  Ping
```

The meaning of various fields in the show result is described as follows.

Field	Description
IP address	The IP addresses which cannot be assigned to the DHCP client.
Detection Method	The conflict detection method.

Related Commands	Command	Description
	clear ip dhcp conflict	Clears the DHCP conflict record.

Platform N/A

Description

4.49 show ip dhcp relay-statistics

Use this command to display the statistics of the DHCP relay.

show ip dhcp relay-statistics

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Privileged EXEC mode

Mode

Usage Guide This command is used to display the statistics of the DHCP relay.

Configuration Examples The following example displays the statistics of the DHCP relay.

Examples Orion_B54Q# show ip dhcp relay-statistics

```
Cycle mode                0

Message                   Count
Discover                  0
Offer                     0
Request                   0
Ack                       0
Nak                       0
Decline                   0
Release                   0
Info                      0
Bad                       0

Direction                 Count
Rx client                  0
Rx client uni              0
Rx client bro              0
Tx client                  0
Tx client uni              0
Tx client bro              0
Rx server                  0
Tx server                  0
```

The meaning of various fields in the show result is described as follows.

Field	Description
Cycle mode	Whether to allow packets to be sent to multiple DHCP servers.
Discover	The number of Discover packets.
Offer	The number of Offer packets.
Request	The number of Request packets.
Ack	The number of Ack packets.
Nak	The number of Nak packets.
Decline	The number of Decline packets.
Release	The number of Release packets.
Info	The number of Info packets.
Bad	The number of error packets.
Rx client	The number of packets received from the client.
Rx client uni	The number of unicast packets received from the client.
Rx client bro	The number of broadcast packets received from the client.

Tx client	The number of packets transmitted to the client.
Tx client uni	The number of unicast packets transmitted to the client
Tx client bro	The number of multicast packets transmitted to the client
Rx server	The number of packets received from the server.
Tx server	The number of packets transmitted to the server.

Related Commands	Command	Description
	N/A	N/A

Platform N/A
Description

4.50 show ip dhcp server statistics

Use this command to display the statistics of the DHCP server.

show ip dhcp server statistics

Parameter Description	Parameter	Description
	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide This command displays the statistics of the DHCP server.

Configuration Examples The following example displays the output result of the **show ip dhcp server statistics** command.

```
Orion_B54Q# show ip dhcp server statistics
Address pools                2
Lease counter                4
Active Lease Counter        0
Expired Lease Counter       4
Malformed messages          0
Dropped messages            0

Message                      Received
BOOTREQUEST                  216
DHCPCDISCOVER                 33
```

```

DHCPREQUEST          25
DHCPDECLINE          0
DHCPRELEASE          1
DHCPINFORM           150

Message              Sent
BOOTREPLY            16
DHCPOFFER            9
DHCPACK              7
DHCPNAK              0
DHCPREQTIMES         0
DHCPREQSUCTIMES     0
DISCOVER-PROCESS-ERROR 0
LEASE-IN-PINGSTATE   0
NO-LEASE-RESOURCE    0
SERVERID-NO-MATCH    0
-----
rcv                   0
send                  0
    
```

The meaning of various fields in the show result is described as follows.

Field	Description
Address pools	Number of address pools.
Lease count	Number of allocated lease.
Automatic bindings	Number of automatic address bindings.
Manual bindings	Number of manual address bindings.
Expired bindings	Number of expired address bindings.
Malformed messages	Number of malformed messages received by the DHCP.
Message Received or Sent	Number of the messages received and sent by the DHCP server respectively.

Related Commands	Command	Description
	clear ip dhcp server statistics	Clears the DHCP server statistics.

Platform N/A
Description

4.51 show ip dhcp socket

Use this command to display the socket used by the DHCP server.

show ip dhcp socket

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example displays the socket used by the DHCP server.

```
Orion_B54Q#show ip dhcp socket
dhcp socket = 47.
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

5 DHCPv6 Commands

5.1 clear ipv6 dhcp binding

Use this command to clear the DHCPv6 binding information.

clear ipv6 dhcp binding [*ipv6-address*]

Parameter	Parameter	Description
Description	<i>ipv6-address</i>	Sets the IPv6 address or the prefix.

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide If the *ipv6-address* is not specified, all DHCPv6 binding information is cleared. If the *ipv6-address* is specified, the binding information for the specified address is cleared.

Configuration Examples The following example clears the DHCPv6 binding information:

```
Orion_B54Q(config)# clear ipv6 dhcp binding
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

5.2 clear ipv6 dhcp conflict

Use this command to clear the DHCPv6 address conflicts.

clear ipv6 dhcp conflict { *ipv6-address* | * }

Parameter	Parameter	Description
Description	<i>ipv6-address</i>	Specifies IPv6 address or prefix.
	*	All IPv6 addresses or prefixes

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide If an IPv6 address conflict is detected, the DHCPv6 client will send the Decline message. Then the DHCPv6 server will add the address in this message into the address conflict queue. The addresses added into the address conflict queue cannot be assigned any longer.
 If the * parameter is not specified, all conflicts of IPv6 addresses or prefixes will be deleted.
 If the *ipv6-address* parameter is specified, only the specified address conflict will be deleted.

Configuration Examples The following example clears a DHCPv6 address conflict.

```
Orion_B54Q# clear ipv6 dhcp conflict 2008:50::2
```

Related Commands	Command	Description
	show ipv6 dhcp conflict	Displays address conflicts.

Platform N/A
Description

5.3 clear ipv6 dhcp relay statistics

Use this command to clear the packet sending and receiving condition with the DHCPv6 Relay function enabled.

clear ipv6 dhcp relay statistics

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example clears the packet sending and receiving condition with the DHCPv6 Relay function enabled.

```
Orion_B54Q# clear ipv6 dhcp relay statistics
```

Related Commands	Command	Description
	show ipv6 dhcp relay statistics	Displays the statistical information.

Platform N/A
Description

5.4 clear ipv6 dhcp server statistics

Use this command to clear the DHCPv6 server statistics.

clear ipv6 dhcp server statistics

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide This command is used to clear the DHCPv6 server statistics.

Configuration Examples The following example clears the DHCPv6 server statistics.

```
Orion_B54Q(config)# clear ipv6 dhcp server statistics
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

5.5 dns-server

Use this command to set the DNS Server list information for the DHCPv6 Server.

Use the **no** form of this command to restore the default setting.

dns-server ipv6-address

no dns-server ipv6-address

Parameter	Parameter	Description
Description	<i>ipv6-address</i>	Sets the IPv6 address or the DNS server.

Defaults By default, no DNS server list is configured.

Command Mode DHCPv6 pool configuration mode

Usage Guide To configure several DNS Server addresses, use the **dns-server** command for several times. The newly-configured DNS Server address will not overwrite the former ones.

Configuration Examples The following example configures the DNS server address.

```
Orion_B54Q(config-dhcp) # dns-server 2008:1::1
```

Related Commands	Command	Description
	domain-name	Sets the DHCPv6 domain name information.
	ipv6 dhcp pool	Sets a DHCPv6 pool.

Platform N/A
Description

5.6 domain-name

Use this command to set the domain name for the DHCPv6 server.

Use the **no** form of this command to restore the default setting.

domain-name *domain*

no domain-name *domain*

Parameter Description	Parameter	Description
	<i>domain</i>	Sets the domain name.

Defaults By default, no domain name is configured.

Command Mode DHCPv6 pool configuration mode

Usage Guide To configure several domain names, use the domain-name command for several times. The newly-configured domain name will not overwrite the former ones.

Configuration Examples The following example sets the domain name for the DHCPv6 server to example.com.

```
Orion_B54Q(config-dhcp) # domain-name example.com
```

Related Commands	Command	Description
	dns-server	Sets the DHCPv6 DNS server list.
	ipv6 dhcp pool	Sets the DHCPv6 pool.

Platform N/A
Description

5.7 iana-address prefix

Use this command to set the IA_NA address prefix for the DHCPv6 Server. Use the **no** form of this

command to restore the default setting.

iana-address prefix *ipv6-prefix/prefix-length* [**lifetime** { *valid-lifetime* | *preferred-lifetime* }]
no iana-address prefix

Parameter	Parameter	Description
Description	<i>ipv6-prefix/prefix-length</i>	Sets the IPv6 prefix and prefix length.
	lifetime	Sets the lifetime of the address allocated to the client. With the keyword lifetime configured, both parameters <i>valid-lifetime</i> and <i>preferred-lifetime</i> shall be configured.
	<i>valid-lifetime</i>	Sets the valid lifetime of using the allocated address for the client.
	<i>preferred-lifetime</i>	Sets the preferred lifetime of the address allocated to the client.

Defaults By default, no IA_NA address prefix is configured.
 The default *valid-lifetime* is 3600s(1 hour).
 The default *preferred-lifetime* is 3600s(1 hour).

Command Mode DHCPv6 pool configuration mode

Usage Guide This command is used to set the IA_NA address prefix for the DHCPv6 Server, and allocate the IA_NA address to the client.
 The Server attempts to allocate a usable address within the IA_NA address prefix range to the client upon receiving the IA_NA address request from the client. That address will be allocated to other clients if the client no longer uses that address again.

Configuration Examples The following example sets the IA_NA address prefix for the DHCPv6 Server.

```
Orion_B54Q(config-dhcp)# iana-address prefix 2008:50::/64 lifetime 2000 1000
Orion_B54Q(config-if)# ip verify urpf drop-rate notify
```

Related Commands	Command	Description
	ipv6 dhcp pool	Sets the DHCPv6 pool.
	show ipv6 dhcp pool	Displays the DHCPv6 pool information.

Platform Description N/A

5.8 ipv6 dhcp pool

Use this command to set the DHCPv6 server pool.
 Use the **no** form of this command to restore the default setting.

ipv6 dhcp pool *poolname*
no ipv6 dhcp pool *poolname*

Parameter	Parameter	Description
Description	<i>poolname</i>	Defines the DHCPv6 pool name.

Defaults By default, no DHCPv6 server pool is configured.

Command Mode Global configuration mode

Usage Guide This command is used to create a DHCPv6 Server configuration pool. After configuring this command, it enters the DHCPv6 pool configuration mode, in which the administrator can set the pool parameters, such as the prefix and the DNS Server information, ect.
After creating the DHCPv6 Server configuration pool, use the **ipv6 dhcp server** command to associate the pool and the DHCPv6 Server on one interface.

Configuration Examples The following example sets the DHCPv6 server pool.

```
Orion_B54Q# configure terminal
Orion_B54Q(config)# ipv6 dhcp pool pool1
Orion_B54Q(config-dhcp)#
```

Related Commands	Command	Description
	ipv6 dhcp server	Enables the DHCPv6 server function on the interface.
	show ipv6 dhcp pool	Displays the DHCPv6 pool information.

Platform Description N/A

5.9 ipv6 dhcp relay destination

Use this command to enable the DHCPv6 relay service and configure the destination address to which the messages are forwarded.

Use the **no** form of this command to restore the default setting.

ipv6 dhcp relay destination*ipv6-address* [*interface-type interface-number*]

no ipv6 dhcp relay destination*ipv6-address* [*interface-type interface-number*]

Parameter	Parameter	Description
Description	<i>ipv6-address</i>	Sets the DHCPv6 relay destination address.
	<i>interface-type interface-number</i>	Specifies the forwarding output interface if the forwarding address is the local link address.

Defaults By default, the relay and forward function is disabled, and the forwarding destination address and the output interface are not configured.

Command Interface configuration mode
Mode

Usage Guide With the DHCPv6 relay service enabled on the interface, the DHCPv6 message received on the interface can be forwarded to all configured destination addresses. Those received DHCPv6 messages can be from the client, or from another DHCPv6 relay service.

The forwarding output interface configuration is mandatory if the forwarding address is the local link address or the multicast address. And the forwarding output interface configuration is optional if the forwarding address is global or station unicast or multicast address.

Without the forwarding output interface configured, the interface is selected according to the unicast or multicast routing protocol.

The relay reply message can be forwarded without the relay function enabled on the interface.

Configuration Examples The following example sets the relay destination address on the interface.

```
Orion_B54Q(config)# interface fastethernet 0/1
Orion_B54Q(config-if)# ipv6 dhcp relay destination 2008:1::1
```

Related Commands	Command	Description
	show ipv6 dhcp interface	Displays the DHCPv6 interface information.

Platform N/A
Description

5.10 ipv6 dhcp server

Use this command to enable the DHCPv6 server on the interface.

Use the **no** form of this command to restore the default setting.

ipv6 dhcp server *poolname* [**rapid-commit] [**preference** *value*]**
no ipv6 dhcp server

Parameter	Parameter	Description
Description	<i>poolname</i>	Defines the DHCPv6 pool name.
	rapid-commit	Allows the two-message interaction process.
	preference <i>value</i>	Sets the preference level for the advertise message. The valid range is from 1 to 100 and the default value is 0.

Defaults This function is disabled by default.

Command Interface configuration mode
Mode

Usage Guide Use the **ipv6 dhcp server** command to enable the DHCPv6 service.

Configuring the keyword **rapid-commit** allows the two-message interaction for the server and the

client when allocating the address prefix and setting other configurations. With this keyword configured, if the client solicit message includes the **rapid-commit** item, the DHCPv6 Server will send the Reply message immediately.

DHCPv6 Server carries with the **preference** value when sending the advertise message if the **preference** level is not 0.

If the **preference** level is 0, the advertise message will not include this field. If the **preference** value is 255, the client sends the request message to the server to obtain the configurations.

DHCPv6 Client, Server and Relay functions are exclusive, and only one of the functions can be configured on the interface.

Configuration Examples The following example enables the DHCPv6 server on the interface.

```
Orion_B54Q(config)# interface fastethernet 0/1
Orion_B54Q(config-if)# ipv6 dhcp server pool1
```

Related Commands	Command	Description
	ipv6 dhcp pool	Sets the DHCPv6 pool.
	show ipv6 dhcp pool	Displays the DHCPv6 pool information.

Platform N/A

Description

5.11 ipv6 local pool

Use this command to configure the local prefix pool of the DHCPv6 server prefix.

Use the **no** form of this command to restore the default setting.

ipv6 local pool *poolname prefix/prefix-length assigned-length*

no ipv6 local pool *poolname*

Parameter Description	Parameter	Description
	<i>poolname</i>	The local prefix pool name
	<i>prefix/prefix-length</i>	The prefix and prefix length
	<i>assigned-length</i>	The assigned prefix length

Defaults By default, no local prefix pool of the DHCPv6 server prefix is configured.

Command Mode Global configuration mode

Usage Guide The **ipv6 local pool** command is used to create the local prefix pool. If the DHCPv6 server requires prefix delegation, you can use the **prefix-delegation pool** command to specify the local prefix pool and then assign prefixes from the prefix pool.

Configuration The following example configures the local prefix pool.

n Examples

```
Orion_B54Q(config)# ipv6 local pool client-prefix-pool 2001::db8::/64 80
The following example specifies the local prefix pool.
Orion_B54Q(config-dhcp)# prefix-delegation pool client-prefix-pool
lifetime 2000 1000
```

Related Commands	Command	Description
	N/A	N/A
Platform Description	N/A	

5.12 option52

Use this command to configure the DHCPv6 Server to set the CAPWAP AC IPv6 address.
 Use the **no** form of this command to restore the default setting.

```
option52 ipv6-address
no option52 ipv6-address
```

Parameter Description	Parameter	Description
	ipv6-address	Sets the CAPWAP AC IPv6 address.

Defaults By default, no option52 is created after pool configuration on the DHCPv6 server is complete.

Command Mode DHCPv6 pool configuration mode

Usage Guide This command can be used to set multiple CAPWAP AC IPv6 addresses. The newly added IPv6 address does not overwrite the old one.

Configuration Examples The following example configures the domain-name address.

```
Orion_B54Q(config-dhcp)# option52 2008:1::1
```

Related Commands	Command	Description
	N/A	N/A
Platform Description	N/A	

5.13 prefix-delegation

Use this command to set the static binding address prefix information for the DHCPv6 server.
 Use the **no** form of this command to restore the default setting.

prefix-delegation *ipv6-prefix/prefix-length client-DUID [lifetime]*
no prefix-delegation *ipv6-prefix/prefix-length client-DUID [lifetime]*

Parameter	Parameter	Description
Description	<i>ipv6-prefix/prefix-length</i>	Sets the IPv6 address prefix and the prefix length.
	<i>client-DUID</i>	Sets the client DUID.
	<i>lifetime</i>	Sets the interval of using the prefix by the client.

Defaults By default, no address prefix information is configured.
 The default *lifetime* is 3600 seconds (one hour).

Command Mode DHCPv6 pool configuration mode

Usage Guide The administrator uses this command to manually set the address prefix information list for the client IA_PD and set the valid lifetime for those prefixes.
 The parameter *client-DUID* allocates the address prefix to the first IA_PD in the specified client. Before receiving the request message for the address prefix from the client, DHCPv6 Server searches for the corresponding static binding first. If it succeeds, the server returns to the static binding; otherwise, the server will attempt to allocate the address prefix from other prefix information sources.

Configuration Examples

```
Orion_B54Q(config-dhcp)# prefix-delegation 2008:2::/64
0003000100d0f82233ac
```

Related Commands	Command	Description
	ipv6 dhcp pool	Sets a DHCPv6 pool.
	ipv6 local pool	Sets a local prefix pool.
	prefix-delegation pool	Specifies the DHCPv6 local prefix pool.
	show ipv6 dhcp pool	Displays the DHCPv6 pool information.

Platform Description N/A

5.14 prefix-delegation pool

Use this command to specify the local prefix pool for the DHCPv6 server.
 Use the **no** form of this command to restore the default setting.
prefix-delegation pool *poolname [lifetime { valid-lifetime | preferred-lifetime }]*
no prefix-delegation pool *poolname*

Parameter	Parameter	Description
Description	<i>poolname</i>	Sets the local prefix pool name.

lifetime	Sets the lifetime of the address prefix allocated to the client. With the keyword lifetime configured, both parameters <i>valid-lifetime</i> and <i>preferred-lifetime</i> shall be configured.
<i>valid-lifetime</i>	Sets the valid lifetime of using the allocated address prefix for the client.
<i>preferred-lifetime</i>	Sets the preferred lifetime of the address prefix allocated to the client.

Defaults By default, no address prefix pool is specified.
The default *valid-lifetime* is 3600s(1 hour).
The default *preferred-lifetime* is 3600s(1 hour).

Command Mode DHCPv6 pool configuration mode

Usage Guide Use the **prefix-delegation pool** command to set the prefix pool for the DHCPv6 Server and allocate the prefix to the client. Use the **ipv6 local pool** command to set the prefix pool.
The Server attempts to allocate a usable prefix from the prefix pool to the client upon receiving the prefix request from the client. That prefix will be allocated to other clients if the client no longer uses that prefix again.

Configuration Examples The following example specifies the local prefix pool for the DHCPv6 server.

```
Orion_B54Q(config-dhcp)# prefix-delegation pool client-prefix-pool
lifetime 2000 1000
```

Related Commands	Command	Description
	ipv6 dhcp pool	Sets a DHCPv6 pool.
	ipv6 local pool	Sets a local prefix pool.
	prefix-delegation	Statically binds the client with the address prefix.
	show ipv6 dhcp pool	Displays the DHCPv6 pool information.

Platform Description N/A

5.15 show ipv6 dhcp

Use this command to display the device DUID.

show ipv6 dhcp

Parameter Description	Parameter	Description
	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode/Interface configuration mode/Global configuration mode

Usage Guide The server, client and relay on the same device share a DUID.

Configuration Examples The following example displays the device DUID.

```
Orion_B54Q# show ipv6 dhcp
This device's DHCPv6 unique identifier (DUID):
00:03:00:01:00:d0:f8:22:33:b0
```

Related Commands	Command	Description
	N/A	N/A
Platform Description	N/A	

5.16 show ipv6 dhcp binding

Use this command to display the address binding information for the DHCPv6 server.

show ipv6 dhcp binding [*ipv6-address*]

Parameter Description	Parameter	Description
	<i>ipv6-address</i>	Sets the IPv6 address or the prefix.

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide If the *ipv6-address* is not specified, all prefixes dynamically assigned to the client and IANA address binding information are shown. If the *ipv6-address* is specified, the binding information for the specified address is shown.

Configuration Examples The following example displays the address binding information for the DHCPv6 server.

```
Orion_B54Q# show ipv6 dhcp binding
Client DUID: 00:03:00:01:00:d0:f8:22:33:ac
  IAPD: iaaid 0, T1 1800, T2 2880
  Prefix: 2001:20::/72
         preferred lifetime 3600, valid lifetime 3600
         expires at Jan 1 2008 2:23 (3600 seconds)
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A
Description

5.17 show ipv6 dhcp conflict

Use this command to display the DHCPv6 address conflicts.

show ipv6 dhcp conflict

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example displays the DHCPv6 address conflicts.

```
Orion_B54Q# show ipv6 dhcp conflict
2008:50::2    declined
2108:50::2    declined
2008:50::3    declined
2008:50::4    declined
2108:50::4    declined
2008:50::5    declined
```

Related Commands	Command	Description
	clear ipv6 dhcp conflict	Clears address conflicts.

Platform N/A
Description

5.18 show ipv6 dhcp interface

Use this command to display the DHCPv6 interface information.

show ipv6 dhcp interface [interface-name]

Parameter	Parameter	Description
Description	<i>interface-name</i>	Sets the interface name.

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide If the *interface-name* is not specified, all DHCPv6 interface information is displayed. If the *interface-name* is specified, the specified interface information is displayed.

Configuration Examples The following example displays the DHCPv6 interface information.

```
Orion_B54Q# show ipv6 dhcp interface
VLAN 1 is in server mode
  Server pool dhcp-pool
  Rapid-Commit: disable
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

5.19 show ipv6 dhcp pool

Use this command to display the DHCPv6 pool information.

show ipv6 dhcp pool [poolname]

Parameter Description	Parameter	Description
	<i>poolname</i>	Defines the DHCPv6 pool name.

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide If the *poolname* is not specified, all DHCPv6 interface information is displayed. If the *poolname* is specified, the specified interface information is displayed.

Configuration Examples The following example displays the DHCPv6 pool information.

```
Orion_B54Q# show ipv6 dhcp pool
DHCPv6 pool: dhcp-pool
  DNS server: 2011:1::1
  DNS server: 2011:1::2
  Domain name: example.com
```

Related Commands	Command	Description
	N/A	N/A

Platform N/A
Description

5.20 show ipv6 dhcp relay destination

Use this command to display the destination information about DHCPv6 Relay Agent.

show ipv6 dhcp relay destination

Parameter description	Parameter	Description
	all	Displays information about all configured destination addresses and relay exits.
	interface <i>interface-type</i> <i>interface-number</i>	Displays the relay destination address and relay exit configured for a specified interface.

Defaults N/A

Command mode Privileged EXEC mode

Usage guideline Use this command to show the relay destination address to which DHCPv6 packets sent from a client are forwarded through a specified relay exit (optional) by an interface for which the relay function has been enabled by Relay Agent.

Examples The following example displays all the relay destination addresses.

```
Orion_B54Q# show ipv6 dhcp relay destination all
Interface: Vlan1 //interface for which the relay function has been
enabled
Destination address(es) Output Interface
3001::2
FF02::1:2 //specified destination address Vlan2
//specified relay exit
```

Related commands	Command	Description
	N/A	N/A

Platform description N/A

5.21 show ipv6 dhcp relay statistics

Use this command to display the packet sending and receiving condition with the DHCPv6 Relay function enabled.

show ipv6 dhcp relay statistics

Parameter	Parameter	Description
Description	N/A.	N/A.

Defaults N/A.

Command Mode Privileged EXEC mode

Usage Guide N/A.

Configuration Examples The following example displays the packet sending and receiving condition with the DHCPv6 Relay function enabled.

```
Orion_B54Q# show ipv6 dhcp relay statistics
Packets dropped          : 2
  Error                  : 2
  Excess of rate limit   : 0
Packets received        : 28
  SOLICIT                : 0
  REQUEST                : 0
  CONFIRM                : 0
  RENEW                  : 0
  REBIND                 : 0
  RELEASE                : 0
  DECLINE                : 0
  INFORMATION-REQUEST    : 14
  RELAY-FORWARD          : 0
  RELAY-REPLY            : 14
Packets sent            : 16
  ADVERTISE              : 0
  RECONFIGURE            : 0
  REPLY                  : 8
  RELAY-FORWARD          : 8
  RELAY-REPLY            : 0
```

Related Commands	Command	Description
	clear ipv6 dhcp relay statistics	Clears the statistical information.

Platform N/A

Description

5.22 show ipv6 dhcp server statistics

Use this command to display the DHCPv6 server statistics.

show ipv6 dhcp server statistics

	Parameter	Description
Parameter		
Description	N/A	N/A

Defaults N/A

Command Privileged EXEC mode

Mode

Usage Guide This command is used to display the DHCPv6 server statistics.

Configuration Examples The following example displays the DHCPv6 server statistics.

```

Orion_B54Q# show ipv6 dhcp server statistics
DHCPv6 server statistics:

Packet statistics:
DHCPv6 packets received:          7
Solicit received:                  7
Request received:                  0
Confirm received:                  0
Renew received:                    0
Rebind received:                   0
Release received:                  0
Decline received:                  0
Relay-forward received:            0
Information-request received:      0
Unknown message type received:    0
Error message received:            0

DHCPv6 packet sent:               0
Advertise sent:                    0
Reply sent:                         0
Relay-reply sent:                  0
Send reply error:                  0
Send packet error:                 0

Binding statistics:
Bindings generated:                0
IAPD assigned:                     0
IANA assigned:                     0

Configuration statistics:
DHCPv6 server interface:           1
DHCPv6 pool:                       0
DHCPv6 iapd binding:              0
    
```

Related Commands	Command	Description
	<code>ipv6 dhcp pool</code>	Sets a DHCPv6 pool.

Platform Description N/A

5.23 show ipv6 local pool

Use this command to display the local prefix pool configuration and usage.

show ipv6 local pool [*poolname*]

Parameter	Parameter	Description
Description	<i>poolname</i>	The local prefix pool name

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide This command is used to display the local prefix pool configuration and usage.

Configuration Examples The following example displays all local prefix pool information.

```
Orion_B54Q#show ipv6 local pool
Pool                               Prefix
Free                               In use
client-prefix-pool                 2001:db8::/64
65536                               0
```

Field	Description
Pool	The local address pool name.
Prefix	The prefix and prefix length.
Free	The available prefix.
In use	The prefix in use.

The following example displays the information about the specified local prefix pool.

```
Orion_B54Q#show ipv6 local pool client-prefix-pool
Prefix is 2001:db8::/64 assign /80 prefix
1 entries in use, 65535 available
Prefix                               Interface
2001:db8::/80
GigabitEthernet 0/0
```

Field	Description
Prefix	The assigned prefix and prefix length.
Interface	The assigning interface.

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

6 DNS Commands

6.1 clear host

Use this command to clear the dynamically learned host name.

clear host [* | *host-name*]

Parameter Description	Parameter	Description
	<i>host-name</i>	Deletes the specified dynamic domain name buffer.
	*	Deletes all dynamic domain name buffer.

Defaults N/A

Command Mode Privileged EXEC mode.

Usage Guide You can obtain the mapping record of the host name buffer table in two ways: 1) the **ip host** static configuration, 2) the DNS dynamic learning. Execute this command to delete the host name records learned by the DNS dynamically.

Configuration Examples The following configuration deletes the dynamically learned mapping records from the host name-IP address buffer table.

```
Orion_B54Q(config)#clear host *
```

Related Commands	Command	Description
	show hosts	Displays the host name buffer table.

Platform Description N/A

6.2 ip domain-lookup

Use this command to enable DNS domain name resolution. Use the **no** form of this command to disable the DNS domain name resolution function.

ip domain-lookup

no ip domain-lookup

Parameter	Parameter	Description
-----------	-----------	-------------

Description		
	N/A	N/A

Defaults This function is enabled by default.

Command Mode Global configuration mode.

Usage Guide This command enables the domain name resolution function.

Configuration Examples The following example disables the DNS domain name resolution function.

```
Orion_B54Q(config)# no ip domain-lookup
```

Related Commands	Command	Description
	show hosts	Displays the DNS related configuration information.

Platform Description N/A

6.3 ip host

Use this command to configure the mapping of the host name and the IP address. Use the **no** form of the command to remove the host list.

ip host *host-name ip-address*

no ip host *host-name ip-address*

Parameter Description	Parameter	Description
	<i>host-name</i>	The host name of the equipment
	<i>ip-address</i>	The IP address of the equipment

Defaults N/A

Command Mode Global configuration mode.

Usage Guide N/A

Configuration Examples The following example configures IPv4 address 192.168.5.243 for domain name www.test.com.

```
Orion_B54Q(config)# ip host www.test.com 192.168.5.243
```

Related Commands	Command	Description
	show hosts	Show the DNS related configuration information.

Platform N/A
Description

6.4 ip name-server

Use this command to configure the IP address of the domain name server. Use the **no** form of this command to delete the configured domain name server.

ip name-server { *ip-address* | *ipv6-address* }
no ip name-server [*ip-address* | *ipv6-address*]

Parameter Description	Parameter	Description
	<i>ip-address</i>	The IP address of the domain name server.
	<i>ipv6-address</i>	The IPv6 address of the domain name server.

Defaults N/A

Command Mode Global configuration mode.

Usage Guide Add the IP address of the DNS server. Once this command is executed, the equipment will add a DNS server. When the device cannot obtain the domain name from a DNS server, it will attempt to send the DNS request to subsequent servers until it receives a response.
 Up to 6 DNS servers are supported. You can delete a DNS server with the *ip-address* option or all the DNS servers.

Configuration Examples The following example configures the IPv4 domain name server.

```
Orion_B54Q(config)# ip name-server 192.168.5.134 via mgmt 2/0
```

Related Commands	Command	Description
	show hosts	Displays the DNS related configuration information.

Platform N/A
Description

6.5 show hosts

Use this command to display DNS configuration.

show hosts [*hostname*]

Parameter Description	Parameter	Description
	<i>hostname</i>	Displays the specified domain name information,

Defaults All domain name information is displayed by default.

Command Mode Privileged EXEC mode.

Usage Guide This command is used to display the DNS related configuration information.

Configuration Examples

```
Orion_B54Q# show hosts
Name servers are:
192.168.5.134 static
```

Host	type	Address	TTL (sec)
switch	static	192.168.5.243	---
www.Orion_B54Q.com	dynamic	192.168.5.123	126

Field	Description
Name servers	Domain name server
Host	Domain name
type	Resolution type: Static resolution and dynamic resolution.
Address	IP address corresponding to the domain name
TTL	TTL of entries corresponding to the domain name/IP address.

Related Commands	Command	Description
	ip host	Configures the host name and IP address mapping by manual.
	ipv6 host	Configures the host name and IPv6 address mapping by manual.
	ip name-server	Configures the DNS server.

Platform Description N/A

7 FTP Server Commands

7.1 ftp-server enable

Use this command to enable the FTP server. Use the **default** form of this command to restore the default setting.

ftp-server enable

default ftp-server enable

Parameter Description	Parameter	Description
	N/A	N/A

Defaults This function is disabled by default.

Command Mode Global configuration mode

Usage Guide This command is used to enable the FTP server to connect the FTP client to upload/download the files.

⚠ To enable the FTP client to access to the FTP server files, this command shall be co-used with the **ftp-server topdir** command.

Configuration Examples The following example enables the FTP Server and confines the FTP client access to the syslog subdirectory:

```
Orion_B54Q(config)# ftp-server topdir /syslog
```

The following example disables the FTP Server:

```
Orion_B54Q(config)# no ftp-server enable
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

7.2 ftp-server login timeout

Use this command to set the timeout interval for login to the FTP server. Use the **no** or **default** form of this command to restore the default setting.

ftp-server login timeout *time*
no ftp-server login timeout
default ftp-server login timeout

Parameter Description	Parameter	Description
	<i>time</i>	Sets the timeout interval for login to the FTP server, in the range from 1 to 30 in the unit of minutes.

Defaults The default is 2 minutes.

Command Mode Global configuration mode

Usage Guide The timeout interval refers to the maximum time when your account is allowed online after you login to the server. If you don't perform authentication again before the timeout interval expires, you will be forced offline.

Configuration Examples The following example sets the timeout interval for login to the FTP server to 5 minutes.

```
Orion_B54Q(config)# ftp-server login timeout 5
```

The following example restores the default setting.

```
Orion_B54Q(config)# no ftp-server login timeout
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

7.3 ftp-server login times

Use this command to set the number of login attempts. Use the **no** or **default** form of this command to restore the default setting.

ftp-server login times *time*
no ftp-server login times
default ftp-server login times

Parameter Description	Parameter	Description
	<i>time</i>	Sets the number of login attempts, in the range from 1 to 10.

Defaults The default is 3.

Command Mode Global configuration mode

Usage Guide The number of login attempts refers to the maximum count you are allowed to perform authentication. If the number of your login attempts exceeds 3, you will be forced offline.

Configuration Examples The following example sets the number of login attempts to 5.

```
Orion_B54Q(config)# ftp-server login times 5
```

The following example restores the default setting.

```
Orion_B54Q(config)# no ftp-server login times
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

7.4 ftp-server password

Use this command to set the login password for the FTP server. Use the **no** form of this command to restore the default setting.

```
ftp-server password [ type ] password
```


```
no ftp-server password
```

Parameter Description	Parameter	Description
	<i>type</i>	Defines the encryption type of the password: 0 or 7. The default type is 0. 0 indicates the password is not encrypted. 7 indicates the password is encrypted.
	<i>password</i>	The login password for the FTP server.

Defaults No password is configured by default.

Command Global configuration mode.
Mode

Usage Guide For the FTP server, the login username and the login password must be configured to verify the client connection. One password can be set at most.
 The password must include the letter or number. The space in front of / behind the password is allowed, but it is ignored. While the space in the middle of the password is a part of password.
 The minimum and maximum lengths of the plain-text password are 1 character and 25 characters. The minimum and maximum lengths of the encrypted password are 4 characters and 52 characters respectively.
 The encrypted password is generated by plain-text password encryption and its format must comply with the encryption specification. If the encrypted password is used for the setting, the client must use the corresponding plain-text password for the purpose of successful login.

 Null password is not supported by the FTP server. Without the password configuration, the client fails to pass the identity verification of the server.

Configuration Examples The following example sets the plain-text password to pass:

```
Orion_B54Q(config)# ftp-server password pass
```

The following example sets the cipher-text password to 8001:

```
Orion_B54Q(config)# ftp-server password 7 8001
```

The following example restores the default setting:

```
Orion_B54Q(config)# no ftp-server password
```

Related Commands

Command	Description
N/A	N/A

Platform N/A
Description

7.5 ftp-server topdir

Use this command to set the directory range for the FTP client to access to the FTP server files. Use the **no** form of this command to restore the default setting.

ftp-server topdir *directory*

no ftp-server topdir

Parameter Description

Parameter	Description
-----------	-------------

<i>directory</i>	Sets the top-directory.
------------------	-------------------------

Defaults No top-directory is configured by default.

Command Mode Global configuration mode.

Usage Guide The FTP server top directory specifies the directory range of the files accessed by the client. Can the FTP client accesses to the files on the FTP server with the top directory correctly specified. Without this command configured, FTP client fails to access to any file or directory on the FTP server.

Configuration Examples The following example enables the FTP Server and confines the FTP client access to the syslog subdirectory.

```
Orion_B54Q(config)# ftp-server topdir /syslog
Orion_B54Q(config)# ftp-server enable
```

The following example restores the default setting.

```
Orion_B54Q(config)# no ftp-server topdir
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

7.6 ftp-server timeout

Use this command to set the FTP session idle timeout. Use the **no** form of this command to restore the default setting.

ftp-server timeout *time*
no ftp-server timeout

Parameter Description	Parameter	Description
	<i>time</i>	Sets the session idle timeout, in the range from 1 to 3600 in the unit of minutes.

Defaults The default is 10 minutes.

Command Mode Global configuration mode.

Usage Guide Use this command to set the FTP session idle timeout. If the session is idle, the FTP server deems the session connection is invalid and disconnects with the user.

 The session idle time refers to the time for the FTP session between two FTP operations

Configuration Examples The following example sets the session idle timeout to 5 minutes:

```
Orion_B54Q(config)# ftp-server timeout 5
```

The following example restores the default setting.

```
Orion_B54Q(config)# no ftp-server timeout
```

Related Commands

Command	Description
N/A	N/A

Platform Description N/A

7.7 ftp-server username

Use this command to set the login username and password for the FTP server. Use the **no** form of this command to restore the default setting.

ftp-server username *username*

no ftp-server username

default ftp-server username

Parameter Description

Parameter	Description
<i>username</i>	Sets the login username.
<i>password</i>	Sets the log password

Defaults No username is set by default.

Command Mode Global configuration mode

Usage Guide Use this command to set the login username for the FTP server. To log in to the FTP server, the correct username and password shall be provided.
 The maximum length of the username is 64 characters and the spaces are not allowed in the middle of the username. The username consists of letters, semiangle number and semiangle mark. One

username can be configured for the FTP server at most.

The password must contain letters or numbers. Spaces before or behind the password are allowed but will be ignored. The spaces within are part of the password.

The plaintext password is in the range from 1 to 25 characters. The encrypted password is in the range from 4 to 52 characters.

⚠ The anonymous user login is not supported on the FTP server. The client fails to pass the identity verification if the username is removed.

Configuration Examples The following example sets the username to user:

```
Orion_B54Q(config)# ftp-server username user
```

The following example restores the default setting:

```
Orion_B54Q(config)# no ftp-server username
```

Related Commands

Command	Description
N/A	N/A

Platform Description N/A

7.8 show ftp-server

Use this command to show the status information of the FTP server.

show ftp-server

Parameter Description

Parameter	Description
N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide The FTP server status information includes:

- Enabled/Disabled server
- The control connection is set up or not (the related IP, Port are shown)
- The data connection is set up or not (the related IP, Port and the working mode are shown)
- The current file transmission type

- The login username and password
- The FTP server top directory
- The session idle timeout setting

Configuration Examples The following example displays the related status information of the FTP server:

```

Orion_B54Q#show ftp-server
ftp-server information
=====
enable : Y
topdir : tmp:/
timeout: 10min
username:aaaa          password:(PLAINTEXT)bbbb          connect num[2]
  [0]trans-type:BINARY (ctrl)server IP:192.168.21.100[21]
                                client IP:192.168.21.26[3927]
  [1]trans-type:ASCII (ctrl)server IP:192.168.21.100[21]
                                client IP:192.168.21.26[3929]
username:a1            password:(PLAINTEXT)bbbb          connect num[0]
username:a2            password:(PLAINTEXT)bbbb          connect num[0]
username:a3            password:(PLAINTEXT)bbbb          connect num[0]
username:a4            password:(PLAINTEXT)bbbb          connect num[0]
username:a5            password:(PLAINTEXT)bbbb          connect num[0]
username:a6            password:(PLAINTEXT)bbbb          connect num[0]
username:a7            password:(PLAINTEXT)bbbb          connect num[0]
username:a8            password:(PLAINTEXT)bbbb          connect num[0]
username:a9            password:(PLAINTEXT)bbbb          connect num[0]
    
```

Related Commands

Command	Description
N/A	N/A

Platform Description

N/A

8 FTP CLIENT Commands

8.1 default ftp-client

Use this command to restore the FTP Client default setting.

default ftp-client [vrf vrf-name]

Parameter Description	Parameter	Description
	vrf vrf-name	VRF name. The default is the public network instance.

Defaults N/A

Command Mode Global configuration mode.

Usage Guide This command is used to restore FTP Client default setting. Specifically, data connection is passive; file transfer is binary; the client source IP address is not bound.

Configuration Examples The following example restores FTP Client default setting.

```
Orion_B54Q(config)# default ftp-client
```

The following example restores FTP Client *vrf-name* default setting.

```
Orion_B54Q(config)# default ftp-client vrf vrf-name
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

8.2 ftp-client ascii

Use this command to use ASCII mode for FTP transfer.

Use the **no** form of this command to restore the default setting.

ftp-client [vrf vrfname] ascii

no ftp-client [vrf vrfname] ascii

default ftp-client [vrf vrf-name]

Parameter Description	Parameter	Description
	vrf <i>vrf-name</i>	Configures the file transfer mode for the specified VRF.

Defaults The default FTP transfer mode is binary.

Command Mode Global configuration mode

Usage Guide The **default** command is used to restore the FTP client setting. Specifically, data connection is in PASV mode and file transfer BINARY. The client source IP address is not bound.

Configuration Examples The following example configures ASCII FTP transfer.

```
Orion_B54Q (config)# ftp-client ascii
```

The following example configures ASCII FTP transfer for *vrf-name*.

```
Orion_B54Q(config)# ftp-client vrf vrf-name ascii
```

The following example configures binary FTP transfer.

```
Orion_B54Q(config)# no ftp-client ascii
```

The following example configures binary FTP transfer for *vrf-name*.

```
Orion_B54Q(config)# no ftp-client vrf vrf-name ascii
```

The following example restores the default setting of the FTP Client.

```
Orion_B54Q(config)# default ftp-client
```

The following example restores the default setting of the FTP Client *vrf-name*,

```
Orion_B54Q(config)# default ftp-client vrf vrf-name
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

8.3 ftp-client port

Use this command to configure PORT mode used for FTP data connection. Use the **no** form of this command to restore the default setting.

```
ftp-client [ vrf vrfname ] port
```

```
no ftp-client [ vrf vrfname ] port
```

```
default ftp-client [ vrf vrf-name ]
```

Parameter Description	Parameter	Description
	vrf <i>vrf-name</i>	VRF name The default is the public network instance.

Defaults The default is PASV mode for FTP data connection.

Command Mode Global configuration mode.

Usage Guide This command is used to configure the connection mode to PORT mode, in which the server will actively connect with the client.
 The **default** command is used to restore the FTP client setting. Specifically, data connection is in PASV mode and file transfer BINARY. The client source IP address is not bound.

Configuration Examples The following example configures PORT mode used for FTP data connection

```
Orion_B54Q (config)# ftp-client port
```

The following example configures PORT mode used for FTP *vrf-name* data connection.

```
Orion_B54Q (config)# ftp-client vrf vrf-name port
```

The following example configures PASV mode for FTP data connection.

```
Orion_B54Q (config)# no ftp-client port
```

The following example configures PASV mode used for FTP *vrf-name* data connection.

```
Orion_B54Q (config)# no ftp-client vrf vrf-name port
```

The following example restores the default setting of the FTP Client.

```
Orion_B54Q (config)# default ftp-client
```

The following example restores the default setting of the FTP Client vrf-name,

```
Orion_B54Q (config)# default ftp-client vrf vrf-name
```

Related Commands

Command	Description
N/A	N/A

Platform Description N/A

8.4 ftp-client source-address

Use this command to bind FTP Client with the source IP address of client and use this IP address to communicate with server. Use the **no** form of this command to disable source IP address binding.

Use the **default** form of this command to restore the default setting.

ftp-client [vrf vrfname] source-address { ip-address | ipv6-address }

no ftp-client [vrf vrfname] source-address

default ftp-client [vrf vrf-name]

Parameter Description

Parameter	Description
vrf vrf-name	VRF name. The default is the public network instance.

<i>ip-address</i>	IP address of FTP client.
<i>ipv6-address</i>	IPv6 address of FTP client.

Defaults By default, the client will not bind the IP address locally. Instead, the router will select the IP address.

Command Mode Global configuration mode

Usage Guide The **default** command is used to restore the FTP client setting. Specifically, data connection is in PASV mode and file transfer BINARY. The client source IP address is not bound.

Configuration Examples The following example binds FTP Client with source IP address 192.168.23.236.

```
Orion_B54Q (config)# ftp-client source-address 192.168.23.236
```

The following example binds FTP Client with source IP address 2003:0:0:0::2.

```
Orion_B54Q(config)# ftp-client source-address 2003:0:0:0::2
```

The following example binds FTP Client *vrf-name* with source IP address 192.168.23.236.

```
Orion_B54Q(config)# ftp-client vrf vrf-name source-address 192.168.23.236
```

The following example binds FTP Client *vrf-name* with source IP address 2003:0:0:0::2.

```
Orion_B54Q(config)# ftp-client vrf vrf-name source-address 2003:0:0:0::2
```

The following example disables source IP address binding.

```
Orion_B54Q(config)# no ftp-client source-address
```

The following example disables source IP address binding.

```
Orion_B54Q(config)# no ftp-client vrf vrf-name source-address
```

The following example restores the default setting of the FTP Client.

```
Orion_B54Q(config)# default ftp-client
```

The following example restores the default setting of the FTP Client *vrf-name*,

```
Orion_B54Q(config)# default ftp-client vrf vrf-name
```

Related Commands

Command	Description
N/A	N/A

Platform Description N/A

8.5 copy ftp

Use this command to download the file from the server to the device through FTP Client.

copy ftp://username:password@dest-address [/remote-directory] / remote-file flash:[local-directory/] local-file]

Parameter Description	Parameter	Description
	<i>username</i>	The username for logging into FTP Server. It is limited to 40 bytes and must not contain ":", "@", "/" and space, neither can it be omitted.
	<i>password</i>	The password for logging into FTP Server. It is limited to 32 bytes and must not contain ":", "@", "/" and space, neither can it be omitted.
	<i>dest-address</i>	IP address of the target FTP Server.
	<i>remote-directory</i>	File directory of FTP Server. It is optional and limited to 255 bytes. No space or Chinese character is supported. If left blank, it implies the current directory of FTP server.
	<i>remote-file</i>	Filename on the remote server. It is limited to 255 bytes and doesn't support space or Chinese character.
	<i>local-directory</i>	Directory of local folder (optional). If this directory is specified, this directory must have been created beforehand. This command doesn't support automatic directory creation. If left blank, it implies the current directory on the local device. It is limited to 255 bytes and doesn't support space or Chinese characters.
	<i>local-file</i>	Filename on the local device. It is limited to 255 bytes and doesn't support space or Chinese character.

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example uses username of "user" and password of "pass" to download a file named "remote-file" from the directory "root" on FTP Server with IP address 192.168.23.69 to directory "home" on the local device, and changes the name to "local-file".

```
Orion_B54Q# copy ftp://user:pass@192.168.23.69/root/remote-file
flash:home/local-file
```


Related Commands

Command	Description
<code>copy tftp</code>	Uses the TFTP protocol to transfer files.

Platform N/A
Description

8.6 copy flash

Use this command to upload the file from the server to the device through FTP Client.

copy flash: *[local-directory/] local-file ftp://username:password@dest-address [/remote-directory] /remote-file*

Parameter Description

Parameter	Description
<i>username</i>	The username for logging into FTP Server. It is limited to 40 bytes and must not contain ":", "@", "/" and space, neither can it be omitted.
<i>password</i>	The password for logging into FTP Server. It is limited to 32 bytes and must not contain ":", "@", "/" and space, neither can it be omitted.
<i>dest-address</i>	IP address of the target FTP Server.
<i>remote-directory</i>	File directory of FTP Server. It is optional and limited to 255 bytes. No space or Chinese character is supported. If left blank, it implies the current directory of FTP server.
<i>remote-file</i>	Filename on the remote server. It is limited to 255 bytes and doesn't support space or Chinese character.
<i>local-directory</i>	Directory of local folder (optional). If this directory is specified, this directory must have been created beforehand. This command doesn't support automatic directory creation. If left blank, it implies the current directory on the local device. It is limited to 255 bytes and doesn't support space or Chinese characters.
<i>local-file</i>	Filename on the local device. It is limited to 255 bytes and doesn't support space or Chinese character.

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example uploads the file named "local-file" in directory "home" of local device to directory "root" on the FTP Server whose user name is user, password is pass and IP address is 192.168.23.69, and changes the filename to "remote-file".

```
Orion_B54Q# copy flash:home/local-file
ftp://user:pass@192.168.23.69/root/remote-file
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

9 Tunnel Configuration Commands

9.1 show interfaces tunnel

Use this command to display the tunnel configuration.

show interfaces tunnel [*number*]

Parameter	Parameter	Description
Description	<i>number</i>	Specifies the tunnel number.

Defaults N/A

Command

Mode Privileged EXEC mode / Global configuration mode / Interface configuration mode

Usage Guide N/A

Configuration The following example displays tunnel 1 information.

Examples

```
Orion_B54Q#show interfaces tunnel 1
// Here is the public information about the interface
Tunnel source 1.1.1.2, destination 1.1.1.1, routeable
  Tunnel TOS/Traffic Class not set, Tunnel TTL 254
  Tunnel config nested limit is 0, current nested number is 0
  Tunnel protocol/transport is ipip
  Tunnel transport VPN is no set
Orion_B54Q#show interface tunnel 2
// Here is the public information about the interface
Tunnel attributes:
  Tunnel source 1.1.1.2, destination 1.1.1.1, routeable
  Tunnel TOS/Traffic Class not set, Tunnel TTL 254
  Tunnel config nested limit is 0, current nested number is 0
  Tunnel protocol/transport is gre ip
    Key 0x2, Sequencing disabled
    Checksumming of packets enabled
  Tunnel transport VPN is vrf_tunnel
```

Field Description

Field	Description
Destination	The tunnel destination address. The address 0.0.0.0 indicates that the destination address is not configured.

Tunnel source	The tunnel source address, which can be either an IPv4 or an IPv6 address. If the tunnel source interface command is configured, the tunnel source address is the interface address.
Tunnel TTL	The TTL or hoplimit field of the transmission protocol.
Tunnel TOS	The TOS or traffic class field of the transmission protocol. Note that there is an exception. If the field is 0, and the transmission protocol is the same as the payload protocol, the field of the payload protocol is copied to the transmission protocol.
Tunnel nested-limit	The limit to the number of tunnel nested encapsulation times. This field is displayed by all tunnels except the 6to4, 6rd and isatap tunnels.
Tunnel protocol/transport	Tunnel encapsulation mode
Key	With the key setting, this field is displayed by only the GRE tunnel.
Checksuming	With the checksum setting, this field is displayed by only the GRE tunnel.
Tunnel VPN	The destination VRF.

**Related
Commands**

Command	Description
N/A	N/A

**Platform
Description**

N/A

9.2 show tunnel statistics

Use this command to display the number of configurable tunnel interfaces and configured tunnel interfaces.

show tunnel statistics

**Parameter
Description**

Parameter	Description
N/A	N/A

Defaults

N/A

Command

Mode Privileged EXEC mode / Global configuration mode / Interface configuration mode

Usage Guide This command is used to display the number of configurable tunnel interfaces and configured tunnel interfaces. Note that the actual forwarding capacity is restricted by the number of chip entries. It is possible that the tunnel interface has been created while the chip entry list is full. In that case, the syslog is generated.

Configuration Examples The following example displays the number of configurable tunnel interfaces and configured tunnel interfaces.

```
Orion_B54Q#show tunnel statistics
used: 2, limit: 1000
```

Related Commands

Command	Description
N/A	N/A

Platform

Description N/A

9.3 tunnel destination

Use this command to specify the destination IP address of a tunnel interface in interface configuration mode.

Use the **no** form of this command to restore the default setting.

tunnel destination *ip-address*

no tunnel destination

Parameter Description

Parameter	Description
<i>ip-address</i>	Sets the IP address of the specified tunnel destination.

Defaults No destination IP address is set by default.

Command

Mode Interface configuration mode

Usage Guide This command must be used to specify the peer address during tunnel setup. Tunnels cannot be set up if this command is not executed.

Configuration Examples The following example sets the destination IP address of tunnel interface 0 to 61.154.101.3.

```
Orion_B54Q(config)# interface tunnel 0
```

```
Orion_B54Q(config-if)# tunnel destination 61.154.101.3
```

Related Commands	Command	Description
	show interface tunnel	Displays tunnel interface information.

Platform Description N/A

9.4 tunnel mode

Use this command to set the encapsulation mode on a tunnel interface.
 Use the **no** or **default** form of this command to restore to the default setting.

```
tunnel mode { gre { ip | ipv6 } | ipip | ipv6ip }
no tunnel mode
default tunnel mode
```

Parameter Description	Parameter	Description
	gre ip	GRE for the route at the IP layer
	gre ipv6	GRE for the route at the IPv6 layer
	ipip	IP over IP encapsulation mode
	ipv6ip	IPv6 over IP encapsulation mode

Defaults For routers, the default encapsulation mode is GRE IP.
 For switches, the default encapsulation mode is IPv6 IP.

Command Mode Interface configuration mode

Usage Guide The tunnel encapsulation format is the tunnel carrier protocol. The default encapsulation format of tunnel interfaces is GRE. You can determine the encapsulation format of tunnel interfaces based on the actual usage. By default, IP tunnel GRE can be implemented without any definition of the encapsulation format.

Configuration Examples The following example encapsulates GRE IP on tunnel interface 0.

```
Orion_B54Q(config)# interface tunnel 0
Orion_B54Q(config-if)# tunnel mode gre ip
```

Related Commands	Command	Description
	show interface tunnel	Displays tunnel interface information.

Platform N/A
Description

9.5 tunnel source

Use this command to configure the source IP address for the tunnel. Use the **no** form of this command to restore the default setting.

tunnel source { ipv4-address|ipv6-address | interface-type interface-number }
no tunnel source

Parameter	Parameter	Description
Description	<i>ipv4-address</i>	Source IPv4 address of the tunnel used as the source IP address of the packets to be transmitted through the tunnel.
	<i>ipv6-address</i>	If the tunnel mode ipv6 or tunnel mode gre ipv6 is configured, the source address of the tunnel shall be the IPv6 address. Using the local address of the link as the source address is not supported currently.
	<i>interface-type</i> <i>interface-number</i>	Interface referenced by the tunnel, which will be used as the source IPv4 address of the packets to be transmitted through the tunnel.

Defaults No tunnel source address is configured by default.

Command Mode Interface configuration mode.

Usage Guide The source IP address of a tunnel can be a specified IPv4 address or an IPv4 address of an interface. When you configure an auto tunnel (for example, 6to4 and isatap), it is recommended to specify the source address.
 A device shall not be configured multiple tunnels with the same encapsulation type, source address and destination address.
 If there are multiple auto tunnels, their source addresses shall be different.

Configuration Examples The following example configures an IPv6 manual tunnel.

```

Orion_B54Q(config)# interface tunnel 1
Orion_B54Q(config-if)# tunnel mode ipv6ip
Orion_B54Q(config-if)# tunnel source vlan 1
Orion_B54Q(config-if)# tunnel destination 192.168.5.1
    
```

Related Commands	Command	Description
	tunnel mode	Configures the mode of a tunnel.
	tunnel destination	Configures the destination address of a tunnel.
	Tunnel ttl	Configures the TTL of the tunnel.

Platform N/A

Description

9.6 tunnel tos

Use this command to set the IPv4 ToS byte or IPv6 traffic class 8 bits in tunnel interface configuration mode. Use the **no** form of this command to restore the default setting.

tunnel tos [*num*]
no tunnel tos

Parameter Description

Parameter	Description
<i>num</i>	IPv4 ToS byte or IPv6 traffic class 8 bits, in the range from 0 to 255.

Defaults

By default, the inner-layer IPv4 ToS byte is copied to the outer-layer IPv4 header, if both the inner-layer carrier and the outer-layer encapsulation on a tunnel interface use the IPv4 protocol. By default, the inner-layer IPv6 traffic class 8 bits are copied to the outer-layer IPv6 header if both the inner-layer carrier and the outer-layer encapsulation on a tunnel interface use the IPv6 protocol. In other circumstances, the outer-layer IPv4 ToS and IPv6 traffic class are 0.

Command

Mode Interface configuration mode

Usage Guide This command is used to set GRE tunnel packets to a higher priority.

Configuration Examples The following example sets the ToS byte for a GRE tunnel outer-layer encapsulation protocol to 20 on interface tunnel 1.

```
Orion_B54Q(config)# interface tunnel 1
Orion_B54Q(config-if)# tunnel tos 20
```

Related Commands

Command	Description
show interface tunnel	Displays tunnel interface information.

Platform N/A
Description

9.7 tunnel ttl

Use this command to specify the TTL value of the IPv4 header in the encapsulated IPv6 messages. Use the **no** form of this command to restore the default setting.

tunnel ttl *value*
no tunnel ttl

Parameter	Parameter	Description
Description	<i>value</i>	TTL value

Defaults The default is 128.

Command Mode Interface configuration mode.

Usage Guide This command is used to specify the TTL value of the IPv4 header in the encapsulated IPv6 messages.

Configuration Examples

```
Orion_B54Q(config)# interface tunnel 1
Orion_B54Q(config-if)# tunnel ttl 64
```

Related Commands	Command	Description
	tunnel mode	Configures the mode of a tunnel.
	tunnel source	Configures the source IP address of the tunnel.
	tunnel destination	Configures the destination IP address of a tunnel.

Platform Description N/A

10 Network Connectivity Test Tool Commands

10.1 ping

Use this command to test the connectivity of a network to locate the network connectivity problem. The command format is as follows:

```
ping [oob | vrf vrf-name | ip] [address [ via mgmt-name ] [length length] [ntimes times] [timeout seconds] [data data] [source source] [df-bit] [validate] [detail] [interval millisecond]]
```

Parameter Description

Parameter	Description
oob	Enables the out-band channel. It must be set when MGMT is specified as the source port.
<i>vrf-name</i>	VRF name
<i>address</i>	Specifies an IPv4 address.
<i>length</i>	Specifies the length of the packet to be sent (range: 36-18024, default: 100).
<i>times</i>	Specifies the number of packets to be sent (range:1-4294967295).
<i>seconds</i>	Specifies the timeout time (range: 1-10 seconds).
<i>data</i>	Specifies the data to fill in.
<i>source</i>	Specifies the source IPv4 address or the source interface. The loopback interface address (for example: 127.0.0.1) is not allowed to be the source address.
df-bit	Sets the DF bit for the IP address. DF bit=1 indicates not to segment the datagrams. By default, the DF bit is 0.
validate	Sets whether to validate the reply packets or not.
detail	Sets whether to contain details in the echoed message. By default, only “!” and “.” are displayed.
<i>interface</i>	Outgoing interface.
<i>next-hop</i>	Next hop IPv4 address
<i>millisecond</i>	Ping interval, in the range from 10 to 300000. The default is 100.

Defaults

Five packets with 100Byte in length are sent to the specified IP address within specified time (2s by default).

Command Mode

Privileged EXEC mode.

Usage Guide If the device can be pinged, the response information is displayed, and the statistics is listed at the end. For the extension functions of ping, the number, quantity and timeout time of the packets to be sent can be specified, and the statistics is also displayed in the end. To use the domain name function, configure the domain name server firstly. For the concrete configuration, refer to the DNS Configuration section.

Configuration Examples

```
The following example tests the connectivity of a network to locate the network connectivity problem (regular ping).
Orion_B54Q# ping 192.168.21.26
Sending 5, 100-byte ICMP Echoes to 192.168.21.26, timeout is 2 seconds:
 < press Ctrl+C to break >
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/2/10 ms
```

The following example displays details.

```
Orion_B54Q#ping 192.168.21.26 detail
*Apr 16 09:16:08: %PING-7-DEBUG: Ping vrf index -1.
Sending 5, 100-byte ICMP Echoes to 192.168.21.26, timeout is 2 seconds:
 < press Ctrl+C to break >
Reply from 192.168.21.26: bytes=100 time=4ms TTL=64
Reply from 192.168.21.26: bytes=100 time=3ms TTL=64
Reply from 192.168.21.26: bytes=100 time=1ms TTL=64
Reply from 192.168.21.26: bytes=100 time=1ms TTL=64
Reply from 192.168.21.26: bytes=100 time=1ms TTL=64
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/2/4 ms.2
```

The following example tests the connectivity of a network to locate the network connectivity problem (extension ping).

```
Orion_B54Q# ping 192.168.21.26 length 1500 ntimes 100 data ffff source 192.168.21.99 timeout 3
Sending 100, 1500-byte ICMP Echoes to 192.168.21.26, timeout is 3 seconds:
 < press Ctrl+C to break >
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
Success rate is 100 percent (100/100), round-trip min/avg/max = 2/2/3 ms
```

The following example displays the details.

```
ping 192.168.21.26 length 1500 ntimes 20 data ffff source 192.168.21.99 timeout 3 detail
Sending 20, 1500-byte ICMP Echoes to 192.168.21.26, timeout is 3 seconds:
 < press Ctrl+C to break >
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
```

```

Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=2ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=3ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64
Reply from 192.168.21.26: bytes=1500 time=1ms TTL=64

```

```

Success rate is 100 percent (20/20), round-trip min/avg/max =
1/1/3 ms

```

Related Commands

Command	Description
N/A	N/A

Platform N/A
Description

10.2 ping ipv6

Use this command to test the connectivity of a network to locate the network connectivity problem. The command format is as follows:

```

ping [vrf vrf-name | [oob] ipv6] [ip-address [ via mgmt-name ] [length length] [ntimes times]
[timeout seconds] [data data] [source source] [detail] [interval millisecond]]

```

Parameter Description

Parameter	Description
oob	Enables the out-band channel. It must be set when MGMT is specified as the source port.
<i>vrf-name</i>	VRF name
<i>ip-address</i>	Specifies an IPv6 address.
<i>length</i>	Specifies the length of the packet to be sent (range: 36-18024, default: 100).
<i>times</i>	Specifies the number of packets to be sent (range:1-4294967295).

<i>seconds</i>	Specifies the timeout time (range: 1-10 seconds).
<i>data</i>	Specifies the data to fill in.
<i>source</i>	Specifies the source IPv6 address or the source interface. The loopback interface address (for example: 127.0.0.1) is not allowed to be the source address.
detail	Sets whether to contain details in the echoed message. By default, only “!” and “.” are displayed.
<i>interface</i>	Outgoing interface.
<i>next-hop</i>	Next hop IPv6 address
<i>millisecond</i>	Ping interval, in the range from 10 to 300000. The default is 100.

Defaults Five packets with 100Byte in length are sent to the specified IP address within specified time 2 seconds by default

Command Mode Privileged EXEC mode.

Usage Guide If the device can be pinged, the response information is displayed, and the statistics is listed at the end. If the response data does not match the request data, a ‘Request receive error.’ message is displayed and the statistics is listed in the end. For the extension functions of ping ipv6, the number, quantity and timeout time of the packets to be sent can be specified, and the statistics is also displayed in the end. To use the domain name function, configure the domain name server firstly. For the concrete configuration, refer to the DNS Configuration section.

Configuration The following example tests the connectivity of a network to locate the network connectivity problem.

Examples

```
Orion_B54Q# ping ipv6 2000::1
Sending 5, 100-byte ICMP Echoes to 2000::1, timeout is 2 seconds:
 < press Ctrl+C to break >
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/2/10 ms

The example below shows the extension ping ipv6.
Orion_B54Q# ping ipv6 2000::1 length 1500 ntimes 100 timeout 3 data ffff
source 192.168.4.10:
Sending 100, 1500-byte ICMP Echoes to 2000::1, timeout is 3 seconds
 < press Ctrl+C to break >
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
Success rate is 100 percent (100/100), round-trip min/avg/max = 2/2/3 ms
```

Related Commands

Command	Description
N/A	N/A

Platform N/A
Description

10.3 traceroute

Use this command to display all gateways passed by the test packets from the source address to the destination address.

traceroute [**oob** | **vrf** *vrf-name* | **ip**] [*address* [**via** *mgmt-name*] [**probe** *number*] [**source** *source*]
 [**timeout** *seconds*] [**t***tl* *minimum maximum*]]

Parameter Description	Parameter	Description
	oob	Enables the out-band channel. It must be set when MGMT is specified as the source port.
	<i>vrf-name</i>	VRF name
	<i>address</i>	Specifies an IPv4 address.
	<i>number</i>	Specifies the number of probe packets to be sent (range: 1-255).
	<i>source</i>	Specifies the source IPv4 address or the source interface. The loopback interface address (for example: 127.0.0.1) is not allowed to be the source address.
	<i>seconds</i>	Specifies the timeout time (range: 1-10 seconds).
	<i>minimum maximum</i>	Specifies the minimum and maximum TTL values (range:1-255).
	<i>interface</i>	Outgoing interface.
	<i>next-hop</i>	Next hop IPv4 address

Defaults By default, *seconds* is 3 seconds, *number* is 3, *minimum* and *maximum* are 1 and 255.

Command Privileged EXEC mode: enables extended functions.

Mode User EXEC mode: enables basic functions.

Usage Guide Use the **traceroute** command to test the connectivity of a network to exactly locate the network connectivity problem when the network failure occurs. To use the function domain name, configure the domain name server. For the concrete configuration, refer to the DNS Configuration part.

Configuration Examples The following is two examples of the application about traceroute, the one is of the smooth network, and the other is the network in which some gateways aren't connected successfully.

1. When the network is connected smoothly:

```
Orion_B54Q# traceroute 61.154.22.36
< press Ctrl+C to break >
Tracing the route to 61.154.22.36

 1  192.168.12.1    0 msec  0 msec  0 msec
 2  192.168.9.2    4 msec  4 msec  4 msec
```

```

3      192.168.9.1      8 msec  8 msec  4 msec
4      192.168.0.10    4 msec  28 msec 12 msec
5      192.168.9.2     4 msec  4 msec  4 msec
6      202.101.143.154 12 msec  8 msec  24 msec
7      61.154.22.36   12 msec  8 msec  22 msec

```

From above result, it's clear to know that the gateways passed by the packets sent to the host with an IP address of 61.154.22.36 (gateways 1~6) and the spent time are displayed. Such information is helpful for network analysis.

2. When some gateways in the network fail:

```

Orion_B54Q# traceroute 202.108.37.42
< press Ctrl+C to break >
Tracing the route to 202.108.37.42

 1      192.168.12.1      0 msec  0 msec  0 msec
 2      192.168.9.2     0 msec  4 msec  4 msec
 3      192.168.110.1   16 msec 12 msec 16 msec
 4      * * *
 5      61.154.8.129   12 msec 28 msec 12 msec
 6      61.154.8.17    8 msec 12 msec 16 msec
 7      61.154.8.250   12 msec 12 msec 12 msec
 8      218.85.157.222 12 msec 12 msec 12 msec
 9      218.85.157.130 16 msec 16 msec 16 msec
10      218.85.157.77  16 msec 48 msec 16 msec
11      202.97.40.65   76 msec 24 msec 24 msec
12      202.97.37.65  32 msec 24 msec 24 msec
13      202.97.38.162  52 msec 52 msec 224 msec
14      202.96.12.38   84 msec 52 msec 52 msec
15      202.106.192.226 88 msec 52 msec 52 msec
16      202.106.192.174 52 msec 52 msec 88 msec
17      210.74.176.158 100 msec 52 msec 84 msec
18      202.108.37.42  48 msec 48 msec 52 msec

```

The above result clearly shown that the gateways passed by the packets sent to the host with an IP address of 202.108.37.42 (gateways 1~17) and the spent time are displayed, and gateway 4 fails.

```

Orion_B54Q# traceroute www.ietf.org

Translating "www.ietf.org"...[OK]
< press Ctrl+C to break >
Tracing the route to 64.170.98.32

 1      192.168.217.1    0 msec  0 msec  0 msec
 2      10.10.25.1      0 msec  0 msec  0 msec
 3      10.10.24.1      0 msec  0 msec  0 msec
 4      10.10.30.1     10 msec  0 msec  0 msec

```

5	218.5.3.254	0 msec	0 msec	0 msec
6	61.154.8.49	10 msec	0 msec	0 msec
7	202.109.204.210	0 msec	0 msec	0 msec
8	202.97.41.69	20 msec	10 msec	20 msec
9	202.97.34.65	40 msec	40 msec	50 msec
10	202.97.57.222	50 msec	40 msec	40 msec
11	219.141.130.122	40 msec	50 msec	40 msec
12	219.142.11.10	40 msec	50 msec	30 msec
13	211.157.37.14	50 msec	40 msec	50 msec
14	222.35.65.1	40 msec	50 msec	40 msec
15	222.35.65.18	40 msec	40 msec	40 msec
16	222.35.15.109	50 msec	50 msec	50 msec
17	* * *			
18	64.170.98.32	40 msec	40 msec	40 msec

Related Commands

Command	Description
N/A	N/A

Platform Description

N/A

10.4 traceroute ipv6

Use this command to display all gateways passed by the test packets from the source address to the destination address.

traceroute [**vrf** *vrf-name* | [**oob** **ipv6**] [*address* [**via** *mgmt-name*] [**probe** *number*] [**timeout** *seconds*] [**tll** *minimum maximum*]]

Parameter Description

Parameter	Description
oob	Enables the out-band channel. It must be set when MGMT is specified as the source port.
<i>vrf-name</i>	VRF name
<i>address</i>	Specifies an IPv6 address.
<i>number</i>	Specifies the number of probe packets to be sent.
<i>seconds</i>	Specifies the timeout time.
<i>minimum maximum</i>	Specifies the minimum and maximum TTL values.
<i>interface</i>	Outgoing interface.
<i>next-hop</i>	Next hop IPv6 address

Defaults By default, *seconds* is 3 seconds, *number* is 3, *minimum* and *maximum* are 1 and 255.

Command Privileged EXEC mode: enables extended functions.
Mode User EXEC mode: enables basic functions.

Usage Guide Use the **traceroute ipv6** command to test the connectivity of a network to exactly locate the network connectivity problem when the network failure occurs. To use the function domain name, configure the domain name server. For the concrete configuration, refer to the DNS Configuration part.

Configuration Examples The following is two examples of the application about traceroute ipv6, the one is of the smooth network, and the other is the network in which some gateways aren't connected successfully.

1. When the network is connected smoothly:

```
Orion_B54Q# traceroute ipv6 3004::1
 < press Ctrl+C to break >
Tracing the route to 3004::1
 1      3000::1          0 msec  0 msec  0 msec
 2      3001::1          4 msec  4 msec  4 msec
 3      3002::1          8 msec  8 msec  4 msec
 4      3004::1          4 msec  28 msec 12 msec
```

From above result, it's clear to know that the gateways passed by the packets sent to the host with an IP address of 3004::1 (gateways 1~4) and the spent time are displayed. Such information is helpful for network analysis.

2. When some gateways in the network fail:

```
Orion_B54Q# traceroute ipv6 3004::1
 < press Ctrl+C to break >
Tracing the route to 3004::1
 1      3000::1          0 msec  0 msec  0 msec
 2      3001::1          4 msec  4 msec  4 msec
 3      3002::1          8 msec  8 msec  4 msec
 4      * * *
 5      3004::1          4 msec  28 msec 12 msec
```

The above result clearly shown that the gateways passed by the packets sent to the host with an IP address of 3004::1 (gateways 1~5) and the spent time are displayed, and gateway 4 fails.

Related Commands

Command	Description
N/A	N/A

Platform Description N/A

11 TCP Commands

11.1 ip tcp keepalive

Use this command to enable the TCP keepalive function. Use the **no** form of this command to restore the default setting,

ip tcp keepalive [**interval** *num1*] [**times** *num2*] [**idle-period** *num3*]
no ip tcp keepalive

Parameter Description	Parameter	Description
	interval <i>num1</i>	The interval of sending the keepalive packet, in the range from 1 to 120 in the unit of seconds, The default is 75.
	times <i>num2</i>	Keepalive packet sending times, in the range from 1 to 10. The default is 6.
	idle-period <i>num3</i>	Idle time, the time period during which the peer end does not send any packet to the local end, in the range from 60 to 1800 in the unit of seconds. The default is 900.

Defaults The function is disabled by default.

Command Mode Global configuration mode

Usage Guide The keepalive function enables TCP to detect whether the peer end is operating properly. Suppose the keepalive function is enabled together with default **interval**, **times** and **idle-period** settings. TCP begins to send the keepalive packet at an interval of 75 seconds if it does not receive any packet from the peer end in 900 seconds. The TCP connection is considered invalid and then disconnected automatically if the device sends the keepalive packet for six consecutive times without receiving any TCP packet from the peer end. This command applies to both IPv4 and IPv6 TCP.

Configuration Examples The following example enables the TCP keepalive function on the device and sets the **idle-period** and **interval** to 180 and 60 respectively. If the device sends the keepalive packet for four consecutive times without receiving any TCP packet from the peer end, the TCP connection is considered invalid.

```
Orion_B54Q(config)# ip tcp keepalive interval 60 times 4 idle-period 180
```

Related Commands	Command	Description
	N/A	N/A

Platform When you run the NOS 10.x command **service tcp-keepalives-in** or **service tcp-keepalives-out**, it

Description is converted to this command automatically in NOS 11.0.

11.2 ip tcp mss

Use this command to set the upper limit of the MSS value. Use the **no** form of this command to restore the default setting.

ip tcp mss *max-segment-size*
no ip tcp mss

Parameter Description	Parameter	Description
	max-segment-size	Upper limit of the MSS value in the range from 68 to 10000 bytes

Defaults The default MSS = Outgoing IPv4/v6 MTU- IPv4/v6 header-TCP header.

Command Mode Global configuration mode

Usage Guide This command is used to limit the maximum value of MSS for the TCP connection to be created. The negotiated MSS cannot exceed the configured value. You can use this command to reduce the maximum value of MSS. However, this configuration is not needed in general. This command applies to both IPv4 and IPv6 TCP.

Configuration Examples The following example sets the upper limit of the MSS value to 1300 bytes.

```
Orion_B54Q(config)# ip tcp mss 1300
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

11.3 ip tcp path-mtu-discovery

Use this command to enable Path Maximum Transmission Unit (PMTU) discovery function for TCP in global configuration mode. Use the **no** form of this command to restore the default setting.

ip tcp path-mtu-discovery [**age-timer** *minutes* | **age-timer infinite**]
no ip tcp path-mtu-discovery

Parameter Description	Parameter	Description
-----------------------	-----------	-------------

age-timer <i>minutes</i>	The time interval for further discovery after discovering PMTU. Its value ranges from 10 to 30 minutes. The default value is 10.
age-timer <i>infinite</i>	No further discovery after discovering PMTU

Defaults This function is disabled by default.

Command Mode Global configuration mode

Usage Guide Based on RFC1191, the TCP path MTU function improves the network bandwidth utilization and data transmission when the user uses TCP to transmit the data in batch. Enabling or disabling this function takes no effect for existent TCP connections and is only effective for TCP connections to be created. This command applies to only IPv4 TCP. This function is enabled for IPv6 TCP constantly and cannot be disabled. According to RFC1191, after discovering the PMTU, the TCP uses a greater MSS to detect the new PMTU at a certain interval, which is specified by the parameter **age-timer**. If the PMTU discovered is smaller than the MSS negotiated between two ends of the TCP connection, the device will be trying to discover the greater PMTU at the specified interval until the PMTU value reaches the MSS or the user stops this timer. Use the parameter **age-timer infinite** to stop this timer.

Configuration Examples The following example enables PMTU discovery.

```
Orion_B54Q(config)# ip tcp path-mtu-discovery
```

Related Commands	Command	Description
		show tcp pmtu

Platform Description N/A

11.4 ip tcp send-reset

Use this command to enable the device to send the reset packet when receiving the TCP port unreachable packet. Use the **no** form of this command to disable this function,

ip tcp send-reset
no ip tcp send-reset

Parameter Description	Parameter	Description
		N/A

Defaults This function is enabled by default.

Command Mode Global configuration mode

Usage Guide In general, when dispatching the TCP packet, the TCP module replies a reset packet automatically to disconnect the TCP connection with the peer end if the TCP connection that this packet belongs to is not found. However, flooding TCP port unreachable packets pose an attack threat to the device. This command can be used to disable the device from sending the reset packet when receiving the TCP port unreachable packet. This command applies to both IPv4 and IPv6 TCP.

Configuration Examples The following example disables the device from sending the reset packet when receiving the TCP port unreachable packet.

```
Orion_B54Q(config)# no ip tcp send-reset
```

Related Commands

Command	Description
N/A	N/A

Platform Description The **ip tcp not-send-rst** command in NOS 10.x is compatible in NOS 11.0. When you run this command, it is converted to the **no ip tcp send-reset** command automatically.

11.5 ip tcp synwait-time

Use this command to set the timeout value for SYN packets (the maximum time from SYN transmission to successful three-way handshake). Use the **no** form of this command to restore the default setting.

ip tcp synwait-time *seconds*

no ip tcp synwait-time *seconds*

Parameter Description

Parameter	Description
<i>seconds</i>	Timeout value for SYN packets in the range from 5 to 300 in the unit of seconds.

Defaults The default is 20.

Command Mode Global configuration mode

Usage Guide If there is an SYN attack in the network, reducing the SYN timeout value can prevent resource consumption, but it takes no effect for successive SYN attacks. When the device actively requests a connection with an external device, reducing the SYN timeout value can shorten the time for the user to wait, such as telnet login. For poor network conditions, the timeout value can be increased

properly. This command applies to both IPv4 and IPv6 TCP.

Configuration Examples The following example set the timeout value for SYN packets to 10 seconds.

```
Orion_B54Q(config)# ip tcp syntime-out 10
```

Related Commands

Command	Description
N/A	N/A

Platform Description N/A

11.6 ip tcp window-size

Use this command to change the size of receiving buffer and sending buffer for TCP connections. Use the **no** form of this command to restore the default setting.

- ip tcp window-size** *size*
- no ip tcp window-size**

Parameter Description

Parameter	Description
size	Size of receiving buffer and sending buffer for TCP connections in the range from 128 to 65535 << 14 bytes.

Defaults The default is 65535.

Command Mode Global configuration mode

Usage Guide The TCP receiving buffer is used to buffer the data received from the peer end. These data will be subsequently read by application programs. Generally, the window size of TCP packets implies the size of free space in the receiving buffer. For connections involving a large bandwidth and mass data, increasing the size of receiving buffer will remarkably improve TCP transmission performance. The sending buffer is used to buffer the data of application programs. Each byte in the sending buffer has a sequence number, and bytes with sequence numbers acknowledged will be removed from the sending buffer. Increasing the sending buffer will improve the interaction between TCP and application programs, thus enhancing the performance. However, increasing the receiving buffer and sending buffer will result in more memory consumption of TCP. This command is used to change the size of receiving buffer and sending buffer for TCP connections. This command changes both the receiving buffer and sending buffer, and only applies to subsequent connections. This command applies to both IPv4 and IPv6 TCP.

Configuration Examples The following example sets the TCP window size to 16386 bytes.

```
Orion_B54Q(config)# ip tcp window-size 16386
```

Related Commands

Command	Description
N/A	N/A

Platform N/A

Description

11.7 service tcp-keepalives-in

Use this command to enable the keepalive function for the TCP server. Use the no form of this command to restore the default setting.

service tcp-keepalives-in [interval] [garbage]

no service tcp-keepalives-in

Parameter Description

Parameter	Description
<i>interval</i>	The interval of sending keepalive packets, in the range from 1 to 65535 in the unit of seconds. The default is 60.
garbage	The keepalive packet contains one-byte invalid data. The invalid data is not contained by default.

Defaults This function is disabled by default.

Command Mode Global configuration mode

Usage Guide The keepalive function enables the TCP server to detect whether the client is operating properly. If the TCP server sends the keepalive packet for four consecutive times without receiving any TCP packet from the client, the TCP connection is considered invalid and then is disconnected automatically.

Configuration Examples The following example enables the keepalive function for the TCP server and sets the interval of sending the keepalive packet to 10 seconds. The keepalive packet contains one-byte invalid data.

```
Orion_B54Q(config)# service tcp-keepalives-in 10 garbage
```

Related Commands

Command	Description
N/A	N/A

Platform When you run this NOS 10.x command, it is converted to the **ip tcp keepalive** command

Description automatically in NOS 11.0.

11.8 service tcp-keepalives-out

Use this command to enable the keepalive function for the TCP client. Use the **no** form of this command to restore the default setting,

service tcp-keepalives-out [*interval*] [**garbage**]

no service tcp-keepalives-out [*interval*] [**garbage**]

Parameter Description

Parameter	Description
<i>interval</i>	The interval of sending keepalive packets, in the range from 1 to 65535 in the unit of seconds. The default is 60.
garbage	The keepalive packet contains one-byte invalid data. The invalid data is not contained by default.

Defaults This function is disabled by default.

Command Mode Global configuration mode

Usage Guide The keepalive function enables the TCP client to detect whether the server is operating properly. If the TCP client sends the keepalive packet for four consecutive times without receiving any TCP packet from the server, the TCP connection is considered invalid and then is disconnected automatically.

Configuration Examples The following example enables the keepalive function for the TCP client and sets the interval of sending the keepalive packet to 10 seconds. The keepalive packet contains one-byte invalid data

```
Orion_B54Q(config)# service tcp-keepalives-out 10 garbage
```

Related Commands

Command	Description
N/A	N/A

Platform Description When you run this NOS 10.x command, it is converted to the **ip tcp keepalive** command automatically in NOS 11.0.

11.9 show ipv6 tcp connect

Use this command to display the current IPv6 TCP connection information.

show ipv6 tcp connect [**local-ipv6** X:X:X:X] [**local-port** *num*] [**peer-ipv6** X:X:X:X] [**peer-**

port num]

Use this command to display the current IPv6 TCP connection statistics.

show ipv6 tcp connect statistics

Parameter Description	Parameter	Description
	local-ipv6 X:X:X:X::X	Local IPv6 address
	local-port num	Local port
	peer-ipv6 X:X:X:X::X	Peer IPv6 address
	peer-port num	Peer port
	statistics	Displays IPv6 TCP connection statistics

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example displays the current IPv6 TCP connection information.

```
Orion_B54Q#show ipv6 tcp connect
Number Local Address      Foreign Address      State      Process
name
1      :::22                :::0                LISTEN     orion-sshd
2      :::23                :::0                LISTEN     orion-
telnetd
3      1000::1:23          1000::2:64201      ESTABLISHED orion-
telnetd
```

The following example displays the current IPv6 TCP connection statistics.

```
Orion_B54Q#show ipv6 tcp connect statistics
State      Count
-----
ESTABLISHED 1
SYN_SENT   0
SYN_RECV   0
FIN_WAIT1  0
FIN_WAIT2  0
TIME_WAIT  0
CLOSED     0
CLOSE_WAIT 0
LAST_ACK   0
LISTEN     1
CLOSING    0
```

Total: 2

Related Commands	Command	Description
	N/A	N/A

Platform N/A
Description

11.10 show ipv6 tcp pmtu

Use this command to display information about IPv6 TCP PMTU.

show ipv6 tcp pmtu [**local-ipv6** X:X:X:X::X] [**local-port** num] [**peer-ipv6** X:X:X:X::X] [**peer-port** num]

Parameter Description	Parameter	Description
		local-ipv6 X:X:X:X::X
	local-port num	Local port
	peer-ipv6 X:X:X:X::X	Peer IPv6 address
	peer-port num	Peer port

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example information about IPv6 TCP PMTU.

```
Orion_B54Q# show ipv6 tcp pmtu
Number  Local Address          Foreign Address         PMTU
1       1000::1:23            1000::2.13560
```

Field	Description
Number	Number
Local Address	Local address and port number. The number after the last colon is the port number.
Foreign Address	Remote address and port number. The number after the last colon is the port number.
PMTU	Path MTU.

Related Commands	Command	Description
	N/A	N/A

Platform N/A

Description

11.11 show ipv6 tcp port

Use this command to display the current IPv6 TCP port status.

show ipv6 tcp port [*num*]

Parameter Description	Parameter	Description
		<i>num</i>

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example displays the current IPv6 TCP port status.

```
Orion_B54Q#show ipv6 tcp port
TCP connections on port 23:
Number  Local Address Foreign Address   State
1       1000::1:23    1000::2:64571    ESTABLISHED
Total: 1

TCP connections on port 2650:
Number  Local Address Foreign Address   State
Total: 0
```

Field	Description
Number	Number
Local Address	Local address and port number.
Foreign Address	Remote address and port number.

State	<p>Current status of the TCP connection. There are eleven possible states:</p> <p>CLOSED: The connection has been closed.</p> <p>LISTEN: Listening state</p> <p>SYNSENT: In the three-way handshake phase when the SYN packet has been sent out.</p> <p>SYNRCVD: In the three-way handshake phase when the SYN packet has been received.</p> <p>ESTABLISHED: The connection has been established.</p> <p>FINWAIT1: The local end has sent the FIN packet.</p> <p>FINWAIT2: The FIN packet sent by the local end has been acknowledged.</p> <p>CLOSEWAIT: The local end has received the FIN packet from the peer end.</p> <p>LASTACK: The local end has received the FIN packet from the peer end, and then sent its own FIN packet.</p> <p>CLOSING: The local end has sent the FIN packet from the peer end, and received the FIN packet from the peer end before the ACK packet for the peer end to respond with this FIN packet is received.</p> <p>TIMEWAIT: The FIN packet sent by the local end has been acknowledged, and the local end has also acknowledged the FIN packet.</p>
Process Name	Process name

The following example displays the current IPv6 TCP connection statistics.

```

Orion_B54Q#show ipv6 tcp connect statistics
State          Count
-----
ESTABLISHED 1
SYN_SENT      0
SYN_RECV      0
FIN_WAIT1     0
FIN_WAIT2     0
TIME_WAIT     0
CLOSED        0
CLOSE_WAIT    0
LAST_ACK      0
LISTEN        1
CLOSING       0
Total: 2
    
```

Related Commands

Command	Description
N/A	N/A

Platform N/A
Description

11.12 show tcp connect

Use this command to display basic information about the current TCP connections.

show tcp connect [**local-ip** *a.b.c.d*] [**local-port** *num*] [**peer-ip** *a.b.c.d*] [**peer-port** *num*]

Use this command to display the current IPv4 TCP connection statistics.

show tcp connect statistics

Parameter Description	Parameter	Description
	local-ip <i>a.b.c.d</i>	Local IP address.
	local-port <i>num</i>	Local port.
	peer-ip <i>a.b.c.d</i>	Peer IP address.
	peer-port <i>num</i>	Peer port.
	statistics	Displays IPv4 TCP connection statistics.

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example displays the current IPv4 TCP connection information.

```
Orion_B54Q#show tcp connect
Number Local Address      Foreign Address      State      Process name
1      0.0.0.0:22              0.0.0.0:0           LISTEN    orion-sshd
2      0.0.0.0:23              0.0.0.0:0           LISTEN    orion-
telnetd
3      1.1.1.1:23              1.1.1.2:64201      ESTABLISHED orion-telnetd
```

Field	Description
Number	Sequence number.
Local Address	The Local address and port number. The number after the last "." is the port number. For example, in "2002::2.23" and "192.168.195.212.23", "23" is the port number.
Foreign Address	The remote address and port number. The number after the last "." is the port number. For example, in "2002::2.23" and "192.168.195.212.23", "23" is the port number.
State	Current status of the TCP connection. There are eleven possible states: CLOSED: The connection has been closed.

	<p>LISTEN: Listening state</p> <p>SYNSENT: In the three-way handshake phase when the SYN packet has been sent out.</p> <p>SYNRCD: In the three-way handshake phase when the SYN packet has been received.</p> <p>ESTABLISHED: The connection has been established.</p> <p>FINWAIT1: The local end has sent the FIN packet.</p> <p>FINWAIT2: The FIN packet sent by the local end has been acknowledged.</p> <p>CLOSEWAIT: The local end has received the FIN packet from the peer end.</p> <p>LASTACK: The local end has received the FIN packet from the peer end, and then sent its own FIN packet.</p> <p>CLOSING: The local end has sent the FIN packet from the peer end, and received the FIN packet from the peer end before the ACK packet for the peer end to respond with this FIN packet is received.</p> <p>TIMEWAIT: The FIN packet sent by the local end has been acknowledged, and the local end has also acknowledged the FIN packet.</p>
Process name	Process name.

The following example displays the current IPv4 TCP connection statistics.

```

Orion_B54Q#show tcp connect statistics
State          Count
-----
ESTABLISHED 1
SYN_SENT      0
SYN_RECV      0
FIN_WAIT1     0
FIN_WAIT2     0
TIME_WAIT     0
CLOSED        0
CLOSE_WAIT    0
LAST_ACK      0
LISTEN        1
CLOSING       0
Total: 2
    
```

Related Commands

Command	Description
N/A	N/A

Platform N/A

Description

11.13 show tcp pmtu

Use this command to display information about TCP PMTU.

show tcp pmtu [**local-ip** *a.b.c.d*] [**local-port** *num*] [**peer-ip** *a.b.c.d*] [**peer-port** *num*]

Parameter Description	Parameter	Description
	local-ip <i>a.b.c.d</i>	Local IP address.
	local-port <i>num</i>	Local port.
	peer-ip <i>a.b.c.d</i>	Peer IP address.
	peer-port <i>num</i>	Peer port.

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example displays PMTU of IPv4 TCP connection.

```
Orion_B54Q# show tcp pmtu
Number  Local Address          Foreign Address          PMTU
1       192.168.195.212.23    192.168.195.112.13560  1440
```

Field	Description
Number	Sequence number.
Local Address	The local address and the port number. The number after the last "." is the port number. For example, in "2002::2.23" and "192.168.195.212.23", "23" is the port number.
Foreign Address	The remote address and the port number. The number after the last "." is the port number. For example, in "2002::2.23" and "192.168.195.212.23", "23" is the port number.
PMTU	PMTU value.

Related Commands	Command	Description
	ip tcp path-mtu-discovery	Enables the TCP PMTU discovery function.

Platform N/A

Description

11.14 show tcp port

Use this command to display information about the current TCP port.

show tcp port [*num*]

Parameter Description	Parameter	Description
	<i>num</i>	Port number

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example displays the current IPv4 TCP port status.

```
Orion_B54Q#sh tcp port
tcp port status:
Tcpv4 listen on 2650 have connections:
TCB          Foreign Address          Port      State
Tcpv4 listen on 2650 have total 0 connections.
Tcpv4 listen on 23 have connections:
TCB          Foreign Address          Port      State
c340800     1.1.1.2                  64571    ESTABLISHED
Tcpv4 listen on 23 have total 1 connections.
Tcpv6 listen on 23 have connections:
TCB          Foreign Address          Port      State
c429980     3000::2                  64572    ESTABLISHED
```

Tcpv6 listen on 23 have total 1 connections.

Field	Description
TCB	The control block's location in the current memory
Foreign Address	Remote address
Port	Remote port number
State	Status of the current TCP connection. There are eleven possible states: CLOSED: The connection has been closed. LISTEN: Listening state SYNSENT: In the three-way handshake phase when the SYN packet has been sent.

	<p>SYNRCVD: In the three-way handshake phase when the SYN packet has been received.</p> <p>ESTABLISHED: The connection has been established.</p> <p>FINWAIT1: The local end has sent the FIN packet.</p> <p>FINWAIT2: The FIN packet sent by the local end has been acknowledged.</p> <p>CLOSEWAIT: The local end has received the FIN packet from the peer end.</p> <p>LASTACK: The local end has received the FIN packet from the peer end, and then sent its own FIN packet.</p> <p>CLOSING: The local end has sent the FIN packet from the peer end, and received the FIN packet from the peer end before the ACK packet for the peer end to respond with this FIN packet is received.</p> <p>TIMEWAIT: The FIN packet sent by the local end has been acknowledged, and the local end has also acknowledged the FIN packet.</p>
--	---

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

12 IPv4/IPv6 REF Commands

12.1 clear ip ref packet statistics

Use this command to clear IPv4 Orion_B54Q Express Forwarding (REF) packet statistics.

clear ip ref packet statistics

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example clears IPv4 REF packet statistics.

```
Orion_B54Q #clear ip ref packet statistics
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A.

12.2 clear ipv6 ref packet statistics

Use this command to clear IPv6 REF packet statistics.

clear ipv6 ref packet statistics

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example clears IPv6 REF packet statistics.

```
Orion_B54Q #clear ipv6 ref packet statistics
```

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A.

12.3 show ip ref adjacency

Use this command to display the information about the specified adjacent node or all adjacent nodes.

```
show ip ref adjacency [ glean | local | ip-address | interface interface_type interface_number | discard | statistics ]
```

Parameter Description	Parameter	Description
	glean	Aggregate adjacent node, which is used for a direct route
	local	Local adjacent node, which is used by the local host
	<i>ip</i>	Next-hop IP address
	<i>interface_type</i>	Interface type
	<i>interface_number</i>	Interface number
	discard	Displays discarded adjacent nodes.
	statistics	Statistics

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide This command can be used to display the information about the adjacent node table in the current REF module. By specifying parameters, the information about the aggregate adjacent node, local adjacent node, adjacent node of the specified IP address, adjacent node associated with the specified interface, and all adjacent nodes can be displayed.

Configuration Examples The following example displays the information about all adjacent nodes in the adjacent node table.

```
Orion_B54Q#show ip ref adjacency
id state      type      rfct chg  ip          interface
linklayer(header data)
1  unresolved mcast    1    0   224.0.0.0
9  resolved   forward  1    0   192.168.50.78 GigabitEthernet 0/0 00 25
64 C5 9D 6A 00 D0 F8 98 76 54 08 00
```

```

7  resolved  forward 1  0  192.168.50.200  GigabitEthernet 0/0  00 04
5F 87 69 66 00 D0 F8 98 76 54 08 00
6  unresolved glean 1  0  0.0.0.0          GigabitEthernet 0/0
4  unresolved local 3  0  0.0.0.0          Local 1

```

Description of fields:

Field	Description
id	Adjacent node ID
state	Adjacent node state: Unresolved Resolved
type	Adjacent node type Local: local adjacency Forward: forward adjacency Discard: discard adjacency Glean: glean adjacency Mcast: multicast adjacency
rfct	Reference count of the adjacent node
chg	Whether the adjacent node is on the changing link.
ip	IP address of the adjacent node
interface	Interface
linklayer	Layer 2 head

Related	Command	Description
Commands	show ip ref route	Displays all route information in the current REF module.

Platform N/A.

Description

12.4 show ip ref exact-route

This command is used to display the IPv4 REF exact route.

show ip ref exact-route [**oob** | **vrf vrf_name**] *source_ipaddress dest_ipaddress*

Parameter	Parameter	Description
Description	oob	Out of band, namely, the network that the management interface belongs to, supported only by the device supporting the management interface.
	vrf vrf_name	VRF name, supported only by the VRF-supported device.
	<i>source_ipaddress</i>	Source IP address of the packet

<i>dest_ipaddress</i>	Destination IP address of the packet
-----------------------	--------------------------------------

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide This command is used to specify the source and the destination IP address of the IP packets, and to display the path of forwarding the current packet with REF

Configuration Examples The following example displays the IPv4 REF exact route from 192.168.217.74 to 192.168.13.1.

```
Orion_B54Q# show ip ref exact-route 192.168.217.74 192.168.13.1
192.168.217.74 --> 192.168.13.1 (vrf global):
id state      type      rfct chg ip          interface
linklayer(header data)
9  resolved forward 1      0  192.168.17.1 GigabitEthernet 0/0 00 25 64
C5 9D 6A 00 D0 F8 98 76 54 08 00
```

Description of fields:

Field	Description
id	Adjacency ID
state	Adjacency state: Unresolved Resolved
type	Adjacency type Local: local adjacency Forward: forward adjacency Discard: discard adjacency Glean: glean adjacency Mcast: multicast adjacency
rfct	Reference count of the adjacency
chg	Whether the adjacency is on the changing link.
ip	Adjacency IP address
interface	Interface
linklayer	Layer 2 head

Related Commands	Command	Description
	show ip ref route	Displays all routing information in the current REF module.

Platform N/A.

Description

12.5 show ip ref packet statistics

Use this command to display IPv4 REF packet statistics.

show ip ref packet statistics

Parameter Description	Parameter	Description
	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example displays IPv4 REF packet statistics.

```
Orion_B54Q #show ip ref pkt-statistic
ref packet statistic:
  bad head          : 0
  lookup fib fail  : 0
  local adj         : 0
  glean adj        : 0
  forward          : 0
  redirect         : 0
  punt adj         : 0
  outif not in ef  : 0
  ttl expiration   : 0
  no ip routing    : 0
```

Field	Description
total recved	Number of total packets received by REF
bad head	Number of the packets with false header
lookup fib fail	Number of the packets with failed REF routing
drop adj	Number of the packets matching the dropped adjacency
local adj	Number of the packets matching the local adjacency

glean adj	Number of the packets matching the gleaned adjacency
forward	Number of the packets matching the forwarded adjacency
no ip routing	Number of the packets not allowed to be forwarded and sent to local.

Related Commands

Command	Description
N/A	N/A

Platform N/A.
Description

12.6 show ip ref resolve-list

Use this command to display the IPv4 REF resolution information.

show ip ref resolve-list

Parameter Description

Parameter	Description
N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example displays IPv4 REF resolution information.

```
Orion_B54Q#show ip ref resolve-list
IP                res_state flags interface
1.1.1.1          unres     1      GigabitEthernet 0/0
```

Field	Description
IP	IP address
res_state	unres: unresolved res: resolved
flags	0: related to adjacency 1: unrelated to adjacency
interface	Interface

Related Commands	Command	Description
	N/A	N/A

Platform N/A
Description

12.7 show ip ref route

Use this command to display all the routing information in the IPv4 REF table.

show ip ref route [oob | vrf vrf_name] [default | ip mask | statistics]

Parameter Description	Parameter	Description
	oob	Out of band, namely, the network that the management interface belongs to, supported only by the device supporting the management interface.
	vrf vrf_name	VRF name, supported only by the VRF-supported device.
	default	Specifies the default route.
	<i>ip</i>	Specifies the destination IP address of the route
	<i>mask</i>	Specifies the mask of the route.
	statistics	Statistics

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide This command is used to display the related routing information on the current REF table, and specify the default route and all the routing information matching IP/MASK.

Configuration Examples The following example displays all the routing information in the IPv4 REF table.

```
Orion_B54Q#show ip ref route
Codes: * - default route
       # - zero route

 ip      mask      weight path-id  next-hop      interface
-----
255.255.255.255 255.255.255.255 1 4 0.0.0.0 Local 0
224.0.0.0      240.0.0.0      1 1 224.0.0.0
224.0.0.0      255.255.255.0  1 4 0.0.0.0 Local 0
192.168.50.0   255.255.255.0   1 6 0.0.0.0 FastEthernet 0/0
192.168.50.255 255.255.255.255 1 2 0.0.0.0
192.168.50.200 255.255.255.255 1 7 192.168.50.200 FastEthernet 0/0
192.168.50.122 255.255.255.255 1 4 0.0.0.0 Local 0
```



```
192.168.50.78 255.255.255.255 1 9 192.168.50.78 FastEthernet 0/0
```

Field	Description
ip	Destination IP address
mask	Mask
path-id	Adjacent identity
next-hop	Address of next hop
weight	Routing weight
interface	Egress

**Related
Commands**

Command	Description
show ip ref exact-route	Displays the accurate REF forwarding path of an IP packet.

Platform N/A
Description

12.8 show ipv6 ref adjacency

Use this command to display the information about the IPv6 adjacent node.

show ipv6 ref adjacency [**glean** | **local** | *ipv6-address* | **interface** *interface_type interface_number* | **discard** | **statistics**]

**Parameter
Description**

Parameter	Description
glean	Aggregate adjacent node, which is used for a direct route
local	Local adjacent node, which is used by the local host
<i>ipv6-address</i>	Next-hop IP address
<i>interface_type</i>	Interface type
<i>interface_number</i>	Interface number
discard	Displays discarded adjacent nodes.
statistics	Statistics

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide This command can be used to display the information about the adjacent node table in the privileged EXEC mode and global configuration mode.

Configuration Examples

The following example displays the information about the IPv6 adjacent node..

```
Orion_B54Q#show ipv6 ref adjacency
id      state      type      rfct chg ip      interface
linklayer(header data)
1       unresolved  glean    1    0   ::      GigabitEthernet 0/0
2       unresolved  local    2    0   :::1    Local 1
```

Description of fields:

Field	Description
id	Adjacent node ID
state	Adjacent node state: Unresolved Resolved
type	Adjacent node type Local: local adjacency Forward: forward adjacency Discard: discard adjacency Glean: glean adjacency Mcast: multicast adjacency
rfct	Reference count of the adjacent node
chg	Whether the adjacent node is on the changing link.
ip	IP address of the adjacent node
interface	Interface
linklayer	Layer 2 head

For distributed routers, id is divided into two fields, namely, gid and lid, standing for global adjacent node ID and local adjacent node ID respectively.

Related Commands

Command	Description
N/A	N/A

Platform Description N/A.

12.9 show ipv6 ref exact-route

This command is used to display the IPv6 REF exact route.

```
show ipv6 ref exact-route [ oob | vrf vrf_name ] source-ipv6-address destination-ipv6-address
```

Parameter Description

Parameter	Description
oob	Out of band, namely, the network that the management interface belongs to, supported only by the device supporting the management interface.

vrf vrf_name	VRF name, supported only by the VRF-supported device.
source-ipv6-address	Source IP address of the packet
destination-ipv6-address	Destination IP address of the packet

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example displays the IPv4 REF exact route from 2001:db8:1::1 to 3001:db8:2::2.

```
Orion_B54Q#show ipv6 exact-route 2001:db8:1::1 3001:db8:2::2
2001:db8:1::1 --> 3001:db8:2::2 (vrf global):
ID state      type    rfct chg ip interface          linklayer(header
data)
3  unresolve  glean  1    0   :: GigabitEthernet 0/0
```

Description of fields:

Field	Description
id	Adjacent node ID
state	Adjacent node state: Unresolved Resolved
type	Adjacent node type Local: local adjacency Forward: forward adjacency Discard: discard adjacency Glean: glean adjacency Mcast: multicast adjacency
rfct	Reference count of the adjacent node
chg	Whether the adjacent node is on the changing link.
ip	IP address of the adjacent node
interface	Interface
linklayer	Layer 2 head

Related Commands	Command	Description
	N/A	N/A

Platform N/A.

Description

12.10 show ipv6 ref packet statistics

Use this command to display IPv6 REF packet statistics.

show ipv6 ref packet statistics

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Privileged EXEC mode

Mode

Usage Guide N/A

Configuration Examples The following example displays IPv6 REF packet statistics.

n Examples

```
Orion_B54Q#show ipv6 ref packet statistics
ref packet statistic:
  bad head          : 0
  lookup fib fail  : 0
  local adj         : 0
  glean adj        : 0
  forward          : 0
  redirect         : 0
  hop-limit expiration : 0
  no ipv6 unicast-routing : 0
```

Field	Description
total recved	Number of total packets received by REF
bad head	Number of the packets with false header
lookup fib fail	Number of the packets with failed REF routing
drop adj	Number of the packets matching the dropped adjacency
local adj	Number of the packets matching the local adjacency

glean adj	Number of the packets matching the gleaned adjacency
forward	Number of the packets matching the forwarded adjacency
no ip routing	Number of the packets not allowed to be forwarded and sent to local.

Related Commands	Command	Description
	N/A	N/A

Platform N/A.
Description

12.11 show ipv6 ref resolve-list

This command is used to display the IPv6 REF resolution information.

show ipv6 ref resolve-list

Parameter	Parameter	Description
Description	N/A	N/A

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide N/A

Configuration Examples The following example displays IPv6 REF resolution information.

```
Orion_B54Q#show ipv6 ref resolve-list
IP                res_state flags interface
1000::1          unres      1      GigabitEthernet 0/0
```

Field	Description
IP	IPv6 address
res_state	unres: unresolved res: resolved

flags	0: related to adjacency 1: unrelated to adjacency
interface	Interface

Related Commands	Command	Description
	N/A	N/A

Platform Description N/A

12.12 show ipv6 ref route

Use this command to display all the routing information in the IPv6 REF table.

show ipv6 ref route [oob | vrf *vrf-name*] [default | statistics | prefix/len]

Parameter Description	Parameter	Description
	oob	Out of band, namely, the network that the management interface belongs to, supported only by the device supporting the management interface.
	vrf <i>vrf_name</i>	VRF name, supported only by the VRF-supported device.
	default	Specifies the default route.
	statistics	Statistics
	prefix/len	Displays the route with the specified prefix (X:X:X:X:/<0-128>).

Defaults N/A

Command Mode Privileged EXEC mode

Usage Guide This command is used to display all routing information in the IPv6 REF table. If there is no VRF parameter, information about the global REF table is displayed; if there is VRF parameter, information about the specified VRF table is displayed. The command can also be used to display information about the default route, the route with the specified prefix, and statistics of all types of

routes.

Configuration Examples

The following example displays all the routing information in the REF IPv6 table.

```
Orion_B54Q#show ipv6 ref route
Codes: * - default route
prefix/len                weight path_id  next_hop interface
2001:da8:ffe:2::/64       1      3      ::      GigabitEthernet
0/0
2001:da8:ffe:2::3/128     1      2      :::1    Local 1
fe80::/10                 1      6      ::      Null 0
fe80::21a:a9ff:fe3b:fa41/128 1      2      :::1    Local 1
```

Field	Description
prefix/len	IPv6 prefix and prefix length.
path-id	Adjacent identity
next-hop	Address of next hop
weight	Routing weight
interface	Interface

Related Commands

Command	Description
N/A	N/A

Platform Description

N/A