

# Port Additional Characteristics Configuration Commands

---

# Table of Contents

Chapter 1 Port Security .....	2
1.1 switchport port-security mode static .....	2
1.2 switchport port-security mode dynamic .....	2
1.3 switchport port-security static mac-address .....	2
1.4 switchport port-security dynamic maximum .....	2
Chapter 2 Port Protection .....	3
2.1 switchport protected .....	3
Chapter 3 Port Storm Control .....	4
3.1 storm-control.....	4
Chapter 4 Port Rate Limitation .....	5
4.1 switchport rate-limit.....	5

## Chapter 1 Port Security

### 1.1 switchport port-security mode static

#### Command description

**switchport port-security mode static {accept | reject}**

**no switchport port-security mode**

Set the static mode of the security port.

### 1.2 switchport port-security mode dynamic

#### Command description

**switchport port-security mode dynamic**

**no switchport port-security mode**

Add/delete the dynamic mode of the security port.

### 1.3 switchport port-security static mac-address

#### Command description

**switchport port-security static mac-address *mac-addr***

**no switchport port-security static mac-address**

Configure the static MAC address of the security port.

### 1.4 switchport port-security dynamic maximum

#### Command description

**switchport port-security dynamic maximum *value***

**no switchport port-security dynamic maximum**

Add/delete the maximum number of dynamic MAC addresses of the security port.

## Chapter 2 Port Protection

### 2.1 switchport protected

#### Command description

**[no] switchport protected**

Configure the port isolation function.

#### Parameter

None

#### Default

The port is not isolated.

#### Explanation

The command must be configured in layer-2 port configuration mode.

#### Example

Configure port f0/1 not to forward the unknown unicast frame.

```
Switch(config)# interface fastethernet0/1
```

```
Switch(config-if)# switchport protected
```

## Chapter 3 Port Storm Control

### 3.1 storm-control

#### Command description

Configure the storm control function of the port.

**storm-control** {**broadcast** | **multicast** | **unicast**} **threshold** *count*

**no storm-control** {**broadcast** | **multicast** | **unicast**} **threshold** *count*

#### Parameter

Parameter	Description
<b>broadcast</b>   <b>multicast</b>   <b>unicast</b>	Defines the storm control of the broadcast, multicast and unicast.
<b>threshold</b> <i>count</i>	Defines the flow percent of the storm control. The <b>count</b> parameter defines the flow caps that lead to the storm. <1-127>, n*64Kbps(n<=28);(n-27)Mbps(n>28)

#### Default

The storm control function is not enabled.

#### Explanation

The command must be configured in layer-2 port configuration mode.

#### Example

Set the storm control of the unknown unicast frame on port f0/1 to 192 Kbps.

```
Switch(config)# interface fastethernet0/1
```

```
Switch(config-f0/1)# storm-control unicast threshold 3
```

## Chapter 4 Port Rate Limitation

### 4.1 switchport rate-limit

#### Command description

**[no] switchport rate-limit *band* { ingress|egress}**

Configure the flow rate limitation for the port.

#### Parameter

Parameter	Description
<i>Band</i>	Flow rate n*64Kbps(n<=28); (n-27)Mbps(n>28)
<b>ingress</b>	Functions at the incoming port.
<b>egress</b>	Functions at the outgoing port.

#### Default

The port has no port rate limitation.

#### Explanation

Layer-2 port configuration mode

#### Example

Set the incoming flow rate limitation on port f0/1 to 1M.

```
Switch(config)# interface f0/1
```

```
Switch(config-if)# switchport rate-limit 28 ingress
```