

## Content

### CHAPTER 1 COMMANDS FOR MIRRORING CONFIGURATION 1-1

- 1.1 MONITOR SESSION SOURCE INTERFACE 1-1
- 1.2 MONITOR SESSION SOURCE INTERFACE ACCESS-LIST 1-1
- 1.3 MONITOR SESSION DESTINATION INTERFACE 1-1
- 1.4 SHOW MONITOR 1-2

### CHAPTER 2 COMMANDS FOR RSPAN CONFIGURATION 2-1

- 2.1 REMOTE-SPAN 2-1
- 2.2 MONITOR SESSION REMOTE VLAN 2-1
- 2.3 MONITOR SESSION REFLECTOR-PORT 2-1

### CHAPTER 3 COMMANDS FOR SFLOW 3-1

- 3.1 SFLOW AGENT-ADDRESS 3-1
- 3.2 SFLOW ANALYZER 3-1
- 3.3 SFLOW COUNTER-INTERVAL 3-1
- 3.4 SFLOW DATA-LEN 3-1
- 3.5 SFLOW DESTINATION 3-2
- 3.6 SFLOW HEADER-LEN 3-2
- 3.7 SFLOW PRIORITY 3-2
- 3.8 SFLOW RATE 3-2
- 3.9 SHOW SFLOW 3-3

### CHAPTER 4 COMMANDS FOR ERSPAN 4-1

- 4.1 MONITOR SESSION DESTINATION TUNNEL 4-1

# Chapter 1 Commands for Mirroring Configuration

## 1.1 monitor session source interface

**Command:** `monitor session <session> source {interface <interface-list> {rx| tx| both}}`

`no monitor session <session> source {interface <interface-list>}`

**Function:** Specify the source interface for the mirror. The no form command will disable this configuration.

**Parameters:** `<session>` is the session number for the mirror. Currently 1 to 7 is supported. `<interface-list>` is the list of source interfaces of the mirror which can be separated by "-" and ",". `rx` means to filter the datagram received by the interface, while `tx` for the datagram sent out, and `both` means both of income and outcome datagram.

**Command mode:** Global mode

**Usage Guide:** This command is used to configure the source interfaces for the mirror. It is not restricted the source interface of the mirror on the switch. The source can be one interface, or can be multiple interfaces. Both of the income and outcome datagram can be mirrored, or they can be mirrored selectively. If no [rx | tx | both] is specified, both are made to be the default. When multiple interfaces are mirrored, the direction of the mirror can be different, but they should be configured separately.

**Example:** Configure to mirror the datagram sent out by interface 1/0/1-4 and to mirror the datagram received by interface 1/0/5

```
Switch(config)#monitor session 1 source interface ethernet 1/0/1-4 tx
Switch(config)#monitor session 1 source interface ethernet1/0/5 rx
```

## 1.2 monitor session source interface access-list

**Command:** `monitor session <session> source {interface <interface-list> access-list <num> {rx|tx|both}}`

`no monitor session <session> source {interface <interface-list> access-list <num>}`

**Function:** Specify the access control for the source of the mirror. The no form command will disable this configuration.

**Parameters:** `<session>` is the session number for the mirror. Currently 1 to 7 is supported. `<interface-list>` is the list of source interfaces of the mirror which can be separated by '-' and ';'. `<num>` is the number of the access list. `rx` means to filter the datagram received by the interface. `tx` for the datagram sent out, and `both` means both of income and outcome datagram.

**Command Mode:** Global Mode.

**Usage Guide:** This command is used to configure the source interfaces for the mirror. It is not restricted the source interface of the mirror on the switch. The source can be one interface, or can be multiple interfaces. For flow mirror, only datagram received can be mirrored. The parameters can be `rx`, `tx`, `both`. The related access list should be prepared before this command is issued. For how to configure the access list, please refer to ACL configuration. The mirror can only be created after the destination interface of the corresponding session has been configured.

**Example:** Configure the mirror interface 1/0/6 to filter with access list 120 in session 2.

```
Switch(config)#monitor session 2 source interface 1/0/6 access-list 120 rx
```

## 1.3 monitor session destination interface

**Command:** monitor session *<session>* destination interface *<interface-number>*

**no monitor session** *<session>* destination interface *<interface-number>*

**Function:** Specify the destination interface of the mirror. The no form command will disable this configuration.

**Parameters:** *<session>* is the session number of the mirror, which is currently limited to 1-7. *<interface-number>* is the destination interface of the mirror.

**Default:** None.

**Command Mode:** Global mode

**Usage Guide:** 7 destination mirror interface is supported on the switch. To be mentioned. The interface which is configured as the destination of the mirror should not be configured as the member of the interface trunk. And the maximum throughput of the interface is recommended to be larger than the total throughput of the interfaces to be mirrored. If the destination of a session is removed, the mirror path configured in the session will be removed at the same time. And if the destination interface is reconfigured, the interface path will be recovered. To be mentioned, the flow mirror can only be recovered after the destination of the interface is re-configured.

**Example:** Configure interface 1/0/7 as the destination of the mirror.

```
Switch(config)#monitor session 1 destination interface ethernet 1/0/7
```

## 1.4 show monitor

**Command:** show monitor

**Function:** To display information about the source and destination ports of all the mirror sessions.

**Command Mode:** Admin Mode

**Usage Guide:** This command is used to display the source and destination ports for the configured mirror sessions. For port mirroring and flow mirroring, the mirror mode of the source can be displayed. For MAC mirroring, MAC mirror configuration will be displayed for the supported switch cards.

**Example:**

```
Switch#show monitor
```

# Chapter 2 Commands for RSPAN Configuration

## 2.1 remote-span

**Command:** `remote-span`  
`no remote-span`

**Function:** To configure VLAN to RSPAN VLAN. The no form of this command will delete the RSPAN VLAN.

**Parameter:** None.

**Command Mode:** VLAN Configuration Mode.

**Default:** Not configured.

**Usage Guide:** This command is used to configure the existing VLAN as RSPAN VLAN. Dedicated RSPAN VLAN should be configured before RSPAN can function. When configuring RSPAN VLAN, it should be made sure that specialized VLAN, such as the default VLAN, dynamic VLAN, private VLAN, multicast VLAN, and layer 3 interface enabled VLAN, should not be configured as RSPAN VLAN. If any existing sessions are still working when RSPAN is disabled, these sessions will be still working regardless the configuration change. However, if any layer 3 interface is configure in the VLAN after RSPAN is disable, the existing RSPAN session will be stopped.

**Example:**

```
Switch(Config-Vlan5)#remote-span
```

## 2.2 monitor session remote vlan

**Command:** `monitor session <session> remote vlan <vid>`  
`no monitor session <session> remote vlan`

**Function:** To configure local mirror session to RSPAN. The no form of this command will restore the RSPAN to local mirror.

**Parameter:** `<session>`: session ID, range between 1~7. `<vid>`: The id of RSPAN VLAN.

**Command Mode:** Global Mode.

**Default:** Not configured.

**Usage Guide:** To configure local mirror session to RSPAN. The VLAN id is the RSPAN VLAN. The mirrored data grams will be attached with RSPAN tags.

**Example:**

```
Switch(config)#monitor session 1 remote vlan 5
```

## 2.3 monitor session reflector-port

**Command:** `monitor session <session> reflector-port <interface-number>`  
`no monitor session <session> reflector-port`  
`<interface-number>`

**Function:** To configure reflector port, the no form of this command will delete the reflector port.

**Parameter:** `<session>`: Session ID, range between 1~7, `<interface-number>`: Interface number.

**Command Mode:** Global Mode.

**Default:** Not configured.

**Usage Guide:** This command configures the reflector port for the destination of mirror data grams, and disables the MAC learning function of the specified port. The configuration of reflector port is to change the mode of the local port from the destination port mode to be the reflector mode. Hence, the configuration of reflector port and the destination port are exclusive. The no command is used to restore the reflector port to normal port. The source port, in access or trunk mode, should not be added to RSPAN VLAN. When the reflector port is configured as springboard of CPU TX direction mirroring, it must be configured as TRUNK port and allows the RSPAN VLAN data passing, the Native VLAN

should not be configured as RSPAN VLAN.

**Example:**

```
Switch(config)#monitor session 1 reflector-port ethernet1/0/3
```

## Chapter 3 Commands for sFlow

### 3.1 sflow agent-address

**Command:** `sflow agent-address <agent-address>`  
`no sflow agent-address`

**Function:** Configure the sFlow sample proxy address. The “no” form of this command deletes the proxy address.

**Parameter:** `<agent-address >` is the sample proxy IP address which is shown in dotted decimal notation.

**Command Mode:** Global Mode.

**Default:** None default value.

**Usage Guide:** The proxy address is used to mark the sample proxy which is similar to OSPF or the Router ID in the BGP. However it is not necessary to make the sFlow sample proxy work properly.

**Example:** Sample the proxy address at global mode.  
switch (config)#sflow agent-address 192.168.1.200

### 3.2 sflow analyzer

**Command:** `sflow analyzer sflowtrend`  
`no sflow analyzer sflowtrend`

**Function:** Configure the analyzer used by sFlow, the no command deletes the analyzer.

**Parameter:** `sflowtrend` is the analyzer of Inmon.

**Command Mode:** Global Mode

**Default:** Do not configure

**Usage Guide:** Configure this command when using sFlowTrend.

**Example:**

Switch(config)#sflow analyzer sflowtrend

### 3.3 sflow counter-interval

**Command:** `sflow counter-interval <interval-value>`  
`no sflow counter-interval`

**Function:** Configure the max interval of the sFlow statistic sampling; the “no” form of this command deletes the statistic sampling interval value.

**Parameter:** `<interval-value>` is the value of the interval with a valid range of 20~120 and shown in second.

**Command Mode:** Port Mode

**Default:** No default value

**Usage Guide:** If no statistic sampling interval is configured, there will not be any statistic sampling on the interface.

**Example:** Set the statistic sampling interval on the interface e1/0/1 to 20 seconds.

Switch(Config-If-Ethernet1/0/1)#sflow counter-interval 20

### 3.4 sflow data-len

**Command:** `sflow data-len <length-value>`  
`no sflow data-len`

**Function:** Configure the max length of the sFlow packet data; the “no sflow data-len” command restores the default value.

**Parameter:** `<length-value>` is the value of the length with a value range of 500-1470.

**Command Mode:** Port Mode.

**Default:** The value is 1400 by default.

**Usage Guide:** When combining several samples to a sFlow group to be sent, the length of the group excluding the MAC head and IP head parts should not exceed the configured value.

**Example:** Configure the max length of the sFlow packet data to 1000.  
switch (Config-If-Ethernet1/0/2)#sflow data-len 1000

### 3.5 sflow destination

**Command:** `sflow destination <collector-address> [<collector-port>]`  
`no sflow destination`

**Function:** Configure the IP address and port number of the host on which the sFlow analysis software is installed. If the port has been configured with IP address, the port configuration will be applied, or else the global configuration will be applied. The “no” form of this command restores the port to default and deletes the IP address.

**Parameter:** `<collector-address>` is the IP address of the analyzer, shown in dotted decimal notation. `<collector-port>` is the destination port of the sent sFlow packets.

**Command Mode:** Global Mode and Port Mode.

**Default:** The destination port of the sFlow packet is defaulted at 6343, and the analyzer has no default address.

**Usage Guide:** If the analyzer address is configured at Port Mode, this IP address and port configured at Port Mode will be applied when sending the sample packet. Or else the address and port configured at global mode will be applied. The analyzer address should be configured to let the sFlow sample proxy work properly.

**Example:** Configure the analyzer address and port at global mode.  
switch (config)#sflow destination 192.168.1.200 1025

### 3.6 sflow header-len

**Command:** `sflow header-len <length-value>`  
`no sflow header-len`

**Function:** Configure the length of the head data packet copied in the sFlow data sampling. The “no” form of this command restores the default value.

**Parameter:** `<length-value>` is the value of the length with a valid range of 32-256.

**Command Mode:** Port Mode.

**Default:** 128 by default.

**Usage Guide:** If the packet sample can not be identified whether it is IPv4 or IPv6 when sent to the CPU, certain length of the head of the group has to be copied to the sFlow packet and sent out. The length of the copied content is configured by this command.

**Example:** Configure the length of the packet data head copied in the sFlow data sampling to 50.

Switch(Config-If-Ethernet1/0/2)#sflow header-len 50

### 3.7 sflow priority

**Command:** `sflow priority <priority-value>`  
`no sflow priority`

**Function:** Configure the priority when sFlow receives packet from the hardware. The “no” form of the command restores the default.

**Parameter:** `<priority-value>` is the priority value with a valid range of 0-3.

**Command Mode:** Global Mode.

**Default:** The default value is 0.

**Usage Guide:** When sample packet is sent to the CPU, it is recommended not to assign high priority for the packet so that regular receiving and sending of other protocol packet will not be interfered. The higher the priority value is set, the higher its priority will be.

**Example:** Configure the priority when sFlow receives packet from the hardware at global mode.

switch (config)#sflow priority 1

### 3.8 sflow rate

**Command:** `sflow rate { input <input-rate> | output <output-rate >}  
no sflow rate [input | output]`

**Function:** Configure the sample rate of the sFlow hardware sampling. The “no” form of this command deletes the sampling rate value.

**Parameter:** `<input-rate>` is the rate of ingress group sampling, the valid range is 1000~16383500.

`<output-rate>` is the rate of egress group sampling, the valid range is 1000~16383500.

**Command Mode:** Port Mode.

**Default:** No default value.

**Usage Guide:** The traffic sampling will not be performed if the sampling rate is not configured on the port. And if the ingress group sampling rate is set to 10000, this indicates there will be one group be sampled every 10000 ingress groups.

**Example:** Configure the ingress sample rate on port e1/0/1 to 10000 and the egress sample rate to 20000.

Switch(Config-If-Ethernet1/0/1)#sflow rate input 10000

Switch(Config-If-Ethernet1/0/1)#sflow rate output 20000

### 3.9 show sflow

**Command:** `show sflow`

**Function:** Display the sFlow configuration state.

**Parameter:** None.

**Command Mode:** All Modes.

**Usage Guide:** This command is used to acknowledge the operation state of sFlow.

Switch#show sflow

Sflow version 1.2

Agent address is 172.16.1.100

Collector address have not configured

Collector port is 6343

Sampler priority is 2

Sflow DataSource: type 2, index 194(Ethernet1/0/2)

Collector address is 192.168.1.200

Collector port is 6343

Counter interval is 0

Sample rate is input 0, output 0

Sample packet max len is 1400

Sample header max len is 50

Sample version is 4

Displayed Information	Explanation
Sflow version 1.2	Indicates the sFlow version is 1.2
Agent address is 172.16.1.100	Address of the sFlow sample proxy is 172.16.1.100
Collector address have not configured	the sFlow global analyzer address is not configured
Collector port is 6343	the sFlow global destination port is the defaulted 6343
Sampler priority is 2	The priority of sFlow when receiving packets from the hardware is 2.
Sflow DataSource: type 2, index 194(Ethernet1/0/1)	One sample proxy data source of the sFlow is the interface e1/0/1 and its type is 2 (Ethernet), the interface index is 194.
Collector address is 192.168.1.200	The analyzer address of the sampling address of the E1/0/1 interface is 192.168.1.200
Collector port is 6343	Default value of the port on E1/0/1 interface sampling proxy is 6343.
Counter interval is 20	The statistic sampling interval on e1/0/1 interface is 20 seconds



Sample rate is input 10000, output 0	The ingress traffic rate of e1/0/1 interface sampling proxy is 10000 and no egress traffic sampling will be performed
Sample packet max len is 1400	The length of the sFlow group data sent by the e1/0/1 interface should not exceed 1400 bytes.
Sample header max len is 50	The length of the packet data head copied in the data sampling of the e1/0/1 interface sampling proxy is 50
Sample version is 4	The datagram version of the sFlow group sent by the E1/0/1 interface sampling proxy is 4.

## Chapter 4 Commands for ERSPAN

### 4.1 monitor session destination tunnel

**Command:** monitor session <session> destination tunnel  
<tunnel-number>

no monitor session <session> destination tunnel  
<tunnel-number>

**Function:** Specify the destination port of the mirror as the tunnel. The no command deletes this configuration.

**Parameters:** <session> is the session number of the mirror, which is currently limited from 1 to 4; <tunnel-number> is the tunnel number.

**Default:** No configuration

**Command Mode:** Global mode

**Usage Guide:** 4 destination tunnels are supported on the switch. To be mentioned, the destination tunnel which is configured as the physical ports or tunnel, it should not be configured as the member of the port aggregation group. And the maximum throughput of the port is recommended to be larger than the total throughput of the source ports to be mirrored. If the destination tunnel of a session is removed, the mirror path configured in the session will be removed at the same time. And if the destination tunnel is reconfigured, the port mirror path will be recovered. To be mentioned, the flow mirror can only be recovered after the destination port is reconfigured. If the destination tunnel is configured as the tunnel which must completed the configuration, and it must be configured as GRE tunnel.

**Example:**

```
Switch(config)#monitor session 4 destination tunnel 1
```